ROHDE&SCHWARZ

DOCUMENTATION



ROHDE&SCHWARZ

Test and
Measurement Division

Operating Manual

SPECTRUM ANALYZER

FSEA20/30
1065.6000.20/.25/.30/.35

FSEB20/30
1066.3010.20/.25/.30/.35

FSEM20/30
1080.1505.20/.21/.25
1079.8500.30/.31/.35

FSEK20/30
1088.1491.20/.21/.25
1088.3494.30/.31/.35

Dear Customer,
if your instrument is equipped with option FSE-B15 (Controller Function) please note the supplement manual included.

Printed in the Federal
Republic of Germany

Digitized by the Internet Archive
in 2025

https://archive.org/details/manualsplus_11448

Tabbed Divider Overview

Contents

Index

Data Sheet

Safety Instructions
Certificate of quality
EC Certificate of Conformity
List of R & S Representatives

Supplement

Tabbed Divider

1	Chapter 1:	Preparation for Use
2	Chapter 2:	Manual Operation
3	Chapter 3:	Remote Control
4	Chapter 4:	Maintenance
5	Chapter 5:	Performance Test
6	Annex A:	Interfaces
7	Annex B:	List of Error Messages
8	Annex C:	List of Commands
9	Annex D:	Programming Example
10	Annex E:	Emulation

Contents

Index

Data Sheet

Safety Instructions

1 Preparing for Operation

1.1 Description of Front and Rear Panel Views 1.1-1
1.1.1 Front View 1.1-1
1.1.2 Rear View 1.1-13

1.2 Start-Up 1.2-1
1.2.1 Unpacking the Instrument 1.2-1
1.2.2 Instrument Setup 1.2-1
1.2.2.1 Stand-alone Operation 1.2-1
1.2.2.2 19" Rack Installation 1.2-1
1.2.3 EMI Protection Measures 1.2-2
1.2.4 Connecting to AC Power 1.2-2
1.2.5 AC Power Line Fuses 1.2-2
1.2.6 Instrument On/Off 1.2-2
1.2.7 Battery-Powered Memory 1.2-1

1.3 Functional Test 1.3-1

1.4 Connecting a Mouse 1.4-1

1.5 Connecting an External Keyboard 1.5-1

1.6 Connecting an Output Device 1.6-1

1.7 Firmware Update 1.7-1

1.8 Options 1.8-1
1.8.1 Option FSE-B17 – Second IEC/IEEE Interface 1.8-1
1.8.1.1 Installing the software 1.8-1
1.8.1.2 Operation 1.8-1
1.8.2 Option FSE-B5 - FFT Filter 1.8-2
1.8.2.1 Prerequisites 1.8-2
1.8.2.2 Enabling the option 1.8-2
1.8.3 Option FSE B16 – Ethernet Adapter 1.8-3
1.8.3.1 Hardware Installation 1.8-3
1.8.3.1.1 BNC (Thin Ethernet, CheaperNet; FSE-B16 Var. 03) 1.8-3
1.8.3.1.2 AUI (Thick Ethernet; FSE B16 Var. 02) 1.8-4
1.8.3.1.3 RJ45 (UTP, 10BaseT, Western Connector) 1.8-4
1.8.3.2 Software Installation 1.8-5
1.8.3.2.1 Installation of Network Drivers 1.8-5
1.8.3.2.2 Installation of Network Operating System 1.8-8
1.8.3.3 Operation 1.8-11
1.8.3.3.1 NOVELL 1.8-11
1.8.3.3.2 MICROSOFT 1.8-13
1.8.3.3.3 TCP/IP 1.8-15
1.8.3.3.4 FTP 1.8-15
1.8.3.3.5 KERMIT 1.8-16

2 Manual Operation

2.1 Measurement Examples 2.1-1
2.1.1 Level and Frequency Measurements 2.1-1
2.1.1.1 Measurement Task 2.1-1
2.1.1.2 Important Spectrum Analyzer Functions 2.1-2
2.1.1.3 Sweep, Level and Frequency Measurements – Example 1 ..... 2.1-2
2.1.1.4 Sweep, Level and Frequency Measurements – Example 2 ..... 2.1-6
2.1.1.5 Level Measurement Accuracy 2.1-9
2.1.2 Measurement of Harmonic Separation 2.1-10
2.1.2.1 Measurement Task 2.1-10
2.1.2.2 Important Spectrum Analyzer Functions 2.1-11
2.1.2.3 Measurement Procedure - Harmonic Separation – Example 1 ..... 2.1-12
2.1.2.4 Measurement Procedure - Harmonic Separation – Example 2 ..... 2.1-16
2.1.2.5 Measurement Procedure - Harmonic Separation – Example 3 ..... 2.1-20
2.1.3 Measurement of Intermodulation Distortions 2.1-24
2.1.3.1 Measuring Task 2.1-24
2.1.3.2 Important Spectrum-Analyzer Functions 2.1-25
2.1.3.3 Measurement 2.1-26
2.1.4 Time-domain Measurements with Pulsed Signals 2.1-31
2.1.4.1 Measuring Task 2.1-31
2.1.4.2 Important Spectrum Analyzer Functions 2.1-31
2.1.4.3 Measurement 2.1-32

2.2 Menu Overview 2.2-1
2.2.1 System Key Group 2.2-1
2.2.2 Configuration Key Group 2.2-3
2.2.3 Hardcopy Key Group 2.2-5
2.2.4 Frequency Key Group 2.2-6
2.2.5 Level Key Group, Input Key 2.2-7
2.2.6 Marker Key Group 2.2-9
2.2.7 Lines Key Group 2.2-13
2.2.8 Trace Key Group 2.2-14
2.2.9 Sweep Key Group 2.2-15
2.2.10 Memory Key Group 2.2-17
2.2.11User Key Group 2.2-19

2.3 Basic Steps of Operation 2.3-1
2.3.1 The Screen 2.3-2
2.3.1.1 Diagram Area 2.3-3
2.3.1.2 Split Screen 2.3-9
2.3.1.3 Softkey Area 2.3-10
2.3.2 Changing the Menu 2.3-11
2.3.3 Setting the Parameters 2.3-13
2.3.3.1 Data Entry 2.3-13

2.3.3.1.1 Numeric Keypad on the Front Panel 2.3-13
2.3.3.1.2 Roll-key and Cursor Keys 2.3-14
2.3.3.2 Entry Windows 2.3-15
2.3.3.2.1 Setting Up the Entry Window 2.3-15
2.3.3.2.2 Editing of Numeric Parameters 2.3-16
2.3.3.2.3 Editing of Alphanumeric Parameters 2.3-17
2.3.3.2.4 Help Line Editor 2.3-17
2.3.3.3 Table Entry 2.3-17
2.3.3.3.1 Shifting Mode 2.3-18
2.3.3.3.2 Editing Mode 2.3-18
2.3.4 Disabling the Control Elements - HOLD Key 2.3-19
2.3.5 Setting the Stepsize - STEP Key 2.3-20
2.3.6 Mouse and External Keyboard Control 2.3-21
2.3.6.1 External Keyboard Control 2.3-21
2.3.6.2 Data Entry Windows with Mouse Control 2.3-21
2.3.6.3 Mouse Control of Further Display Elements 2.3-21
2.4 General Configuration – *SYSTEM* and *CONFIGURATION* Key Groups 2.4-1
2.4.1 FSE Initial Configuration – *PRESET* Key 2.4-1
2.4.2 Display Configuration – *DISPLAY* Key 2.4-2
2.4.2.1 Display Screen Mode Selection 2.4-3
2.4.2.2 Measurement Window Coupling 2.4-4
2.4.2.3 Display Screen Configuration 2.4-5
2.4.3 FSE Calibration – *CAL* Key 2.4-8
2.4.3.1 Calibration Function Calls 2.4-9
2.4.3.2 Calibration Results 2.4-11
2.4.4 Instrument Status and Measurement Parameters – *INFO* Key 2.4-12
2.4.4.1 Firmware Versions 2.4-12
2.4.4.2 Hardware Configuration and Options 2.4-13
2.4.4.3 Self Test 2.4-14
2.4.4.4 System Messages 2.4-15
2.4.5 Mode Selection – *MODE* Key 2.4-16
2.4.6 Preliminary Setup and Interface Configuration – *SETUP* Key 2.4-18
2.4.6.1 Using Transducers 2.4-18
2.4.6.1.1 Activating Transducer Factors and Transducer Sets 2.4-19
2.4.6.1.2 New Entry and Editing of Transducer Factors 2.4-21
2.4.6.1.3 New Entry and Editing of Transducer Sets 2.4-25
2.4.6.2 External Reference Oscillator 2.4-29
2.4.6.3 Enabling Firmware Options 2.4-29
2.4.6.4 Programming the Interface Configuration and Time 2.4-30
2.4.6.4.1 IEC Bus Address Selection 2.4-31
2.4.6.4.2 Switching the Beeper ON/OFF 2.4-31
2.4.6.4.3 User Port Configuration 2.4-32
2.4.6.4.4 Serial Interface Configuration 2.4-33
2.4.6.4.5 Setting Date and Time 2.4-36
2.4.6.4.6 Mouse Configuration 2.4-37
2.4.6.4.7 External Keyboard Configuration 2.4-38
2.4.6.5 Service Functions 2.4-39
2.5 Status Display-Remote/Manual Control – *STATUS Key Group* 2.5-1

2.6 Measurement Documentation – *HARDCOPY* Key Group 2.6-1
2.6.1 Printing Data – *START* Key 2.6-1
2.6.2 Printing Configuration – *SETTINGS* Key 2.6-2
2.6.2.1 Selection of Displayed Elements and Colour Settings 2.6-3
2.6.2.2 Selection of Hardcopy Format 2.6-4
2.6.2.3 Entry of Comment Text 2.6-5
2.6.2.4 Selection and Configuration of the Output Device 2.6-6

2.7 Saving and Recalling Data Sets – *MEMORY* Key Group 2.7-1
2.7.1 Configuration of Memory – *CONFIG* Key 2.7-3
2.7.2 Saving Data Sets – *SAVE* Key 2.7-5
2.7.2.1 Selecting the Data Set for Storage 2.7-6
2.7.2.2 Selecting the Data subset for Storage 2.7-8
2.7.3 Recalling of Data Sets – *RECALL* Key 2.7-9
2.7.3.1 Selecting the Data Set for Recalling 2.7-10
2.7.3.1.1 Building a Data Set 2.7-12

2.8 Macros – *USER Key* 2.8-1
2.8.1 Fundamentals 2.8-1
2.8.2 Starting Macros 2.8-2
2.8.3 Defining Macros 2.8-3

2.9 Analyzer Mode 2.9-1
2.9.1 Frequency and Span Selection – *FREQUENCY Key Group* 2.9-1
2.9.1.1 Start Frequency – *START* Key 2.9-1
2.9.1.2 Stop Frequency – *STOP* Key 2.9-3
2.9.1.3 Center Frequency – *CENTER* Key 2.9-4
2.9.1.4 Center Frequency Step Size 2.9-6
2.9.1.5 Frequency Span – *SPAN* Key 2.9-8
2.9.1.6 Display Zoom 2.9-10
2.9.2 Level Display and RF Input Configuration – *LEVEL Key Group* 2.9-11
2.9.2.1 Reference Level – *REF* key 2.9-11
2.9.2.2 Display Units 2.9-13
2.9.2.3 Level Range – *RANGE* Key 2.9-16
2.9.2.4 RF Input Configuration – *INPUT* Key 2.9-17
2.9.3 Marker Functions – *MARKER Key Group* 2.9-20
2.9.3.1 Main Markers– *NORMAL Key* 2.9-20
2.9.3.1.1 LF Demodulation 2.9-24
2.9.3.1.2 Frequency Measurement 2.9-26
2.9.3.1.3 Noise Power Density Measurement 2.9-27
2.9.3.1.4 Channel Power Measurements 2.9-28
2.9.3.1.4.1 Channel Configuration 2.9-29
2.9.3.1.4.2 Channel Power Measurement 2.9-32
2.9.3.1.4.3 Signal / Noise Power Measurement 2.9-34
2.9.3.1.4.4 Adjacent Channel Power 2.9-36
2.9.3.1.4.5 Occupied Bandwidth Measurement 2.9-37
2.9.3.1.4.6 Channel Power Measurements / Configuration 2.9-38
2.9.3.1.5 Marker Step Size 2.9-40
2.9.3.2 Delta Markers – *DELTA Key* 2.9-41

2.9.3.2.1 Phase Noise Measurement 2.9-44
2.9.3.2.2 Delta-Marker Step Size - *STEP Key* 2.9-45
2.9.3.3 Search Functions – SEARCH Key 2.9-46
2.9.3.3.1 Summary Marker 2.9-51
2.9.3.4 Instrument Parameter Changes via Markers – MKR ➔ Key 2.9-54
2.9.4 Setup of Display and Limit Lines – *LINES* Key Field 2.9-56
2.9.4.1 Display Lines – *D LINES Key* 2.9-56
2.9.4.2 Limit Lines – *LIMITS Key* 2.9-59
2.9.4.2.1 Limit Line Selection 2.9-60
2.9.4.2.2 Entry and Editing of Limit Lines 2.9-63
2.9.5 Trace Selection and Setup –*TRACE Key Group* 2.9-68
2.9.5.1 Measurement Function Selection - *TRACE 1 to 4* key 2.9-68
2.9.5.2 Detector Selection 2.9-73
2.9.5.3 Quasi Analog Display 2.9-76
2.9.5.4 Mathematical Functions for Traces 2.9-77
2.9.6 Sweep Control – *SWEEP Key Group* 2.9-79
2.9.6.1 Coupled Settings – *COUPLING* Key 2.9-79
2.9.6.1.1 Setting and Coupling the Coupling Resolution, Video Bandwidth and Sweep Time 2.9-80
2.9.6.1.2 Sweep Coupling Ratio 2.9-85
2.9.6.2 Sweep Trigger – TRIGGER Key 2.9-87
2.9.6.3 Sweep Setup – SWEEP Key 2.9-89
2.9.6.3.1 Gated Sweep 2.9-91
2.9.6.3.2 Sweep Blanking – Gap Sweep 2.9-97

3 Remote Control

3.1 Introduction **3.2-1**

3.2 Brief Instructions **3.2-1**

3.3 Switchover to Remote Control **3.3-1**

3.3.1 Remote Control via IEC Bus 3.3-1

3.3.1.1 Setting the Device Address 3.3-1

3.3.1.2 Indications during Remote Control 3.3-1

3.3.1.3 Return to Manual Operation 3.3-2

3.3.2 Remote Control via RS-232-Interface 3.3-3

3.3.2.1 Setting the Transmission Parameters 3.3-3

3.3.2.2 Indications during Remote Control 3.3-3

3.3.2.3 Return to Manual Operation 3.3-3

3.3.2.4 Limitations 3.3-3

3.3.3 Remote Control via RSIB Interface 3.3-4

3.3.3.1 Indications during Remote Control 3.3-4

3.3.3.2 Return to Manual Operation 3.3-4

3.4 IEC-Bus Messages **3.4-1**

3.4.1 IEE/IEEE-Bus Interface Messages 3.4-1

3.4.2 RSIB Interface Messages 3.4-1

3.4.3 Device Messages (Commands and Device Responses) 3.4-2

3.5 Structure and Syntax of the Device Messages **3.5-1**

3.5.1 SCPI Introduction 3.5-1

3.5.2 Structure of a Command 3.5-1

3.5.3 Structure of a Command Line 3.5-4

3.5.4 Responses to Queries 3.5-4

3.5.5 Parameters 3.5-5

3.5.6 Overview of Syntax Elements 3.5-6

3.6 Description of Commands **3.6-1**

3.6.1 Notation 3.6-1

3.6.2 Common Commands 3.6-4

3.6.3 ABORt Subsystem 3.6-7

3.6.4 CALCulate Subsystem 3.6-7

3.6.4.1 CALCulate:DELTamarker Subsystem 3.6-8

3.6.4.2 CALCulate:DLINe Subsystem 3.6-14

3.6.4.3 CALCulate:FEED Subsystem 3.6-17

3.6.4.4 CALCulate:FORMat Subsystem 3.6-18

3.6.4.5 CALCulate:LIMit Subsystem 3.6-19

3.6.4.6 CALCulate:MARKer Subsystem 3.6-32

3.6.4.7 CALCulate:MATH Subsystem 3.6-55

3.6.4.8 CALCulate:UNIT Subsystem 3.6-56

3.6.5 CALibration Subsystem 3.6-57

3.6.6 CONFigure Subsystem 3.6-59
3.6.6.1 CONFigure:BTS Subsystem 3.6-59
3.6.6.2 CONFigure:BURSt Subsystem 3.6-63
3.6.6.3 CONFigure:MS Subsystem 3.6-65
3.6.6.4 CONFigure:SPECtrum Subsystem 3.6-68
3.6.6.5 CONFigure:SPURious Subsystem 3.6-70
3.6.7 DIAGnostic Subsystem 3.6-72
3.6.8 DISPlay Subsystem 3.6-73
3.6.9 FETCh Subsystem 3.6-82
3.6.9.1 FETCh:BURSt Subsystem 3.6-82
3.6.9.2 FETCh:SPECtrum Subsystem 3.6-86
3.6.9.3 FETCh:SPURious Subsystem 3.6-88
3.6.10 FORMat Subsystem 3.6-90
3.6.11 HCOPy Subsystem 3.6-91
3.6.12 INITiate Subsystem 3.6-96
3.6.13 INPut Subsystem 3.6-97
3.6.14 INSTrument Subsystem 3.6-99
3.6.15 MMEMory Subsystem 3.6-101
3.6.16 OUTPut Subsystem 3.6-111
3.6.17 READ Subsystem 3.6-113
3.6.17.1 READ:BURSt Subsystem 3.6-113
3.6.17.2 READ:SPECtrum Subsystem 3.6-120
3.6.17.3 READ:SPURious Subsystem 3.6-122
3.6.18 SENSe Subsystem 3.6-124
3.6.18.1 SENSe:ADEMod Subsystem 3.6-124
3.6.18.2 [SENSe:]AVERage Subsystem 3.6-126
3.6.18.3 SENSe:BANDwidth Subsystem 3.6-127
3.6.18.4 SENSe:CORRection-Subsystem 3.6-130
3.6.18.5 SENSe:DETector Subsystem 3.6-138
3.6.18.6 SENSe:DDEMod Subsystem 3.6-139
3.6.18.7 SENSe:FILTer Subsystem 3.6-145
3.6.18.8 SENSe:FREQuency Subsystem 3.6-148
3.6.18.9 SENSe:MIXer - Subsystem 3.6-152
3.6.18.10 SENSe:MSUMmary Subsystem 3.6-156
3.6.18.11 SENSe:POWer Subsystem 3.6-158
3.6.18.12 SENSe:ROSCillator Subsystem 3.6-161
3.6.18.13 SENSe:SWEep Subsystem 3.6-162
3.6.18.14 SENSe:TV Subsystem 3.6-166
3.6.19 SOURce Subsystem 3.6-167
3.6.20 STATus Subsystem 3.6-170
3.6.21 SYSTem Subsystem 3.6-181
3.6.22 TRACe Subsystem 3.6-186
3.6.23 TRIGger Subsystem 3.6-188
3.6.24 UNIT Subsystem 3.6-193

3.7 Instrument Model and Command Processing 3.7-1

3.7.1 Input Unit 3.7-1

3.7.2 Command Recognition 3.7-2

3.7.3 Data Set and Instrument Hardware 3.7-2

3.7.4 Status Reporting System 3.7-2

3.7.5 Output Unit 3.7-3

3.7.6 Command Sequence and Command Synchronization 3.7-3

3.8 Status Reporting System 3.8-1

3.8.1 Structure of an SCPI Status Register 3.8-1

3.8.2 Overview of the Status Registers 3.8-3

3.8.3 Description of the Status Registers 3.8-4

3.8.3.1 Status Byte (STB) and Service Request Enable Register (SRE) 3.8-4

3.8.3.2 IST Flag and Parallel Poll Enable Register (PPE) 3.8-5

3.8.3.3 Event-Status Register (ESR) and Event-Status-Enable Register (ESE) 3.8-5

3.8.3.4 STATus:OPERation Register 3.8-6

3.8.3.5 STATus:QUEStionable Register 3.8-7

3.8.3.6 STATus QUEStionable:ACPLimit Register 3.8-8

3.8.3.7 STATus QUEStionable:FREQuency Register 3.8-9

3.8.3.8 STATus QUEStionable:LIMit Register 3.8-10

3.8.3.9 STATus QUEStionable:LMARgin Register 3.8-11

3.8.3.10 STATus QUEStionable:POWer Register 3.8-12

3.8.3.11 STATus QUEStionable:SYNC Register 3.8-13

3.8.3.12 STATus QUEStionable:TRANsducer Register 3.8-14

3.8.4 Application of the Status Reporting Systems 3.8-15

3.8.4.1 Service Request, Making Use of the Hierarchy Structure 3.8-15

3.8.4.2 Serial Poll 3.8-15

3.8.4.3 Parallel Poll 3.8-16

3.8.4.4 Query by Means of Commands 3.8-16

3.8.4.5 Error-Queue Query 3.8-16

3.8.5 Resetting Values of the Status Reporting System 3.8-17

3.9 Table of Softkeys with IEC/IEEE-Bus Command Assignment 3.9-1

3.9.1 Basic Instrument - Signal Analysis Mode 3.9-1

3.9.1.1 FREQUENCY Key Group 3.9-1

3.9.1.2 LEVEL Key Group 3.9-3

3.9.1.3 INPUT Key 3.9-4

3.9.1.4 MARKER Key Group 3.9-4

3.9.1.5 LINES Key Group 3.9-9

3.9.1.6 TRACE Key Group 3.9-10

3.9.1.7 SWEEP Key Group 3.9-12

3.9.2 Basic Instrument - General Device Settings 3.9-15

3.9.2.1 DATA VARIATION Key Group 3.9-15

3.9.2.2 SYSTEM Key Group 3.9-15

3.9.2.3 CONFIGURATION Key Group 3.9-17

3.9.2.4 STATUS Key Group 3.9-20

3.9.2.5 HARDCOPY Key Group 3.9-21

3.9.2.6 MEMORY Key Group 3.9-22
3.9.2.7 USER Key 3.9-24
3.9.3 Vector Signal Analysis Mode (Option FSE-B7) 3.9-25
3.9.3.1 CONFIGURATION Key Group - Digital Demodulation 3.9-25
3.9.3.2 CONFIGURATION Key Group - Analog Demodulation 3.9-28
3.9.3.3 FREQUENCY Key Group 3.9-29
3.9.3.4 LEVEL Key Group 3.9-29
3.9.3.5 INPUT Key 3.9-31
3.9.3.6 MARKER Key Group 3.9-31
3.9.3.7 LINES Key Group 3.9-33
3.9.3.8 TRACE Key Group 3.9-34
3.9.3.9 SWEEP Key Group 3.9-35
3.9.3.10 SWEEP Key Group - Digital Demodulation 3.9-35
3.9.3.11 SWEEP Key Group - Analog Demodulation 3.9-36
3.9.4 Tracking Generator Mode (Option FSE-B8 to B11) 3.9-37
3.9.4.1 CONFIGURATION Key Group 3.9-37
3.9.5 TV-Demodulation Mode (Option FSE-B3) 3.9-38
3.9.5.1 CONFIGURATION Key Group 3.9-38
3.9.5.2 SWEEP Key Group 3.9-38
3.9.6 GSM BTS Analysis Mode (Option FSE-K11) 3.9-39
3.9.6.1 CONFIGURATION Key Group 3.9-39
3.9.7 GSM MS Analysis Mode (Option FSE-K10) 3.9-44
3.9.7.1 CONFIGURATION Key Group 3.9-44
3.9.8 External Mixer (Option FSE-B21) 3.9-49
3.9.8.1 INPUT Key Group 3.9-49

4 Maintenance and Troubleshooting

4.1 Maintenance **4.1-1**

4.1.1 Mechanical Maintenance 4.1-1

4.1.2 Electrical Maintenance 4.1-1

4.1.2.1 Testing the Level Measuring Accuracy 4.1-1

4.1.2.2 Testing the Frequency Accuracy 4.1-1

4.2 Monitoring the Function of the FSE **4.2-1**

4.2.1 Switch-on Test 4.2-1

4.2.2 Monitoring of the Synthesizers and Signal Levels 4.2-1

4.2.3 Error Messages of the Synthesizer 4.2-2

4.2.4 Overload Messages 4.2-2

4.3 Function Description of the Overall Instrument **4.3-1**

4.3.1 Introduction 4.3-1

4.3.2 Modules of the Analog Unit 4.3-1

4.3.3 Modules of the Digital Unit 4.3-1

4.3.4 Description of the Analog Unit 4.3-2

4.3.5 Processor Structure 4.3-3

4.3.5.1 Tasks of the Level Transputer 4.3-3

4.3.5.2 Tasks of the Frequency Transputer 4.3-3

4.4 Selftest **4.4-1**

4.4.1 Operation 4.4-1

4.4.2 Testing the Processor Functions 4.4-1

4.4.3 Testing the Synthesizers 4.4-1

4.4.4 Testing the Signal Path 4.4-2

5 Checking the Rated Specifications

5.1 Measuring Equipment and Accessories 5.1-1

5.2 Test Instructions 5.2-1

5.2.1 Checking the Calibration Source at 120 MHz 5.2-1

5.2.2 Checking the Frequency Accuracy of the Reference Oscillator 5.2-2

5.2.3 Checking the Return Loss at the RF Input 5.2-3

5.2.4 Checking Imunity to Interference 5.2-5

5.2.4.1 1st IF Image Frequency Rejection 5.2-5

5.2.4.2 2nd IF Image Frequency Rejection 5.2-6

5.2.4.3 1st IF Rejection 5.2-6

5.2.5 Checking Non-linearities 5.2-7

5.2.5.1 Third-Order Intercept 5.2-7

5.2.5.2 Second-Order Harmonic Distortion 5.2-8

5.2.6 Checking IF Filters 5.2-10

5.2.6.1 Checking the Level Error 5.2-10

5.2.6.2 Checking 3-dB Bandwidths 5.2-11

5.2.6.3 Checking the Shape Factor 5.2-12

5.2.7 Checking LO Feedthrough, Noise Display 5.2-13

5.2.7.1 LO Feedthrough 5.2-13

5.2.7.2 Noise Display 5.2-13

5.2.8 Checking the Frequency Response 5.2-14

5.2.9 Checking the Display Linearity 5.2-16

5.2.10 Checking the Attenuator 5.2-17

5.2.11 Checking the IF Gain Switching 5.2-18

5.2.12 Checking the Phase Noise 5.2-20

5.2.13 Checking the Tracking Generator – Option FS-B8/B9/B10/B11 ..... 5.2-22

5.2.13.1 Checking the Output Level 5.2-22

5.2.13.2 Checking the Frequency Response 5.2-22

5.2.13.3 Checking the I/Q Modulator 5.2-23

5.3 Performance Test Report 5.3-1

5.4 Test Instructions (option FSE-B22 included) 5.4-1

5.4.1 Checking the Calibration Source at 120 MHz 5.4-1

5.4.2 Checking IF Filters 5.4-2

5.4.2.1 Checking the Level Error 5.4-2

5.4.3 Checking the Frequency Response 5.4-3

5.4.4 Checking the Display Linearity 5.4-5

5.4.5 Checking the Attenuator 5.4-6

5.5 Performance Test Report (option FSE-B22 included) 5.5-1

6 Annex A - Interfaces

A.1 IEC Bus Interface A-1
A.2 RS-232-C Interface A-5
A.3 RSIB Interface Functions A-9
A.4 User Interface (USER) A-17
A.5 Printer Interface (LPT) A-18
A.6 Measurement Converters (PROBE CODE) A-19
A.7 Probe Connector (PROBE POWER) A-19
A.8 AF-Output (AF OUTPUT) A-20
A.9 IF Output 21.4 MHz (21.4 MHz OUT) A-20
A.10 Video Output (VIDEO OUT) A-20
A.11 Reference Output/Input (EXT REF IN/OUT) A-20
A.12 Sweep Output (SWEEP) A-20
A.13 External Trigger Input (EXT TRIGGER/GATE) A-20
A.14 Noise Source Control (NOISE SOURCE) A-21
A.15 External Keyboard (KEYBOARD) A-21
A.16 Mouse Connector (MOUSE) A-21
A.17 Monitor Connector (MONITOR) A-22

7 Annex B – List of Error Messages

8 Annex C – Alphabetical List of Commands

9 Annex D – Programming Examples

D.1 Including IEC-Bus Library for QuickBasic D-1
D.2 Initialization and Default Status D-1
D.3 Transmission of Instrument Setting Commands D-2
D.4 Switchover to Manual Control D-2
D.5 Reading out Instrument Settings D-2
D.6 Positioning a Marker and Displaying Values D-2
D.7 Command synchronization D-3
D.8 Service Request D-4
D.9 Programming via the RSIB Interface D-6

10 Annex E - Emulations

E.1 Mouse Control of Display Elements E-1
E.2 Front Panel Keyboard Emulation E-2

Tables

Table 1.6-1 Interface Connectors for Output Devices 1.6-1
Table 1.6-2 Factory settings for *DEVICE 1* and *DEVICE 2* 1.6-2

Table 2.1-1 Important PRESET settings 2.1-1

Table 2.3-1 Assignment of traces to windows with split screen 2.3-9
Table 2.3-2 Factory-set color assignment of soft keys 2.3-10

Table 2.4-1..Initial State of FSE 2.4-1

Table 3.7-1 Synchronisation using *OPC, *OPC? and *WAI 3.7-3
Table 3.8-1 Meaning of the bits in the status byte 3.8-4
Table -3.8-2 Meaning of the bits in the event status register 3.8-5
Table 3.8-3 Meaning of the bits in the STATus.OPERation register 3.8-6
Table 3.8-4 Meaning of bits in STATus:QUEStionable register 3.8-7
Table 3.8-5 Meaning of bits in STATus:QUEstionable:ACPLimit register 3.8-8
Table 3.8-6 Meaning of bits in STATus:QUEstionable:FREQuency register 3.8-9
Table3.8-7 Meaning of bits in STATus:QUEstionable:LIMit register 3.8-10
Table3.8-8 Meaning of bits in STATus: QUEstionable:LMARgin register 3.8-11
Table3.8-9 Meaning of bits in STATus:QUEstionable:POWer register 3.8-12
Table 3.8-10 Meaning of bits in STATus: QUEstionable:SYNC register 3.8-13
Table 3.8-11 Meaning of bits in STATus: QUEstionable:TRANsducer register 3.8-14
Table 3.8-12 Resettting instrument functions 3.8-17

Table A-1 Interface functions A-3
Table A-2 Universal Commands A-4
Table A-3 Addressed Commands A-4

Figures

Fig. 1.1-1 Front View 1.1-2
Fig. 1.1-2 Rear View 1.1-12

Fig. 2.1-1 200-MHz signal. The measured values are displayed in the marker field. 2.1-4
Fig. 2.1-2 Frequency measurement using the internal frequency counter. 2.1-6
Fig. 2.1-3 The The MARKER ZOOM function requires the entry of the measurement frequency range (span) 2.1-8
Fig. 2.1-4 Theoretical display curve of fundamental and first harmonic with a k2 intercept of 50 dBm. 2.1-9
Fig. 2.1-5 The 10-MHz-fundamental and harmonics to 55 MHz 2.1-14
Fig. 2.1-6 First harmonic separation: approx. 40 dB referred to the fundamental 2.1-15
Fig. 2.1-7 Fundamental with REFERENCE FIXED marker 2.1-18
Fig. 2.1-8 Measurement of the first harmonic 2.1-19
Fig. 2.1-9 SPLIT-SCREEN Mode 2.1-21
Fig. 2.1-10 Alternate representation of fundamental and first harmonic 2.1-23
Fig. 2.1-11 Intermodulation products P_{S1} and P_{S2} 2.1-24
Fig. 2.1-12 Dependance of the spurious product level from the level of the information signals .. 2.1-25
Fig. 2.1-13 Measuring diagram in low distortion mode 2.1-29
Fig. 2.1-14 Parameter beim Meßwertausblendung – Gap Sweep 2.1-31
Fig. 2.1-15 Representation of pulse sequence with video trigger 2.1-35
Fig. 2.1-16 Measured-value blanking for simultaneous display of rising and falling edge of a pulse signal. 2.1-37

Fig. 2.3-1 Subdivision of screen 2.3-2
Fig. 2.3-2 Subdivision of the FSE screen in analyzer mode (without measuring diagram) 2.3-3
Fig. 2.3-3 Measuring diagram 2.3-3
Fig. 2.3-4 Subdivision of the screen in Split Screen mode 2.3-9
Fig. 2.3-5 Setup of the softkey area 2.3-10
Fig. 2.3-6 Theory of menu selection 2.3-11
Fig. 2.3-7 Switching between main menu and supplementary menu 2.3-12
Fig. 2.3-8 Setup of an entry window 2.3-15
Fig. 2.3-9 Setup of numeric parameters 2.3-15
Fig. 2.3-10 Help line editor 2.3-17
Fig. 2.3-11 Shifting mode 2.3-18

Fig. 2.4-1 Split screen mode, screens uncoupled 2.4-2
Fig. 2.4-2 Linear frequency axis and linear interpolation 2.4-23
Fig. 2.4-3 Logarithmic frequency axis and logarithmic interpolation 2.4-24
Fig. 2.4-4 Logarithmic frequency axis and linear interpolation 2.4-24

Fig. 2.9-1 Determination of the channel width 2.9-32
Fig. 2.9-2 Example: Measurement of the signal/noise power 2.9-35
Fig. 2.9-3 Measurement of the adjacent channel power 2.9-36
Fig. 2.9-4 Example for level measurements at different 2.9-49
Fig. 2.9-5 Pulsed signal GATE 2.9-91
Fig. 2.9-6 TDMA-signal with GATE ON 2.9-91
Fig. 2.9-7 Interaction of the parameters *GATE MODE*, *GATE DELAY* and *GATE LENGTH* 2.9-92
Fig. 2.9-8 Setting the GATE DELAY and GATE LENGTH times in the time domain using the GD and GL lines. 2.9-96
Fig 2.9-9 Trace blanking in sweep mode.– Gap Sweep 2.9-97
Fig. 2.9-10 Display of a burst without gaps 2.9-97
Fig. 2.9-11 Display of a burst with a gap 2.9-98

Fig. 3.5-1 Tree structure the SCPI command systems using the SENSe system as an example 3.5-2

Fig. 3.7-1 Instrument model in the case of remote control by means of the IEC bus 3.7-1

Fig. 3.8-1 The status-register model 3.8-1
Fig. 3.8-2 Overview of the status registers 3.8-3

Fig. A-1 Pin assignment of IEC-Bus interface A-1
Fig. A-2 Pin assignment of the RS-232-C interface A-5
Fig. A-3 Wiring of the data lines for software handshake A-7
Fig. A-4 Wiring of the data, control and acknowledge lines for hardware handshake A-8
Fig. A-5 Pin assignments for the USER connector. A-17
Fig. A-6 Pin assignments for the LPT connector. A-18
Fig A.-7 Pin assignment for the 12-pin Tuchel connector. A-19
Fig. A-8 Pin assignments of the KEYBOARD connector. A-21
Fig A-9 Pin assignments for the MOUSE connector. A-21
Fig. A-10 Pin assignments of the MONITOR connector. A-22

Index

A

Abort
- hardcopy ... 2.6-1
- macro ... 2.5-1

ACP measurement ... 2.9-33
Addressed command ... A-4
AF demodulation ... 2.4-16; 2.4-17
Alphanumeric parameter
- editing ... 2.3-17

Ascii # ... 3.5-6
AUI connector ... 1.8-4
AUTO SELECT ... 3.6-138
Average ... 2.9-70
- display ... 2.9-52
- single sweep ... 2.9-71
- sweep count ... 2.9-70

B

Bandwidth
- channel ... 2.9-31
- occupied ... 2.9-37
- resolution ... 2.9-80
- video ... 2.9-81

Beeper ... 2.4-31
Block data ... 3.5-6
BNC connector ... 1.8-3
Boolean parameter ... 3.5-5

C

Calibrate ... 2.4-8
Center frequency ... 2.9-4
Channel
- bandwidth ... 2.9-31
- power measurement ... 2.9-32
- spacing ... 2.9-31

Characters, special ... 3.6-2
Clear/Write ... 2.9-69
Colon ... 3.5-6
COM1/2 interface ... 2.4-33
Comma ... 3.5-6
Command
- # ... 3.5-6
- addressed ... A-4
- colon ... 3.5-6
- comma ... 3.5-6
- header ... 3.5-2
- line ... 3.5-4
- long form ... 3.5-3
- overlapping execution ... 3.7-3
- query ... 3.5-4
- question mark ... 3.5-4; 3.5-6
- quotation mark ... 3.5-6
- recognition ... 3.7-2
- sequence ... 3.7-3
- short form ... 3.5-3
- structure ... 3.5-1
- suffix ... 3.5-3
- synchronization ... 3.7-3
- syntax elements ... 3.5-6
- univeral ... A-4
- white space ... 3.5-6

Common Commands ... 3.6-4
Configuration ... 2.4-18
Coupling ... 2.9-79

D

D Lines ... 2.9-56
Data set
- creation ... 2.7-9
- partial ... 2.7-8
- recall ... 2.7-9
- save ... 2.7-5

Date input ... 2.4-36
dB*/MHz ... 2.9-14
dBµA/MHz ... 2.9-14
dBµA/mMHz ... 2.9-14
dBµV/MHz ... 2.9-14
dBµV/mMHz ... 2.9-14
dBmV/MHz ... 2.9-14
DCL ... 3.7-2
Delete file ... 2.7-4
Delta marker ... 2.9-41
- step size ... 2.9-45

Demodulation ... 2.9-24
Detector
- auto select ... 2.9-75
- autopeak ... 2.9-75
- average ... 2.9-76
- max peak ... 2.9-75
- min peak ... 2.9-75
- RMS ... 2.9-76
- sample ... 2.9-76

Device
- reset (hardcopy) ... 2.6-10
- reset (overall) ... 2.4-1

Directory
- create ... 2.7-4
- rename ... 2.7-4

Disable
- front panel ... 2.3-19
- keyboard ... 2.3-19

Diskette
- format ... 2.7-4

Display
- configuration ... 2.4-2
- mean value ... 2.9-52
- rms value ... 2.9-52
- split screen ... 2.3-8

Double dagger ... 3.5-6
Driver
- NDIS ... 1.8-6
- packet ... 1.8-8

Drivers
- installation ... 1.8-5

E

ENABle register part ... 3.8-2
Enhancement labels ... 2.3-6
Entry
- abortion ... 2.3-16
- alphanumeric parameters ... 2.3-17
- numeric parameter ... 2.3-16
- table ... 2.3-17
- termination ... 2.3-16

Entry window ... 2.3-15
- mouse control ... 2.3-21

Error-queue query ... 3.8-16
ESE (event status enable register) ... 3.8-5
ESR (event status register) ... 3.8-5

Ethernet Adapter 1.8-3
EVENt register part 3.8-2
Event status enable register (ESE) 3.8-5
Event status register (ESR) 3.8-5
Ext Trig/Gate
input A-20

F

FFT-Filter 2.9-83
File
copy 2.7-4
delete 2.7-4
rename 2.7-4
sort 2.7-4
Firmware
update 1.7-1
version 2.4-12
Frequency
counter 2.9-26
line 2.9-56
measurement window 2.9-1
offset 2.9-5
zoom 2.9-10
Frequency axis
labelling 2.3-8
Front panel
disable 2.3-19
keyboard emulation E-2
FTP operation 1.8-15
Fuse 1.2-2

G

GET (Group Execute Trigger) 3.7-2

H

Handshake A-6
Hardcopy
abort 2.6-1
Bildelemente 2.6-3
comments 2.6-5
format 2.6-10
output device 2.6-6
position 2.6-4
settings 2.6-2
start 2.6-1
Hardware options
installed 2.4-12
Hardware settings
indication 2.3-5
Header 3.5-2
Help line editor 2.3-17

I

IEC/IEEE bus
address 2.4-31
output device 2.6-9
interface A-1
interface functions A-3
Indication
hardware settings 2.3-5
instrument settings 2.3-6
marker information 2.3-5
Input
Ext Trig/Gate A-20
external reference A-20
Input buffer 3.7-1
Installation
network operating system 1.8-8
Instrument settings
indication 2.3-6
Interface functions
IEC/IEEE-bus A-3
RS-232-C A-6
RSIB A-11
Interrupt 3.8-15
IST flag 3.8-5

K

KERMIT
installation 1.8-11
operation 1.8-16
Key
CAL 2.4-8
CENTER 2.9-4
CONFIG 2.7-3
COUPLING 2.9-79
cursor 2.3-14
D LINES 2.9-56
DELTA 2.9-41
DISPLAY 2.4-2
HOLD 2.3-19
INFO 2.4-12
INPUT 2.9-17
LIMITS 2.9-59
LOCAL 2.5-1
MENU 2.3-12
MKR 2.9-54
MODE 2.4-16
NORMAL 2.9-20
numeric keypad 2.3-13
PRESET 2.4-1; 3.6-185
RANGE 2.9-16
RECALL 2.7-9
REF 2.9-11
roll-key 2.3-14
SAVE 2.7-5
SEARCH 2.9-46
SETTINGS 2.6-2
SETUP 2.4-18
SPAN 2.9-8
START (frequency) 2.9-1
START (hardcopy) 2.6-1; 3.6-93
STEP 2.3-20
STOP 2.9-3
SWEEP 2.9-89
TRACE1 to 4 ..... 2.9-68
TRIGGER 2.9-87
USER 2.8-1
Keyboard
configuration 2.4-38
connection 1.5-1
connector A-21
disable 2.3-19
external 2.3-21

L

Level
- line ... 2.9-58
- maximum ... 2.9-12
- mixer ... 2.9-18
- range ... 2.9-16
- reference ... 2.9-11
- unit ... 2.9-13

LF demodulation ... 2.9-24
Limit line
- copy ... 2.9-62
- delete ... 2.9-62
- edit ... 2.9-63
- save ... 2.9-67
- select ... 2.9-60
- shift ... 2.9-67
- value ... 2.9-66

Line
- display 1,2 ... 2.9-58
- frequency 1, 2 ... 2.9-58
- limit ... 2.9-60
- reference ... 2.9-58
- threshold ... 2.9-58
- time 1, 2 ... 2.9-58

Lower case ... 3.6-2
LPT interface ... A-18

M

Macro
- abort ... 2.5-1
- definition ... 2.8-3
- start ... 2.8-1

Manual control
- switch to ... 2.5-1
- return to ... 3.3-2

Marker
- center ... 2.9-54
- demodulation ... 2.9-25
- indication ... 2.3-5
- info ... 2.9-24
- n-dB-down ... 2.9-50
- normal ... 2.9-20
- peak ... 2.9-47; 2.9-54
- search limit ... 2.9-50
- signal track ... 2.9-23
- step size ... 2.9-40
- zoom ... 2.9-24

Max hold ... 2.9-71
Mean power (GSM burst) ... 2.9-52
Measurement converters
- connector ... A-19

Measurement window ... 2.3-2; 2.4-2
Memory
- battery-powered ... 1.2-1
- configuration ... 2.7-3

Menu
- overview ... 2.2-1
- switching ... 2.3-11

MICROSOFT NET
- installation ... 1.8-10
- operation ... 1.8-13

Min hold ... 2.9-72
Minimum search ... 2.9-47
Mixer level ... 2.9-18
Mode ... 2.4-16
Modification level
- modules ... 2.3-12; 2.4-12

Modulation filter ... 2.9-30
Monitor
- connector ... A-22

Mouse
- configuration ... 2.4-37
- connection ... 1.4-1
- connector ... A-21
- control ... 2.3-21
  - display elements ... E-1

N

NDIS (driver) ... 1.8-6
Network drivers ... 1.8-5
Network operating system
- FTP ... 1.8-15
- installation ... 1.8-8
- KERMIT ... 1.8-11; 1.8-16
- MICROSOFT NET ... 1.8-10; 1.8-13
- NOVELL NETWARE ... 1.8-8; 1.8-11
- TCP/IP ... 1.8-10; 1.8-15

Noise power density measurement ... 2.9-27
NOVELL NETWARE
- installation ... 1.8-8
- operation ... 1.8-11

NTRansition register part ... 3.8-2
Numeric keypad ... 2.3-13
Numeric parameter
- editing ... 2.3-16

Numerical values (command) ... 3.5-5

O

ODI drivers ... 1.8-5
Offset frequency ... 2.9-5
Option
- FSE-B3 - TV Demodulation ... 2.4-16
- FSE-B5 - FFT Filter ... 1.8-2;
- FSE-B7 - Vector Analyzer ... 2.4-16
- FSE-B8 - Tracking Generator ... 2.4-16
- FSE-B16 - Ethernet Adapter ... 1.8-3
- FSE-B17 - Second IEC/IEE Interface ... 1.8-1

Output
- AF ... A-20
- IF ... A-20
- noise source control ... A-21
- reference ... A-20
- sweep ... A-20
- video out ... A-20

Output buffer ... 3.7-3
Output device
- formfeed ... 2.6-11
- paperfeed ... 2.6-11

P

Packet driver ... 1.8-8
Parallel poll ... 3.8-16
Parallel poll enable register (PPE) ... 3.8-5
Parameter
- block data ... 3.5-6
- boolean ... 3.5-5
- numerical values ... 3.5-5
- string ... 3.5-6
- text ... 3.5-6

Path ... 2.7-3

Peak
excursion 2.9-48
search 2.9-47
Plotter
connection 1.6-1
Power mean 2.9-52
Power measurement
adjacent channel 2.9-36
automatic optimisation of settings 2.9-38
bandwidth, occupied 2.9-37
channel 2.9-32
channel configuration 2.9-28
signal/noise 2.9-34
PPE (parallel poll enable register) 3.8-5
Preset 2.1-1; 2.4-1
Pre-trigger 2.9-99
Printer
connection 1.6-1; A-18
Probe Code
connector A-19
Probe Power
connector A-19
PTRansition register part 3.8-2

Q

Quasi analog display 2.9-76
Query 3.5-4; 3.8-16
Question mark 3.5-4; 3.5-6
Quotation mark 3.5-6

R

Rack installation 1.2-1
Recall data set 2.7-9
Reference
external 2.4-29
line 2.9-58
Reference level 2.9-11
offset 2.9-12
Remote control
IEC/IEEE-bus 3.3-1
indications 2.5-1, 3.3-1
RS-232-C 3.3-3
RSIB 3.3-4
switch over 3.3-1
Rename
directory 2.7-4
file 2.7-4
Reset device 2.2-1; 2.4-1
Resolution bandwidth 2.9-80
RF attenuation
auto 2.9-18
auto low distortion 2.9-18
auto low noise 2.9-18
RF input 2.9-17
RJ45 (star topology) 1.8-4
Roll-key 2.3-14
RS-232-C
interface A-5
interface functions A-6
transmission parameters A-6

S

Save
configuration 2.7-1
data set 2.7-5
limit line 2.9-67
measurement 2.7-1
SCPI introduction 3.5-1
Screen 2.3-2
split screen 2.3-9
subdivision 2.3-3
Search
limit 2.9-50
minimum 2.9-47
peak 2.9-47
Self test 2.4-14; 4-1
Serial interface
configuration 2.4-33
Serial poll 3.8-15
Service functions 2.4-39
Service request (SRQ) 2.5-1; 3.8-4; 3.8-15
Service request enable register (SRE) 3.8-4
Setup 2.4-18
general 2.4-30
Soft key
% POWER BANDWIDTH 2.9-31; 3.6-160
ACP STANDARD 2.9-30; 3.6-46
ACTIVE MKR / DELTA 2.9-47
ACTIVE SCREEN A/B 2.4-3
ADJACENT CHAN POWER 2.9-36; 3.6-44; 3.6-45
ADJUST CP SETTINGS 2.9-38; 3.6-160
ADJUST TO TRACE 2.9-78
ALL DELTA OFF 2.9-42; 3.6-9
ALL MARKER OFF 2.9-23; 3.6-34
ALL SUM MKR OFF 2.9-53
AM 2.9-25; 3.6-40
AMPERE 2.9-15; 3.6-56
ANALOG TR ON/OFF 2.9-76; 3.6-80
ANALYZER 2.4-16; 2.9-1; 3.6-99
area 2.3-10
ATTEN AUTO LOW DIST 2.9-18; 3.6-97
ATTEN AUTO LOW NOISE 2.9-18; 3.6-97
ATTEN AUTO NORMAL 2.9-18; 3.6-97
AUTO 0.1 * RBW 2.9-6; 3.6-149
AUTO 0.1 * SPAN 2.9-6; 3.6-149
AUTO 0.5 * RBW 2.9-7; 3.6-149
AUTO 0.5 * SPAN 2.9-7; 3.6-149
AUTO RECALL 2.7-10; 3.6-104
AUTO SELECT 2.9-75; 3.6-138
AUTO X * RBW 2.9-7; 3.6-149
AUTO X * SPAN 2.9-7; 3.6-149
AVERAGE 2.9-70; 3.6-80
AVERAGE ON/OFF 2.9-53; 3.6-52
BLANK 2.9-69; 3.6-81
BRIGHTNESS 2.3-5; 2.4-5; 3.6-75
C/N 2.9-34; 3.6-44; 3.6-45
C/No 2.9-34; 3.6-44; 3.6-45
CAL CORR ON/OFF 2.4-10; 3.6-58
CAL I/Q 2.4-9; 3.6-57
CAL LO SUPP 2.4-9; 3.6-58
CAL LOG 2.4-9; 3.6-58
CAL RES BW 2.4-9; 3.6-57
CAL RESULTS 2.4-11
CAL SHORT 2.4-9; 3.6-58
CAL TOTAL 2.4-9; 3.6-57
CENTER FIXED 2.9-2; 2.9-3; 2.9-9; 3.6-149; 3.6-150
CENTER MANUAL 2.9-4; 3.6-148
CH FILTER ON/OFF 2.9-30; 3.6-46
CHANNEL BANDWIDTH 2.9-31; 3.6-159
CHANNEL POWER 2.9-32; 3.6-44; 3.6-45
CHANNEL SPACING 2.9-31; 3.6-158; 3.6-159
CLEAR ALL MESSAGES 2.4-15

CLEAR MESSAGE 2.4-15; 3.6-184
CLEAR/WRITE 2.9-69; 3.6-80
COLOR ON/ OFF 2.6-3; 3.6-92
COM PORT 1/2 ..... 2.4-33; 3.6-182; 3.6-183
COMMENT SCREEN A/B 2.6-5; 3.6-94
CONFIG DISPLAY 2.4-5
CONTINUOUS SWEEP 2.9-89; 3.6-96
COPY 2.7-4; 3.6-103
COPY (TRACE) 2.9-72
COPY LIMIT LINE 2.9-62; 3.6-26
COPY SCREEN 2.6-3; 3.6-93
COPY TABLE 2.6-3; 3.6-94
COPY TRACE 2.6-3; 3.6-95
COUNTER RESOL 2.9-27; 3.6-35
COUPLING CONTROL 2.4-4; 3.6-100
COUPLING DEFAULT 2.9-82; 3.6-128; 3.6-162
COUPLING RATIO 2.9-85
CP/ACP ABS/REL 2.9-33; 3.6-160
DATA SET CLEAR 2.7-7; 3.6-106
DATA SET CLEAR ALL 2.7-7; 3.6-106
DATA SET LIST 2.7-6
DATAENTRY OPAQUE 2.4-7
DATAENTRY X 2.4-7
DATAENTRY Y 2.4-7
DATE 2.4-36; 3.6-183
dB*/MHz 2.9-14; 3.6-56
dBµA 2.9-14; 3.6-56
dBµV 2.9-14; 3.6-56
dBm 2.9-14; 3.6-56
dBmV 2.9-14; 3.6-56
dBpW 2.9-14
DEFAULT COLORS 2.4-6; 3.6-74
DEFAULT CONFIG 2.7-8; 3.6-110
DEFAULT POSITION 2.4-7
DEFINE MACRO 2.8-3
DEFINE PAUSE 2.8-3
DELETE 2.7-4; 3.6-103; 3.6-105
DELETE FACTOR/SET 2.4-21; 3.6-133; 3.6-134
DELETE LIMIT LINE 2.9-62; 3.6-26
DELETE MACRO 2.8-4
DELETE VALUE (limit line) 2.9-66
DELTA 1 to 4 ..... 2.9-41; 3.6-8; 3.6-9; 3.6-10
DELTA ABS REL 2.9-42; 3.6-9
DELTA TO STEPSIZE 2.9-40
DETECTOR 2.9-75; 3.6-138
DETECTOR AUTOPEAK 2.9-75; 3.6-138
DETECTOR AVERAGE 2.9-76; 3.6-138
DETECTOR MAX PEAK 2.9-75; 3.6-138
DETECTOR MIN PEAK 2.9-75; 3.6-138
DETECTOR RMS 2.9-76; 3.6-138
DETECTOR SAMPLE 2.9-76; 3.6-138
DISABLE ALL ITEMS 2.7-8; 2.7-12; 3.6-110
DISPLAY COMMENT 2.4-6; 3.6-76
DISPLAY LINE 1 ..... 2.9-58; 3.6-14
EDIT ACP LIMITS 2.9-31; 3.6-30; 3.6-31
EDIT COMMENT 2.7-6; 3.6-110
EDIT LIMIT LINE ..... 2.9-64; 3.6-21 to 3.6-26
EDIT NAME 2.7-6; 2.7-10; 3.6-104; 3.6-106
EDIT PATH 2.7-3; 2.7-6; 2.7-10; 3.6-102; 3.6-105
EDIT TRD FACTOR 2.4-22; 3.6-132
EDIT TRD SET 2.4-25; 3.6-133
ENABLE ALL ITEMS 2.7-8; 2.7-12; 3.6-109
ENABLE DEV1 / DEV2 ..... 2.6-12
ENABLE OPTION 2.4-30
ENTER PASSWORD 2.4-40; 3.6-184
ENTER TEXT 2.6-5
EXCLUDE LO ON/OFF 2.9-48; 3.6-36
EXECUTE TEST 2.4-14; 3.6-6
EXT GATE ON / OFF 2.9-92
EXT GATE SETTINGS 2.9-93
EXT REF FREQUENCY 2.4-29; 3.6-161
EXTERN (trigger) 2.9-88; 3.6-188; 3.6-189
EXTERNAL KEYBOARD 2.4-38
FIRMWARE VERSION 2.4-12; 3.6-5
FM 2.9-25; 3.6-40
FORMAT DISK 2.7-4; 3.6-103
FREE RUN 2.9-87; 3.6-188
FREQ AXIS LIN/LOG 2.9-2; 2.9-9; 3.6-77; 3.6-165
FREQUENCY LINE 2.9-58; 3.6-15
FREQUENCY OFFSET 2.9-5; 3.6-151
FREQUENCY ON/OFF 2.4-6; 3.6-74
FULL PAGE 2.6-4; 3.6-95
FULL SCREEN 2.4-3; 3.6-74
FULL SPAN 2.9-8; 3.6-149
GAP LENGTH 2.9-100; 3.6-165
GAP SWEEP ON/OFF 2.9-98; 3.6-164
GAP SWEEP SETTINGS 2.9-99
GATE ADJUST 2.9-95
GATE DELAY 2.9-94; 3.6-163
GATE EXTERN 2.9-94; 3.6-164
GATE LENGTH 2.9-94; 3.6-164
GATE LEVEL 2.9-93; 3.6-163
GATE MODE LEVEL/EDGE 2.9-93; 3.6-163
GATE ON/OFF 3.6-163
GATE POL POS/NEG 2.9-93; 3.6-163
GATE RF POWER 2.9-94; 3.6-164
GENERAL SETUP 2.4-30
GPIB ADDRESS 2.4-31; 3.6-181
GRID ABS/REL 2.9-12; 2.9-16; 3.6-78
HARDCOPY DEVICE 2.6-6; 3.6-92
HARDWARE+OPTIONS 2.4-13; 3.6-5
HOLD CONT ON/OFF 2.9-72; 3.6-81
HORIZONTAL SCALING 2.4-4; 3.6-100
INPUT CAL 2.4-39; 3.6-72
INPUT RF 2.4-39; 3.6-72
INPUT SELECT 2.9-19
INSERT VALUE (limit line) 2.9-66
KEY CLICK ON/OFF 2.4-31
LAST SPAN 2.9-9
LIMIT CHECK 2.9-31; 3.6-30; 3.6-31
LINE (trigger) 2.9-87; 3.6-188
LINEAR/% 2.9-16; 3.6-80
LINEAR/dB 2.9-16; 3.6-80
LOCK ALL 2.3-19
LOCK DATA 2.3-19
LOG 10dB/20dB/50dB/100dB/120dB 2.9-16
LOG MANUAL 2.9-16; 3.6-78; 3.6-80
LOGO ON/OFF 2.4-6; 3.6-74
LOWER LEFT 2.6-4; 3.6-95
LOWER RIGHT 2.6-4; 3.6-95
MACRO 1 to 7 ..... 2.8-2
MACRO TITLE 2.8-4
MAIN PLL BANDWIDTH 2.9-84; 3.6-129
MAKE DIRECTORY 2.7-4; 3.6-104
MANUAL STEPSIZE 3.6-13
MARKER ->TRACE 3.6-35
MARKER 1 to 4 ..... 2.9-21; 3.6-34; 3.6-35; 3.6-36
MARKER DEMOD 2.9-25
MARKER INFO 2.9-24; 3.6-13; 3.6-39; 3.6-40; 3.6-41; 3.6-45; 3.6-51; 3.6-52; 3.6-75
MARKER ZOOM 2.9-24; 3.6-40
MAX HOLD 2.9-71; 3.6-80
MAX LEVEL AUTO 2.9-12; 3.6-79
MAX LEVEL MANUAL 2.9-12; 3.6-79
MEAN 2.9-52; 3.6-51
MIN 2.9-47; 3.6-11; 3.6-37
MIN HOLD 2.9-72; 3.6-80
MIXER LEVEL 2.9-18; 3.6-98
MKR -> CENTER 2.9-54; 3.6-53
MKR -> CF STEPSIZE 2.9-55; 3.6-53
MKR -> REF LEVEL 2.9-55; 3.6-54
MKR -> START 2.9-55; 3.6-53
MKR -> STOP 2.9-55; 3.6-53
MKR -> TRACE 2.9-55; 3.6-9

MKR DEMOD ON/OFF....2.9-25; 3.6-40
MKR STOP TIME....2.9-25; 3.6-41
MKR TO STEPSIZE....2.9-40; 3.6-54
MODE COUPLED....2.4-4; 3.6-100
MOUSE....2.4-37
MOVE ZOOM START....2.9-10; 3.6-77
MOVE ZOOM STOP....2.9-10; 3.6-77
MOVE ZOOM WINDOW....2.9-10; 3.6-77
N dB DOWN....2.9-50; 3.6-39
NAME (limit line)....2.9-65; 3.6-26
NEW FACT/SET....3.6-131; 3.6-133
NEW FACTOR/SET....2.4-22; 2.4-25
NEW LIMIT LINE....2.9-64
NEXT MIN....2.9-48; 3.6-11; 3.6-37
NEXT MIN LEFT....2.9-48; 3.6-11
NEXT MIN RIGHT....2.9-48; 3.6-11; 3.6-38
NEXT PEAK....2.9-47; 3.6-10; 3.6-37
NEXT PEAK LEFT....2.9-47; 3.6-11; 3.6-37
NEXT PEAK RIGHT....2.9-47; 3.6-10; 3.6-37
NOISE....2.9-27; 3.6-40
NOISE SOURCE....2.4-39; 3.6-72
OCCUPIED PWR BANDW....2.9-37; 3.6-44; 3.6-45
OPTIONS....2.4-13; 2.4-29; 3.6-5
PEAK....2.9-47; 3.6-10; 3.6-36
PEAK EXCURSION....2.9-48; 3.6-38
PEAK HOLD ON/OFF....2.9-53; 3.6-52
PHASE NOISE....2.9-44; 3.6-13
POWER MEAS SETTINGS....2.9-29
PRE TRIGGER (gap sweep)....2.9-99; 3.6-164
PREDEFINED COLORS....2.4-6; 3.6-75
PROBE CODE ON/OFF....2.9-15; 3.6-193
RBW / VBW MANUAL....2.9-86; 3.6-129
RBW / VBW NOISE....2.9-86; 3.6-129
RBW / VBW PULSE....2.9-86; 3.6-129
RBW <= NORM/FFT....2.9-83; 3.6-128
RBW 1kHz ANA/DIG....2.9-82; 3.6-128
RBW / VBW SINE [1]....3.6-129; 2.9-85
RECORD ON/OFF....2.8-3
REF LEVEL....2.9-12; 3.6-78
REF LEVEL OFFSET....2.9-12; 3.6-78
REF POINT FREQUENCY....2.9-43; 3.6-12
REF POINT LEVEL....2.9-43; 3.6-12
REF POINT LVL OFFSET....2.9-43; 3.6-12
REF POINT TIME....2.9-43; 3.6-12
REFERENCE....2.4-40; 3.6-161
REFERENCE PROG....2.4-40;,3.6-161
REFERENCE FIXED....2.9-42; 3.6-12
REFERENCE INT/EXT....2.4-29; 3.6-161
REFERENCE LINE....2.9-58; 3.6-15
REFERENCE POINT....2.9-43
RENAME....2.7-4; 3.6-105
RES BW AUTO....2.9-80; 3.6-128
RES BW MANUAL....2.9-81; 3.6-127
RF ATTEN MANUAL....2.9-17; 3.6-97
RF INPUT 50 OHM....2.9-19; 3.6-98
RF INPUT 75 OHM/RAM....2.9-19; 3.6-98
RF INPUT 75 OHM/RAZ....2.9-19; 3.6-98
RF POWER (trigger)....2.9-883.6-188
RMS....2.9-52; 3.6-50
SATURATION....2.4-6; 3.6-75
SAVE LIMIT LINE....2.9-67
SCREEN COUPLING....2.4-4
SCREENS UNCOUPLED....2.4-4; 3.6-100
SEARCH LIMIT ON/OFF....2.9-50; 3.6-35
SELECT ITEMS....2.7-8; 2.7-12; 3.6-106 to 3.6-109
SELECT LIMIT LINE....2.9-60; 3.6-20; 3.6-26
SELECT MACRO....2.8-4
SELECT MARKER....2.9-47
SELECT OBJECT....2.4-5
SELECT QUADRANT....2.6-4
SELFTEST....2.4-14; 3.6-6
SERVICE FUNCTION....2.4-39; 3.6-72
SET CP REFERENCE....2.9-33; 3.6-160
SET NO. OF ADJ CHAN'S....2.9-29; 3.6-159
SETTINGS DEVICE 1/2....2.6-7;3.6-92
SGL SWEEP DISP OFF....2.9-90; 3.6-96
SHAPE FACT 60dB/3dB....2.9-51; 3.6-41
SHAPE FACT 60dB/6dB....2.9-51; 3.6-41
SHIFT X LIMIT LINE....2.9-67; 3.6-22
SHIFT Y LIMIT LINE....2.9-67; 3.6-23; 3.6-25
SIGNAL COUNT....2.9-26; 3.6-35
SIGNAL TRACK....2.9-23; 3.6-42
SINGLE SWEEP....2.9-89; 3.6-96
SLOPE POS/NEG....2.9-88; 3.6-189
SORT MODE....2.7-4
SPAN / RBW AUTO [50]....2.9-86; 3.6-128
SPAN / RBW MANUAL....2.9-86; 3.6-128
SPAN FIXED....2.9-1; 2.9-3; 2.9-5; 3.6-148; 3.6-150
SPAN MANUAL....2.9-8; 3.6-149
SPLIT SCREEN....2.4-3; 3.6-74
START FIXED2.9-3; 2.9-5; 2.9-9; 3.6-148; 3.6-149; 3.6-150
START MANUAL....2.9-1; 3.6-150
STEPSIZE = CENTER....2.9-7
STEPSIZE AUTO....3.6-13; 3.6-38
STEPSIZE MANUAL....2.9-7; 3.6-38; 3.6-148
STOP FIXED....2.9-1; 2.9-5; 2.9-9; 3.6-148 to 3.6-150
STOP MANUAL....2.9-3; 3.6-150
SUM MKR ON/OFF....2.9-51; 3.6-46
SUMMARY MARKER....2.9-52
SWEEP COUNT....2.9-53; 2.9-71; 2.9-90; 3.6-162
SWEEP TIME AUTO....2.9-82; 3.6-162
SWEEP TIME MANUAL....2.9-82; 3.6-162
SYSTEM MESSAGES....2.4-15; 3.6-184
T1-REF....2.9-77; 3.6-55
T1-T2+REF....2.9-77; 3.6-55
T1-T3+REF....2.9-77; 3.6-55
THRESHOLD LINE....2.9-58; 3.6-14; 3.6-15
TIME....2.4-36; 3.6-185
TIME LINE 1/2....2.9-58; 3.6-16
TIME ON/OFF....2.4-6; 3.6-76
TIME/DIVB7....3.6-162
TINT....2.4-6; 3.6-75
TITLE....2.6-5; 3.6-94
TRACE MATH....2.9-77
TRACE MATH LIN/LOG....2.9-78
TRACE MATH OFF....2.9-78; 3.6-55
TRACKING GENERATOR....2.4-16; 3.6-99; 3.6-111
TRANSD SET NAME....2.4-26; 3.6-133
TRANSD SET RANGES....2.4-27; 3.6-134
TRANSD SET UNIT....2.4-26; 3.6-133
TRANSDUCER FACTOR....2.4-20; 3.6-132
TRANSDUCER SET....2.4-20; 3.6-133; 3.6-134
TRC COLOR AUTO INC....2.6-3; 3.6-95
TRD FACTOR UNIT....2.4-23; 3.6-132
TRD FACTOR VALUES....2.4-24; 3.6-132
TRG TO GAP TIME....2.9-100; 3.6-164
TRIGGER DELAY....2.9-88; 3.6-189
TRIGGER LEVEL (gap sweep)....2.9-99; 3.6-189
TV DEMOD....2.4-16; 3.6-99
UNIT....2.9-13; 3.189
UNLOCK....2.3-19
UPDATE MESSAGES....2.4-15
UPPER LEFT....2.6-4; 3.6-95
UPPER RIGHT....2.6-4; 3.6-95
USER PORT A/B....2.4-32; 3.6-98; 3.6-111
VALUES (limit line)....2.9-66
VECTOR ANALYZER....2.4-17; 3.6-99
VERTICAL SCALING....2.4-4; 3.6-100
VIDEO (trigger)....2.9-87; 3.6-188; 3.6-189
VIDEO BW AUTO....2.9-81; 3.6-129
VIDEO BW MANUAL....2.9-81; 3.6-129
VIEW....2.9-69; 3.6-80
VOLT....2.9-15; 3.6-56
VOLUME....2.9-25; 3.6-185

WATT ... 2.9-15; 3.6-56
X OFFSET ... 2.9-62; 3.6-21
Y OFFSET ... 2.9-62; 3.6-23; 3.6-24
ZERO SPAN ... 2.9-8; 3.6-149
ZOOM ... 2.9-10; 3.6-76
ZOOM OFF ... 2.9-10; 3.6-76
Span ... 2.9-8
measurement window ... 2.9-1
Special characters ... 3.6-2
Split screen mode ... 2.4-3
SRE (service request enable register) ... 3.8-4
SRQ (service request) ... 3.8-4; 3.8-15
Start frequency ... 2.9-1
Start-Up ... 1.2-1
Status byte (STB) ... 3.8-4
Status information ... 2.3-4
Status Questionable
FREQuency register (IEC) ... 3.8-9
LIMit register (IEC) ... 3.8-10
LMARgin register (IEC) ... 3.8-11
POWer register (IEC) ... 3.8-12
SYNC register (IEC) ... 3.8-13
TRANsducer register (IEC) ... 3.8-14
Status register
CONDition part ... 3.8-2
ENABle part ... 3.8-2
ESE ... 3.8-5
ESR ... 3.8-5
EVENt part ... 3.8-2
NTRansition part ... 3.8-2
overview ... 3.8-3
PPE ... 3.8-5
PTRansition part ... 3.8-2
SRE ... 3.8-4
STATus OPERation ... 3.8-6
STATus QUEStionable ... 3.8-7
FREQuency ... 3.8-9
LIMit ... 3.8-10
LMARgin ... 3.8-11
POWer ... 3.8-12
SYNC ... 3.8-13
TRANsducer ... 3.8-14
STB ... 3.8-4
structure ... 3.8-1
sum bit ... 3.8-2
Status reporting system ... 3.8-1
resetting values ... 3.8-17
STATus:OPERation register ... 3.8-6
STATus:QUEStionable register ... 3.8-7
Staus information
DIFOVL ... 2.3-4
ExtRef ... 2.3-4
IFOVLD ... 2.3-4
LO LvD ... 2.3-4
LO Lvl ... 2.3-4
LO unl ... 2.3-4
MAX / REF LVL ... 2.3-4
OCXO ... 2.3-4
OVLD ... 2.3-4
UNCAL ... 2.3-4
UNLD ... 2.3-4
STB (status byte) ... 3.8-4
Step size
center frequency ... 2.9-6
delta marker ... 2.9-45
marker ... 2.9-40
setting ... 2.3-20
Stop frequency ... 2.9-3
String ... 3.5-6
Suffix ... 3.5-3
Sum bit ... 3.8-2
Sweep
count ... 2.9-90
coupling ... 2.9-79
gap ... 2.9-97
gap length ... 2.9-100
gated ... 2.9-91
mode ... 2.9-89
single ... 2.9-89
time ... 2.9-82
Sweep count ... 2.9-71
Syntax elements
command ... 3.5-6
System messages ... 2.4-15

T

Table
entry ... 2.3-17
TCP/IP
installation ... 1.8-10
operation ... 1.8-15
Test functional ... 1.3-1
Text parameter ... 3.5-6
Thick Ethernet ... 1.8-4
Thin Ethernet ... 1.8-3
Time input ... 2.4-36
Trace ... 2.9-68
copy ... 2.9-72
detector ... 2.9-73
mathematics ... 2.9-77
Transducer ... 2.4-18
entry ... 2.4-21
set ... 2.4-25
switch on ... 2.4-19
Transmission parameters
RS-232-C ... A-6
Trigger
delay ... 2.9-88
free run ... 2.9-87
gap sweep ... 2.9-99
line ... 2.9-87
pre-trigger ... 2.9-99
RF power ... 2.9-88
slope ... 2.9-88
video ... 2.9-87

U

Units ... 2.9-13
Universal command ... A-4
Upper case ... 3.6-2
User interface ... A-17
User port
configuration ... 2.4-32

V

Vector analyzer mode ... 2.4-17
Video bandwidth ... 2.9-81
View ... 2.9-69
Volume ... 2.9-25

W

White space ... 3.5-6

Z

Zero span ... 2.9-8
Zoom ... 2.9-10; 2.9-69
amplitude ... 2.9-69

Safety Instructions

This unit has been designed and tested in accordance with the EC Certificate of Conformity and has left the manufacturer's plant in a condition fully complying with safety standards.

To maintain this condition and to ensure safe operation, the user must observe all instructions and warnings given in this operating manual.

Safety-related symbols used on equipment and documentation from R&S:

Observe operating instructions

Weight indication for units >18 kg

PE terminal

Ground terminal

Danger! Shock hazard

Warning! Hot surfaces

Ground

Attention! Electrostatic sensitive devices require special care

1. The unit may be used only in the operating conditions and positions specified by the manufacturer. Unless otherwise agreed, the following applies to R&S products:

   Pollution severity 2, overvoltage category 2, IP degree of protection 2X, altitude max. 2000 m.

   The unit may be operated only from supply networks fused with max. 16 A.

2. For measurements in circuits with voltages V_{rms} > 30 V, suitable measures should be taken to avoid any hazards.

   (using, for example, appropriate measuring equipment, fusing, current limiting, electrical separation, insulation).

3. If the unit is to be permanently wired, the PE terminal of the unit must first be connected to the PE conductor on site before any other connections are made (installation and cabling of the unit to be performed only by qualified technical personnel).

4. For permanently installed units without built-in fuses, circuit breakers or similar protective devices, the supply circuit must be fused such as to provide suitable protection for the users and equipment.

5. Prior to switching on the unit, it must be ensured that the nominal voltage set on the unit matches the nominal voltage of the AC supply network.

   If a different voltage is to be set, the power fuse of the unit may have to be changed accordingly.

6. Units of protection class I with disconnectible AC supply cable and appliance connector may be operated only from a power socket with earthing contact and with the PE conductor connected.

7. It is not permissible to interrupt the PE conductor intentionally, neither in the incoming cable nor on the unit itself as this may cause the unit to become electrically hazardous.

   Any extension lines or multiple socket outlets used must be checked for compliance with relevant safety standards at regular intervals.

8. If the unit has no power switch for disconnection from the AC supply, the plug of the connecting cable is regarded as the disconnecting device. In such cases it must be ensured that the power plug is easily reachable and accessible at all times (length of connecting cable approx. 2 m). Functional or electronic switches are not suitable for providing disconnection from the AC supply.

   If units without power switches are integrated in racks or systems, a disconnecting device must be provided at system level.

9. Applicable local or national safety regulations and rules for the prevention of accidents must be observed in all work performed.

   Prior to performing any work on the unit or opening the unit, the latter must be disconnected from the supply network.

   Any adjustments, replacements of parts, maintenance or repair may be carried out only by authorized R&S technical personnel.

   Only original parts may be used for replacing parts relevant to safety (eg power switches, power transformers, fuses). A safety test must be performed after each replacement of parts relevant to safety.

   (visual inspection, PE conductor test, insulation-resistance, leakage-current measurement, functional test).

continued overleaf

10. Ensure that the connections with information technology equipment comply with IEC950/ EN60950.
11. Lithium batteries must not be exposed to high temperatures or fire.

    Keep batteries away from children.

    If the battery is replaced improperly, there is danger of explosion. Only replace the battery by R&S type (see spare part list)

    Lithium batteries are suitable for environmentally-friendly disposal or specialized recycling. Dispose them into appropriate containers, only.

    Do not short-circuit the battery.
12. Equipment returned or sent in for repair must be packed in the original packing or in packing with electrostatic and mechanical protection.
13. Electrostatics via the connectors may damage the equipment. For the safe handling and operation of the equipment, appropriate measures against electrostatics should be implemented.
14. Any additional safety instructions given in this manual are also to be observed.

Important Hints before Operation:

For instruments without the computer function FSE-B15 (all models):

- The disks used must have been formatted by the FSE itself or by MS-DOS. Pre-formatted disks can cause errors.

For instruments with the computer function FSE-B15 (models 1073.5696.02/03):

- The drives D: and Q: are reserved for system software and must not be altered. Any changes in the drives D: and Q: can cause function errors.
- When operating a PS/2 mouse, a mouse driver has to be loaded via the designated entry in the autoexec.bat file.
- The files AUTOEXEC.BAT and CONFIG.SYS are write protected. User-specific programs which are to be executed automatically during the system startup must be entered in the file C:\AUTOUSER.BAT. Network drivers for option FSE-B16 must be entered in the file C:\NETWORK.BAT.
- After switching on the instrument, the startup process can be interrupted if required. This is achieved by pressing any key on the external keyboard repeatedly until "ABORT SYSTEM BOOT [Y/N?]" is queried on the display. The instrument works then in the DOS mode.

For instruments without computer function and for instruments with the DOS computer function FSE-B15 (models 1073.5696.02/03):

- Aborting a hardcopy is not possible when printout is in progress. Print jobs in the queue can be deleted before printout has been started by pressing the HARDCOPY START key until the message "Hardcopy in progress. Abort?" is displayed. The length of the queue is two jobs.

Patent Information

This product contains technology licensed by Marconi Instruments LTD. under US patent 4609881 and under the corresponding patent in Germany and elsewhere.

Certified Quality System

ISO 9001

DQS REG. NO 1954-04

Qualitätszertifikat

Sehr geehrter Kunde,

Sie haben sich für den Kauf eines Rohde & Schwarz-Produktes entschieden. Hiermit erhalten Sie ein nach modernsten Fertigungsmethoden hergestelltes Produkt. Es wurde nach den Regeln unseres Qualitätsmanagementsystems entwickelt, gefertigt und geprüft. Das Rohde & Schwarz-Qualitätsmanagementsystem ist nach ISO 9001 zertifiziert.

Certificate of quality

Dear Customer,

You have decided to buy a Rohde & Schwarz product. You are thus assured of receiving a product that is manufactured using the most modern methods available. This product was developed, manufactured and tested in compliance with our quality management system standards.
The Rohde & Schwarz quality management system is certified according to ISO 9001.

Certificat de qualité

Cher client,

Vous avez choisi d'acheter un produit Rohde & Schwarz. Vous disposez donc d'un produit fabriqué d'après les méthodes les plus avancées. Le développement, la fabrication et les tests respectent nos normes de gestion qualité.
Le système de gestion qualité de Rohde & Schwarz a été homologué conformément à la norme ISO 9001.

ROHDE & SCHWARZ

ROHDE&SCHWARZ

EC Certificate of Conformity

CE

Certificate No.: 9502002

This is to certify that:

Equipment type	Order No.	Designation
FSEA20/30	1065.6000.20/.25/.30/.35	Spectrum Analyzer
FSEB20/30	1066.3010.20/.25/.30/.35	
FSEK20/21	1088.1491.20/.21/.25	
FSEK30/31	1088.3494.30/.31/.35	
FSEM20/21	1080.1505.20/.21/.25	
FSEM30/31	1079.8500.30/.31/.35	

complies with the provisions of the Directive of the Council of the European Union on the approximation of the laws of the Member States

- relating to electrical equipment for use within defined voltage limits (73/23/EEC revised by 93/68/EEC)
- relating to electromagnetic compatibility (89/336/EEC revised by 91/263/EEC, 92/31/EEC, 93/68/EEC)

Conformity is proven by compliance with the following standards:

EN61010-1 : 1991
EN50081-1 : 1992
EN50082-1 : 1992

Affixing the EC conformity mark as from 1995

ROHDE & SCHWARZ GmbH & Co. KG
Mühldorfstr. 15, D-81671München

Munich, 2000-02-11

Central Quality Management FS-QZ / Becker

ROHDE&SCHWARZ

EC Certificate of Conformity

CE

Certificate No.: 9502052

This is to certify that:

Equipment type	Stock No.	Designation
FSE-B1	1073.4990.02	Color Display
FSE-B10	1066.4769.02	Tracking Generator
FSE-B11	1066.4917.02	Tracking Generator
FSE-B12	1066.5065.02	Output Attenuator
FSE-B13	1119.6499.02	1 dB Input Attenuator
FSE-B15	1073.5696.02/.03	Computer Function
FSE-B16	1073.5973.02/.03/.04	Ethernet Interface
FSE-B17	1066.4017.02	2nd IEC BUS Interface
FSE-B18	1088.6993.02	Removeable Harddrive
FSE-B2	1073.5044.02	7 GHz Frequency Extension
FSE-B21	1084.7243.02	External Mixer Output
FSE-B23	1088.7348.02	741,4 MHz Broadband Output
FSE-B24	1106.3680.02	44 GHz Frequency Extension
FSE-B3	1073.5244.02	TV Demodulator
FSE-B4	1073.5396.02	OCXO 10 MHz and Low Phase Noise
FSE-B7	1066.4317.02	Signal Vectoranalysis
FSE-B77	1102.8493.02	Signal Vectoranalysis
FSE-B8	1066.4469.02	Tracking Generator
FSE-B9	1066.4617.02	Tracking Generator
FSE-Z2	1084.7043.02	PS/2 Mouse

complies with the provisions of the Directive of the Council of the European Union on the approximation of the laws of the Member States

- relating to electromagnetic compatibility
  (89/336/EEC revised by 91/263/EEC, 92/31/EEC, 93/68/EEC)

Conformity is proven by compliance with the following standards:

EN50081-1 : 1992
EN50082-1 : 1992

Affixing the EC conformity mark as from 1995

ROHDE & SCHWARZ GmbH & Co. KG
Mühldorfstr. 15, D-81671 München

Munich, 2000-03-13

Central Quality Management FS-QZ / Becker

Adressen/Addresses

FIRMENSITZ/HEADQUARTERS

	Telefon/Phone Telefax E-mail
ROHDE & SCHWARZ GmbH & Co. KG	
Mühldorfstraße 15 · D-81671 München	+49 89 41 29-0
Postfach 801469 · D-81614 München	+49 89 41 29-21 64
Internet: http://www.rsd.de	–

WERKE/PLANTS

ROHDE & SCHWARZ Meßgerätebau GmbH	+49 83 31 1 08-0
Riedbachstraße 58 · D-87700 Memmingen	+49 83 31 1 08-1 24
Postfach 16 52 · D-87686 Memmingen	–
ROHDE & SCHWARZ GmbH & Co. KG	
Werk Teisnach	+49 99 23 8 50-0
Kaikenrieder Straße 27 · D-94244 Teisnach	+49 99 23 8 50-1 74
Postfach 11 49 · D-94240 Teisnach	–
ROHDE & SCHWARZ GmbH & Co. KG · Werk Köln	+49 22 03 49-0
Graf-Zeppelin-Straße 18 · D-51147 Köln	+49 22 03 49-3 08
Postfach 98 02 60 · D-51130 Köln	–

TOCHTERUNTERNEHMEN/SUBSIDIARIES

ROHDE & SCHWARZ Vertriebs-GmbH	+49 89 4129-20 07
Mühldorfstraße 15 · D-81671 München	+49 89 4129-35 67
Postfach 80 14 69 · D-81614 München	–
ROHDE & SCHWARZ International GmbH	+49 89 4129-20 05
Mühldorfstraße 15 · D-81671 München	+49 89 4129-35 97
Postfach 80 14 60 · D-81614 München	–
ROHDE & SCHWARZ Engineering and Sales GmbH	+49 89 4129-37 11
Mühldorfstraße 15 · D-81671 München	+49 89 4129-37 23
Postfach 80 14 29 · D-81614 München	–
R&S BICK Mobilfunk GmbH	+49 50 42 9 98-0
Im Landerfeld 7 · D-31848 Bad Münder	+49 50 42 9 98-105
Postfach 20 62 · D-31844 Bad Münder	–
ROHDE & SCHWARZ FTK GmbH	+49 30 6 58 91-0
Wendenschloßstraße 168, Haus 28	+49 30 65 55 02 21
D-12557 Berlin	–
SIT Gesellschaft für Systeme	
der Informationstechnik mbH	+49 30 6 58 84-2 22
Wendenschloßstraße 168, Haus 28	+49 30 6 58 84-1 83
D-12557 Berlin	–

ADRESSEN DEUTSCHLAND/ADDRESSES GERMANY

Rohde & Schwarz Vertriebs-GmbH	+49 89 4129-2007
Mühldorfstraße 15 · D-81671 München	+4989 4129-3567
Postfach 801469 · D-81614 München	–

Zweigniederlassungen der Rohde & Schwarz Vertriebs-GmbH/Branch offices of Rohde & Schwarz Vertriebs-GmbH

Zweigniederlassung Berlin	(030) 34 79 48-0
Ernst-Reuter-Platz 10 · D-10587 Berlin	(030) 34 79 48-48
Postfach 100620 · D-10566 Berlin	–
Zweigniederlassung Büro Bonn	(02 28) 918 90-0
Josef-Wirmer-Straße 1–3 · D-53123 Bonn	(02 28) 25 50 87
Postfach 140264 · D-53057 Bonn	–
Zweigniederlassung Hamburg	(040) 63 29 00-0
Steilshooper Allee 47 · D-22309 Hamburg	(040) 630 78 70
Postfach 602240 · D-22232 Hamburg	–
Zweigniederlassung Köln	(0 22 03) 807-0
Graf-Zeppelin-Straße 18 · D-51147 Köln	(0 22 03) 807-50
Postfach 900149 · D-51111 Köln	–
Zweigniederlassung München	(089) 41 86 95-0
Mühldorfstraße 15 · D-81671 München	(089) 40 47 64
Postfach 801449 · D-81614 München	–
Zweigniederlassung Nürnberg	(09 11) 64203-0
Donaustraße 36	(09 11) 64203-33
D-90451 Nürnberg	–
Zweigniederlassung Telekommunikation + Mitte	(0 61 02) 20 07-0
Siemensstraße 20	(0 61 02) 20 07-12
D-63263 Neu-Isenburg	–

ADRESSEN WELTWEIT/ADDRESSES WORLDWIDE

Algeria	ROHDE & SCHWARZ Bureau d'Alger 5 B, Place de Laperrine 16035 Hydra-Alger	+2 13 2 592453 +2 13 2 594786 –
Argentina	Precisión Electrónica SRL Esmeralda 582, Piso 4, Off. 11 1007 Capital Federal Buenos Aires	+54 1 3 94 48 15 +54 1 3 27 23 32 –
Australia	ROHDE & SCHWARZ (AUSTRALIA) Pty. Ltd. 63 Parramatta Road Silverwater, N.S.W. 2141	+61 2 97 48 01 55 +61 2 97 48 1836 rsaussyd@ozemail.com.au
Austria	ROHDE & SCHWARZ-ÖSTERREICH Ges. m. b. H. Sonnleithnergasse 20 A-1100 Wien	+43 1 6 02 61 41-0 +43 1 6 02 61 41-14 office@rsoe.com
Azerbaijan	ROHDE & SCHWARZ GmbH & Co. KG Representative Office Baku Azerbaijan avenue 35 370139 Baku	+99 4 12 93 31 38 +99 4 12 93 03 14 –
Baltic Countries	siehe/see Denmark	
Bangladesh	Business International Ltd. Corporation Office House No: 95/A, Block -'F' Road No: 4, Banani Dhaka - 1213	+880 2 87 06 53 +880 2 88 82 91 –
Belgium	ROHDE & SCHWARZ BELGIUM N.V. Excelsiorlaan 31 Bus 1 B-1930 Zaventem Alfons_Verpoorten%RSB@notesgw.Compuserve.Com	+32 2 7 21 50 02 +32 2 7 25 09 36
Brazil	ROHDE & SCHWARZ Precisão Eletrônica Ltda. Rua Geraldo Flausino Gomes, 42-°and 04575-060 São Paulo-SP	+55 11 5505 21 77 +55 11 5505 57 93 rsbras@ibm.net
Brunei	GKL Equipment PTE. Ltd. #11-01 BP Tower 396, Alexandra Road Singapore 119954 Republic of Singapore	+65 2 76 06 26 +65 2 76 06 29 gkleqpt@signet.com.sg

Bulgaria
ROHDE & SCHWARZ +359 2 9 63 43 34
Representation Office Bulgaria +359 2 9 63 21 97
39, Fridtjof Nansen Blvd. –
1000 Sofia

Canada
Kommunikationstechnik/Communications Equipment:
ROHDE & SCHWARZ CANADA Inc. +1 6 13 5 92 80 00
555 March Rd. +1 6 13 5 92 80 09
Kanata, Ontario K2K 2M5 –

Meßtechnik/T & M Equipment:
TEKTRONIX CANADA, Inc. +1 4 16 7 97 50 00
785 Arrow Road +1 4 16 7 47 75 81
Weston, Ontario, M9M 2L4 –

Chile
DYMEQ Ltda. +56 2 277 50 50
Avenida Larrain 6666 +56 2 227 87 75
Santiago –

China
ROHDE & SCHWARZ +86 10 64 67 23 65
Representative Office Beijing +86 10 64 67 23 15
Beijing Towercrest Plaza, Rm 821 rsbp@public3.bta.net.cn
No. 3 Mai Zi Dian West Road
Chao Yang District
Beijing 100016/People's Republic of China

Colombia
Ferrostaal de Colombia Ltda. +57 1 2 67 63 21
Av. Eldorado No. 97-03 Interior 2 +57 1 4 13 18 06
Santa Fé de Bogotá, D.C. –

Costa Rica
siehe/see Mexico

Republic of Cyprus
HINIS TELECAST LTD. +357 4 42 51 78
Agiou Thoma 18 +357 4 42 46 21
Kiti
Larnaca 7550

Czech Republic
ROHDE & SCHWARZ – Praha, s.r.o. +420 2 24 32 20 14
Pod kastany 3 +420 2 24 31 70 43
CZ-160 00 Praha 6 rscz@rohde.mail.602.cz

Denmark
ROHDE & SCHWARZ DANMARK A/S +45 43 43 66 99
Ejby Industrivej 40 +45 43 43 77 44
DK-2600 Glostrup RSDK@post1.tele.dk

Ecuador
DIGITEC Cia. Ltda. +593 2 43 03 73
Casilla 17-03-408A +593 2 44 37 82
El Heraldo 121 y El Dia digitec1@digitec.com.ec
Quito

El Salvador
siehe/see Mexico

Finland
Orbis Oy +358 9 47 88 30
P.O. B. 15 +358 9 53 16 04
FIN-00421 Helsinki info@orbis.fi

France
ROHDE & SCHWARZ FRANCE +33 1 41 36 10 00
Immeuble "Le Newton" +33 1 41 36 11 10
25-27, rue Jeanne Braconnier
F-92366 Meudon-la-Forêt Cédex –

Niederlassung/Subsidiary Rennes:
ROHDE & SCHWARZ FRANCE +33 2 99 51 97 00
Sigma 1 +33 2 99 41 91 31
Rue du Bignon –
F-35135 Chantepie

Niederlassung/Subsidiary Toulouse:
ROHDE & SCHWARZ FRANCE +33 5 61 39 10 69
Technoparc 3 +33 5 61 39 99 10
B.P.501 –
F-31674 Labège Cédex

Büros/Offices:
Aix-en-Provence +33 4 94 07 39 94
+33 4 94 07 55 11
Lyon +33 4 78 29 88 10
+33 4 78 29 94 71
Nancy +33 3 83 54 51 29
+33 3 83 55 39 51

Greece
MERCURY SA. +30 1 7 22 92 13
6, Loukianou Str. +30 1 7 21 51 98
GR-10675 Athens mercury@hol.gr

Guatemala
siehe/see Mexico

Honduras
siehe/see Mexico

Hong Kong
Schmidt & Co. (HK) Ltd. +8 52 2 5 07 03 33
9/F North Somerset House +8 52 2 8 27 56 56
Taikoo Place frankwong@shk.schmidtgroup.com
979 King's Road
Quarry Bay, Hong Kong

Hungary
ROHDE & SCHWARZ +36 1 203-02 82
Budapesti Iroda +36 1 203-02 82
Etele ut. 68 rsh@euroweb.hu
H-1115 Budapest

Iceland
siehe/see Denmark

India
ROHDE & SCHWARZ +91 11 461 52 85/469 22 38
India Pvt. Ltd. +91 11 462 63 24
A-382 Defence Colony –
New Delhi 110024

Indonesia
P.T. REKANUSA SOLUSI +62 21 576 16 02
Menara Rajawali, +62 21 576 16 04
24th floor –
Jl Mega Kuningan Lot # 5.1
Kawasan Mega Kuningan
Jakarta 12950

Iran
ROHDE & SCHWARZ IRAN +98 21 8 73 02 82/8 73 54 78
Liaison Office - Reg. N° RFC 1947 +98 21 8 73 02 83
Dr. Beheschty Ave., Pakistan Ave., –
12th Street N° 1
Tehran 15317

Ireland
siehe/see Great Britain

Italy
ROHDE & SCHWARZ ITALIA S.p.a. +39 06 41 59 81
Via Tiburtina 1182 +39 06 41 59 82 70
I-00156 Roma –

Centro Direzionale Lombardo +39 02 95 70 41
Via Roma 108 +39 02 95 30 27 72
I-20060 Cassina de' Pecchi (MI)

Japan
ADVANTEST Corporation +81 3 39 30 40 30
RS Sales Department +81 3 39 30 41 86
1-32-1 Asahi-cho yoshimu@inst.advantest.co.jp
Nerima-ku
Tokyo 179

Kazakhstan
ROHDE & SCHWARZ GmbH & Co. KG +7 32 72 63 55 55
Representative Office Almaty +7 32 72 63 46 33
Pl. Respubliki 15 –
480091 Almaty

Korea
Hana Technica Corp. +82 2 5 14 45 46
Seoul Kangnam, P.O. Box 1458 +82 2 5 14 45 49
Young Dong Bldg. 4F hanateco@unitel.co.kr
63-16 Nonhyun-Dong, Kang Nam-Ku

Seoul

Kuwait
Zaid Al-Kazemi Sons Trading Co. +965 243 72 00
P.O. Box 30, Safat 13001 +965 240 15 62
Zaid Al-Kazemi Building adnan@ncc.moc.kw
Mubarak Al-Kabeer Street
Kuwait City

Lebanon
CONNECTIONS S.A.R.L. +961 1 42 48 25/6/7
Sami Solh Street +961 1 42 55 57
Cemate Building 201 – 2nd Fl. TREZKALL@INCO.COM.LB
Sami El-Solh Street – Badaro
Beirut

Liechtenstein siehe/see Switzerland

Luxembourg siehe/see Belgium

Malaysia
DAGANG TEKNIK SDN. BHD. +60 3 7035503/7035568
No. 9, Jalan SS 4D/2 +60 3 7 03 34 39
Taman People´s Park danik@tm.net.my
47301 Petaling Jaya
Selangor Darul Ehsan

Malta
ITEC – International Technology Ltd. +35 6 37 43 00
B'Kara Road +35 6 37 43 53
San Gwann itec@keyworld.net

Mexico
Vertrieb Kommunikationstechnik/
Sales Communications Equipment:
ELECTROINGENIERIA de Precisión S.A. +52 5 5 59 76 77
EPSA S.A. +52 5 5 75 33 81
Uxmal 520, Colonia Vertiz Narvarte epsa@compuserve.com
03600 Mexico DF

Vertrieb Meßtechnik/Sales T & M Equipment:
Tektronix, S.A. de C.V. +525 666 63 33
Periférico Sur 5000, 8° Piso +525 666 63 36
Col. Insurgentes Cuicuilco
Coyoacán
04530 - Mexico, D.F.

Nepal
Abishek Trade Links (P) Ltd. +97 71 25 69 30
P.O.B. 9700 +97 71 24 25 73
Kathmandu Durbar@hotel.mos.com.np

Netherlands
ROHDE & SCHWARZ +31 30 6 00 17 00
NEDERLAND B.V. +31 30 6 00 17 99
Perkinsbaan 1 Rob.DenHartog/RSN%RSN@RSD.de
3439 ND Nieuwegein

New Zealand
Nichecom +64 4 2 32 32 33
Level 1 Tawa Plaza +64 4 2 32 32 30
210 Main Rd / P.O.B. 56-045 ISDN +64 4 2 37 30 10
Tawa, Wellington robin.hodgson@nichecom.co.nz

Nicaragua siehe/see Mexico

Norway
ROHDE & SCHWARZ NORGE +47 23 17 22 50
Østensjøveien 36, P.O.B. 103 BRYN +47 23 17 22 69
N-0611 Oslo –

Pakistan
TelcoNet Communications & +92 51 25 69 53
Engineering +92 51 51 86 27
213/D, Ordnance Road telecom@tnc.isb.erum.com.pk
Rawalpindi-Pakistan-46000

Panama siehe/see Mexico

Papua-New Guinea siehe/see Australia

Philippines
MARCOM Industrial Equipment, Inc. +632 8 13 29 31
MCC P.O.Box 2307 +632 8 17 05 07
6-L Mezzanine Suite, Vernida I
Condominium120 Amorsolo St.
Legaspi Village
Makati City/Philippines 3117

Poland
ROHDE & SCHWARZ +48 22 8 60 64 90 bis 98
Oddzial w Polsce +48 22 8 60 64 99
ul. Stawki 2, Pietro 28 rspoland@rsoe
00-193 Warszawa

Portugal
TELERUS
Sistemas de Telecomunicações, S.A. +351 1 4 12 35 90
Rua General Ferreira Martins, Lote 6,2.°B+351 1 4 12 36 00
P-1495 Algés telerus@mail.telepac.pt

Romania
ROHDE & SCHWARZ +40 1 4 10 68 46
Representation Office Bucharest +40 1 4 11 20 13
Uranus 98 sandu@rohde.eunet.ro
Bloc U8, Scara 2, Etaj 5, Ap. 36
RO-76102 Bucuresti

Russian Federation
ROHDE & SCHWARZ +7 095 2 34 49 62
Representative Office Moscow +7 095 2 34 49 63
1-j Kazacij per., 7 evg@rohde-schwarz.msk.ru
109017 Moscow

Saudi Arabia
Haji Abdullah Alireza & Co. Ltd. +966 1 4 65 44 78
P.O.B. 361 +966 1 4 65 07 82
Riyadh 11411 –
Kingdom of Saudi Arabia

Singapore
Vertrieb/Sales:
INFOTEL TECHNOLOGIES LTD. +65 2 87 68 22
19 Tai Seng Drive +65 2 84 95 55
Kinergy Building # 06-00 general@infotel.com.sg
Singapore 535222

Support Centre Asia:
Rohde & Schwarz Support Centre
Asia Pvt. Ltd. +65 4 88 30 10
6th Floor, Singapore Technologies Building +65 2 87 30 61
19 Tai Seng Drive RSSCA@mbox4.singnet.com.g
535 222 Singapore

Slovak Republic
3S Specialne systemy a software, a.s. +421 7 72 24 88
Ilkovicova 3 +421 7 72 07 68
SK-81219 Bratislava 3s@internet.sk

Slovenia
ROHDE & SCHWARZ +3 86 61 1 23 46 51
Repräsentanz Ljubljana +3 86 61 1 23 46 11
Koprska 92
SI-61000 Ljubljana –

South Africa
S.A. Electro-Medical (Pty) Ltd. +27 12 8 04-16 20
115 Siersteen Road +27 12 8 04-20 09
Silvertondale mail@saem.co.za
P.O.B. 1784
Pretoria 0001

Spain
REMA Leo Haag S.A. +34 91 3 34 10 70
Salcedo, 11 +34 91 7 29 05 06
E-28034 Madrid rema@rema.es

Sri Lanka
LANKA AVIONICS +94 1 95 66 78
658/1/1, Negombo Road +94 1 95 83 11
Mattumagala –
Ragama

Sweden
ROHDE & SCHWARZ SVERIGE AB +46 8 6 05 19 00
Flygfältsgatan 15 +46 8 6 05 19 80
S-12830 Skarpnäck info@rss.se

Switzerland
Roschi Télécommunication AG +41 31 9 22 15 22
Papiermühlestrasse 145, Postfach +41 31 9 21 81 01
CH-3063 Ittigen –

Syria
Electro Scientific Office +963 11 2 31 59 74
Baghdad Street +963 11 2 31 88 75
Dawara Clinical Lab. Building –
P.O.B. 8162
Damascus

Taiwan
FUNCTION ENTERPRISE CO., LTD. +8 86 2 23 21 70 70
16F, No. 30, Pei-Ping East Road +8 86 2 23 95 87 82
Taipei, Taiwan R.O.C. hibiscus@function.linkease.com.tw

Thailand
Vertrieb Kommunikationstechnik/Sales Communications Equipment:
TPP Operations Co. Ltd. +662 4 48 51 59
70 MOO, 3 Mooban Mantana, +662 8 84 17 98
Soi Chimplee 4, Boromrajchonnee Rd.,
Talingchan, Bangkok 10170

Vertrieb Meßtechnik/Sales T & M Equipment:
Schmidt Scientific (Thailand) Ltd. +662 6 43 1330-9
Government Housing Bank Bldg. +662 6 43 1340-1
Tower II, 19th Floor, 212 Rama 9 Rd.,
Huaykwang, Bangkok 10320

Turkey
ROHDE & SCHWARZ +90 2 16 3 85 19 17
LIAISON OFFICE ISTANBUL +90 2 16 3 85 19 18
Bagdad Cad. 191/3, Ard. RSTURK@unimedya.net.tr
TR-81030 Selamicesme-Istanbul

Ukraine
ROHDE & SCHWARZ GmbH & CoKG +3 80 44 2 68 60 55
Representative Office Kiev +3 80 44 2 68 83 64
ul. Patrisa Lumumba, 4 rsbkiev@public.ua.net
UKR-252042 Kiev

United Arab Emirates
Service-Center für den Mittleren Osten/
Service Center for the Middle East:
ROHDE & SCHWARZ Emirates L.L.C. +9 71 2 31 20 40
P.O.B. 31156 +9 71 2 31 30 40
Abu Dhabi –

Vertrieb/Sales:
ROHDE & SCHWARZ +9 71 4 48 28 29
P.O.B. 53726 +9 71 4 48 27 94
Dubai –

R&S BICK Mobile Communication
P.O.B. 17466 +9 71 4 81 36 75
JAFZ, LOB 04-028 +9 71 4 81 36 76
Dubai -

United Kingdom
ROHDE & SCHWARZ UK Ltd. +44 12 52 81 13 77
Ancells Business Park +44 12 52 81 14 47
Fleet, Hampshire GU 13 8UZ –

USA
Vertrieb Kommunikationstechnik/
Sales Communications Equipment:
ROHDE & SCHWARZ, Inc. +1 301 4 59 88 00
4425 Nicole Drive +1 301 4 59 28 10
Lanham, MD 20706 –

Vertrieb Meßtechnik/Sales T & M Equipment:
TEKTRONIX Inc. +1 800 835 9433 Ext. 6630
P.O.B. 500, M/S 50-216 +1 800 835 7732
Beaverton, OR 97076 -

Vietnam
Schmidt Vietnam Co., Ltd. +84 4 8 34 61 86
8/F, Schmidt Tower, Hanoi +84 4 8 34 61 88
Intern. Technology Centre SVNHN@SCHMIDTGROUP.COM
Cau Giay, Tu Liem, IPO Box 89
Hanoi

Yugoslavia
see/siehe Austria

Nicht aufgeführte Länder/Countries not listed:
ROHDE & SCHWARZ GmbH & Co. KG –
Division 5Z +49 89 41 29-36 62
Postfach 80 14 69 –
D-81614 München

Supplement A
to Operating Manual
Spectrum Analyzer FSEA20/30, FSEB20/30, FSEM20/21/30/31, FSEK20/21/30/31

(Firmware Version 1.93 and higher (for instruments without controller function or with DOS controller function))

(Firmware Version 2.07 and higher (for instruments with Windows NT controller function))

Dear Customer,

your spectrum analyzer is equipped with a new firmware version. The new firmware offers a number of extensions and improvements which are not yet described in the operating manual. They are explained on the following pages. The new functions concern:

- Extension of the adjacent channel power measurement.
- Screen saver
- Trace export in analyzer mode
- Baseline clipping in analyzer mode
- Statistic functions for input attenuator switching
- Extended functionality for operating mode vector signal analysis (option FSE-B7)
- Extended functionality for operating modes GSM BTS ANALYZER (FSE-K11) and GSM MS ANALYZER (FSE-K10).
- New option FSE-B13, 1 dB Attenuator
- Additional IEEE/IEC-bus commands

Adjacent Channel Power Measurements

The chapter "Channel Configuration" of the operating manual was extended to include adjacent channel power measurements.

The *ACP STANDARD* softkey activates the selection of a digital mobile-radio standard. The parameters for the adjacent channel power measurement are set according to the regulations of the selected standard.

ACP STANDARD	
NONE	
NADC	NADC (IS-54 B)
TETRA	TETRA
PDC	PDC (RCR STD-27)
PHS	PHS (RCR STD-28)
CDPD	CDPD
CDMA800 FWD	CDMA 800 FWD
CDMA800 REV	CDMA 800 REV
CDMA1900 FWD	CDMA 1900 REV
CDMA1900 REV	CDMA 1900 FWD
W-CDMA FWD	W-CDMA FWD
W-CDMA REV	W-CDMA REV
W-CDMA 3GPP FWD	W-CDMA 3GPP FWD
W-CDMA 3GPP REV	W-CDMA 3GPP REV
CDMA2000 MC	CDMA2000 Multi Carrier
CDMA2000 DS	CDMA2000 Direct Sequence
CDMA ONE 800 FWD	CDMA ONE 800 FWD
CDMA ONE 800 REV	CDMA ONE 800 REV
CDMA ONE 1900 FWD	CDMA ONE 1900 REV
CDMA ONE 1900 REV	CDMA ONE 1900 FWD

The following standards can be selected:

Screen Saver

Section "Display Configuration" of the FSE operating manual has been extended for the screen saver.

SYSTEM DISPLAY-CONFIG DISPLAY submenu:



The *SCR. SAVER* softkey is used to switch on/off the screen saver for the display.
After the elapse of the response time (*SCR. SAVER TIME)* the display is completely switched off, ie including backlighting.

The screen saver is deactivated by pressing any key or by sending the corresponding IEEE/IEC bus command.

Note: *If, with option FSE-B15, switchover was made to the screen of the controller function using the ALT SYSREQ key, the screen saver was deactivated.*

The *SCR. SAVER TIME* softkey activates the entry of the time for the screen saver to respond. The response time is entered in minutes between 1 to 100 minutes.

Trace Export for ANALYZER Mode

Section "Measurement Function Selection – TRACE 1 to 4 Key" of the FSE operating manual has been extended for the function ASCII EXPORT.



In analyzer mode, the *ASCII EXPORT* softkey stores the corresponding trace in a file with ASCII format.
Upon pressing the ASCII EXPORT softkey, a file name can be entered. The default name is TRACE.DAT. Then the measured data of the trace are stored.
The function can be configured in the *ASCII CONFIG* submenu.



In the *ASCII CONFIG* submenu, various settings for the *TRACE ASCII EXPORT* function can be made.

The *EDIT PATH* softkey defines the directory in which the file is to be stored.

With the *DECIM SEP* softkey, the separator for the ASCII file can be selected: '.' (decimal point) or ',' (comma). Different language versions of analysis programs may require different notations of the decimal point.

The *APPEND NEW* softkey defines whether output data are to be written to an existing file or a new file.

- With *APPEND*, the data are added to an existing file.
- With *NEW*, either a new file is generated or an existing file is overwritten by storage of the data.

The *HEADER ON/OFF* softkey defines whether important instrument settings should be stored at the beginning of the file.

Structure of the ASCII file:

The file consists of the header containing important scaling parameters and a data section containing the trace data.

The data of the file header consist of three columns, each separated by a semicolon:
parameter name; numeric value; basic unit

The data section starts with the keyword " Trace <n> " (<n> = number of stored trace), followed by the measured data in one or several columns (depending on measurement) which are also separated by a semicolon.
This format can be read in from spreadsheet calculation programs, eg MS-Excel. It is necessary to define ';' as a separator.

	Content of file	Description
File header	Type;FSEA30;	Instrument model
	Version;1.93;	Firmware version
	Date;01.Jul 1999;	Date of data set storage
	Mode;Spectrum;	Instrument mode
	Start;10000;Hz Stop;100000;Hz	Start/stop of the display range. Unit: Hz for span > 0, s for span = 0,
	Center Freq;55000;Hz	Center frequency
	Span;90000;Hz	Frequency range (0 Hz with zero span)
	Freq Offset;0;Hz	Frequency offset
	x-Axis;LIN;	Scaling of x axis linear (LIN) or logarithmic (LOG)
	y-Axis;LOG;	Scaling of y axis linear (LIN) or logarithmic (LOG)
	Ref.Level;-30;dBm	Reference level
	Level Offset;0;dB	Level offset
	Max Level	Maximium level
	Level Range;100;dB	Display range in y direction. Unit: dB with x axis LOG, % with x axis LIN
	RF Att;20;dB	Input attenuation
	RBW;100000;Hz	Resolution bandwidth
	VBW;30000;Hz	Video bandwidth
	SWT;0.005;s	Sweep time
	Trace Mode;AVERAGE;	Display mode of trace: CLR/WRITE,AVERAGE,MAXHOLD,MINHOLD
	Detector;SAMPLE;	Detector set: AUTOPEAK,MAXPEAK,MINPEAK,AVERAGE, RMS,SAMPLE
	Sweep Count;20;	Number of sweeps set
Data section of the file	Trace 1:;;	Selected trace
	x-Unit;Hz;	Unit of x values: Hz with span > 0; s with span = 0; dBm/dB with statistics measurements
	y-Unit;dBm;	Unit of y values: dB*/V/A/W depending on the selected unit with y axis LOG or % with y axis LIN
	Values;500;	Number of test points
	10000;-10.3;-15.7 10180;-11.5;-16.9 10360;-12.0;-17.4 ...;...;	Measured values: <x value>, <y1>, <y2> <y2> being available only with detector AUTOPEAK and containing in this case the smallest of the two measured values for a test point.

Example:

```
Type;FSEA 30;
Version;1.93;
Date;20.Sep 1999;
Mode;Spectrum;
Start;0.000000;Hz
Stop;3500000000.000000;Hz
Center Freq;1750000000.000000;Hz
Span;3500000000.000000;Hz
Freq Offset;0.000000;Hz
x-Axis;LIN;
y-Axis;LOG;
Level Range;100.000000;dB
Ref. Level;-20.000000;dBm
Level Offset;0.000000;dBm
Max. Level;-20.000000;dBm
RF Att;10.000000;dB
RBW;3000000.000000;Hz
VBW;3000000.000000;Hz
SWT;0.005000;s
Trace Mode;CLR/WRITE;
Detector;AUTOPEAK;
Sweep Count;0;
TRACE 1:
x-Unit;Hz;
y-Unit;dBm;
Values;500;
0.000000;-44.465958;-60.190887
7014028.056112;-49.233063;-81.451668
14028056.112224;-75.692101;-101.811501
21042084.168337;-75.147057;-101.229843
28056112.224449;-75.114517;-95.358429
35070140.280561;-71.769005;-100.755981
...
```

If all traces are to be stored in one file with the header information stored only once, the following procedure is recommended:

[TRACE 1] [MENU ⇒][ASCII CONFIG]	
[ASCII CONFIG] [NEW]	Generate new file
[ASCII CONFIG] [HEADER ON]	with header
[TRACE 1] [MENU ⇒][ASCII EXPORT]	Store trace 1 with header
[TRACE 2] [MENU ⇒][ASCII CONFIG]	
[ASCII CONFIG] [APPEND]	Append to end of file
[ASCII CONFIG] [HEADER OFF]	without header
[TRACE 2] [MENU ⇒][ASCII EXPORT]	Write trace 2 to file
[TRACE 3] [MENU ⇒][ASCII EXPORT]	Write trace 3 to file
[TRACE 4] [MENU ⇒][ASCII EXPORT]	Write trace 4 to file

Baseline Clipping in ANALYZER Mode

Section "Display Lines – D LINES Key"of the FSE operating manual has been extended for the function *BASELINE CLIPPING*.



The *BASELINE CLIPPING* softkey switches on or off the *BASELINE CLIPPING* function and allows a limit value to be entered.

The *BASELINE CLIPPING* function is for blanking measured values (for example noise) which are below a preset threshold.
If the *BASELINE CLIPPING* function is active and a measured value is below the preset threshold, the value is set to a lower boundary (-400 dBm).
Measured values above the clipping level are not changed.

Note: *It is advisable not to combine the BASELINE CLIPPING function with the AUTOPEAK detector.*
If the set clipping value is within the displayed noise band (AUTOPEAK detector), activation of the CLIPPING function and the resulting clipping of the MIN PEAK values will lead to a drastic enlargement of the displayed noise band.

Statistics Function for Input Attenuator Switching

The INFO display function has been extended by a STATISTICS display. The INFO display function is described in Section "Instrument Status and Measurement Parameters – INFO Key".

SYSTEM INFO menu:

The *INFO* key is used to display general information about the instrument. This includes:

- Firmware version
- Designations of installed hardware options
- Modification status of modules
- Results of self-tests plus facility of calling up self-test functions
- List of system messages that have been output
- List of options installed
- Statistical evaluations



The *STATISTICS* softkey calls a submenu for indication of device statistics.

The *ATT SWITCHES* softkey displays various tables listing the mechanical switches and attenuators fitted in the instrument, plus the number of switching operations for the respective switch or attenuator.

INPUT ATTENUATOR	
Date	5 Aug 1999
Calibration Input	6
10 dB	121
20 dB	217
30 dB	137

Note: *If the instrument was equipped with a firmware version < V1.91/V2.05 prior to the update, the number of switching operations from the update is displayed.*

Limit lines with additional unit dBpT, editing feature extended

dBpT can be set as additional unit for limit lines.
In firmware versions used so far, a physical unit once set could not be changed. In the new firmware version this is now possible. The entered reference values remain unchanged

Correction of Level Errors in Frequency Domain above 7 GHz for FSEM and FSEK

Despite coupled sweep times, level errors occurred at stop frequencies above 7 GHz. The calculation of the sweep time was changed. A longer sweep time is thus obtained at stop frequencies >7 GHz and large spans.

External Mixer option FSE-B21 extended

The permissible setting range of parameter *HARMONIC NUMBER* under *BAND LOCK OFF* was increased from 40 to 62.

New Option FSE-B13, 1 dB Attenuator

The option 1 dB Attenuator FSE-B13 is used to set the attenuator with a step size of 1 dB up to an upper limit frequency of 7 GHz.

The functions of the option are described in the supplementary manual:
Supplementary Manual, 1 dB Attenuator, Order No. 1119.6501.xx-01

where xx = 51 (German)
52 (English)
59 (English, US letter format)
53 (French)

Extended Functionality for Vector Analyzer Operating Mode (Option FSE-B7)

Functions for the Vector Analyzer Mode have been considerably extended:

- Additional demodulator and measurement/reference filter for digital demodulation.
- Digital standard EDGE
- Changed sync pattern for EDGE standard and "Don't Care Bits"

These extensions are described in the operating manual, which has been completely revised:

Operating Manual, Vector Signal Analysis FSE-B7, Order No. 1066.4323.xx-07

where xx = 11 (German)
12 (English)
19 (English, US letter format)

Notes:

Changed Sync Pattern for EDGE Standard

The predefined sync patterns for the EDGE standard were adapted to the modified version of the standard (ETSI Group SMG2, TDOC SMG2 590/99). The change consists in an inversion of the bits of the sync patterns of V1.80/V2.03.

Adaptations for EDGE

The EDGE measurement with a receiver filter and the EVM calculation are performed according to ETSI-TDOC **SMG2 829/99** / ANNEX H. This specified filter is effective in all display and measurement modes. Since it is a lowpass filter intersymbol-interference-free (ISI-free) points no longer occur in the display modes such as constellation diagram and vector diagram. In addition, the sync sequences provided in the unit were adapted by inverting the bits.

Note: *If measurements are to be performed without a receiver filter, deactivate digital standard EDGE (eg by switching from modulation parameter, meas filter from edge_mes to egde_ref and back to edge_mes).*

Extended Functionality for GSM BTS ANALYZER and GSM MS ANALYZER Operating Modes

Functions for the GSM BTS ANALYZER and GSM MS ANALYZER modes have been considerably extended:

- Extended functions for entering level and frequency
- Editable limit lines
- Additional measurement functions

These extensions are described in the operating manuals, which have been completely revised:

Operating Manual, GSM/DCS/PCS Mobile Tests FSE-K10, Order No. 1057.3140.xx-03

where xx = 41 (German)
42 (English)
49 (English, US letter format)

Operating Manual GSM/DCS/PCS Base Station Tests FSE-K11, Order No. 1057.3440.xx-03

where xx = 41 (German)
42 (English)
49 (English, US letter format)

Note:

The measurement MODULATION SPECTRUM - RX BAND as specified in GSM-11.10, chapter 13.4.4, section d)

d) The resolution and video bandwidth on the spectrum analyser are adjusted to 100 kHz and the measurements are made at the following frequencies:

on every ARFCN from 1 800 kHz offset from the carrier to the edge of the relevant transmit band for each measurement over 50 bursts.

at 200 kHz intervals over the 2 MHz either side of the relevant transmit band for each measurement over 50 bursts.

at 200 kHz intervals over the band 925 - 960 MHz for each measurement over 50 bursts.

at 200 kHz intervals over the band 1805 - 1880 MHz for each measurement over 50 bursts.

covers also for the P-GSM the E-GSM RX band.

In the new firmware release the measurement covers the following bands:

Selected standard	Modulation RX bands
P-GSM	935 – 960 MHz
E-GSM	925 – 960 MHz
R-GSM	921 – 960 MHz

The band selection will be changed in future firmware release.

Work around:
For P-GSM modulation RX band measurement use standard E-GSM.

New IEEE-Bus Commands

The new firmware was extended by the following IEEE-bus commands:

- Baseline clipping
- New option FSE-B13, 1dB attenuator.
- Comment definition for transducer factor and transducer set.
- Standard EDGE (vector analyzer mode).
- Additional commands for selection of reference and measurement filters (vector analyzer mode).
- Screen saver
- Trace ASCII export
- Statistics function (attenuator switching cycles)
- Additional commands for selection and definition of sync. pattern
- CATalog-commands for limit lines, transducer, conversion loss table
- New command for setting the trigger level for analog demodulation and AF-trigger.
- Additional commands for reading out the results of premeasurements in operating modes GSM BTS ANALYZER (FSE-K11) and GSM MS ANALYZER (FSE-K10).
- Additional commands for reading out the status of phase/frequency measurements in operating modes GSM BTS ANALYZER (FSE-K11) and GSM MS ANALYZER (FSE-K10)

The commands are listed alphabetically.

CALCulate<1|2>:CTHReshold MINimum to MAXimum (depending on the current unit)

This command defines the position of a threshold line (base line), below which all measured values are cleared.

Example: "CALC:CTHR -82dBm"

Features: *RST value: - (STATe to OFF)
SCPI: device-specific

The units DEG, RAD, S, HZ, PCT are available only in the vector signal analyzer mode.

CALCulate<1|2>:CTHReshold:STATe ON | OFF

This command is for switching on or off the threshold line (base line), below which all measured values are cleared.

Example: "CALC:CTHR:STAT ON"

Features: *RST value: OFF
SCPI: device-specific

CALCulate:LIMit:CATalog?

This command reads out the names of all limit lines stored on the harddisk.

Syntax of output format:

<Sum of file lengths of all subsequent files>,<free memory on hard disk>,
<1st file name>,,<1st file length>,<2nd file name>,,<2nd file length>,....,<nth file name>,
<nth file length>

Example: "CALC:LIM:CAT?"

Features: *RST value: -
SCPI: device-specific

CALCulate<1|2>:MARKer<1...4>: FUNCtion:POWer:PRESet NADC | TETRA | PDC | PHS | CDPD | FWCDma | RWCDma | FW3Gppcdma | RW3Gppcdma| F8CDma | R8CDma | F19Cdma | R19Cdma | M2CDma | D2CDma | FO8Cdma | RO8Cdma | FO19cdma | RO19cdma | NONE

This command selects the settings for power measurement of one of the standards.

Example: "CALC:MARK:FUNC:POW:PRES NADC"

Features: *RST value: -
SCPI: device-specific

F8CDma	CDMA800 forward
R8CDma	CDMA800 reverse
F19Cdma	CDMA1900 forward
R19Cdma	CDMA1900 reverse
FWCDma	W-CDMA forward
RWCDma	W-CDMA reverse
FW3Gppcdma	W-CDMA 3GPP forward
RW3Gppcdma	W-CDMA 3GPP reverse
M2CDma	CDMA2000 Multi Carrier
D2CDma	CDMA2000 Direct Sequence
FO8Cdma	CDMA One 800 forward
RO8Cdma	CDMA One 800 reverse
FO19cdma	CDMA One 1900 forward
RO19cdma	CDMA One 1900 reverse

The selection of a standard influences the parameters weighting filter, channel bandwidth and spacing, resolution and video bandwidth, as well as detector and sweep time.

This command is an event which is why it is not assigned an *RST value and query.

DIAGnostic:INFO:CCOunt:ATTenuation<1 | 2>?

This command queries the counts of the attenuators. The suffix indicates the attenuator.
1: basic instrument 2: tracking generator

Example: "DIAG:INFO:CCO:ATT?"

Features: *RST value: -
SCPI: device-specific

This command is a query and therefore not assigned a *RST value

DISPlay:PSAVe[:STATe] ON | OFF

This command switches on or off the screen saver mode of the display.

Example: "DISP:PSAVe ON"

Features: *RST value: OFF
SCPI: device-specific

DISPlay:PSAVe:HOLDoff 1 to 100

This command sets the response time for the screen-saver mode of the display. The settable value range is 1 to 100 minutes, the resolution 1 minute. The entry is dimensionless.

Example: "DISP:PSAV:HOLD 10"

Features: *RST value: 1
SCPI: device-specific

FETCh:BURSt:PERRor:RMS:STATus?

This command reads out the status of the RMS-measurement of the phase error taken over the selected number of bursts.

0: failed, 1: passed

Example: "FETC:BURS:PERR:RMS:STAT?"

Features: *RST value: --
SCPI: device-specific

If no measurement has been performed yet, a query error results.
This command is a query and has therefore no *RST value assigned. It is available only when measurement of the phase/frequency error is selected (see CONFigure:BURSt:PFERror).

FETCh:BURSt:PERRor:PEAK:STATus?

This command reads out the status of the peak measurement of the phase error taken over the selected number of bursts.

0: failed, 1: passed

Example: "FETC:BURS:PERR:PEAK:STAT?"

Features: *RST value --
SCPI: device-specific

If no measurement has been performed yet, a query error results.
This command is a query only and therefore has no *RST value assigned. It is available only if measurement of the phase/frequency error is selected (see CONFigure:BURSt:PFERror).

FETCh:BURSt:FERRor:STATus?

This command reads out the status of the measurement of the frequency error taken over the selected number of bursts.

0: failed, 1: passed

Example: "FETC:BURS:FERR:STAT?"

Features: *RST value: --
SCPI: device specific

If no measurement has been performed yet, a query error results.
This command is a query only and therefore has no *RST value assigned. It is available only if measurement of the phase/frequency error is selected (see CONFigure:BURSt:PFERror).

FETCh:SPECtrum:MODulation:REFerence?

This command reads out the result of the premeasurement.

Parameter: The result is output as a list of partial result strings separated by ',' in the following (ASCII) format: <Level1>,<Level2>,<RBW>
<Level1>: measured level
<Level2>: level corrected by means of the bandwidth
<RBW>: bandwidth

Example: "FETC:SPEC:MOD:REF?"
Result: 36.2,43.2,30000

Features: *RST value: --
SCPI: device-specific

If no measurement has been performed yet, a query error results.
This command is a query only and therefore has no *RST value assigned. It is available only if measurement of the modulation spectrum is selected (see CONFigure:SPECtrum:MODulation).

FETCh:SPECtrum:SWITching:REFerence?

This command queries the result of the premeasurement

Parameter: The result is output as a list of partial result strings separated by ',' in the following (ASCII) format:

<Level1>,<Level2>,<RBW>

<Level1>: measured level

<Level2>: level corrected by means of the bandwidth

<RBW>: bandwidth

Example: "FETC:SPEC:SWIT:REF?"
Result: 43.2,43.2,300000

Features: *RST value --
SCPI: device specific

If no measurement has been performed yet, a query error results.
This command is a query only and therefore has no *RST value assigned. It is available only if measurement of the transient spectrum is selected (see CONFigure:SPECtrum:SWITching).

FETCh:PTEMplate:REFerence?

This command reads out the results of the premeasurement

Parameter: The result is output as a list of partial result strings separated by ',' in the following (ASCII) format:

<Level1>,<Level2>,<RBW>

<Level1>: measured level

<Level2>: level corrected by means of the bandwidth

<RBW>: bandwidth

Example: "FETC:PTEM:REF?"
Result: 43.2,43.2,1000000

Features: *RST value: --
SCPI: devicespecific

Modes: BTS, MS

If no measurement has been performed yet, a query error results.
This command is a query only and therefore has no *RST value assigned. It is available only if measurement of Power versus Time is selected (see CONFigure:BURSt:PTEMplate).

FORMat:DEXPort:APPend[:STATe] ON|OFF

This command defines whether data are to be added to the output file or whether the output file is to be overwritten.

Example: "FORM:DEXP:APP OFF

Features: *RST value: ON
SCPI: device-specific

FORMat:DEXPort:DSEParator POINt | COMMA

This command defines which decimal separator (decimal point or comma) is to be used for outputting measurement data to the file in ASCII format. Different languages of evaluation programs (eg MS-Excel) can thus be supported.

Example: `"FORM:DEXP:DSEP POIN`

Features: *RST value: POINt
SCPI: device-specific

FORMat:DEXPort:HEADer[:STATe] ON | OFF

This command defines whether a header (start frequency, sweep time, detector, etc) is to be stored at the beginning of the output file or if only the measured values are to be stored.

Example: `"FORM:DEXP:HEAD OFF`

Features: *RST value: ON
SCPI: device-specific

INPut<1|2>:ATTenuation:STEPsize 1dB | 10dB

This command defines the attenuator stepsize.

Example: `"INP:ATT:STEP 1dB"`

Features: *RST value: 10dB
SCPI: device-specific

This command is only available in conjunction with option FSE-B13, 1-dB attenuator.

MMEMory:STORe:TRACe 1...4,<file_name>

This command stores the trace selected with 1 to 4 in a file with ASCII format.

Parameter: 1 to 4 := selected measurement curve Trace 1 to 4
<file_name> := DOS file name

Example: `"MMEM:STOR2:TRAC 3,'A:\TEST.ASC'"`

Features: *RST value: -
SCPI: device-specific

[SENSe<1|2>:]CORRection:CVL:CATalog?

This command reads out the names of all conversion loss tables stored on the harddisk.

Syntax of output format:

<Sum of file lengths of all subsequent files>,<free memory on hard disk>,
<1st file name>,,<1st file length>,<2nd file name>,,<2nd file length>,....,<nth file name>,
<nth file length>

Example: `"CORR:CVL:CAT?"`

Features: *RST value: -
SCPI: device-specific

This command is available only in conjunction with option External Mixer Output, FSE-B21.

[SENSe<1|2>:]CORRection:TRANsducer:ACTive?

This command reveals the active transducer factor. If no transducer factor is switched on, a void string will be output.

Example: `"CORR:TRAN:ACT?"`

Feature: *RST value: -
SCPI: device-specific

[SENSe<1|2>:]CORRection:TRANsducer:CATalog?

This command reads out the names of all transducer factors stored on the harddisk.

Syntax of output format:

<Sum of file lengths of all subsequent files>,<free memory on hard disk>,
<1st file name>,,<1st file length>,<2nd file name>,,<2nd file length>,....,<nth file name>,
<nth file length>

Examples: `"CORR:TRAN:CAT?"`

Features: *RST value: -
SCPI: device-specific

[SENSe<1|2>:]CORRection:TRANsducer:COMMent <string>

This command defines the comment for the selected transducer factor.

Example: `"CORR:TRAN:COMM 'FACTOR FOR ANTENNA'"`

Features: *RST value: " "(empty comment)
SCPI: device specific

Prior to this command, the command `SENS:CORR:TRAN:SEL` must be sent.

[SENSe<1/2>:]CORRection:TSET:ACTive?

This command reveals the active transducer set. If no transducer set is switched on, a void string will be output.

Example: `"CORR:TSET:ACT?"`

Feature: *RST value: -
SCPI: device-specific

[SENSe<1|2>:]CORRection:TSET:CATalog?

This command reads out the names of all transducer sets stored on the harddisk.

Syntax of output format:

<Sum of file lengths of all subsequent files>,<free memory on hard disk>,
<1st file name>,,<1st file length>,<2nd file name>,,<2nd file length>,....,<nth file name>,
<nth file length>

Example: `"CORR:TSET:CAT?"`

Features: *RST value: -
SCPI: device-specific

[SENSe<1|2>:]CORRection:TSET:COMMent <string>

This command defines the comment for the selected transducer set.

Example: "CORR:TSET:COMM 'SET FOR ANTENNA'"

Features: *RST value: " " (empty comment)
SCPI: device specific

Prior to this command, the command SENS:CORR:TRAN:SEL must be sent.

[SENSe<1|2>:]DDEMod:PRESet GSM | EDGe | TETRa | DCS1800 | PCS1900 | PHS | PDCup | PDCDown | APCO25CQPSK | APCO25C4FM | CDPD | DECT | CT2 | ERMes | MODacom | PWT | TFTS | F16 | F322 | F324 | F64 | FQCDma|F95Cdma | RQCDma|R95Cdma | FNADc | RNADc

This command selects the automatic setting of modulation parameters in line with a standardized transmission technique.

Example: "DDEM:PRES TETRa"

Features: *RST value: GSM
SCPI: device-specific

Short designations used			
	APCO25CQPSK	APCO25 Continuous Phase QPSK
	APCO25C4FM	APCO25Continous Phase 4FM
	F16	FLEX 1600 - 2FSK
	F322	FLEX 3200 - 2FSK,
	F324	FLEX 3200 - 4FSK
	F64	FLEX 6400 - 4FSK
	FNADc	Forward NADC
	RNADc	Reverse NADC
	FQCDma or F95Cdma	Forward CDMA to IS95 standard
	RQCDma or R95Cdma	Reverse CDMA to IS95 standard

[SENSe<1|2>:]DDEMod:FILTer:MEASurement OFF | RCOSine | RRCosine | GAUSsian| B22 | B25 | B44 | QFM | FM95 | QFR | FR95 | QRM | RM95 | QRR | RR95 | A25Fm | EMES | EREF

This command selects the receive filter for the test signal.

B22	Bessel 22	B25	Bessel 25
B44	Bessel 44	QFM or FM95	IS95CDMA fm
QFR or FR95	IS95-CDMA fr	QRM or RM95	IS95-CDMA rm
QRR or RR95	IS95-CDMA rr	A25Fm	APCO 25 fm
EMES	EDGE mes	EREF	EDGE ref

Example: "DDEM:FILT:MEAS RCOS"

Features: *RST value: OFF
SCPI: device-specific

[SENSe<1|2>:]DDEMod:FILTer:REFerence RCOSine | RRCosine | GAUSsian| B22 | B25 | B44 | QFM | FM95 | QFR | FR95 | QRM | RM95 | QRR | RR95 | A25Fm | EMES | EREF

This command selects the receive filter for the reference signal (see SENSe.DDEMod:FILTer:MEASurement)

Example: "DDEM:FILT:REF RCOS"

Features: *RST value: GAUSsian
SCPI: device-specific

[SENSe<1|2>:]DDEMod:SEARch:SYNC:CATalog?

This command reads out the names of all sync patterns stored on the harddisk.

Syntax of output format:

<Sum of file lengths of all subsequent files>,<free memory on hard disk>,
<1st file name>,,<1st file length>,<2nd file name>,,<2nd file length>,....,<nth file name>,
<nth file length>

Example: "DDEM:SEAR:SYNC:CAT?"

Features: *RST value: -
SCPI: device-specific

[SENSe<1|2>:]DDEMod:SEARch:SYNC:COMMent <string>

This command defines a comment on a sync file. This sync file must be previously selected by the command DDEM:SEARch:SYNC:NAME.

Example: "DDEM:SEAR:SYNC:COMM "PATTERN FOR PPSK"

Feature: *RST value: ""
SCPI: device-specific

[SENSe<1|2>:]DDEMod:SEARch:SYNC:DATA <string>

This command defines a synchronization pattern for the sync file. Inputs other than "1" or "0" are interpreted as "Don't Care Bits". This sync file must be previously selected by the command DDEM:SEARch:SYNC:NAME..

Example: "DDEM:SEAR:SYNC:DATA "1101001"

Feature: *RST value: ""
SCPI: device-specific

[SENSe<1|2>:]DDEMod:SEARch:SYNC:DELete <string>

This command deletes a synchronization pattern on the hard disk. This sync file must be previously selected by the command DDEM:SEARch:SYNC:NAME.

Example: "DDEM:SEAR:SYNC:DEL

Features: *RST-value: ""
SCPI: device-specific

[SENSe<1|2>:]DDEMod:SEARch:SYNC:NAME <string>

This command selects a sync file to be edited or entered anew.

Example: "DDEM:SEAR:SYNC:NAME "PATT_NEW"

Feature: *RST value: ""
SCPI: device-specific

[SENSe<1|2>:]DDEMod:SEARch:SYNC:SELect <string>

This command selects a predefined sync file. A file that has been set previously by the command DDEM:SEARch:SYNC:PATTern becomes invalid.

Example: "DDEM:SEAR:SYNC:SEL "PATT_1"

Feature: *RST value: ""
SCPI: device-specific

[SENSe<1|2>:]DDEMod:SEARch:SYNC:MONLy ON | OFF

For setting ON, this command sets the analyzer so that the measured values are displayed and taken into account in the error analysis only if the set sync pattern is found . Bursts with a wrong sync pattern (sync not found) are ignored.

Example: `"DDEM:SEAR:SYNC:MONL ON"`

Features: *RST value: OFF
SCPI: device specific

[SENSe<1|2>:]MSUMmary:RUNit PCT | DB

This command selects the relative unit of the summary marker in the relative result display.

Example: `"MSUM:RUN DB"`

Features: *RST value: DB
SCPI: device-specific

[SENSe<1|2>:]POWer:ACHannel:PRESet ACPower | CPOWer | OBANdwidth|OBWidth | CN | CN0 | ADJust

This command selects the type of power measurement and resets the instrument depending on the selected standard.

Selection of parameter `ADJust` optimises automatically the settings (span, RBW, VBW and detector) of the analyzer for the power measurement selected by command `CALCulate<1|2>:MARKer:FUNCtion:POWer:SELect` (see Softkey ADJUST CP SETTINGS).

Example: `"POW:ACH:REF:PRES ACP"`

Features: *RST value: -
SCPI: device-specific

SYSTem:BINFo?

This command queries all present modules with variant, main index and subordinate index. Entries are separated by commas.

Return format: module1, model1, main index1, subordinate index1, module2, model 2, main index2, subordinate index2, module3,...,moduleN, modelN, main indexN, subordinate indexN

Example: `"SYST:BINF?"`

Features: *RST value: –
SCPI: device-specific

TRIGger<1|2>[:SEQuence]:LEVel:AF

This command defines the level of the demodulated trigger source. The units are PCT (range: ± 120PCT) for AM , HZ (range: ± 1000 HZ) for FM and DEG or RAD (range: ± 12 RAD) for PM demodulation.

Example: `"TRIG:LEV:AF 50PCT"`

Features: *RST value: 0 PCT
SCPI: device specific

Correction of Operating Manual

DISPlay:CMAP<1...13>:HSL <hue>,<sat>,<lum>

For the parameters <hue>, <sat> and <lum>, a settable range of 0.0 to 1.0 is listed. In fact, this range is 0.0 to 100.0.

1 Preparing for Operation

Chapter 1 presents the front and rear view of the instrument and explains step by step how to set up and connect the FSE.

1.1 Description of Front and Rear Panel Views

1.1.1 Front View

1

Display Screen — see Chap.2, Section 2.3.1

2

Soft Keys — see Chap.2, Section 2.3

3 USER

Writing Macros — see Chap. 2, Section 2.8

4 MARKER



Select and set marker

NORMAL	Select and set the marker
SEARCH	Set and start the peak/min search
DELTA	Select and set the delta markers
MKR ⇒	Set the active marker

see Chap. 2, Section 2.2 and Section 2.9.3

5 FREQUENCY



Define frequency axis in the active window

CENTER	Set center frequency
SPAN	Set sweep width
START	Set start frequency
STOP	Set stop frequency

see Chap. 2, Section 2.2 and Section 2.9.1



Fig. 1.1-1 Front View

6 LINES

Setup evaluation lines and tolerance limits

D LINES Setup evaluation lines (display lines)

LIMITS Definition and recall of tolerance limits

see Chap. 2, Section 2.2 and Section 2.9.4

7 LEVEL

Define reference levels and display range in the active measurement window.

REF Set reference level (= max. display level)

RANGE Set range

see Chap.2, Section 2.2 and Section 2.9.2

8 DATA ENTRY

Keypad for data input

0...9 input numbers

. input decimal point

– change sign

CLR
- close input field (for uncompleted or already closed inputs, the original entry is kept)
- erase the current entry in input field (beginning of an input)
- close message window (status, error and warning messages)

BACK erase last character input

GHz s
V -dBm
MHz ms
mV dBm
kHz µs
µV dB..
Hz ns
nV dB

The units keys close the data input and define the multiplication factor for each basic unit. For dimension-less or alphanumeric inputs, the units keys have weight 1. They behave, in this case, like the ENTER key.

EXP Append an exponent

see Chap.2, Section 2.3



Figure 1.1-1 Front View

9

3 1/2" diskette drive; 1.44 MByte

10 MEMORY

Memory media and file management

SAVE	Save instrument data
RECALL	Recall instrument data
CONFIG	Configuration of memory media and data

see Chap. 2, Section 2.2 and Section 2.7

11 INPUT

Set impedance and attenuation at the RF input.

12 RF INPUT



RF-Input

Caution:
The maximum DC voltage is 0 V, the maximum power is 1 W (≙ 30 dBm at ≥ 10 dB attenuation)

see Chap. 2 Section 2.9.2.4

13 DATA VARIATION

Key group for entering data and for cursor movement

HOLD	Disable control elements / overall control. The LED indicates the hold condition.
STEP	Set step size for cursor keys and roll-key.
Cursor keys	– Move the cursor within the input fields and tables. – Vary the input value. – Define the direction of movement for the roll-key.
Roll-key	– Vary input values. – Move markers and limits. – Select letters in the help line editor. – Move cursor in the tables

see Chap. 2, Section 2.3



Figure 1.1-1 Front View

14 PROBE/CODE



Power supply and coded socket for R&S accessories.(12-pin Tuchel)

15 SWEEP

Input sweep parameters

TRIGGER Set trigger source. The LED illuminates on valid trigger.

SWEEP Set type of sweep.

COUPLING Set coupled parameters. Resolution BandWidth (RBW), Video BandWidth (VBW) and SWeep Time (SWT). The LEDs light indicating coupled parameters which are manually cancelled.

see Chap. 2, Section 2.2 and Section 2.9.6

16

Reserved for options

17 MENU



Menu-change keys

Call main menu

Change to left menu

Change to right menu

see Chap. 2, Section 2.3.2

18 TRACE



Select and activate measurement traces (Trace 1...4).

The LEDs indicate traces turned on.

see Chap. 2, Section 2.2 and Section 2.9.5



Figure 1.1-1 Front View

19 PROBE POWER

Power supply connector (+15V / - 12.6V) for measurement accessories (probes)

see Annex A

20

Reserved for options

21

Reserved for options

22 AF OUTPUT

AF output connector (head phones) (miniature phone jack)

see Annex A

23



Internal loudspeaker

The loudspeaker is disabled when the phone jack is inserted in the AF output.

see Annex A

24

ON/STANDBY

Caution:
In standby mode, the AC line voltage is still present within the instrument.

see Chap. 1, Section 1.2.6



Fig.1.1-1 Front View

25 STATUS

Indicators for remote control and switch for manual control.

LOCAL — Switch from remote to manual control.

The LED SRQ indicates that a service request from the instrument is active on the IEC Bus.
The LED REMOTE indicates that the instrument is under remote control.

see Chap. 2, Section 2.5 and Chap. 3, Section 3.3

26 HARDCOPY

Printer control

START — Start a print job with the setup defined in the SETTING menu.

SETTING — Configure the diagram, parameter list and measurement protocol outputs on the various output media.

see Chap. 2 Sections 2.2 and 2.6

27 CONFIGURATION

Select operational modes and define default settings

MODE — Select mode

SETUP — Define configurationss

see Chap. 1, Sections 1.3 to 1.6 and Chapter 2, Section 2.2 and Sections 2.4.5 to 2.4.6

28 SYSTEM

General instrument default settings

PRESET — Recall instrument default settings

DISPLAY — Configure the display screen format

CAL — Calibrate the analyzer

INFO
- Information concerning instrument state and measurement parameters
- Call help functions

see Chap. 2 Section 2.2 and Sections 2.4.1 to 2.4.4



Fig. 1.1-2 Rear View

1.2 Start-Up

Important Note:

Before turning the instrument on, it must be observed that the following conditions are fulfilled:

- *instrument covers are in place and all fasteners are tightened,*
- *fan openings are free from obstructions,*
- *signal levels at the input connectors are all within specified maximums,*
- *signal outputs are correctly connected.and not overloaded.*

Non-observance may cause damage to the instrument .

1.2.1 Unpacking the Instrument

After the instrument has been removed from its packaging, insure that all deliverable items are present as follows:

- spectrum analyzer
- AC power cable
- operating manual

Now check the instrument for visible mechanical damage. If damage is present, promptly inform the delivery firm that delivered the instrument. In case damage is found, retain the carton and the packing materials.

1.2.2 Instrument Setup

1.2.2.1 Stand-alone Operation

The instrument is designed for use under general laboratory conditions. The ambient conditions required at the operational site are as follows:

- The ambient temperature must be in the range of + 5 to + 45 °C.
- All fan openings must be unobstructed and the air exhaust at the rear panel and at the side-panel perforations must not be covered. The distance to the wall should be at least 10 cm.
- The mounting surface should be flat.

  For applications in the laboratory or on a work bench, it is recommended that the support feet on the bottom of the instrument be extended. For the LCD display, this provides the optimum viewing angle which typically ranges from perpendicular to the display front to approximately 30° below.

1.2.2.2 19" Rack Installation

Important Note:

For rack installation, insure that the air flow at the side-panel perforations and the air exhaust at the rear panel are not obstructed.

The instrument may be mounted in a 19" rack by using the rack adapter kit ZZA-95 (order number: 396.4911.00). The installation instructions are included in the adapter kit.

1.2.3 EMI Protection Measures

In order to prevent electromagnetic interference (EMI), the instrument may be operated only when all covers are correctly in place. Only adequately shielded signal and control cables may be used (see recommended accessories).

1.2.4 Connecting to AC Power

The FSE is equipped with an AC voltage selection feature and will automatically set itself according to the applied AC voltage (range: 90 to 132 VAC and 180 to 265 VAC, 47 to 440 Hz). The AC power connector is located on the rear panel (see below).

➢ Connect the instrument to the AC power source using the AC power cable delivered with the instrument.

1.2.5 AC Power Line Fuses

The FSE is protected by two fuses as specified on the power supply name-plate. The fuses are located in a removable fuse holder which is located between the AC power switch and the AC power connector (see below).

1.2.6 Instrument On/Off

AC power switch on the rear panel



Power On/Off

➢ Depress the AC Power Switch to the desired position ON/OFF.

After turn-on (position ON), the instrument is in the ready state (STANDBY) or in operation dependent upon the position of the ON/STANDBY switch located on the instrument front panel (see below).

Note: *The AC power switch may remain ON continuously. Switching to OFF is only required when the instrument must be completely removed from the AC power source.*

Switching to OFF (position OFF) removes all instrument circuitry from the AC power source.

ON/STANDBY switch on the front panel



Caution:

In standby mode, the AC power voltage is present within the instrument.

Standby

➢ ON/STANDBY switch is not depressed.

The yellow LED (STANDBY) is illuminated. The DC power supply is supplied with power and the quartz oven is maintained at normal operating temperature.

Operation

➢ ON/STANDBY is depressed.

The green LED (ON) is illuminated. The instrument is ready for operation. All modules within the instrument are supplied with power.

1.2.7 Battery-Powered Memory

The FSE is equipped with a battery-powered read/write memory (CMOS-RAM) where instrument settings are saved at power-off. After each power-on, the FSE is reloaded with the operational parameters which were active just prior to the last power-off (STANDBY or AC power OFF).

A lithium battery is used to supply power to the CMOS-RAM. When the battery is depleted (expected life is approx. 5 years), any data stored in CMOS-RAM will be lost. In this case, the factory standard setup is loaded at turn-on. For changing batteries please contact the representative of our company responsible for you.

1.3 Functional Test

After turning on the AC power, the FSE returns the following message to the display screen:

Analyzer BIOS
Rev.x.y

Copyright
Rohde & Schwarz
Munich

Booting

After appearance of the above message, a self-test of the digital hardware is performed. Any errors which occur in self-test are transferred as ASCII text to the printer interface (LPT). Thus, an error diagnosis can be carried out, even for serious failures. A check of the data contents of the spectrum analyzer is performed in self calibration (CAL, *CAL TOTAL* key) The individual results of the calibration (PASSED / FAILED) can be displayed in the calibration menu.
With the aid of the built-in self-test functions (*INFO* key, *SELFTEST* soft key), the functional integrity of the analyzer can be verified and/or defective modules can be localized.

1.4 Connecting a Mouse

Caution:
The mouse may only be connected when the instrument is switched off (STANDBY). Otherwise, correct operation of the mouse and instrument cannot be guaranteed.

In order to ease manual operations, the FSE provides an option for connecting a mouse to a PS/2 mouse (MOUSE) or a serial interface (COM1 or COM2) connector.

During measurement operation, soft keys, tables and data input fields may also be controlled via the mouse. With the installed option FSE-B15, the mouse can be selectively assigned to measurement instrument operation, DOS operation or both modes of operation. If the option FSE-B15 is not installed, then the mouse can only be assigned to measurement instrument operation.

The control functions for the mouse are described in Chapter 2 in the section "Mouse Operations". Appendix E contains a list in which the screen display elements for mouse control of the corresponding soft keys and push buttons of the instrument are described. Appendix A contains the interface description.

The Microsoft mouse is the supported mouse type and is available under option PS-B1 (order number 1006.6359.02). The mouse connectors are located on the rear panel.

After connection of the mouse, the selected interface must be configured and the mouse assigned to either single or dual mode of operation.

The configuration is performed according to menu *SETUP-GENERAL SETUP* (key group: *CONFIGURATION,* see in Chapter 2, the section "Preliminary Setup and Interface Configuration").

- The parameter *MOUSE INTERFACE* configures the selected interface.
- The parameter *MOUSE OWNER* assigns the mouse to either single or dual mode of operation.

In the following illustrative example, the mouse is connected to the PS/2 interface and is assigned to the dual mode of operation.



Select SETUP-GENERAL SETUP menu

➢ Press the *SETUP* key in the *CONFIGURATION* key group.

The *SETUP* menu is opened.

➢ Press the *GENERAL SETUP* soft key.

The *GENERAL SETUP* sub-menu is opened and the current settings of the general instrument parameters are displayed in tabular form on the display screen.





Select interface

➢ Press the *MOUSE* soft key.

The *INTERFACE* parameter in the *MOUSE* table is marked by the selection bar.



➢ Press one of the units keys.

The *INTERFACE* selection box appears on the display screen. The current state (*NOT CONNECTED*) is indicated by a check mark and the selection bar is in the background.



➢ Press the cursor key ⓪ until the entry PS/2 is indicated by the selection bar.



➢ Press one of the units keys.

The *INTERFACE* selection box is closed, the setting PS/2 is entered in the MOUSE table and the selection bar is automatically set to the OWNER parameter.



Assign mouse mode

➢ Press one of the units keys.

The *OWNER selection box appears on the display screen. The current state (INSTRUMENT) is indicated by a check mark* and the selection bar is in the background.



➢ Press the cursor key ⓤ until the entry *INSTR AND DOS* is indicated by the selection bar.



➢ Press one of the units keys.

The *OWNER* selection box is closed and the setting *INSTR AND DOS* is entered in the MOUSE table.

The mouse is now installed and is available in both the measurement instrument and DOS modes.

Return to main menu

➢ Press the menu-change key several times.

1.5 Connecting an External Keyboard

Caution:
The keyboard may only be connected when the instrument is switched off (STANDBY). Otherwise, correct operation of the keyboard cannot be guaranteed.

The FSE provides an option for connecting an external PC keyboard to the 5-pin DIN connector at the rear panel.

During measurement operations, the keyboard simplifies the input of commentary text, filenames, etc. If the option FSE-B15 (computer function) is installed, the keyboard has the usual DOS-mode functions.

Note: *Using the key combination <ALT><S-Abf> (German keyboard) or <ALT><SYSREQ> (US-keyboard), the representation on the display screen can be rapidly toggled between the measurement instrument and the DOS display formats.*

Appendix E contains a list which describes the assignment of the FSE front-panel key functions to the key codes of the external keyboard as well as special key combinations used for quick operations. Appendix A contains the interface dscription.

The keyboard connection (KEYBOARD) is located on the rear panel.

After connecting the keyboard, the connection must be entered into the instrument and the key assignments for measurement instrument operations must be determined.

The configuration takes place in the menu *SETUP-GENERAL SETUP* (key group: *CONFIGURATION, see in Chapter* 2, the section "Preliminary Setup and Interface Configuration").

- The parameter *EXT KEYBOARD CONNECTION* informs the instrument that an external keyboard is connected.
- The parameter *EXT KEYBOARD LANGUAGE* sets the keyboard language definition for measurement instrument operation (*US-AMERICAN* or *GERMAN*).

  Note: *During measurement instrument operation, the key combination <ALT> <F1> can be used to toggle the language definition.*

In the following illustrative example, the instrument is informed that a keyboard has been connected. The GERMAN keyboard definition is selected.



Call SETUP-GENERAL SETUP menu

➢ Press the *SETUP* key of the *CONFIGURATION* key group.

The *SETUP* menu is opened.

➢ Press the *GENERAL SETUP* soft key.

The *GENERAL SETUP* sub-menu is opened and the current settings of the general instrument parameters are shown in tabular form on the display screen.





Setup keyboard connection

➢ Press the *EXTERNAL KEYBOARD* soft key.

The *CONNECTION* parameter in the *EXT KEYBOARD* table is marked by the selection bar.



➢ Press one of the units keys.

The *CONNECTION* selection box appears on the display screen. The current state (NOT CONNECTED) is indicated by a check mark and the selection bar is in the background.



➢ Press the cursor key ⓤ until the *CONNECTED* entry is indicated by the selection bar.



➢ Press one of the units keys.

The *CONNECTION* selection box is closed, the setup *CONNECTED* is entered in the table, *EXT KEYBOARD* is entered and the selection bar is automatically set to the *LANGUAGE* parameter.



Select German keyboard

➢ Press one of the units keys.

The *LANGUAGE* selection box appears on the display screen. The current state is indicated by a check mark and the selection bar is in the background.



➢ Press the cursor key ⓘ until the *GERMAN entry* is indicated by the selection bar.



➢ Press one of the units keys.

The *LANGUAGE* selection box is closed and the *GERMAN* setting is entered in the *EXT KEYBOARD* table.

Note: *This setting is valid only for the measurement instrument mode. The keyboard assignment in DOS mode is independently set by using the corresponding MS-DOS command.*

Return to MAIN MENU

➢ Press the menu-change key several times.

1.6 Connecting an Output Device

Caution:
The output device may be connected only when the instrument is switched off (STANDBY)

The FSE provides an option for connecting up to four different output devices to allow printing a hard copy of the display screen. The output devices supported by the FSE can be found in the selection box *DEVICE/LANGUAGE* in the HARDCOPY –SETTINGS DEVICE1/2 menu (see in Chapter 2, the section "Documentation of Measurement Results").
Appendix A contains the interfeace description of the connectors.

The interface connectors are located on the rear panel (see Table 1.6-1).

Table 1.6-1 Interface Connectors for Output Devices

Rear panel interface connectors	LPT	COM1	COM2	<SCPI> IEC625
Name in instrument control	LPT1	COM1	COM2	GPIB1

After connection of the output device to the appropriate interface connector, the configuration of the interface as well as the output device must be entered and the output device must be assigned to the interface.

The configuration of the selected interface (COM1, COM2 or GPIB1) is performed according to the *SETUP-GENERAL SETUP* menu (key group: *CONFIGURATION,* see in Chapter 2, the section "Preliminary Setup and Interface Configuration").

Note: *Interface LPT cannot be configured. If the option FSE-B15, computer function, is installed, LPT1 can be used for printing in both the measurement instrument mode and the DOS mode. However, it can only be used for one mode at a time.*

Interfaces COM1 and COM2

- The parameters *COM PORTS BAUDRATE, BITS, PARITY, STOPBITS, HW/SW-HANDSHAKE* determine the transmission parameters of the interface.

  Note: *The transmission parameters must agree with the specifications of the output device (see the operating manual for the output device).*

- The parameter *COM PORTS PROTOCOL* informs the instrument that an output device is connected to an interface (REMOTE setting).

- The parameter *COM PORTS OWNER* assigns the interface to one or both operational modes.

  Note: *If printing is required in the measurement instrument mode, then this parameter must be set to INSTRUMENT or INSTRUMENT AND DOS. If, on the other hand, printing is required in DOS mode (Option FSE-B15, computer function), then the parameter must be set to DOS or INSTRUMENT AND DOS.*

Interface GPIB1

- The parameter *GPIB ADDRESS* passes the IEC Bus address of the output device to the instrument.

  Note: *If the output device is operated in "listen only" mode, this setup may be omitted.*

The configuration of the connected output device and the assignment to the interface takes place in the *HARDCOPY DEVICE–SETTINGS DEVICE1/2* menu (key group:*HARDCOPY*, see in Chapter 2, the section "Selection and Configuration of the Output Device "). The configuration of up to two output devices (DEVICE1 and DEVICE2) may be entered, of which, at least one must be activated for printing.

- The parameter *DEVICE/LANGUAGE* determines which output device is to be used.

  Note: *During the selection of the printer type, it must be observed that the selected printer type and the connected output device are compatible. In case of doubt, consult the operating manual for the output device.*

- The parameter *CONNECTION* sets the interface which is to be used.

The number of additional parameters which need to be entered depends upon the selected interface and the output device used.

- The parameter *ORIENTATION* sets the page format to horizontal or vertical (portrait).
- The parameter *DEVICE RESET* determines if the output device is to be reset before each print job.
- The parameter *FORMFEED* determines if a formfeed should follow each print job.
- The parameter *PAPER FEED* specifies the paper feeder (single sheet or endless paper).

Table 1.6-2 shows the standard factory settings for the two output devices.

The standard factory settings for *DEVICE 1* correspond to an output device controlled by the command language HPGL, typically, a plotter connected to the IEC-Bus interface.

The standard factory settings for *DEVICE 2* correspond to a Epson printer (and compatible) connected to the parallel interface LPT.

Table 1.6-2 Factory settings for *DEVICE 1* and *DEVICE 2* in the *HARDCOPY-DEVICE SETTINGS* menu.

Parameter	**Parameter Name**	***DEVICE 1 Settings***	***DEVICE 2 Settings***
Output Device/Descriptive Language	DEVICE/LANGUAGE	HPGL	EPSON 24
Output Channel	CONNECTION	GPIB 1	LPT
IEC Bus Address	GPIB ADDRESS	4	---
Paper Format	ORIENTATION	PORTRAIT	PORTRAIT
Output Device Reset	DEVICE RESET	OFF	OFF
Formfeed	FORMFEED	OFF	ON
Paperfeed	PAPERFEED	MANUAL	MANUAL

In the following illustrative examples, a Postscript printer is connected to the LPT interface.

Note: *Interface LPT cannot be configured. The configuration of the other interfaces (COM1, COM2 or GPIB1) is performed according to the SETUP-GENERAL SETUP menu (key group: CONFIGURATION, see in Chapter 2, the section "Preliminary Setup and Interface Configuration").*



Configure printer and connect to interface

➢ Press the *SETTINGS* key of the *HARDCOPY* key group.

The *SETTINGS* menu is opened.

➢ Press the *HARDCOPY DEVICE* soft key

The *HARDCOPY DEVICE* sub-menu is opened and the current settings for the two possible output devices are displayed in tabular form on the display screen.





➢ Press the *SETTINGS DEVICE2* softkey.

The current selection in the first line of the table column *SETTINGS DEVICE2* is marked by the selection bar.



➢ Press one of the units keys.

The *SELECT DEVICE* selection box appears on the display screen. The current selection is indicated by a check mark and the selection bar is in the background.



➢ Press the cursor key ⓘ until the *POSTSCR* entry is indicated by the selection bar.

DEVICE SETTINGS		
ITEM	SETTINGS DEVICE 1	SETTINGS DEVICE 2
Device/Language	HPGL	POSTSCR
Connection	GPIB 1	LPT
GPIB Address	4	
Orientation	PORTRAIT	PORTRAIT
Device Reset	OFF	OFF
Formfeed		ON
Paperfeed		MANUALFEED

➢ Press one of the units keys.

The *SELECT DEVICE* selection box is closed and the *POSTSCR* setting is entered in the table column *SETTINGS DEVICE2.* The selection bar now indicates the current entry in the next row of the table.

Note: *The CONNECTION parameter is set to LPT at the factory and, therefore, must not be changed. The selection of the printer type automatically sets the parameters ORIENTATION, DEVICE RESET, FORM FEED and PAPER LENGTH to values which correspond to a standard mode of operation with this output device.*

Activate printer

➢ Press the *ENABLE* soft key until DEV2 in the second soft key line is selected.

Return to main menu

➢ Press the menu-change key several times.

1.7 Firmware Update

The installation of a new firmware version can be performed using the built-in diskette drive and does not require opening the spectrum analyzer. The deliverable items contained in the Firmware Update Kit and the installation program call procedure may be found in the documentation accompanying the kit. The installation program then leads the user through the remaining steps of an update.
This page is intentionally left blank

This page is left blank intentionally.

1.8 Options

1.8.1 Option FSE-B17 – Second IEC/IEEE Interface

Besides the FSE external devices can also be controlled via the IEC/IEEE bus using the optional 2nd bus interface FSE-B17 and the computer function for FSE (option FSE-B15) . The interface software permits IEC/IEEE-bus commands to be included in user programs.

1.8.1.1 Installing the software

1. The operating software is already installed and need not be loaded from the driver diskettes which serve as backup diskettes.
2. The driver GPIB.COM must be loaded on the start-up of DOS. For this to take place, the line DEVICE = C:\AT-GPIB\GPIB.COM has to be entered in the file C:\CONFIG.SYS. If the option is factory fitted, this line will have been entered in the factory.
3. The configuration of the card can be modified with the program C:\AT-GPIB\IBCONF.EXE. The following parameters may not be changed:

   Bios version < 3.0:

   ```
   Enable Auto Serial Polling .. No
   Base I/O Address ............ 02C0h
   Interrupt Level ............. NONE
   DMA Channel ................. 5 DMA
   ```

   Bios version ≥ 3.0:

   ```
   Enable Auto Serial Polling .. No
   Base I/O Address ............ 02C0h
   Interrupt Level ............. NONE
   Channel ..................... NONE
   ```

   For further parameters, refer to manual for the card.
4. The parameters of units connected are also set with the program IBCONF.EXE. The logic designation for FSE is preset to DEV1 and the address to 20. For further equipment refer to manual for the card.

   Note: *Ensure that the names assigned to the connected units are not the same as the directory names under DOS.*

1.8.1.2 Operation

The second IEC/IEEE-bus interface corresponds physically to that of FSE (see appendix A).
If the FSE is to be controlled via the IEC/IEEE bus, a bus cable must be plugged to both bus connectors.

The interface can be driven under DOS/WINDOWS by R&S software (FSE-K3, Order No. 1057.2996.02, etc.) or by user-written software. The handling of IEC/IEEE-bus commands in user programs is described in the manual for the card.

The files for DOS in the computer function are in directory C:\AT-GPIB, those for WINDOWS in directory C:\AT-GPIBW .

Note: *The program IBIC.EXE (see manual for the card) may not be used for controlling the FSE (measuring unit section); however external units can be controlled via the bus.*

1.8.2 Option FSE-B5 - FFT Filter

Option FFT Filter FSE-B5 is a firmware option. It has to be enabled by a keyword.

1.8.2.1 Prerequisites

1. Keywords
   The keyword is printed on a label which is part of the equipment supplied and has to be stuck to the rear of FSE.
2. Hardware
   The modification state of module DIGITAL IF has to be either MODIF INDEX > 5 or MODIF INDEX = 5 and HW CODE ≥ 6. The modification state can be checked in the module list *INSTALLED COMPONENTS* in menu *INFO HARDWARE+OPTIONS.*
3. Firmware
   The modification state of the firmware has to ≥ 1.62. The modification state can be checked in table *FIRMWARE VERSION* in menu *INFO FIRMWARE VERSIONS.*

1.8.2.2 Enabling the option



➢ Call up menu *SETUP* by pressing the *SETUP* key.

➢ Call up submenu *OPTIONS* by pressing the *OPTIONS* softkey.

Table *FIRMWARE OPTIONS* is displayed, listing the installed options.

➢ Activate the entry field by pressing the *ENABLE NEW OPTION* soft key.



➢ Enter the 10-digit keyword via the numeric keypad and terminate the entry by pressing one of the unit keys.

Now option FFT filter is listed in table *FIRMWARE OPTIONS.*

Note: *Message 'option key invalid' indicates an invalid entry.*

1.8.3 Option FSE B16 – Ethernet Adapter

With the option Ethernet Adapter FSE-B16, the device can be connected to an Ethernet-LAN (local area network). Together with the option Computer Function FSE-B15 it is possible to transmit data via the network and to use the network printer. The adapter operates with a 10 MHz Ethernet in line with standards IEEE 802.3 10Base2 (Thin Ethernet, CheaperNet, BNC-Net) (B16 model 03) or 10Base5 (Thick Ethernet) (B16 model 02). Operation without the option Computer Function FSE-B15 is not possible.

1.8.3.1 Hardware Installation

Caution:
Prior to installation contact the network administrator, especially in case of complex LAN installations since mistakes in cabling might have influence the whole network.

If the adapter is installed at the factory, it is preconfigured. In case of retrofitting, refer to the installation instructions. The hardware settings must not be modified since the functions of the device could otherwise be impaired.

The following parameters are factory-set:

```
I/O Addr. 300,      IRQ 5,      MEM CA000
```

The connection with the network depends on the connectors used in the network.

1.8.3.1.1 BNC (Thin Ethernet, CheaperNet; FSE-B16 Var. 03)

Connection

The device is looped into the LAN segment via rear-panel 2 BNC connectors.
If a cable is not connected to one of the BNC connectors, this BNC connector has to be terminated with 50 Ohm. BNC T connectors must not be used.

Network traffic

Note that the network traffic is disturbed if a segment is interrupted.

Requirements

Thin Ethernet segment requirements have to be complied with:
- maximum segment length of 185 m
- minimum distance between the connectors of 0.5 m
- maximum of 30 connectors per segment.

If components that comply with enhanced requirements are exclusively used (Ethernet Adapter FSE-B16 complies with the enhanced requirements):
- maximum length of segment of 300 m
- maximum number of connectors of 100

With repeaters used:
- maximum total length of the network of 900 m containing a
- maximum of 3 segments
- maximum of two repeaters between two connectors

1.8.3.1.2 AUI (Thick Ethernet; FSE B16 Var. 02)

Connection

The device is connected to the LAN segment using a transceiver cable (DB-15 AUI connector, not part of the equipment supplied) which is connected to the rear panel and to the transceiver.

Network traffic

The connection does not conflict with the network traffic. The device can also be disconnected from the network without any problems but make sure that data are not being transmitted.

Requirements

The Thick Ethernet segment requirements have to be taken into account.
- The maximum segment length should be 500 m and the
- distance between the connectors should at least be 2.5 m.
- A maximum of 100 connectors may be used in a segment.

With repeaters used,
- the total length of the network must not be more than 2500 m containing
- a maximum of 3 segments.
- There should be no more than two repeaters between two connectors.

If other network components are used, these conditions may vary.

1.8.3.1.3 RJ45 (UTP, 10BaseT, Western Connector)

Connection

A direct connection to a RJ45 star topology is not possible. With a MINI transceiver (AUI → RJ45) used, connection can be made via the AUI port at the rear of the device.

Network traffic

This connection does not conflict with the network traffic. The device can also be disconnected from the network without any problems but make sure that data are not being transmitted.

Requirements

Since RJ45 is not a bus but a star topology no special requirements have to be taken into account for the connection.
The LAN requirements should be considered in the installation.

1.8.3.2 Software Installation

Data transmission within the network is by means of data blocks, the so-called packets. Besides user data other information, the so-called protocol data (transmitter, receiver, type of data, order) are transmitted. The drivers corresponding to the protocol have to be installed to process protocol information. A network operating system is required for network services (data transmission, directory services, printing in the network) and thus has to be installed.

1.8.3.2.1 Installation of Network Drivers

a) ODI

ODI drivers have been developed by NOVELL for the network operating system NETWARE. It is an open standard so that other systems can be based on it, too. The driver system is of modular design and can thus be easily adapted to the hardware.

Files required for installation:

```
LSL.COM       (ODI drivers)
SMC8000.EXE   (hardware drivers for the adapter)
NET.CFG       (configuration file)
```

The `NET.CFG` file comprises information required for the installation of the network drivers. It is a text file that can be generated by any editor e.g. EDIT.

At least the following information has to be contained in the `NET.CFG` file:

```
Link Support
      Max Stacks 8
      Buffer 12 1586
      MemPool 8192

Link Driver SMC8000
      Port 300
      Mem  CA000
      Int  5
      Frame ETHERNET_II
```

Parameter `Frame ...` depends on the type of packets used in the network. The network administrator can provide information about the frame type used. With a wrong type used, problems will not occur in the network but a connection to other systems cannot be set up.

Loading the drivers

The drivers have to be loaded under DOS in the following order:

```
LSL

SMC8000
```

To allow for an automatic start, the drivers can be entered into the `C:\NETWORK.BAT` file. This batch file will be executed automatically when the device is started. The drivers can be unloaded if the programs are called up with the parameter `/U`. Unloading has to be in the reverse order.

b) NDIS

NDIS drivers are mainly used by network operating systems from MICROSOFT (DOS MS-NET,WINDOWS FOR WORKGROUPS, WINDOWS 95, WINDOWS NT). It is an open system so that other systems can be based on it, too. The driver system is of modular design and can thus be easily adapted to the hardware.

Files required for installation:

```
PROTMAN.DOS
PROTMAN.EXE
NET.EXE
NET.MSG
IFSHLP.SYS
PROTOCOL.INI
NDISHLP.SYS
NETH.MSG
WFWSYS.CFG
SMC8000.DOS     (Hardware drivers for the adapter)
SYSTEM.INI
```

Files `PROTOCOL.INI` and `SYSTEM.INI` contain information required for installing the network drivers. They are text files that can be created or modified by any editor, e.g. EDIT.

At least the following information has to be contained in the `PROTOCOL.INI` file:

```
[network.setup]
version=0x3110
netcard=ms$w8003e,1,MS$W8003E,3
transport=ms$nwlinknb,NWLINK
transport=ms$ndishlp,MS$NDISHLP
transport=ms$netbeui,NETBEUI
lana0=ms$w8003e,1,ms$nwlinknb
lana1=ms$w8003e,1,ms$ndishlp
lana2=ms$w8003e,1,ms$netbeui

[protman]
DriverName=PROTMAN$
PRIORITY=MS$NDISHLP

[NWLINK]

BINDINGS=MS$W8003E
[MS$NDISHLP]
DriverName=ndishlp$
BINDINGS=MS$W8003E

[NETBEUI]
DriverName=netbeui$
SESSIONS=10
NCBS=12
BINDINGS=MS$W8003E
LANABASE=1

[MS$W8003E]
DriverName=SMC8000$
irq=5
iobase=0x300
ramaddress=0xca00

[SMC8000W]
Adapters=MS$W8003E
```

At least the following information has to be contained in the SYSTEM.INI file:

```
[Network]
winnet=wfwnet/00025100
multinet=nonet
FileSharing=Yes
PrintSharing=Yes
LogonDisconnected=yes
EnableSharing=Yes
UserName=FSE
Workgroup=WORKGROUP
ComputerName=FSE
Comment=FSE
[network drivers]
netcard=smcmac.dos
transport=ndishlp.sys,*netbeui
devdir=C:\NDIS
LoadRMDrivers=No

[NWNBLINK]
LANABASE=0
```

Parameter "UserName= ..."	comprises the user name for the network.
Parameter "Workgroup= ..."	comprises the user name for the network.
Parameter "ComputerName= ..."	determines the name of the device in the network. This name has to be unique in the network.

All drivers should be copied into a directory, e.g. C:\NDIS.

Requirements in the CONFIG.SYS file

The C:\CONFIG.SYS file has to be extended by the following line:

```
DRIVER = C:\NDIS\IFSHLP.SYS
```

To do this, the read-only attribute of the file has to be removed by the following DOS command:

```
ATTRIB C:\CONFIG.SYS -R
```

Loading the drivers

On startup of the device, the network drivers will be loaded automatically.

c) Packet Drivers

The "Packet" network driver system has been developed by universities and can be used free of charge. Many free-of-charge network operating systems (KERMIT) are based on this driver system. Although the drivers for these network cards used to be made at universities, manufacturers have now started to supply their own drivers.

File required for installation:

```
PKT8000.COM
```

Loading the drivers

The driver should be copied into a directory, e.g. `C:\PACKET`.

The DOS command

```
C:\PACKET\PKT8000 -i 0x7e 5 0x300 0xca00
```

starts the driver.

To allow for an automatic start, the driver can be entered into the `C:\NETWORK.BAT` file. This batch file will be executed automatically on the startup of the device.

1.8.3.2.2 Installation of Network Operating System

a) NOVELL NETWARE

ODI drivers are the precondition for NOVELL NETWARE. The access software is available in three models: NETWARE SHELL, NETWARE REQUESTER and NETWARE CLIENT 32. NETWARE SHELL allows access to NETWARE 3 servers only. The NETWARE REQUESTER allows access to NETWARE 3 as well as NETWARE 4 (NDS). NETWARE CLIENT 32 cannot run on the device.

NETWARE SHELL

Files required for installation:

```
IPXODI.COM
NETX.EXE
```

The files should be copied into the directory comprising the network drivers.

If a connection to a certain network server is requested, the name of the server can be entered into the `NET.CFG` file by means of the following line:

```
PREFERRED SERVER = FSESERVER
```

(FSESERVER has to be replaced by the server name in the network).

Loading the drivers

The drivers are loaded under DOS in the following order:

```
IPXODI

NETX
```

To allow for an automatic start, the drivers can be entered into the `C:\NETWORK.BAT` file in addition to the network drivers. This batch file will be executed automatically on the startup of the device. The drivers can be unloaded if the programs are called up with the parameter `/U` . Unloading has to be in the reverse order.

NETWARE REQUESTER

Files required for installation:

```
IPXODI.COM
AUTO.VLM
BIND.VLM
CONN.VLM
FIO.VLM
GENERAL.VLM
IPXNCP.VLM
NDS.VLM
NETX.VLM
NMR.VLM
NWP.VLM
PNW.VLM
PRINT.VLM
REDIR.VLM
RSA.VLM
SECURITY.VLM
TRAN.VLM
VLM.EXE
```

The files should be copied into the directory comprising the network drivers.

Changes in the `CONFIG.SYS` file

In the `C:\CONFIG.SYS` file line

```
LASTDRIVE = V:
```

has to be replaced by line

```
LASTDRIVE = Z:
```

To do this, the read-only attribute of the file has to be removed with the DOS command

```
ATTRIB C:\CONFIG.SYS -R
```

Changes in the `NET.CFG` file

The `NET.CFG` file is extended by the following lines:

```
Netware Dos Requester
     NETWARE PROTOCOL = NDS  BIND
     FIRST NETWORK DRIVE = W
     SHOW DOTS = ON
     SPX CONNECTIONS = 99
     IPX PACKET SIZE LIMIT = 1514
     hold= off
```

If a connection to a certain network server is requested, the name of the server can be entered into the NET.CFG file by means of line

```
PREFERRED SERVER = FSESERVER
```

(FSESERVER has to be replaced by the server name in the network).

Loading the drivers

The drivers are loaded under DOS in the following order:

```
IPXODI
VLM
```

To allow for an automatic start, the drivers can be entered into the `C:\NETWORK.BAT` file in addition to the network drivers. This batch file will be executed automatically on the startup of the device. The drivers can be unloaded if the programs are called up with the parameter `/U`. Unloading has to be in the reverse order.

b) MICROSOFT NET

Drivers required

The NDIS drivers are the precondition for the MICROSOFT NET. Other drivers are not required.

Loading the drivers

The start is via the following DOS command:

```
C:\NDIS\NET START
```

To allow for an automatic start, the command can be entered into the `C:\NETWORK.BAT` file. This batch will be executed automatically on the startup of the device.

c) TCP/IP

TCP/IP (Transmission Control Protocol / Internet Protocol) is not a network operating system but a standard. This standard allows to transmit data between computers using different operating systems. The services are managed by utility programs such as FTP, TELNET, KERMIT, HTTP, RSH. TCP/IP only provides services for the transport and network addressing.

Drivers required

TCP/IP can be based on the ODI or PACKET drivers. Normally, another driver providing the TCP/IP support is required. See corresponding product about the use of the drivers.

d) KERMIT

Drivers required

The data transmission program KERMIT is based on the PACKET drivers. To install KERMIT it is required to copy all the files into a directory, e.g. `C:\KERMIT`. The precondition for this is that an IP address is assigned to the device by the network administrator and that the Sub Net Mask for the network is known. Both addresses are in the form of four digits from 0 to 255 separated by a dot. An IP address in the network has to be unique as problems might otherwise occur. The Sub Net Mask is the same in the whole network.

Examples of IP address: `89.0.0.14`

Example of Sub Net Mask: `255.255.0.0`

1.8.3.3 Operation

After installing the network operating system it is possible to transfer data between the device and other computers and to use printers in the network. A precondition for network operation is the authorization to use network resources. Resources may be access to the file directories of other computers or the use of a central printer. The network or server administrator will grant the authorizations. The network name of the resource and the corresponding authorization are required. Passwords protect the resources against improper use. A user name is normally assigned to every authorized user. The user also has a password. Resources may then be assigned to the user. The type of access, i.e. whether data are only read or also written as well as a shared access to data has to be defined. Other types are possible depending on the network operating system.

1.8.3.3.1 NOVELL

Operating system NETWARE from NOVELL is as server-supported system. Data transfer between the individual workstations is not possible. Data transfer is between workstation computers and a central computer, the server. This server provides storage capacity and the connection to the network printers. Like under DOS, the data on a server are organized in directories and are offered to the workstation as virtual drives. A virtual drive on a workstation is like a hard disk and data can be processed accordingly. This is called drive mapping. Also network printers can be addressed as normal printers. Network operating system NOVELL is available in two forms: NETWARE 3 and NETWARE 4 NDS. In the previous version NETWARE 3, each server manages its own resources itself and is independent. A user has to be managed separately on each server. For NOVELL 4 NDS, all resources are managed in the NDS (NOVELL DIRECTORY SERVICE). The user only has to log in once and gains access to the resources released for him. The individual resources and the user are managed as objects in a hierarchical tree (NDS TREE). The position of the object in the tree is called CONTEXT for NETWARE and must be known in order to access the resources.

Logging into network

After all network drivers have been loaded and the device has established a connection with the server, a new drive `W:` is generated. After a change to this drive, the log in can be started with the

```
LOGIN
```

command. The user name and the password are queried.

For NOVELL 4 NDS it is necessary to set the CONTEXT beforehand using the

```
CX <context>
```

command.

Virtual drives

To generate a virtual drive on the computer function of a device, the following command is used

```
MAP [ROOT]<dr>:=<server>/,<volume>:<directory>
```

where:

dr	drive indicator under which the virtual drive is addressed (E to P, R to V)
server	name of the NOVELL server on which the directory is located.
volume	name of the data medium on which the directory is located.
directory	name of the directory which is to be accessed.

If parameter ROOT is specified, the higher directories can no longer be addressed.

Example:

```
MAP P:=VENUS/SYS:MESURE\FSE
```

causes that the directory \MESURE\FSE on hard disk SYS of server VENUS appears on the device as drive P . In drive P it is also possible to see the directory structure of MESURE. If the command is called up with the parameter ROOT, it would only be possible to access directory structures below FSE.

The

```
MAP DEL <lw>:
```

command allows drive mapping to be canceled.

Storage of device data on a server

Instead of storing device data on hard disks, they can be stored on virtual drives. To do this, it is first required to generate a virtual drive E: in the computer function. The LOADINFO file in directory d:\ has to comprise line

```
ATTACHDEVICE E_DOS AS :C: EDOS
```

to enable the device to recognize the drive. Access to E: is according to normal device functions.

Printing on a network printer

To be able to use a printer in the computer function, this printer has to be connected first with the computer function by means of the following command

```
CAPTURE L=<lpt> Q=<printer_queue>
```

where:

lpt	printer port (1=LPT1, 2=LPT2, 3=LPT3)
printer_queue	name of printer queue.

Example:

```
CAPTURE L=1 Q=PRINTER_FSE
```

causes printer data which are normally sent to printer port LPT1 to be routed to the network printer called PRINTER_FSE.

Hardcopy from device to a network printer

It is not possible to directly route a hardcopy from the device to a network printer. It has to be printed first into a file on the hard disk (Print to File). This file is then copied to the printer in the computer function.

This procedure is automated by the following DOS batch file:

```
START:
IF NOT EXIST C:\USER\OUTPUT.PRN GOTO START
COPY C:\USER\OUTPUT.PRN LPT1 /B
DEL C:\USER\OUTPUT.PRN
GOTO START
```

If this batch program is called up, the computer function waits until the device has generated a print file called OUTPUT.PRN, prints this file and deletes it again.

1.8.3.3.2 MICROSOFT

For MICROSOFT, data can be transferred between workstations (peer-to-peer) but also between workstations and servers. The servers can provide access to individual files as well as the connection to network printers. Like under DOS, the data on a server are organized in directories and are offered to the workstation as virtual drives. A virtual drive on a workstation is like a hard disk and data can be processed accordingly. This is called drive mapping. Also network printers can be addressed as normal printers. A connection to DOS, WINDOWS FOR WORKGROUPS, WINDOWS95, WINDOWS NT is possible.

Logging into network

After all network drivers are loaded and the device has established a connection with the server, a new drive W: is generated. After a change to this drive, the log in can be started with the

```
NET LOGON
```

command. The user name and the password are queried.

Virtual Drives

To generate a virtual drive on the computer function of a device, the following command is used

```
NET USE <dr>: \\<server>\<directory>
```

where:

dr	drive indicator under which the virtual drive is addressed (E to P, R to V)
server	name of the server on which the directory is located.
directory	name of the directory which is to be accessed.

Example:

```
NET USE P: VENUS\MESSUNG\FSE
```

causes the directory \MESURE\FSE of server VENUS to appear as drive P on the device.

Drive mapping is canceled by means of

```
NET USE <lw>: \\<server>\<directory> /DELETE
```

Storage of device data on a server

Instead of storing device data on hard disks, they can be stored on virtual drives. To do this, it is first required to generate a virtual drive E: in the computer function. The LOADINFO file in directory `d:\` has to comprise line

```
ATTACHDEVICE E_DOS AS :C: EDOS
```

to enable the device to recognize the drive. Access to `E:` is according to normal device functions.

Printing on a network printer

To be able to use a printer in the computer function, this printer has to be connected first with the computer function by means of the following command

```
NET USE <port>: \\<server>\<printerqueue>
```

port	printer port (LPT1, LPT2, LPT3)
server	name of server on which the directory is located
printerqueue	name of printer queue of printer

Example:

```
NET USE LPT1: \\VENUS\PRINTER_FSE
```

uses printer data which are normally sent to printer port LPT1 to be routed to the network printer called PRINTER_FSE.

Hardcopy from device to a network printer

It is not possible to directly route a hardcopy from the device to a network printer. It has to be printed first into a file on the hard disk (Print to File). This file is then copied to the printer in the computer function.
This procedure is automated by the following DOS batch file:

```
START:
IF NOT EXIST C:\USER\OUTPUT.PRN GOTO START
COPY C:\USER\OUTPUT.PRN LPT1 /B
DEL C:\USER\OUTPUT.PRN
GOTO START
```

If this batch program is called up, the computer function waits until the device has generated a print file called OUTPUT.PRN, prints this file and deletes it again.

1.8.3.3.3 TCP/IP

The TCP/IP protocol allows files to be transmitted between different computer systems. A program running on both computers is required to control the data transfer. The same operating or file system need not be used by the two partners. A file transfer is possible between DOS/WINDOWS and UNIX, for example. One partner has to be configured as host the other as client or vice versa. The system performing several processes at the same time (UNIX) will normally be the host. The usual file transfer program used for TCP/IP is FTP (File Transfer Protocol). An FTP host is installed as standard on most of the UNIX systems.

Columbia University provides the KERMIT program which not only allows file transfer via networks but also via modem. KERMIT can be used free of charge. The two procedures provide safe data transmission, i.e. errors normally do not occur.

1.8.3.3.4 FTP

For a complete description of the functions and commands see the FTP documentation.

Establishing a connection

The program is started with the DOS command

```
FTP
```

The following command sets up the connection:

```
OPEN <xx.xx.xx.xx>
```

xx.xx.xx.xx = IP address, e.g. 89.0.0.13

File transmission

To transmit a file to the target system, the following command is used:

```
PUT <file name>
```

file name = name of file e.g. DATA.TXT.

To call a file from the target system, the following command is used:

```
GET<file name>
```

file name = name of file e.g. SETTING.DAT.

```
TYPE B
```

allows the transmission of files in the BINARY format, no conversion is performed.

```
TYPE A
```

allows the transmission of files in the ASCII format. Thus, control characters are converted so that the text files can be read on the target system, too.

Examples:

```
PUT C:\AUTOEXEC.BAT
```

sends the `AUTOEXEC.BAT` file to the target system.

```
LCD DATA
```

changes to subdirectory DATA in the computer function.

```
CD SETTING
```

changes to the subdirectory SETTING on the target system.

Changing directories

The command

```
LCD <path>
```

changes the directory as the corresponding DOS command.

```
LDIR
```

lists the directory.

These commands refer to the computer function of the instrument. If the 'L' preceding the commands is omitted, they apply to the target system.

1.8.3.3.5 KERMIT

KERMIT comprises a large number of functions described in detail in the help file KERMIT.HLP.

Establishing a connection

The program is started by means of the DOS command

```
KERMIT
```

The

```
SET TCP/IP ADDRESS <xx.xx.xx.xx>
```

xx.xx.xx.xx = IP address e.g. 89.0.0.13

command allows to set the individual IP address.

The Sub Net Mask is set by means of

```
SET TCP/IP SUBNETMASK <xx.xx.xx.xx>
```

xx.xx.xx.xx= Sub Net Mask e.g. 255.0.0.0.

These commands can also be entered into the `MSCUSTOM.INI` file and will be executed automatically when KERMIT is started.

The computer to which data are to be transferred is set by means of

```
SET PORT TCP/IP <xx.xx.xx.xx>
```

xx.xx.xx.xx=IP address of target computer.

A prerequisite is that the KERMIT program on the target computer is running in the host mode.

KERMIT can be ordered via Internet in WWW (URL: http://WWW.COLUMBIA.EDU) from COLUMBIA UNIVERSITY for almost all operating systems.

The

```
CONNECT
```

command sets up the connection.

The

```
HANGUP
```

command allows to stop the connection and the

```
QUIT
```

command to leave the program.

Data transmission

To transmit a file to the target system, the

```
SEND <file name>
```

```
file name = name of file e.g. DATA.TXT
```

command is used. To transmit a file from the target system, the

```
GET<file name>
```

```
file name = name of file e.g. SETTING.DAT
```

command is used.

Changing directories

Like with DOS, the directory is changed by means of the

```
CD <path>
```

command and the contents of the directory is indicated by means of the

```
DIRECTORY
```

command.

These commands concern the computer function of the device. If `REMOTE..` is used in front of the commands, they apply to the target system.

Examples:

```
SEND C:\AUTOEXEC.BAT
```

sends the `AUTOEXEC.BAT` file to the target system.

```
CD DATA
```

changes to the subdirectory DATA in the computer function.

```
REMOTE CD SETTING
```

changes to the subdirectory `SETTING` on the target system.

2 Manual Operation

Chapter 2 describes the manual operation of the instrument. It includes section 2.1 "Measurement Examples", Section 2.2, "Menu Overview", and section 2.3 "Basic Operation", allowing to get familiar with FSE operation.
Starting from section 2.4, the complete functions of the FSE are described in detail.

2.1 Measurement Examples

This section describes a typical, simple measurement task for a spectrum analyzer. In the following description, each step is explained in detail using the FSE so that the instrument can be immediately used without the need for learning all of the available functions. The described measurement applications are:

- Measurement of the level and frequency of a sine wave signal.
- Measurement of harmonics.
- Measurement of third order intermodulation and determination of the intercept point.
- Zero span measurement of a pulsed signal.

All of the following examples assume the standard settings for the analyzer. These are set with the *PRESET* key in the *SYSTEM* key field. The most important standard settings are shown in Table 2.1-1. A complete listing of standard settings can be found in Chapter 2.4.

Table 2.1-1 Important PRESET settings

Parameter	Parameter name	Setting			
		FSEA	FSEB	FSEM	FSEK
Mode	Mode	analyzer	analyzer	analyzer	analyzer
Center frequency	Center Frequency	1,75 GHz	3,5 GHz	13,25 GHz	20 GHz
Active Freq. Meas. Range	Span	3,5 GHz	7 GHz	26,5 GHz	40 GHz
Reference Level	Ref Level	– 20 dBm	– 20 dBm	– 20 dBm	– 20 dBm
RF Attenuation	RF ATT	10 dB	10 dB	10 dB	10 dB
Level Display Range	Level Range	100 dB	100 dB	100 dB	100 dB
Resolution Bandwidth	Res Bw	3 MHz	3 MHz	3 MHz	3 MHz
Video Bandwidth	Video Bw	3 MHz	3 MHz	3 MHz	3 MHz
Sweep Time	Sweep Time	5 ms	5 ms	150 ms	225 ms
Trigger	Trigger	free run	free run	free run	free run

2.1.1 Level and Frequency Measurements

2.1.1.1 Measurement Task

The determination of the level and frequency of a signal is one of the most frequently encountered measurement tasks typically performed by a spectrum analyzer. Usually, for the measurement of an unknown signal, the PRESET settings are initially selected. If levels above +30 dBm are expected or possible, then a power attenuator must be inserted ahead of the analyzer input. Without attenuation, these signal levels might damage or destroy the input attenuator or the input mixer.

2.1.1.2 Important Spectrum Analyzer Functions

Important parameters for level and frequency measurements are the settings for the *CENTER FREQUENCY*, the selection of the active measurement frequency range (*SPAN*) and the *MARKER* functions.

2.1.1.3 Sweep, Level and Frequency Measurements – Example 1

In this example, a signal with a frequency of 200 MHz and a level of -10 dBm are applied to the RF INPUT of the analyzer. The selection of the center frequency and the active frequency range takes place manually.
The necessary setup functions are performed almost without exception by the fixed-function keys. The menus which appear with a key can, for the most part, be ignored. In this manner, fast, key-oriented operation is possible.

The following setup steps are performed:

1. Reset the instrument.
2. Apply the test signal.
3. Set the center frequency to 200 MHz.
4. Reduce the active measurement frequency range (SPAN) to 1 MHz.
5. Measure the level and frequency using the marker.
6. Optimize the measurement dynamic range and reduce the level measurement error.
7. Measure the frequency with the internal frequency counter

1. Reset the instrument.

➢ Press the *PRESET* key.

2. Connect the test signal to the RF INPUT located on the instrument front panel.



3. Set the center frequency to 200 MHz.

➢ Press the *CENTER* key in the *FREQUENCY* key field.

The input field for center frequency appears on the display screen.



➢ Enter *200* via the numeric keypad and terminate with the *MHz* key.



4. *Reduce the measurement frequency range (SPAN) to 1 MHz.*

➢ Press the *SPAN* key in the *FREQUENCY* key field.



➢ Enter *1* via the numeric keypad and terminate with the *MHz* key.

Note: *In conjunction with the change in measurement frequency range (SPAN), the resolution bandwidth (RES BW), video bandwidth (VIDEO BW) and sweep time (SWEEP TIME) are set to new values since they are defined as coupled functions in the standard PRESET settings.*

5. *Measure level and frequency using the marker and read the resulting values on the display screen.*

➢ Press the *NORMAL* key in the *MARKER* key field.

The marker jumps to the largest signal peak shown on the display screen.

Note: *When the marker is switched on for the first time, it automatically performs the PEAK SEARCH function as demonstrated in this example.*
If a marker was already active, the SEARCH key in the MARKER key field must be pressed in order to set the currently active marker to the displayed signal maximum.

The level and frequency measured by the marker can be read in the marker field at the upper edge of the display screen. (see Figure 2.1-1).



➢ Using the roll-key, the marker can be moved along the measured curve.

The corresponding level and frequency values appear in the marker field.

Figure 2.1-1 shows the measured curve on the display screen over a 1 MHz range as well as the marker level and frequency values.



Fig. 2.1-1 200-MHz signal. The measured values are displayed in the marker field.

At low signal-to-noise ratios, the level measurement accuracy can be improved by an optimum selection of the FSE parameters. The accuracy of the frequency display can also be enhanced by applying the internal frequency counter.



6. Optimize the dynamic range and reduce the level measurement error.

➢ Press the *MKR→* key in the *MARKER* key field.

The *MARKER-MKR→* menu is opened.

➢ Press *MKR → REF LEVEL* soft key.

The reference level (REF LEVEL) is reduced to the signal level.

7: Determine the exact frequency with the internal frequency counter.

***Note:** The frequency counter measures the frequency of the marked signal with the selected counter resolution and at the accuracy of the internal frequency reference. A frequency measurement made using the marker is, however, limited by the number of horizontal display points and the applicable resolution bandwidth.*



➢ Press the *NORMAL* key in the *MARKER* key field.

The *MARKER NORMAL* menu is opened.

➢ Press the *SIGNAL COUNT* soft key.

The internal frequency counter is now active and measures the signal frequency with the PRESET resolution. The resolution is to be increased to 10 Hz.



➢ Press the menu change key ▷.

The supplementary menu is opened.



➢ Press the *COUNTER RESOL* soft key.

The *COUNTER RESOLUTION* sub-menu is opened.

➢ Press the *10 Hz* soft key.

The desired frequency resolution (10 Hz) is now selected.

In the marker field, the item [CNT] indicates that the counter is active (see Fig. 2.1-2).



Figure 2.1-2 Frequency measurement using the internal frequency counter.

2.1.1.4 Sweep, Level and Frequency Measurements – Example 2

The zoom function (*MARKER ZOOM*) operates much faster than the manual input of center frequency and measurement frequency range, and permits the measurement frequency range displayed on the screen to be as narrow as desired.

As in Example 1, a signal with a frequency of 200 MHz and a level of -10 dBm is applied to the analyzer RF INPUT.

The following setup steps are performed:

1. Reset the instrument.
2. Apply the signal.
3. Zoom in on the signal.
4. Measure the level and frequency with the marker.
5. Optimize the dynamic range and reduce the level measurement error.
6. Measure the frequency with the internal frequency counter.

Steps 1 to 2 and 4 to 6 correspond to steps 1 to 2 and 5 to 7, respectively, of Example 1. Step 3 replaces the manual input of center frequency and measurement frequency range. (steps 3 and 4).

See steps 1 and 2 of example 1

1. Reset the instrument to standard settings.

2. Connect the test signal to the analyzer RF INPUT.

3. Zoom in on the signal.

➢ Press the *NORMAL* key in the *MARKER key field*.

The marker moves to the largest signal displayed on the screen. In this example, it is the signal at 200 MHz. (PEAK SEARCH function, see step 5 in Example 1).

➢ Press the *MARKER ZOOM* soft key.

The input field for the measurement frequency range appears on the display screen.



➢ Enter 1 via the numeric keypad and terminate with the *MHz* key.

After entry of the measurement frequency range, the marked signal is counted and then used as the new center frequency. At the same time, the entered measurement frequency range is set.

Note: *In conjunction with the active measurement frequency range (SPAN) change, the resolution bandwidth (RES BW), video bandwidth (VIDEO BW) and sweep time (SWEEP TIME) are also set to new values since they are defined as coupled functions in the standard PRESET settings.*

See steps 5 to 7 of example 1:

4. Read the values for level and frequency as measured by the marker.

5. Optimize the dynamic range and reduce the level measurement error.

6. Determine the frequency with the internal frequency counter.



Figure 2.1-3 The The MARKER ZOOM function requires the entry of the measurement frequency range (span)

2.1.1.5 Level Measurement Accuracy

The level measurement accuracy of an analyzer is influenced by the following parameters:

- RF attenuator (*RF-ATT*)
- IF amplification
- Resolution bandwidth (*RES BW*)
- Display range (*LEVEL RANGE*)
- Display linearity (*SCALE FIDELITY*)

The error in a level measurement for the FSE is < 1 dB for frequencies up to 1 GHz and < 1.5 dB for frequencies from 1 GHz to 3.5 GHz. This specification includes all of the above mentioned influential factors. The frequency characteristics of the pertinent modules (RF divider, front end) are stored individually in memory on each module. The FSE initializing routines read out the corresponding values during execution immediately after the analyzer is turned on and corrects the frequency characteristics during the sweep. Any errors in the attenuation settings, the filter bandwidth or the video rectifier are corrected after calling the built-in calibration routines. For calibration purposes, the FSE has an internal 120 MHz calibration source which is switched internally to the RF INPUT.
The measurement accuracy is guaranteed only after running the calibration routines. It should be noted, however, that the individual parameters are so stable that a calibration need only be performed, after approximately 15 minutes warm-up time, for larger temperature variations. Normally, a weekly calibration is more than adequate.

2.1.2 Measurement of Harmonic Separation

2.1.2.1 Measurement Task

The measurement of signal harmonics is a frequently occurring task which can be optimally performed by a spectrum analyzer. In general, all signals will contain harmonics to some degree. Harmonics are especially critical in high-power transmitters, e.g., in radio transmitters, where a significant radiated harmonic component may interfere with the reception of other radio services. Generally, non-linear device characteristics create harmonics which are often selectively reduced through the use of low-pass filters. Since the spectrum analyzer also has non-linear characteristics, e.g., at the first mixer, it is necessary to exercise caution during a measurement to insure that the spurious harmonics generated by the analyzer do not influence the measurement results. If necessary, the fundamental frequency must be selectively attenuated with respect to the harmonics by insertion of an appropriate high-pass filter.

For harmonic-content measurements, the achievable measurement dynamic range is dependent upon the k2 intercept of the spectrum analyzer. The k2 intercept point is defined as the fictitious first-mixer input level where the levels of the first harmonic and of the fundamental frequency are equal. In practice, this level cannot be applied to the mixer since, to do so, would cause its destruction. However, using the k2 intercept point concept, the achievable measurement dynamic range for the harmonics of a Unit Under Test (UUT) can be calculated with relative simplicity.

As can be seen in Fig. 2.1-4, the harmonic level is reduced by 20 dB when the level at the fundamental frequency is reduced by 10 dB.



Figure 2.1-4 Theoretical display curve of fundamental and first harmonic with a k2 intercept of 50 dBm.

From the linear equations and the given intercept point, the following formula can be derived for the achievable harmonic separation a_{k2} in dB:

$$a_{k2} = IP2 - P_e \qquad (1)$$

a_{k2} = harmonic separation
P_e = mixer level/dBm
IP2 = k2 intercept point

The formula for the internally produced level P_1 at the first harmonic in dBm is:

$$P_1 = 2 \bullet P_e - IP2 \qquad (2)$$

The lower harmonic measurement limit is dictated by the noise figure of the spectrum analyzer. Through adequate averaging with the video filter, the UUT harmonic level which is to be measured should be at least 4 dB over the noise figure so that the measurement error caused by the input noise is less than 1 dB.

From the above, the following rules for the measurement of large harmonic separations can be derived:

- Select an IF bandwidth as narrow as possible in order to reduce the noise figure.
- Select the RF attenuation as high as required so that the necessary harmonic separation can still be measured.

Note: *The mixer amplitude is the applied RF level reduced by the selected RF attenuation. The low distortion (LOW DISTORTION function) mode of the analyzer automatically sets the optimum RF attenuation for the best harmonic separation.*

The maximum harmonic separation is achieved when the harmonics level is equal to the inherent noise level of the receiver. The corresponding level at the mixer according to (2) is:

$$P_e[dBm] = \frac{P_{noise} / dBm + IP2}{2}$$

For a 30 Hz resolution bandwidth, (noise level < -140 dB, IP2 = 50 dBm), this level is -45 dBm. Therefore, according to (1) , the maximum measurable harmonic separation is 95 dB less 4 dB minimum signal-to-noise ratio.

2.1.2.2 Important Spectrum Analyzer Functions

In addition to frequency and level settings, the harmonic separation measurement requires, above all, the delta markers. Also, the MRK→ CF STEP SIZE function (marker frequency = center frequency step-width) is used in order to quickly measure the individual harmonics with the cursor keys.

There are several methods to measure harmonic content:

- The measurement of fundamental and harmonic signals in one measurement frequency range.
- The individual measurement of the harmonic separation in a narrow measurement frequency range. This method is preferred when high harmonic separation is to be measured (requires large dynamic range and, thus, narrow resolution bandwidth) or the frequency of the fundamental is very high, i.e., a very wide measurement frequency range is necessary.
- The measurement of fundamental and harmonics in two independent windows on the display screen (SPLIT SCREEN mode).

Example 1 describes the measurement of fundamental and harmonics in one measurement frequency range.

Example 2 describes the measurement of harmonic separation in separate measurement frequency ranges.

Example 3 shows the measurement of fundamental and harmonics in two independent windows on the display screen.

2.1.2.3 Measurement Procedure - Harmonic Separation – Example 1

The analyzer 10 MHz reference signal is used at the input signal. The connector EXT REF IN/OUT on the rear panel is connected to the analyzer front-panel RF INPUT. Since the output level is 7 dBm, the reference level must be set to 10 dBm.

The following setup steps are performed:

1. Reset the instrument.
2. Set the reference level to 10 dBm.
3. Connect the rear-panel 10 MHz reference signal to the analyzer input RF INPUT.
4. Set the start frequency to 5 MHz.
5. Set the stop frequency to 55 MHz.
6. Smooth the displayed noise with the video bandwidth.
7. Measure the fundamental signal with the marker.
8. Measure the harmonic separation with the delta marker.
9. Measure the separation of remaining harmonics.



1. Reset the analyzer.

➢ Press the *PRESET key.*



2. Set the reference level to 10 dBm.

➢ Press *REF* key in the *LEVEL* key field.

The entry field for the reference level appears on the display screen.



➢ Enter 10 via the numeric keypad and terminate with the *dBm* key.

3. Connect the 10 MHz-reference signal (output EXT REF IN/OUT) to the analyzer RF INPUT.



4. Set the start frequency to 5 MHz

➢ Press the *START* key in the *FREQUENCY* key field.

The entry window for the start frequency appears on the display screen.



➢ Enter 5 via the numeric keypad and terminate with the *MHz* key.

5. Set the stop frequency to 55 MHz

➢ Press the *STOP* key in the *FREQUENCY* key field.

The entry window for the stop frequency appears on the display screen.



➢ Enter 55 via the numeric keypad and terminate with the *MHz* key.



6. Smooth the displayed noise with the video bandwidth

➢ Press the *COUPLING* key in the *SWEEP* key field.

The *SWEEP-COUPLING* menu is opened.

The video bandwidth can now be either automatically coupled to the resolution bandwidth or manually entered.



either:

Automatic coupling of the video bandwidth to the measurement frequency range

➢ Press the *COUPLING RATIO* soft key.

The sub-menu for setting the automatic coupling of bandwidths to the measurement frequency range is opened.

➢ Press the *RBW / VBW NOISE* soft key *[10].*

The video bandwidth is set to a factor of 10 less than the resolution bandwidth. This smoothes the displayed noise.

➢ Press the menu change key .

The *COUPLING RATIO* submenu is closed.

or:

Manual input of the video bandwidth

➢ Press the *VIDEO BW MANUAL soft key.*

The entry field for the video bandwidth appears on the display screen.



➢ Enter 10 via the numeric keypad and terminate with the *kHz* key.

The analyzer displays the fundamental as well as the first to third harmonics (see Fig. 2.1-5).



Figure 2.1-5 The 10-MHz-fundamental and harmonics to 55 MHz

7. Measure the fundamental with the marker.

➢ Press the *NORMAL* key in *MARKER* key field.

The marker appears at the fundamental peak (see also level and frequency measurement step 5 of the PEAK SEARCH function).

The measured values can be read at the upper left of the display screen.

8: Activate the delta marker and measure the harmonic separation

➢ Press the *DELTA* key in the *MARKER* key field

The delta marker is active and appears on the fundamental.



➢ Press the *SEARCH* key in the *MARKER* key group .

The *SEARCH-MARKER* menu is opened.

➢ Press the *NEXT PEAK RIGHT* soft key.

The delta marker jumps to the first harmonic and measures the difference between the harmonic and the fundamental. The measured values can be read at the upper left of the display screen. In this example, the harmonic separation is approx. 40 dB (see Fig. 2.1-6).

9. Measure the separation of additional harmonics

➢ Press the *NEXT PEAK RIGHT* soft key.

The delta marker jumps to the next highest harmonic. The measured value can be read as before.



Figure 2.1-6 First harmonic separation: approx. 40 dB referred to the fundamental

2.1.2.4 Measurement Procedure - Harmonic Separation – Example 2

In example 2, the fundamental frequency of the test signal and the separation of the individual harmonics are measured. The reference to the fundamental is established with the REFERENCE FIXED marker, and the movement from harmonic to harmonic is performed with the MKR→ CF STEP SIZE and step keys. This method is recommended when the highest dynamic range is to be achieved.

The following measurement steps are carried out:

1. Reset the instrument.
2. Set the reference level to 10 dBm.
3. Connect the rear-panel 10 MHz reference signal (connector EXT REF IN/OUT) to the analyzer input RF INPUT.
4. Set the start frequency to 5 MHz.
5. Set the stop frequency to 55 MHz.
6. Smooth the displayed noise with the video bandwidth.
7. Measure the fundamental signal with the marker.
8. Reduce the measurement frequency range (ZOOM function):
9. Set the frequency step size to the fundamental frequency.
10. Save the reference value (REFERENCE FIXED)
11. Measure the separation to the first harmonic.
12. Measure the separations to the remaining harmonics.

Set the analyzer according to Example 1 up to and including "Measure the fundamental with the marker" (steps 1 to 7).

8. Reduce the measurement frequency range.



➢ Press the *NORMAL* key in the *MARKER key field*.

The *MARKER-NORMAL* menu is opened.

➢ Press the *MARKER ZOOM* soft key.

The entry field for the measurement frequency range appears on the display screen.



➢Enter 100 via the numeric keypad and terminate with the *kHz* key.

9. Set the frequency step size to the fundamental frequency

➢ Press the *MKR →* key in the *MARKER* key field

The *MARKER-MKR →* menu is opened.



➢ Press the *PEAK* soft key.

The marker appears at peak of the fundamental signal.

➢ Press the *MKR → CF STEP SIZE* soft key.

The step size used when setting the center frequency with the cursor keys is set equal to the marker frequency.



10. Fix reference value

➢ Press the *DELTA* key in the *MARKER* key field.

The *DELTA-MARKER* menu is opened.

➢ Press the *REFERENCE FIXED* soft key.

The position of the marker is now a curve-independent reference for the delta measurement, even when the actual reference point is not visible on the display screen.



Figure 2.1-7 Fundamental with REFERENCE FIXED marker



11. Measure the harmonic

➢ Press the *CENTER* key in the *FREQUENCY* key field.

The entry field for the center frequency appears on the display screen.



➢ Press the cursor key ⌓ in the *DATA VARIATION* key field.

The center frequency is increased by one step (= fundamental frequency).



➢ Press the *SEARCH* key in the *MARKER* key field.

The *SEARCH-MARKER* menu is opened.

➢ Press the *PEAK* softkey.

The delta marker appears at the first harmonic and measures the separation from harmonic to fundamental. The measured value is displayed in the marker field at the upper left of the display screen (see Fig. 2.1-8).

12. Measure the separation of additional harmonics

➢ Repeat all of step 11.

The center frequency is once again increased by the frequency of the fundamental. The delta marker thus appears at the next harmonic.



Figure 2.1-8 Measurement of the first harmonic

Note: *The spurious harmonics generated internal to the analyzer can be easily recognised by switching in additional RF attenuation. When an additional 10 dB attenuation is inserted, the displayed level of harmonics generated by the analyzer will be reduced by 10 dB, however, harmonics from the UUT will remain unchanged. This assumes that the receiver noise is substantially below the displayed level.*

2.1.2.5 Measurement Procedure - Harmonic Separation – Example 3

The measurement of fundamental and harmonics can also be performed in two independent windows on the display screen (SPLIT-SCREEN mode). This mode permits the simultaneous presentation of the fundamental and harmonics with higher resolution and dynamic range.

The following measurement steps are carried out:

1. Reset the instrument.
2. Set the reference level to 10 dBm.
3. Connect the rear-panel 10 MHz reference signal (connector EXT REF IN/OUT) to the analyzer input RF INPUT.
4. Set the start frequency to 5 MHz.
5. Set the stop frequency to 55 MHz.
6. Smooth the displayed noise with the video bandwidth.
7. Measure the fundamental signal with the marker.
8. Reduce the measurement frequency range (ZOOM function):
9. Set the frequency step size to the fundamental frequency.
10. Set the display to two measurement windows.
11. Uncouple the window settings.
12. Measure the harmonic separation.

Set the analyzer according to Example 2 up to and including " Set the frequency step size to the fundamental frequency" (steps 1 to 9).



10. Set the display to two uncoupled measurement windows.

➢ Press the *DISPLAY* key in the *SYSTEM* key field.

The *SYSTEM DISPLAY* menu is opened.

➢ Press the *SPLIT SCREEN* soft key.

Two windows are displayed simultaneously on the display screen (see Fig. 2.1-9). The upper measurement window is called Screen A and the lower is called Screen B. At the initial turn-on, both measurement windows are coupled, i.e., changes in settings such as frequency or levels take place in both windows.



11. Uncouple the window settings

➢ Press the *SCREEN COUPLING* soft key.

The *SCREEN COUPLING* sub-menu is opened.



➢ Press the *SCREEN UNCOUPLED* soft key .

The settings for each measurement window can now be selected independently. The entry is assigned to either *ACTIVE SCREEN A* or *ACTIVE SCREEN B* as selected by the soft key in the main menu window.



Figure 2.1-9 SPLIT-SCREEN Mode



12. Measure the harmonic in the lower measurement window SCREEN B.

➢ Press the menu change key ⌂ .

The main menu is opened.

➢ Press the *ACTIVE SCREEN B* soft key.

The following entries are now valid for the lower window which is used to measure the harmonic separation.



➢ Press the *CENTER* key in the *FREQUENCY* key field.

The entry field for the center frequency appears on the display screen.



➢ Press the cursor key ⌂ in the *DATA VARIATION* key field.

The center frequency is increased by one step. (= fundamental frequency).



➢ Press the *SEARCH* key in the *MARKER* key field.

The *SEARCH-MARKER* menu is opened.

➢ Press the *PEAK* soft key.

A marker appears at the first harmonic and measures the level of the harmonic. The measured value is displayed in the marker field at the upper left of the second measurement window (see Fig. 2.1-10).



Figure 2.1-10 Alternate representation of fundamental and first harmonic

2.1.3 Measurement of Intermodulation Distortions

2.1.3.1 Measuring Task

If several signals are applied to a transmission quadripole with a non-linear characteristic, intermodulation products occur at its output due to addition and subtraction of the signals. The non-linear characteristic causes harmonics of the information signals to occur, which are mixed up at the characteristic. The low-order mixture products are particularly significant since they have the highest levels and are close to the information signals. The third-order intermodulation product causes the most significant distortions. In case of two-tone modulation it is the mixture product of the first information signal and the first harmonic of the second information signal.
The frequencies of the spurious signals occur with an offset of the information signals above and below the information signals. Figure 2.1-11 shows the intermodulation products P_{S1} and P_{S2}, which are obtained from the two information signals P_{N1} and P_{N2}.



Fig. 2.1-11 Intermodulation products P_{S1} and P_{S2}

The intermodulation product at f_{S2} is obtained by mixture of the first harmonic of the information signal P_{N2} with the signal P_{N1}, the intermodulation product at f_{S1} by mixture of the first harmonic of the information signal P_{N1} with the signal P_{N2} .

$f_{s1} = 2 \times f_{n1} - f_{n2}$ (1)

$f_{s2} = 2 \times f_{n2} - f_{n1}$ (2)

The level of the spurious products depends on the level of the information signals. If both information signals are increased by 1 dB, the level of the spurious responses increases by 3 dB. I.e., the offset a_{d3} of the spurious responses decreases by 2 dB. This is illustrated by fig. 2.1-12.



Fig. 2.1-12 Dependance of the spurious product level from the level of the information signals

The information signals at the output of a four-terminal network increase as the input level increases as long as the input level is in the linear range. If the level changes by 1 dB at the input, it also changes by 1 dB at the output. At a specified input level the quadripole compresses and the output level does not increase any more. The third-order intermodulation products increase three times as fast as the information signals. The intercept point is the fictitious level where both lines intersect. It cannot be measured directly since the wanted level is limited by the maximum output power of the quadripole.
It can however be calculated from the known gradients of the lines and the measured intermodulation offset a_{D3} with a given level using the following formula:

$$IP3 = \frac{a_{D3}}{2} + P_N \qquad (3)$$

If, e.g., the intermodulation offset is 60 dB and the input level P_N is -20 dBm, the third-order intercept IP3 is calculated as follows:

$$IP3 = \frac{60}{2} + (-20dBm) = 10dBm. \qquad (4)$$

2.1.3.2 Important Spectrum-Analyzer Functions

Correct setting of the RF attenuation is particularly important for intermodulation measurements. In the FSE, the attenuation can be set automatically according to the reference level. There are three coupling methods:

- RF ATTEN AUTO
- ATTEN AUTO LOW DIST
- ATTEN AUTO LOW NOISE

The coupling mode ATTEN AUTO LOW DIST is recommended to be used for measurement of intermodulation distortions since the intrinsic spurious products are minimized.

2.1.3.3 Measurement

In the following, measurement of the third-order intercept of an amplifier is described, by way of example.

Two signal generators with the frequencies f_1 and f_2 supply signals to the amplifier via a power divider. The output of the device under test is connected to the RF input of the FSE. The level of the two signal generators is the same and is selected such that the DUT is not overloaded.

f_1 = 99.5 MHz

f_2 = 100.5 MHz

Level at amplifier input = -20 dBm with f_1 and $f_2$1

Test setup:



The following measurement steps are carried out:

1. Reset the FSE.
2. Set the center frequency to 100 MHz.
3. Set the frequency-display range to 5 MHz (SPAN function).
4. Set the reference level to -10 dBm.
5. Set the resolution bandwidth to 10 kHz.
6. Set the RF attenuation for low-distortion mode.
7. Measure the intercept point using the markers.
8. Calculate IP3 from the measured offset and the signal level according to (4)

Cf. measurement example Level and Frequency Measurements (steps 1 to 3)

1. Reset the instrument.

2. Set the center frequency to 100 MHz.

3. Set the frequency-display range to 5 MHz.



4. Set the reference level to -10 dBm

➢ Press the *REF* key in the *LEVEL* key field.

The entry window for the reference level is displayed.



➢ Enter *-10* via the numeric keypad in the entry field and terminate the entry by pressing the *dBm* key.



5. Set the resolution bandwidth to 10 kHz

➢ Press the *COUPLING* key in the *SWEEP* key field.

The *SWEEP-COUPLING* menu is opened.



➢ Press the *RES BW MANUAL* softkey.

The entry field for the resolution bandwidth is displayed. .



➢ Enter *10* in the entry field via the numeric keypad and terminate the entry by pressing the *kHz* key.



6. Set low-distortion mode

➢ Press the *INPUT* key

The *INPUT* menu is opened.

either

➢ Press the *ATTEN AUTO LOW DIST* softkey.

The low-distortion mode is selected. Thus, the combination of input attenuation and IF gain is selected such that the internal intermodulation products are the smallest possible and the intermodulation-free range is as large as possible.

The FSE shows the measuring diagram in fig. 2.1-13



or

➢ Press the *RF ATTEN MANUAL softkey.*

The entry window for the RF attenuation is displayed .



➢ Vary the RF attenuation using the roll-key.

If the amplitude of the IM products doesn't change, the existing setting is sufficient
(see Fig. 2.1-13)



Fig. 2.1-13 Measuring diagram in low distortion mode

7. Measure the intercept point using the markers

➢ Press the *NORMAL* key in the *MARKER* key field.

The marker appears on the fundamental (see also level and frequency measurement step 5, PEAK SEARCH function).

The measured values can be read off at the upper left of screen.

➢ Press the *DELTA* key in the *MARKER* key field.

The delta marker is active. It appears on the fundamental.



either

➢ Move the marker to an intermodulation product using the roll-key (see Fig. 2.1-13).



or

➢ Press the *SEARCH* key of the *MARKER* keys.

The *SEARCH-MARKER* menu is opened.

➢ Press the *NEXT PEAK RIGHT* softkey until the delta marker appears on one of the IM products (see fig. 2.1-13).

8. Calculate IP3 from the measured offset and the signal level according to (4)

In the example, an intermodulation ratio of approx. 60 dB at a level of -10 dBm was measured. IP3 is thus:

$$IP3 = 60\ dB/2 + (-10dBm) = 20\ dBm$$

2.1.4 Time-domain Measurements with Pulsed Signals

2.1.4.1 Measuring Task

A lot of systems which handle pulsed signals do not only require measurement of the pulse width and the pulse repetition rate which can be derived from the spectrum but also assess the rise and fall time as well as the power ramping during the pulse. In particular, modern digital mobile radio systems which, like GSM e.g., employ the TDMA method, require the power to be measured versus time over a wide dynamic range.

Time-domain measurements are performed using the spectrum analyzer with ZERO SPAN selected. The analyzer operates as fix-tuned receiver on the set center frequency such that the signal power versus time is displayed.

2.1.4.2 Important Spectrum Analyzer Functions

Trigger functions such as video trigger and sweep settings such as blanking of the measured value (GAP SWEEP) are of particular importance for time-domain measurements. The pretrigger function of the GAP SWEEP just enables measurement of rise times since it allows for representation of measurements prior to the trigger point. The GAP function, which enables cutout of a part of the pulse allows for simultanous representation of both edges of a pulse signal on the screen at high time resolution. During the GAP time, the sweep and thus data acquisition at the time marked by the "GAP" line is interrupted and thus the pulse is not completely displayed (the part which is not important for this measurement is blanked) (see fig. 2.1-14).



Fig. 2.1-14 Parameter beim Meßwertausblendung – Gap Sweep

Note: *If the pretrigger time and the trg-to-gap time is 0 s, the gap time function has the same effect as a delayed trigger.*

2.1.4.3 Measurement

This example shows the measurement of the rise and fall times as well as the power ramping during the pulse.

The signal generator SME with built-in pulse modulation source SME-B4 is used as signal source. A signal generator providing for pulse modulation in conjunction with an external pulse generator may be used, instead.
Settings on the signal generator:

Frequency	900 MHz
Level	–5 dBm
Modulation	Pulse
Pulse width	ca. 600 µs
Pulse frequency	ca. 500 Hz

The following measuring steps are made:

1. Reset the instrument.
   The video bandwidth is thus set to 3 MHz.
2. Set the center frequency to 900 MHz.
3. Set the frequency display range to zero span.
4. Set the reference level to 0 dBm.
5. Set the resolution bandwidth to 2 MHz.
6. Set the sweep time to 1 ms.
7. Connect the RF output of the SME to the RF input of the FSE.
8. Set the video trigger.
9. Set the sweep time to 100 µs.
10. Set the trigger points.
11. Activate the gap sweep.

---

comp. measuring example - level and frequency measurement (steps 1 to 3)

1. Set the instrument to the default state. I.e., the video bandwidth is set to 3 MHz.

2. Set the center frequency to 900 MHz.

3. Set the frequency-display range to zero span.

Note: *With first calling of the zero span following preset, a resolution bandwidth of 1 MHz is automatically set. Apart from that, switching on the zero span always causes that resolution bandwidth to be set that was last set in zero span.*



4. Set the reference level to 0 dBm.

➢ Press the *REF* key in the *LEVEL* key field.

The entry field for the reference level appears on the display screen.



➢ Enter *0* in the entry field via the numeric keypad and terminate the entry by pressing the *MHz/ms* key.



5. Set the resolution bandwidth to 2 MHz

➢ Press the *COUPLING* key in the *SWEEP* key field.

The *SWEEP-COUPLING* menu is opened.



➢ Press the *RES BW MANUAL* soft key.

The entry field for the resolution bandwidth appears on the display screen.



➢ Enter *2* via the numeric key pad and terminate the entry by pressing the *MHz* key.



6. Set the sweep time to 1 ms

➢ Press the *SWEEP TIME MANUAL* softkey.

The entry field for the sweep time is opened.



➢ Enter *1* in the entry field via the numeric keypad and terminate the entry by pressing the *MHz* key.

7. Connect the RF output of the SME to the RF input of the FSE.



8. Initiate triggering by means of the display voltage (video trigger)

➢ Press the *TRIGGER* key in the *SWEEP* key field

The *TRIGGER* menu is opened.

➢ Press the *VIDEO* softkey.

A dashed horizontal line is displayed which marks the trigger level.



➢ Set the trigger level using the roll key such that a triggered display is obtained.
(see fig. 2.1-15)



9. Set the sweep time to 100 µs

➢ Press the *SWEEP TIME MANUAL* softkey.

The window for entering the sweep time is opened.



➢ Enter *100* via the numeric keypad and terminate the entry by pressing the *kHz/µs* key.



Fig. 2.1-15 Representation of pulse sequence with video trigger



10. Set the trigger points.

➢ Press the *SWEEP* key in the *SWEEP* keyfield.

The *SWEEP* menu is opened.



➢ Press the *GAP SWEEP SETTINGS* softkey.

The *GAP SWEEP SETTINGS* submenu for setting the trigger points is opened.

➢ Press the *PRE TRIGGER* softkey.

The entry field for the pretrigger is opened.



➢ Enter *10* via the numeric keypad in the entry field and terminate the entry by pressing the *kHz/µs* key.

➢ Press the *TRG TO GAP* softkey.

The entry field for the trigger-to-gap-time is opened.



➢ Enter *40* via the numeric keypad in the entry field and terminate the entry by pressing the *kHz/µs* key.

➢ Press the *GAP LENGTH* softkey.

The entry field for the length of the time gap is opened.



➢ Enter *540* in the entry field via the numeric keypad and terminate the entry by pressing the *kHz/µs* key.



11. Activate the measurement with mask-out of measured value

➢ Press the menu change key.

The right supplementary menu is opened.

➢ Press the *GAP SWEEP ON/OFF* key.

The measurement with blanking of measured value is activated. The measurement results are shown in figure 2.1-16



Fig. 2.1-16 Measured-value blanking for simultaneous display of rising and falling edge of a pulse signal. The position of the gap is indicated by the thick vertical line. The gap time is indicated via the double label 50 µs and 590 µs in the time axis.

This page is left blank intentionally.

2.2 Menu Overview

2.2.1 System Key Group




SYSTEM
PRESET
CAL
DISPLAY
CALIBRATE
CAL SHORT
CAL TOTAL
CAL RES BW
CAL LOG
Mod 30
CAL LO SUPP
(only with option FSE-B7)
CAL I/Q
PRESEL PEAK
CAL CORR ON OFF
CALIBRATE
CAL RESULTS
PAGE UP
PAGE DOWN


SYSTEM
PRESET
CAL
DISPLAY
INFO
INFO
FIRMWARE VERSIONS
HARDWARE+ OPTIONS
SELFTEST
SYSTEM MESSAGES
OPTIONS
SELFTEST
EXECUTE TESTS
SYSTEM MESSAGES
CLEAR MESSAGE
CLEAR ALL MESSAGES
UPDATE MESSAGES

2.2.2 Configuration Key Group




CONFIGURATION
MODE
SETUP
SETUP
TRANSDUCER
OPTIONS
REFERENCE INT EXT
EXT REF FREQUENCY
SERVICE
GENERAL SETUP
SERVICE
INPUT RF
INPUT CAL
NOISE SOURCE
ENTER PASSWORD
GENERAL SETUP
GPIB ADDRESS
USER PORT A
USER PORT B
COM PORT 1
COM PORT 2
TIME
DATE
MOUSE
EXTERNAL KEYBOARD
KEY CLICK ON OFF
TRANSDUCER
TRANSDUCER FACTOR
TRANSDUCER SET
EDIT TRD FACTOR
EDIT TRD SET
NEW FACTOR/SET
DELETE FACTOR/SET
PAGE UP
PAGE DOWN
EDIT TRD FACTOR
TRD FACTOR NAME
TRD FACTOR UNIT
TRD FACTOR VALUES
INSERT LINE
DELETE LINE
SAVE TRD FACTOR
EDIT TRANSD SET
TRANSD SET NAME
TRANSD SET UNIT
TRANSD SET RANGES
INSERT LINE
DELETE LINE
SAVE TRD SET
PAGE UP
PAGE DOWN

2.2.3 Hardcopy Key Group



without soft key menu

2.2.4 Frequency Key Group



2.2.5 Level Key Group, Input Key




LEVEL
REF
RANGE
LEVEL RANGE
LOG 120 dB
LOG 100 dB
LOG 50 dB
LOG 20 dB
LOG 10 dB
LOG MANUAL
LINEAR/dB
LINEAR/%
GRID ABS REL
INPUT
INPUT
RF ATTEN MANUAL
ATTEN AUTO NORMAL
ATTEN AUTO LOW NOISE
ATTEN AUTO LOW DIST
MIXER LEVEL
INPUT SELECT
INPUT SELECT
RF INPUT 50 OHM
RF INPUT 75 OHM/RAM
RF INPUT 75 OHM/RAZ

2.2.6 Marker Key Group



MARKER SEARCH
PEAK
NEXT PEAK
NEXT PEAK RIGHT
NEXT PEAK LEFT
SUM MKR ON OFF
SUMMARY MARKER
SEARCH LIM ON OFF
SELECT MARKER
ACTIVE MKR DELTA

SUMMARY MARKER
RMS
MEAN
PEAK HOLD ON OFF
AVERAGE ON OFF
SWEEP COUNT
ALL SUM MKR OFF

MARKER SEARCH
MIN
NEXT MIN
NEXT MIN RIGHT
NEXT MIN LEFT
EXCLUDE LO ON OFF
PEAK EXCURSION
SELECT MARKER
ACTIVE MKR DELTA

MARKER SEARCH
N DB DOWN
SHAPE FACT 60/3 DB
SHAPE FACT 60/6 DB
SELECT MARKER
ACTIVE MKR DELTA



DELTA MARKER

- DELTA 1
- DELTA 2
- DELTA 3
- DELTA 4
- PHASE NOISE
- (blank)
- REFERENCE POINT ⬇
- REFERENCE FIXED
- DELTA MKR ABS REL
- ALL DELTA OFF

REFERENCE POINT

- REF POINT LEVEL
- REF POINT LVL OFFSET
- REF POINT FREQUENCY
- REF POINT TIME
- (blank)
- (blank)
- (blank)
- (blank)
- (blank)
- (blank)



MARKER →

- PEAK
- MKR→ CENTER
- MKR→ REF LEVEL
- (blank)
- MKR->CF STEPSIZE
- MKR→ START
- MKR→ STOP
- MKR→ TRACE
- SELECT MARKER
- ACTIVE MKR DELTA

2.2.7 Lines Key Group





2.2.8 Trace Key Group



2.2.9 Sweep Key Group




SWEEP
TRIGGER
SWEEP
RBW
VBW
SWT
COUPLING
COUPLED FUNCTIONS
RES BW MANUAL
RES BW AUTO
VIDEO BW MANUAL
VIDEO BW AUTO
SWEEP TIME MANUAL
SWEEP TIME AUTO
COUPLING DEFAULT
COUPLING RATIO
COUPLED FUNCTIONS
RBW 1kHz ANA DIG
RBW<=1kHz NORM FFT
MAIN PLL BANDWIDTH
COUPLING RATIO
RBW / VBW SINE [1]
RBW / VBW PULSE [.1]
RBW / VBW NOISE [10]
RBW / VBW MANUAL
SPAN / RBW AUTO [50]
SPAN / RBW MANUAL

2.2.10 Memory Key Group




MEMORY
SAVE
RECALL
CONFIG
MEMORY RECALL
EDIT NAME
EDIT PATH
AUTO RECALL
SEL ITEMS TO RECALL
DATA SET LIST
DATA SET CLEAR
DATA SET CLEAR ALL
PAGE UP
PAGE DOWN
SEL ITEMS TO RECALL
SELECT ITEMS
ENABLE ALL ITEMS
DISABLE ALL ITEMS
DEFAULT CONFIG

2.2.11 User Key Group



This page is intentionally left blank.

2.3 Basic Steps of Operation

After switching on the instrument a message about the BIOS version installed is displayed for a few seconds (e.g. "Analyzer BIOS Rev. 1.2").

The results of the self test is displayed next.

```
MAINPROCESSOR
SELFTEST STARTING ...
TESTING CMOS ...
DMA CHANNEL ...
INTERRUPTS ...
NMI ...
BASE MEMORY ...
EXTENDED MEMORY ...
HD CAPACITY ...
INIT FLOPPY DRIVE ...
INIT HD ...

SELFTEST DONE,
SYSTEM IS BOOTING ...
```

Subsequently, the instrument starts measuring. The type of measurement which was activated prior to last switch-off is performed, as long as no other instrument configuration was selected via *AUTO RECALL* in the *MEMORY RECALL* menu. While the measurement is being performed other menus and measuring modes can be entered simultaneously. The measurement results and the settings of the parameters are displayed on the screen.

2.3.1 The Screen

The screen informs continuously on the results and parameters of the selected measuring functions. It shows the assignment of the softkeys and menus, which are required for setting the measuring parameters. The display of test results, the softkey labeling and the type of menu depend on the selected measuring function.

The screen is subdivided into two areas:



Fig. 2.3-1 Subdivision of screen

Diagram area This area contains the measuring diagrams and other measured-value information as well as the parameters and status information which are important for analysis of the results.
In addition, message fields, entry windows and tables may be shown in this area.

Softkey area This area contains the instrument functions which can be selected via the softkeys. The softkey area is not superimposed by other graphics.

2.3.1.1 Diagram Area



Fig. 2.3-2 Subdivision of the FSE screen in analyzer mode (without measuring diagram)



Fig. 2.3-3 Measuring diagram

The following graphic elements are displayed in the diagram area:

Status information Hint at irregularity (e.g. UNCAL)

In addition the status display displays MAX / REF LVL, if the maximum level and the reference level have different values.

UNCAL "UNCAL" is indicated under the following circumstances:

- no valid calibration data (Status CALIBRATION FAILED in table CAL RESULTS), may occur after a cold start following a firmware update
  ⇒ Total calibration
- correction data are switched off (menu CAL, CAL CORR OFF).
  ⇒ switch on CAL CORR ON or PRESET
- Sweep time too short for current instrument settings (span, resolution bandwidth, video band width).
  ⇒ increase sweep time
- resolution bandwidth too small for set symbol rate (option FSE-B7: digital demodulation) .
  ⇒ increase resolution bandwidth

OVLD „Overload“ is indicated when the input mixer is overloaded
⇒ Increase input attenuation

IFOVLD „IF Overload“ is indicated when overload occurs after the input mixer.
⇒ Increase reference level

DIFOVL „Digital IF Overload“ is indicated when the digital resolution filter is overloaded.
⇒ Increase reference level

ExtRef „External Reference“ is indicated when the instrument is set to *REFERENCE EXT* (menu *SETUP*), but the reference signal is missing at the rear panel connector.
⇒ Ceck input signal of external reference

LO unl „LO unlock“ is indicated when the 1st LO is unlocked (moduleerror).

LO Lvl „LO Level“ is indicated when the output level of the 1st LO is too small (module error).

LO LvD „LO Level Digital IF“ is indicated when the output level of the oscillator of module Digital IF is too small (module error).

OCXO „OCXO cold“ is indicated when the crystal oscillator has not yet reached ist operating temperature. This indication vanishes after a few minutes after switch on.

UNLD „Underload“ is indicated when the analyzer is not in ist optimal dynamic range. In this case the measuring accuracy is not optimal. This indication is only output in vector analyzer operating mode only with option FSE-B7
⇒ Decrease reference level

Marker/Deltamarker

This label displays the position of the last selected marker or deltamarker in the x and y-directions and the marker/deltamarker index. As additional information, 2 fields in square brackets are provided which contain the curve which the marker is assigned to and the active measuring function of the marker indicated. The measuring function of the markers in the second field is indicated by the following abbreviations:

CNT frequency counter active

TRK signal track active

NOI noise measurement active

The marker text has the same color as the trace which the marker is assigned to. If, for example, the active marker is assigned to trace 1, and trace 1 is yellow, the marker text will be yellow, too.

Hardware settings

Analyzer mode

RBW Indication of the set resolution bandwidth.

VBW Indication of the set video bandwidth.

SWT Indication of the set sweep time.

RF Att Indication of the set RF attenuation.

Mixer Indication of the user set level at the input mixer (only when level differs from standard settings (= level of the reference level REF LVL).

Unit Indication of the level unit of the measuring results and the associated setting and test parameters in full length. This label is particularly important for selection of units with more than 4 digits, since they can only be indicated as dB* in the other labels (except for marker).

Tracking generator mode Only available with one of the options FSE-B8/9/10/11

TG Lvl Indication of the set output level of the tracking generator

Vector Analyzer mode Only available with option FSE-B7

CF Indication of the set center frequency

SR Indication of the symbol rate

Demod Indication of the switched on demodulator.

Standard Indication of the set standard (e.g. GSM)

DEMOD BW Indication of the demodulation bandwidth for analog demodulation.

Grid

X-axis: frequency or time,
Y-axis: level

Screen FSE

Instrument settings (Enhancement Labels)

Indication of user instrument settings which influence the measuring result and which are not immediately obvious when viewing the measured values.

***** The current instrument setting does not correspond to the one which applied when one of the displayed curves had been stored. This occurs under the following circumstances:

- The instrument setting is modified while a sweep is being performed.
- The instrument setting is modified in SINGLE SWEEP mode subsequent to the end of the sweep and no new sweep is started.
- The instrument setting is modified after setting the trace to VIEW.

The display is retained until the cause is eliminated by the user. I.e., either a new sweep is started (SINGLE SWEEP mode), or the trace of interest is switched to BLANK (all cases).

A Identification for screen A. Screen A is activated for the entry of test parameters.

B Identification for screen B. Screen B is activated for the entry of test parameters.

C If, in the Vector Analyzer (Option FSE-B7) mode, the inphase and quadrature signal is displayed in the measurement window A, the window is subdivided into two diagrams. The upper diagram is marked with an A and the bottom one with C.

D If, in the Vector Analyzer (Option FSE-B7) mode, the inphase and quadrature signal is displayed in the measurement window B, the window is subdivided into two diagrams. The upper diagram is marked with an B and the bottom one with D.

LN The automatic setting of the input attenuation is set to ATTEN LOW NOISE.

LD The automatic setting of the input attenuation is set to ATTEN LOW DISTORTION.

NOR Normalization is activated; high accuracy (only with one of the options FSE-B8/9/10/11).

APP Normalization is activated; medium accuracy (only with one of the options FSE-B8/9/10/11).

TDF A antenna correction factor (*TRANSDUCER FACTOR*) is switched on.

TDS A set of antenna correction factors (*TRANSDUCER SETS*) is switched on.

LVL A level offset ≠ 0 dB has been set. A level offset of the installed tracking generator (option) leads to the same display.

FRQ A frequency offset ≠ 0 Hz has been set.

SGL The sweep is set to SINGLE SWEEP.

1-<n> Subtraction Trace 1 - Trace <n> active (<n>: numeric value) or subtraction Trace 1 - Reference Line active (<n>: R)

2-<n> Subtraction Trace 2 - Trace <n> active (<n>: numeric value) or subtraction Trace 1 - Reference Line active (<n>: R)

3-<n> Subtraction Trace 3 - Trace <n> active (<n>: numeric value) or subtraction Trace 1 - Reference Line active (<n>: R)

4-<n> Subtraction Trace 4 - Trace <n> active (<n>: numeric value) or subtraction Trace 1 - Reference Line active (<n>: R)

<n>AP For trace <n> (n = 1 to 4) the detector is set to AUTOPEAK.

<n>MA For trace <n> (n = 1 to 4) the detector is set to MAX PEAK.

<n>MI For trace <n> (n = 1 to 4) the detector is set to MIN PEAK.

<n>SA For trace <n> (n = 1 to 4) the detector is set to SAMPLE..

<n>AV For trace <n> (n = 1 to 4) the detector is set to AVERAGE..

<n>RM For trace <n> (n = 1 to 4) the detector is set to RMS.

GAT The frequency sweep is controlled via the *EXT TRIG/GATE* input of the instrument.

TRG The instrument is not triggered in *FREE RUN* mode.

EXT The unit is configured for operation with external reference

75 Ω The input impedance of the unit is set to 75 Ω.

MAC Macro recording active.

PRN A printer output is active. PRN overwrites the enhancement label MAC.

<n>VIEW Trace <n> (n = 1 to 4) is set to VIEW

<n>AVG Trace <n> (n = 1 to 4) is set AVERAGE

MIX The external mixer output is switched on (option FSE-B21).

SID External mixer output: SIGNAL ID is switched on (option FSE-B21).

AID External mixer output: AUTO ID is switched on (option FSE-B21).

Frequency axis labeling Display of the x-scaling.

123.4 ms/Div

The distance between two grid lines is displayed in this label.

Center 1.2345678901234 GHz

Start 1.2345678901234 GHz

The set center frequency or start frequency is displayed in this label depending on whether the keys CENTER/SPAN or START/STOP were last pressed.
If span = 0 Hz, the center frequency is always displayed.

Span 1.2345678901234 GHz

Stop 1.2345678901234 GHz

Trigger 1.234 ms

The set frequency range (*SPAN*) or the stop frequency is displayed, depending on whether the keys CENTER/SPAN or START/STOP were last pressed.
If span = 0 Hz, the trigger moment (*PRETRIGGER*) is displayed.

Optional labeling Optional indication of date, time and comment.

14.Jun 97 12:13

Level axis labeling Display of the y-scaling.

Entry window The data entry window is superimposed in the diagram area, if required.

Reference level/ Max. level Display of the set reference level or combined display of maximum level and reference level.

Limit lines Limit lines are used to mark level curves or spectral distributions which must not be exceeded or dropped below.

Traces 1 to 4 Up to 4 traces can be displayed simultaneously.

Display lines Utilities for trace analysis.

The FSE provides two display modes:

- Full Screen: 1 window, all traces are displayed in one window.
- Split Screen: 2 windows, traces, grid and labels are distributed on the two windows.

2.3.1.2 Split Screen



Fig. 2.3-4 Subdivision of the screen in Split Screen mode

In Split Screen mode, the screen is divided into two halves. The upper half is assigned Screen A, the lower one Screen B. The settings for measurement can be selected independently for both screens. E.g., a spectrum may be displayed in Screen A and a time amplitude in the time range is displayed in Screen B. The window for entry of the measuring parameters or the marker operation is selected using the *DISPLAY* key.

The assignment of traces to the windows is fixed and cannot be modified.

Table 2.3-1 Assignment of traces to windows with split screen

Trace 1:	upper (screen A)
Trace 2:	lower (screen B)
Trace 3:	upper (screen A)
Trace 4:	lower (screen B)

The two windows can be subdivided into two measurement diagrams. This applies to separate display of measurement values, eg to the display of the inphase and quadrature signal in vector analysis. Screen A is divided into diagrams A and C, screen B is divided in diagrams B and D.

2.3.1.3 Softkey Area

The setup of the softkey area is independent of the operating mode. It consists of the following graphic elements:



Fig. 2.3-5 Setup of the softkey area

The softkeys have different functions depending on the instrument state. Therefore, their labeling can be varied. The function and current state of the softkeys is indicated in the label by different texts and colors. The color assignment is factory-set as follows:

Table 2.3-2 Factory-set color assignment of soft keys

Softkey color	Meaning
gray	Softkey switched off
green	Softkey switched on
red	Softkey switched on and data entry active

These colors can be changed by the user as desired.
A softkey is switched on or off by pressing the respective hardkey. If a mouse is connected to the instrument, the softkey label on the display can be selected using the mouse, alternatively.

If instrument functions depend on **options**, the associated softkeys may be completely masked out, if the options are not fitted. If instrument functions are not available temporarily due to different **operating modes,** the corresponding softkeys are disabled. Actuating the softkey has no function then. In this case, the softkey is represented "plane", i.e., without 3D effect.

2.3.2 Changing the Menu

With manual control, the FSE can be operated via the front-panel keys, the external keyboard or with a mouse.

Operation is menu-controlled. Various **softkey menus** are displayed depending on the instrument status. The individual menus constitute the so-called menu tree. The top menu (the root of the menu tree) is always called by means of a keystroke. The individual softkeys are then used to branch into further menus (submenus).



Fig. 2.3-6 Theory of menu selection

Each softkey menu consists of max. 30 softkeys, 10 softkeys being arranged in a main menu, 10 in a left-hand supplementary menu and 10 in a right-hand supplementary menu. In contrast to empty main menus, empty supplementary menus are not displayed. Arrows at the lower edge of the softkey area indicate whether a supplementary menu exists or not.



Fig. 2.3-7 Switching between main menu and supplementary menu

The menu arrows help to orient inside the menu tree.

Examples: ⇦ ⇨ This menu has a right-hand and a lefthand supplementary menu. It is the root menu since there is no ⇧ arrow.

⇧ ⇨ Only a right-hand supplementary menu or the upper menu can be accessed from this menu.

The MENU keys allow for selecting the main menu and the supplementary menus. If a mouse is connected to the instrument, the menu arrows can be selected to enter the respective menus. The MENU keys have the following functions:



When this key is pressed, the FSE enters the left-hand supplementary menu.

This key is pressed to call the upper menu which is located in the next higher hierarchical level in the menu tree. Several menus provide for automatic change, i.e., return to the next higher menu is caused automatically after pressing a softkey.

The right-hand supplementary menu is selected by pressing this key.
A supplementary menu cannot be selected from another supplementary menu but only via the main menu.

The labelling of all softkeys which call a submenu includes an arrow. Selection of a submenu is always effected via a softkey.

The softkeys are masked out in remote mode and during macro processing.

2.3.3 Setting the Parameters

2.3.3.1 Data Entry

Instrument parameters can be entered in an entry window or in a table via the numeric keypad on the front panel (*DATA ENTRY*), an external keyboard and the roll-key.
The numeric keypad *DATA ENTRY* is provided for entry of numeric parameters (e.g., the start frequency). The roll-key is used for fast incrementing or decrementing of numeric parameters with a defined step size.

It is advisable to use the external keyboard for definition of alphanumeric parameters (e.g., file names) since the front panel does not allow for entry of letters. If no external keyboard is provided, the help line editor is called automatically for entry of alphanumeric parameters.

2.3.3.1.1 Numeric Keypad on the Front Panel

The keys are assigned the following functions:

Number keys

Changes the sign of the mantissa or exponent of a numeric parameter. A "-" is inserted at the cursor position in case of an alphanumeric parameter.

Inserts a decimal point "." at the cursor position in the numeric string.



Provide the numeric value entered with the selected unit and terminate the entry.

The unit keys are all assigned the value "1" if quantities are indicated without dimensions in order to prevent faulty operations The unit keys thus adopt the function of an ENTER key. The same applies for an alphanumeric entry field.

Adds an exponent (E-xx) to the end of the numeric string.

Deletes the character left to the cursor with numeric entry.
After entry has been terminated it allows for toggling between the current parameter and the previous value (UNDO function).

Exit from the entry window and removal from screen prior or subsequent to entry.
Complete deletion of the entry string just being entered during numeric entry.
Deletion of the system messages or warnings which are displayed in an individual field.

2.3.3.1.2 Roll-key and Cursor Keys



The roll-key has various functions.

- With numeric entry, the instrument parameter is incremented (turning clockwise) or decremented (turning counterclockwise) at a defined step size.

  The step size may be equal to or smaller (e.g., 1/10) than the step size being defined for the cursor keys (see description of the *STEP* key).
- In tables, the roll-key can be used to shift the cursor horizontally or vertically when no entry window is open. The direction (horizontal/ vertical) is switched over using the cursor keys.
- The roll-key is used with the help-line editor to select the individual letters.
- It can be used to shift markers, display lines, limit lines etc.

The roll-key provides an acceleration algorithm, i.e., the variation step size increases with increasing rotational speed.

Cursor keys:



With numeric entry, the keys ⏶ or ⏷ are used to increase or decrease the instrument parameter by the selected step size. The keys are disabled With alphanumeric entry, the keys are used to toggle between the editing line and the help line editor.

The keys ⏴ and ⏵ are used to shift the cursor inside the entry window to reach a particular position in the number string.

In tables, the cursor keys are used to shift the cursor between the lines and columns of the table.

2.3.3.2 Entry Windows

2.3.3.2.1 Setting Up the Entry Window

The instrument parameters are not entered at the location where the parameter is displayed but in an individual entry window.

The entry window is called by a softkey or a hardkey and is used for definition of numeric or alphanumeric instrument parameters (START FREQUENCY by way of example):


START FREQUENCY
10.2457535 GHZ
START FREQUENCY OUT OF RANGE
Headline with parameter designation
Editing line with parameter value and unit
Status and error messages

Fig. 2.3-8 Setup of an entry window

Subsequent to calling the entry window the current parameter value including the unit is displayed in the editing line. Status and error messges which refer to the current entry are displayed in the third and (optionally) fourth line.

The entry window is displayed in the left upper edge of the active measuring window with the default setting. When a mouse is connected to the instrument, open entry windows can be shifted to any position on the screen provided that they do not cover the softkey line. The new position is valid until measuring window is selected. The data entry window is represented transparent or non-transparent, as required.

Alphanumeric parameters are displayed as a simple character string in the editing line. Numeric parameters which consist of mantissa, exponent and unit are set up as follows:



Fig. 2.3-9 Setup of numeric parameters

Mantissa: The first character is the sign of the mantissa, the positive sign is not displayed. The actual numeric value follows. The number of digits depends on the instrument parameter. The cursor may be shifted to the first digit of the mantissa at maximum, however, it may not precede the sign. The decimal point can be set as required.

Exponent: The exponent is separated from mantissa by a space character. The sign field of the exponent follows the "E", the positive sign "+" being not displayed similar to the representation of the mantissa. The cursor skips the "E" and the sign field. Two characters are fixed for the exponent value.

Unit: The unit (not represented in editing mode) is separated from the exponent by a space character.

The number of digits which can be entered for each instrument parameter is limited by the width of the input field only, but not by the amount which is physically enabled. (Example: Levels should be indicated with two decimals. The user may, however, enter as many decimals as desired - the entered value is rounded accordingly).

There are two types of entry windows:



The editing line of the entry window for numeric parameters allows for display of up to 24 characters. Horizontal scrolling is not possible in the editing line.

The editing line of the entry window for alphanumeric parameters allows for display of up to 60 characters (cf. display section). Maximum 256 characters may be entered. Horizontal scrolling is possible.
If no external keyboard is provided, the three-line entry window is replaced by a letter field which allows for individual selection of characters using the cursor keys (see help line editor)

2.3.3.2.2 Editing of Numeric Parameters

Calling the entry window:

- Subsequent to calling the entry window, the current value of the numeric parameter including the unit is displayed in inverted color. The cursor is not displayed in this state. The transparent data entry window has no background color.
- The entry window is closed upon pressing the key CLR.

Editing mode:

- Pressing a number, sign or decimal point key causes the value and unit to be deleted. The new value is output left-justified. The individual characters are entered in insert mode. If the maximum amount of characters for the mantissa or the exponent has been entered, no further entry is possible (no horizontal scrolling). If characters are positioned to the right of the cursor, they are shifted right when reaching the maximum length and get lost.
- Pressing the keys DATA VARIATION ◁ or ▷ causes normal representation of the current value. The unit is no longer displayed and the cursor precedes the first digit of the mantissa (◁) or follows the last digit entered (▷). The DATA VARIATION keys ◁ and ▷ change the numeric value of the cursor.
- Pressing the DATA VARIATION keys △ or ▽ or the roll-key causes the original parameter value to be restored and modified according to the defined step size for this parameter.
- The data management of the instrument stores the previous value of a parameter in addition to the current value. The BACK key allows for toggling between these two values.

Termination and abortion of entry:

- The editing mode is terminated by pressing a unit key. The validity of the new parameter value is checked and accepted for the instrument setting. If an error occurs, a corresponding error message is displayed in the status line of the editing field, e.g., *"Out of range"*, *"Value adjusted"*, etc.
- Editing of a parameter can be aborted by pressing the key CLR. The original parameter is then displayed again. The entry window is closed by pressing the CLR key again.
- Pressing a key or softkey subsequent to starting the entry causes the entry to be aborted and the entry window to be closed. If the same softkey which has opened the entry window is activated during entry, the original value is restored and displayed.

2.3.3.2.3 Editing of Alphanumeric Parameters

Generally, the regulations for numeric parameters analogously apply for alphanumeric parameters. Note the exceptions given below:

- Alphanumeric parameters are not displayed with a unit.
- The four unit keys adopt the function of the ENTER key.
- Horizontal scrolling is possible in the editing line.
- Incrementing or decrementing cannot be effected via the keys ⏢, ⏣ or the roll-key.
- Pressing the sign key causes a "-" character to be inserted at the cursor position, the decimal point key causes insertion of a point ".".
- The exponent key has no function.

2.3.3.2.4 Help Line Editor

The help line editor allows for labelling or text entries to be made without an external keyboard being required. In this case, a field containing letters and special characters is added to the standard entry window. The help line editor is displayed automatically if no external keyboard is provided and an entry window for alphanumeric entry is opened.



Fig. 2.3-10 Help line editor

- The keys ⏢ and ⏣ are used to toggle between the editing line and the help line editor.
- The cursor can be positioned to the required character in the help line editor using the cursor keys and the roll-key.
- A character is entered in the editing line by pressing any of the unit keys.
- If the cursor is already located in the editing line, pressing a unit key terminates data entry.

2.3.3.3 Table Entry

The FSE uses numerous tables for indication and configuration of instrument parameters. The tables differ very much in the number of lines, columns and inscriptions and have a different functionality.

Tables are represented in a non-transparent form. The size is predefined and cannot be modified. If a mouse is connected, the tables may be shifted on the display without covering the softkeys. Tables can be superimposed by entry windows or suchlike.

Tables are mostly coupled to a softkey menu which provides further functions for editing table entries, e.g., deletion of tables, copying lines or columns, marking of table elements, restoring of default states etc. Another kind of tables is exclusively used for indication of instrument parameters and cannot be edited.

The definition of individual tables and the operation of particular editing functions can be looked up in the reference section with the description of the corresponding softkey menu.

The basic concept of operation is, however, the same for all tables. A differentiation is made between shifting mode and editing mode.

2.3.3.3.1 Shifting Mode

This mode is active subsequent to opening a table. The **cursor** is shifted between the table elements by means of the cursor keys. The table element which is below the cursor is represented in inverted color.



Fig. 2.3-11 Shifting mode

2.3.3.3.2 Editing Mode

A table element which is marked by a cursor can be editied as follows:

- by pressing one of the unit keys on the front panel or the *ENTER* key on the external keyboard.
- by a double-click of the mouse on the table element. If the clicked element is not yet marked by the cursor, the letter is positioned on the element, additionally.
- For numeric or alphanumeric instrument parameters, the editing operation may be started by entry of any number or letter on the front panel or on the external keyboard.

The data entry window, the selection list or the toggle editor are provided for this purpose.

After the editing operation has been terminated, the table enters the shifting mode again. The cursor is positioned automatically on the next table element.

2.3.4 Disabling the Control Elements - HOLD Key

The individual softkeys have the following functions:



The functions of the *HOLD* menu allow for disabling individual control elements or the complete instrument control. The LED above the *HOLD* key indicates that either the function *LOCK DATA* or *LOCK ALL* has been activated. The control can be enabled again by successively pressing the two *UNLOCK* softkeys in any order.

Switching off the instrument resets control such that the instrument can be normally operated again after subsequent switch-on.

After selecting the two UNLOCK soft keys, the instrument keyboard is enabled again. The LED above the HOLD key goes out.

Selection of soft key *LOCK DATA* causes the roll-key to be disabled in order to prevent a parameter from being varied by mistake.

Selection of *LOCK ALL* soft key disables the complete front panel (including the *PRESET* key and roll-key, not including the *UNLOCK* softkeys), the mouse and all keys of the external keyboard. Exit from the *HOLD* menu is no longer possible. Control is enabled again by actuating the two *UNLOCK* softkeys.

2.3.5 Setting the Stepsize - STEP Key

A number of numeric instrument parameters allow for step-by-step incrementing or decrementing the value in the editing line of the entry window using the keys ⏶ or ⏷ or the roll-key. The stepsize used with the cursor keys can be specified for the selected parameters in the *STEP* menu.

Notes: – *It is not possible to set the stepsize by all of the numeric parameters.*
– *An extended STEP menu is available by some parameters. The extra functions are described by the respective parameter.*
– *Setting the step size has no effect on the roll-key (the resolution of the roll-key is higher than that of the step size functuion)*



The *STEP* key opens the *STEP* menu for entry of the stepsize.

The stepsize of an instrument parameter can only be varied when this parameter is edited in an entry window.
The soft keys in the *STEP* menu are disabled if no instrumentnparameter is being varied or if the parameter being edited does not support stepsize variation (as is the case by all of the alphanumeric parameters.

The key ⏶ leads to exit from the *STEP* menu and automatic return to the previously active menu.

The softkey *STEPSIZE AUTO* causes the stepsize for the corresponding instrument parameter to be set automatically and be continuously varied with varying instrument settings (in accordance with other parameters).

Example:
The stepsize of the *CENTER* frequency depends on the selected span.

The softkey *STEPSIZE NORMAL* calls an entry window for definition of a stepsize by the user. The parameter whose stepsize is varied, is displayed in the headline of the entry window:



The stepsize remains constant until a new value is entered or until the STEPSIZE AUTO soft key is activated. It is no longer coupled to other instrument parameters.

2.3.6 Mouse and External Keyboard Control

2.3.6.1 External Keyboard Control

The connection of an external keyboard provides additional characters for the entry (letters and special characters). It is permitted to use both, front panel keys and the external keyboard, for control. The number, cursor and sign keys have the same effect as the corresponding front panel keys. A few keys of the external keyboard provide an extended functionality with entries or tables which is described in the Appendix E.

2.3.6.2 Data Entry Windows with Mouse Control

With a mouse being connected, additional functions are provided in the entry windows. Therefore, buttons are displayed in the entry window.

Essentially, the definitions which have been made for all types of entry window also apply for mouse control. However, note the following deviations:

- The so-called close-button is displayed on the left margin of the headline. Selecting this button via the mouse aborts the entry and closes the entry window. This corresponds to the function of the CLR key with manual control.
- In the numeric entry window, two buttons (⇕) are displayed on the left margin of the editing line. Simply clicking the buttons causes the parameter in the editing line to be incremented or decremented (similar to the keys ↑ / ↓ or the roll-key with manual control).
- The cursor can be positioned in the entry line by clicking a character using the mouse.
- A character in the letter window of the help line editor can be selected by a single click. A double click copies the character from the letter window into the editing line.
- Open entry windows can be shifted across the complete screen using the mouse; they must not, however, be superimposed on the softkey line. Shifting is performed by clicking the headline and pushing the mouse while he mouse-key is being pressed.

Example: Numeric entry window with mouse control



2.3.6.3 Mouse Control of Further Display Elements

To increase operating ease, all display and control elements (enhancement labels, softkeys, function labels, etc.), which are indicated on the instrument, can be mouse-controlled.

Double-klicking an display or control element opens the corresponding soft key menu. The assignment of soft keys/keys to display elements is shown in appendix E.

Klicking the right mouse key call all soft key menus one after the other.

This page is left blank intentionally.

2.4 General Configuration – *SYSTEM* and *CONFIGURATION* Key Groups

2.4.1 FSE Initial Configuration – *PRESET* Key



Using the *PRESET* key, the FSE can be brought to a predefined initial state equivalent to the state after power on. All previous setting are deleted if they were not previously saved in memory. Returning to the *PRESET* state is not critical with regard to an arbitrary signal which may still be present at the input as long as the signal is within the specified voltage range.

Note: *The initial state set by the PRESET key can be adapted to arbitrary applications using the AUTO RECALL function. This function implies that the AUTO RECALL dataset is loaded upon pressing the PRESET key. For further information refer to section 2.7.3.*

Pressing the *PRESET* key, causes the FSE to enter its initial state according to the following table:

Table 2.4-1 Initial State of FSE

Parameter	Setting				
	FSEA	**FSEB**	**FSEM**	**FSEK**	
Mode	analyzer	analyzer	analyzer	analyzer	
Center Frequency	1,75 GHz	3,5 GHz	13,25 GHz	20 GHz	
Center Frequency Step Width	350 MHz	700 MHz	2,65 GHz	4GHz	auto, 0.1×Span
Span	3,5 GHz	7 GHz	26,5 GHz	40 GHz	
RF Attenuation	10 dB	10 dB	10 dB	10 dB	auto
Ref Level	-20 dBm	-20 dBm	-20 dBm	- 20 dBm	
Level Range	100 dB log	100 dB log	100 dB log	100 dB log	
Detector	auto peak	auto peak	auto peak	auto peak	
Sweep Time	5 ms	5 ms	150 ms	225 ms	auto
Res BW	3 MHz	3 MHz	3 MHz	3 MHz	auto
Video BW	3 MHz	3 MHz	3 MHz	3 MHz	auto
Sweep	cont	cont	cont	cont	
Trigger	free run	free run	free run	free run	
Trace	1	1	1	1	clr write
Trace	2, 3, 4	2, 3, 4	2, 3, 4	2, 3, 4	blnk

2.4.2 Display Configuration – *DISPLAY Key*

The display of the measurement results on the FSE display screen takes place in either one or two measurement windows. In some cases, the two windows can be subdivided into two diagrams each, e. g. for the representation of the inphase and quadrature signal in the vector analyzer mode (option FSE-B7).

If only one window is used, this window fills the complete display screen. Two measurement windows are always placed over each other. The axes labelling and measurement settings are defined independently in each measurement window.

When two measurement windows are used, the settings can be chosen to be either coupled or fully independent from each other. The measurement procedure is always sequential.

New instrument settings can only be entered in the active measurement window. This window is marked on the upper right corner of the grid. Coupled settings are changed simultaneously in both windows at the time of entry.

The entry of the measurement parameters for each of the two windows can be either independent from one another using numerical inputs, or by graphical definition of the span through the use of level and frequency lines. The former case, e.g., may be used for harmonic or frequency converter measurements, and the latter case, for a zoom display of a frequency or level segment.



Figure 2.4-1 Split screen mode, screens uncoupled

SYSTEM DISPLAY menu:



The *DISPLAY* key calls a menu which is used to configure the display screen and to select the active measurement window in SPLIT-SCREEN mode.

2.4.2.1 Display Screen Mode Selection

SYSTEM DISPLAY menu:



The *FULL SCREEN* soft key configures the display screen to one measurement window. This is the default setting of the FSE.

In this mode, the *ACTIVE SCREEN A / ACTIVE SCREEN B* and *SCREEN COUPLING* soft keys are not used.

The *SPLIT SCREEN* soft key sets the display screen to show two measurement windows. The upper window is called *SCREEN A*, the lower is called *SCREEN B*.

If *SPLIT SCREEN* display is activated, the *ACTIVE SCREEN A* and *ACTIVE SCREEN B* soft keys are used to activate either window A or window B.

The entry of new settings is only possible for the active window.

When switching back to FULL SCREEN mode, the active measurement window is displayed.

If, in addition, the two windows are both subdivided into two diagrams, the *ACTIVE SCREEN A/B* softkeys activate the upper diagram, *ACTIVE SCREEN C/D* the lower diagram in each window.

2.4.2.2 Measurement Window Coupling

For the most part, the settings for the two windows can be either independently performed or coupled to one another. In many cases, when changes are made in one window (e.g., the reference level) it is desirable to also make the corresponding changes in the second window. The measurement window parameters which are to be coupled may be selected in the *SCREEN COUPLING* menu.

SYSTEM DISPLAY-SCREEN COUPLING submenu:



The *SCREEN COUPLING* soft key calls a sub-menu in which the coupling between the two measurement windows *SCREEN A* and *SCREEN B* can be defined. This coupling is only effective when both windows are displayed (*SPLIT SCREEN*).

In the default setting, all of the items which are selectable are also coupled.

The *MODE COUPLED* soft key switches the coupling of the operating mode (Analyzer, Vector Analyzer) on/off.



The *HORIZONTAL SCALING* soft key switches the coupled scaling of the horizontal axes on and off. In the frequency domain, the center frequency and the frequency span are identical. In the time domain, the sweep time for both windows is the same.

The *VERTICAL SCALING* soft key switches the coupled scaling of the vertical axes on and off. For a level measurement, this means that the reference level and the vertical resolution (*LEVEL RANGE*) are set to the same values in both windows.

The *COUPLING CONTROL* soft key switches the coupling of the trigger and gate parameters and of SWEEP COUNT and SWEEP SINGLE/ CONTINOUS on/off.



The *SCREENS UNCOUPLED* soft key switches all of the possible couplings between the measurement windows to off.

2.4.2.3 Display Screen Configuration

SYSTEM DISPLAY-CONFIG DISPLAY submenu:



The *CONFIG DISPLAY* soft key calls a submenu and its supplementary menu, in which the selection of color and brightness for the individual elements on the display screen takes place. The actual selection of the elements takes place in the corresponding menu table.

The color assignment of the soft keys is coupled with the color assignment of other display elements.

Changing for example the color of SOFTKEY STATE OFF causes the color of the table background to be changed at the same time. The same applies to SOFTKEY STATE DATA ENTRY and to SOFTKEY STATE ON and enhancement labels.

In the supplementary menu, date, time and a diagram label can be displayed on the screen.

The *SELECT OBJECT* soft key activates the SELECT DISPLAY OBJECT table, with which a graphics element can be selected. After selection, the brightness, tint and saturation of the selected element can be changed using the soft keys of the same name. The color changes can be seen immediately on the display screen.



The *BRIGHTNESS* soft key activates the entry of the brightness of the color for the selected element. The range of input values is 0 to 100%.

The *TINT* soft key activates the entry of the color tint of the selected element. The entered value is related to a continuous color spectrum ranging from red (0%) to blue (100%).

The *TINT* function is not available for monochrome (black/white) displays.

The *SATURATION* soft key activates the entry of the color saturation for the selected element.

The range of inputs is from 0 to 100%.

The *DEFAULT COLORS* soft key restores the default settings for brightness, color tint and color saturation for all display screen elements.

The *PREDEFINED COLORS* soft key activates a table, with which the predefined colors for the diplay screen elements can be selected.

The *LOGO* soft key switches the Rohde & Schwarz company logo displayed in the upper left corner of the display screen on or off.

The *FREQUENCY* soft key switches the displaying of frequency information on the screen on and off.

ON Frequency information is displayed.

OFF Frequency information is not outputted to the display. This can be used for example to protect confidential data.

The *TIME* soft key switches on or off the display of date and time at the lower edge of the diagram.

The *DISPLAY COMMENT* soft key activates the entry of a label comprising a maximum of 50 characters. This label is displayed at the lower edge of the diagram.
Pressing the soft key again causes the label to be switched off. The stored text, however, is not deleted.

SYSTEM DISPLAY-CONFIG DISPLAY DATAENTRY FIELD Untermenü:



The *DATAENTRY FIELD* soft key displays a submenu used to specify the position and characteristics of the data entry field.

The *DATAENTRY X* soft key shifts the position of the data entry field horizontally.

The *DATAENTRY Y* soft key shifts the position of the data entry field vertically.



The *DEFAULT POSITION* soft key positions the data entry field automatically. In general, its position is the upper left edge of the grid on the active screen.

The *DATAENTRY OPAQUE* soft key sets the data entry windows to opaque. This means that entry windows are underlayed with the background color for tables and that diagrams and traces behind an entry window can no longer be seen.

2.4.3 FSE Calibration – *CAL Key*

The FSE maintains its high measurement accuracy through the application of numerous self-calibration techniques. The *CAL* hard key provides a series of calibration functions which allow not only the calibration of the complete instrument, but also calibration functions which are specifically applicable to the measurement requirements of relevant instrument sections.

The measurement settings of the FSE are saved and, after calibration, completely restored. The calibration data valid before calibration are saved and, in case of a calibration abort, restored.

A window shows the progress of the calibration while it is running. ABORT can be used to abort the calibration at any time.



SYSTEM CAL menu:



The *CAL* key displays a menu with the available calibration functions.

2.4.3.1 Calibration Function Calls

SYSTEM CAL menu:

The *CAL SHORT* soft key starts a short calibration, in which the absolute gain of the analyzer as well as the gain errors of the selected bandwidth are corrected.

The *CAL TOTAL* soft key starts a complete calibration of the analyzer including additional partial calibrations shown in the menu.

UNCAL is displayed in the status line if calibration cannot be successfully completed or if the correction data are disabled (*CAL CORR* soft key= *OFF*).

The *CAL RES BW* soft key starts the correction of the center frequency, the bandwidth and the gain of the resolution filter.

The *CAL LOG* softkey starts the calibration of the linearity of the logarithmic amplifier.

The *CAL LO SUPP* softkey calibrates the compensation of the first oscillator at low frequencies. After calibration, the display of the internal oscillator at the frequency 0 Hz is very small.

It is recommended that the calibration be performed whenever sensitive measurements are to be made at low frequencies.

The softkey is only available on model 30 of FSE.



The *CAL I/Q* softkey calibrates the gain error of the I/Q demodulator.

The softkey is only available in conjunction with option FSE-B7.

The *PRESEL PEAK* softkey optimizes the tuning of the preselector for input signals in the frequency range above 7 GHz.

This calibration should be used whenever signal levels in the frequency range above 7 GHz are to be measured and high accuracy is desired.

If a marker is not active when the *PRESEL PEAK* softkey is pressed, marker 1 is activated as the reference marker and placed on the signal maximum in the active trace. Otherwise the active marker is used.

The following window is displayed on the screen while the peaking function is running. The function can be aborted at any time using the *ABORT* line. In this case, the correction value determined at the factory is restored.



The input signal's signal-to-noise ratio must be at least 10dB in order that the peaking function runs properly. Otherwise, the preselector may be set incorrectly, which would cause level errors by subsequent measurements.

If the instrument setting (start/stop frequency, sweep time) is changed after *PRESEL PEAK* has been called, the correction value for the preselector determined by the function is no longer used. Instead, the correction value determined at the factory is restored.

The softkey is only available by those FSE models which have an input frequency range above 7 GHz.

The *CAL CORR ON/OFF* soft key switches the calibration data on/off.

ON The status message depends upon the results of the total calibration

OFF The message *UNCAL* appears in the FSE status line.

2.4.3.2 Calibration Results

SYSTEM CAL menu:

The *CAL RESULTS* soft key in the right-hand supplementary menu calls the *CALIBRATION RESULTS* table, which shows the correction data found during calibration.

The *CALIBRATION RESULTS* table contains the following information:

page 1:

- date and time of the last total calibration
- overall results of the total calibration
- list of the calibration procedures according to function/module, including the correction values, the measured results and the individual results for each of the calibration procedures

The results for the individual calibration procedures are categorised and displayed as follows:

PASSED	calibration successful without restrictions
CHECK	deviations larger than expected, however, corrections could be performed
FAILED	deviations too large, no corrections were possible
ABORTED	calibration aborted

CALIBRATION RESULTS

```
CALIBRATION: PASSED
Last cal total: 05.Jun 1997 16:24:54

Calibration of IF Filters    PASSED
IF GAIN Adjust               PASSED
Bandwidth:
Filter  Cal Val [Hz] DAC Val State
  1kHz   2.806e+01    1679   PASSED
  2kHz   1.603e+01    2887   PASSED
  3kHz  -6.012e+00    3238   PASSED
  5kHz  -1.002e+01    3514   PASSED
 10kHz   1.804e+02    3703   PASSED
 20kHz   3.607e+02    3801   PASSED
 30kHz   8.417e+02    3831   PASSED
 50kHz   1.403e+03    3743   PASSED
100kHz   1.804e+03    3698   PASSED
200kHz   3.607e+03    3606   PASSED
300kHz   8.417e+03    3516   PASSED
500kHz   1.403e+04    3329   PASSED
  1MHz   2.806e+04    2881   PASSED
```

The *PAGE UP* and *PAGE DOWN* soft keys can be used to page through the table of calibration results.

2.4.4 Instrument Status and Measurement Parameters – INFO Key

SYSTEM INFO menu:



The *INFO* key is used to request general information concerning the instrument. These include:

- firmware version
- installed hardware and hardware options
- modification level of the individual modules
- self-test results with the option of calling self-test functions
- list of generated system messages
- installed firmware and hardware options.

2.4.4.1 Firmware Versions

SYSTEM INFO menu:

The *FIRMWARE VERSIONS* soft key opens two tables, which provide the following informations:

- Table MODEL displays the exact instrument model.

- In the FIRMWARE VERSION table, the version of each software component installed in the instrument is listed. The versions of programmable logic devices are also included if the firmware version of the device can be determined.



2.4.4.2 Hardware Configuration and Options

SYSTEM INFO menu:

The *HARDWARE+OPTIONS* soft key opens two tables in which the modules (INSTALLED COMPONENTS) installed in the instrument are listed.

- Table *MODEL* lists the instrument name and model:

MODEL
FSEA 30

- Table *INSTALLED COMPONENTS* consists of four columns:
  COMPONENT name of module
  MODEL INDEX model number of the module
  MODIF INDEX main modification index of the module
  HW CODE secondary modification index of the module

  These lists contain only the modules which are actually present in the instrument, i.e., the modules which were identified by the module recognition software.

INSTALLED COMPONENTS			
COMPONENT	MODEL INDEX	MODIF INDEX	HW CODE
Main Processor	4	n/a	0
Graphic Board	4	n/a	0
I/O Board	4	n/a	0
FRAC SYN	4	0	4
RF Module	4	0	4
2nd IF Converter	3	2	2
Detector	4	0	2
IF Filter	3	2	3
Digital IF	2	0	2



The *OPTIONS* softkey opens two tables listing the options installed.

FIRMWARE OPTIONS		
DESIGNATION	TYPE	CODE
FFT	B5	1938496289

Note: *New firmware options can be enabled in the SETUP menu.*

HARDWARE OPTIONS	
DESIGNATION	CODE
Low Phase Noise & OCXO	B4

2.4.4.3 Self Test

SYSTEM INFO-SELFTEST submenu:



The *SELFTEST* soft key opens a submenu with which the self test can be started.

The instrument has extensive self test functions which comprehensively test instrument functionality. In case of a fault, the instrument can locate a defective module on its own. The self test sequence is described in more detail in chapter 4 (Maintenance and Troubleshooting).

The *EXECUTE TESTS* soft key starts the test of the complete instrument. During the self test a window is displayed:

The functions are tested in the following order:

1. Modules main CPU, digital motherboard, graphics and the interfaces
2. Reference frequency conditioning, the synthesizer modules and all LO signals
3. All RF, IF and signal-weighting modules

If no failure occurs during the execution of the self test, the following message is displayed when the complete self test is finished:



If a failure occurs during the execution of the self test, the self test is immediately aborted and a message indicating the defective module and the defective function is displayed:



Further testing should be performed by an R&S service department.

2.4.4.4 System Messages

The *SYSTEM MESSAGES* soft key opens a submenu including a table in which the generated system messages are displayed. The most recent messages are at the top of the list.
The following information is presented:

NO	Device specific three digit error code (shown as XXX in the figure)
MESSAGE	Brief description of the reason for the message
COMPONENT	Hardware messages name of the affected module Software messages if needed, the name of the affected software components
DATE/TIME	Date and time of occurrence of the message

The system messages are displayed in various colors.

Red error message	The message has occurred since the last call to the *SYSTEM MESSAGES* menu,
Black error message	The message was already present at the last call.

SYSTEM INFO-SYSTEM MESSAGES submenu:



The *CLEAR MESSAGE* soft key deletes the message just selected.
All subsequent messages are shifted automatically one line upwards so that no empty lines exist. When the last message has been deleted, the selection bar also disappears.

The *CLEAR ALL MESSAGES* soft key deletes all messages.

The *UPDATE MESSAGES* soft key causes all newly arrived messages to be entered at the top of the table.
At this time, all messages previously indicated as "new" are displayed as "old" messages

2.4.5 Mode Selection – *MODE* Key

The FSE can be operated in one of several modes, each of which is different with respect to functionality and control. The differences in control, however, consist not only in the enabling/disabling of additional soft keys within existing soft key menus, but rather in the fact that existing menus are completely replaced by new menus and menu trees which are tailored to the functional requirements. In the simultaneous application of two measurement diagrams, two modes may also simultaneously enabled. Each mode can be assigned to a measurement window.

CONFIGURATION MODE menu



The *MODE* key opens the menu for selection of the mode.

Herein, the modes can be selected according to the available FSE options.

- Analyzer
- Tracking Generator
- Vector Signal Analysis and
- TV Demodulation

The *ANALYZER* soft key selects the *ANALYZER* mode.

The functions provided correspond to those of a conventional spectrum analyzer. The analyzer measures the frequency spectrum of the test signal over the selected frequency range with the selected resolution and sweep time, or, for a fixed frequency, displays the waveform of the video signal.

The *TRACKING GENERATOR* soft key selects the operating mode Scalar Network Analysis.
The softkey is only available if FSE is equipped with one of the following options: FSE-B8/B9/B10 and B11. For a detailed description of operation see manual of options.

The *TV DEMOD* softkey selects the operating mode TV Demodulation.
The softkey is only available if FSE is equipped with Option FSE-B3. For a detailed description of operation see manual of options.

Softkey *VECTOR ANALYZER* selects the vector analysis mode.

The softkey is only available if FSE is equipped with Option FSE-B7.

In the vector analyzer mode the FSE is automatically set to a fixed frequency (centre frequency) since vector analysis can only be carried out on one frequency.
The IF signal is digitized by the selected resolution bandwidth after filtering and mixed into the baseband by a digital mixer. Further processing is via digital signal processors which display the time characteristic of the amplitude or phase. As an option, the baseband can also be demodulated and the demodulated signal can be displayed. Principally any type of modulation (digital and analog) can be processed.

The functions of the analyzer mode are supplemented by the vector analysis functions which are described in detail in a separate manual to the option.

2.4.6 Preliminary Setup and Interface Configuration – *SETUP* Key

CONFIGURATION SETUP menu:



The *SETUP* key opens the menu for configuration of the FSE.

The *TRANSDUCER* softkey opens a submenu to consider the characteristics of transducers in the test result.

The *OPTIONS* softkey allows the enabling of firmware options (Application Firmware Modules).

The *REFERENCE INT/EXT* and *EXTERNAL REF FREQUENCY* soft key determine the reference to be used.

The *SERVICE* soft key provides special setup functions which, although not necessary in normal use, are useful in instrument service.

The *GENERAL SETUP* softkey opens a submenu for all the general settings such as date and time as well as the configuration of the device interfaces.

2.4.6.1 Using Transducers

A transducer is often connected ahead of FSE both during the measurement of useful signals and EMI and converts the useful or interference variable such as field strength, current or RFI voltage into a voltage across 50 Ohm. Transducers with a frequency-independent transducer factor can be coded in 10-dB steps together with the unit at connector *PROBE CODE*. They are supplied at the same time by this connector. Transducers such as antennas, probes or current probes mostly have a frequency-dependent transducer factor which can be stored in FSE and automatically has the correct unit during level measurement.

If a transducer is switched on it is considered as part of the unit during the measurement, ie the measured values are displayed in the correct unit and magnitude. When working with two measurement windows, the transducer is always assigned to two windows.

FSE distinguishes between **transducer factor** and **transducer set**. A transducer factor takes the frequency response of a single transfer element, eg an antenna into consideration. A transducer set can summarize different transducer factors in several subranges (several transducer factors at the same time), eg an antenna, a cable and a diplexer.

A transducer factor consists of max. 50 reference values defined with frequency, transducer factor and the unit.

Several factors can be compiled in a transducer set provided that all factors have the same unit or unit "dB". The frequency range covered by a set can be subdivided into max. 10 subranges (each with up to 4 transducer factors) which follow each other without a gap, ie the stop frequency of a subrange is the start frequency of the next subrange.

The transducer factors used in a subrange have to fully cover the subrange.

The definition of a transducer set is recommended if different transducers are used in the frequency range to be measured or if a cable attenuation or an amplifier has to be taken into consideration.

If a transducer set is defined during a frequency sweep, the latter can be stopped at the interface between two transducer ranges and the user is asked to exchange the transducer.
The following message informs the user that the limit has been reached:

TDS Range # reached, CONTINUE / BREAK

He can continue the sweep by confirming the message (*CONTINUE*) or he can switch off the transducer (*BREAK*).

With the automatic switchover of the transducer used, the frequency sweep is not interrupted.

Note: *Transducers cannot be used in vector analyzer mode.*

2.4.6.1.1 Activating Transducer Factors and Transducer Sets

The *TRANSDUCER* softkey opens a submenu in which already defined transducer factors or sets can be activated or deactivated, new transducer factors or sets can be generated or existing transducer factors or sets can be edited. Tables with the defined transducer factors and sets are displayed. The table (factor or set) in which a transducer is active is set.

By switching on the transducers all the level settings and outputs are automatically made in the unit of the transducer. A change of the unit in menu *LEVEL REF* is no longer possible as FSE together with the transducer used is regarded as a measuring instrument. Only if the transducer has the unit dB, can the original unit at FSE be maintained and changed.

Note: *If one of the units dBµV, dBµV/m, dBµA, or dBµA/m is selected, the LEVEL REF key (see UNIT-submenu) can be used to switch to the corresponding units referred to the bandwidth, i.e. dBµV/MHz, dBµV/mMHz, dBµA/MHz, dBµA/mMH.*

If a transducer factor is active, TDF is displayed in the column of the enhancement labels and TDS if the transducer set is active.
After switching off all the transducers, FSE continues to use the unit which was selected before a transducer was switched on.

In the analyzer mode, an active transducer for a sweep is uniquely calculated for each point displayed after its setting and added to the result of the level measurement during the sweep. If the sweep range is changed, the correction values are recalculated. If several measured values are combined, only a single value is taken into consideration.

If an active transducer factor/set is not defined over the whole sweep or scan range during the measurement, the missing values are replaced by zero.

CONFIGURATION SETUP Menu



The upper table *ACTIVE TRANSDUCER FACTOR / SET* indicates the active transducer factor or the set with the associated name, frequency range and unit. If no factor or set is active, *none* is displayed in the table. Additional information can be entered in a comment line. If a transducer factor is active, the selected interpolation is displayed in addition, if a set is active, the break setting is displayed.

The left table *TRANSDUCER FACTOR* comprises all the defined factors with name and unit. If the number of defined transducer factors exceeds the number of possible lines in the table, the table will be scrolled.

The right table *TRANSDUCER SET* comprises all the defined transducer sets with the corresponding information.

Only one set or transducer can be activated. An already active transducer factor or set is switched off automatically if another one is switched on. An activated transducer factor or set is marked with a check sign.



The *TRANSDUCER FACTOR* softkey sets the selection bar to the position of the active transducer factor.
If no transducer factor is switched on, the bar is positioned to the first line of the table.

The *TRANSDUCER SET* softkey sets the selection bar to the position of the active transducer set.
If no transducer set is switched on, the bar is set to the first line of the table.

The *DELETE FACTOR/SET* softkey deletes the marked factor or set. To avoid deletion by mistake, deletion has to be confirmed.



The *PAGE UP* and *PAGE DOWN* softkeys are used to scroll in large tables which cannot fully be displayed on the screen.

2.4.6.1.2 New Entry and Editing of Transducer Factors

A transducer factor is characterized by

- reference values with frequency and transducer factor (*Values*)
- the unit of the transducer factor (*Unit*) and
- the name (*Name*) to distinguish between the different factors.

During the entry, FSE checks the transducer factor according to specific rules that have to be met to ensure trouble-free operation.

- The frequencies for the reference values always have to be entered in ascending order. Otherwise, the entry is not accepted and the following message is displayed:

  Frequency Sequence!

- The entered frequencies do not necessarily have to be set at FSE, as only the values for the frequency display range are considered for a set sweep or scan. The minimum frequency for a reference value is 0 Hz, the maximum frequency 200 GHz.

- The minimum or maximum value for a transducer factor is -200 dB or 200 dB. The unit "dB" means that the transducer factor is always logarithmic and has nothing to do with the physical transducer factor, which, for example, establishes the relationship between field strength and voltage into 50 Ohm. If the minimum or maximum value is exceeded, FSE signals:

  Min Level -200 dB or
  Max Level 200 dB.

- Amplifiers have a negative transducer factor, attenuation values have to be entered as a positive transducer factor.

Note: *A unit activated by switching on the transducer has priority over a coded unit of the connected probe.*
With the exception of dB/MHz, the softkeys for the unit in the menu under key LEVEL REF are inoperative with the transducer switched on.*



The *EDIT TRD FACTOR* and *NEW FACTOR/SET* softkeys both open the submenu for editing and entering new transducer factors. A precondition for the *NEW FACTOR/SET* softkey is that the selection bar is located in the table when the table *TRANSDUCER FACTOR* is called up.



The table with the data of the marked factor (the *EDIT TRD FACTOR* softkey) or an empty table is displayed in which the following entries are preset (the *NEW FACTOR/SET* softkey):

Unit: dB

Interpolation: LIN for linear frequency scaling

The characteristics of the factor can be entered in the header field of the table, the frequency and the transducer factor in the columns of the table.

Name	Entry of the name
Unit	Selection of unit
Interpolation	Selection of interpolation
Comment	Entry of a comment
FREQUENCY	Entry of the frequency of the reference points
TDF/dB	Entry of the transducer factor.

An overwritten transducer factor remains stored in the background as long as the edited factor is stored with the *SAVE TRD FACTOR* softkey or until the table is closed. A factor overwritten by mistake can be restored by leaving the entry.

The *TRD FACTOR NAME* softkey activates the entry of the transducer factor characteristics in the header field of the table.

***Name* - Entry of name**

A maximum of 8 characters is permissible for the name. The characters have to comply with the convention of DOS file names. The unit automatically stores all transducer factors with the extension .TDS.

If an existing name is changed, the factor stored under the previous name is retained and will not be overwritten automatically with the new name. The previous factor can be deleted at a later time, using *DELETE FACTOR/SET*. Thus, factors can be copied.

***Unit* - Selection of unit**

The unit of the transducer factor is selected from a selection box activated by the *TRD FACTOR UNIT* softkey.



The default setting is dB.

***Interpolation* - Selection of interpolation**

Linear or logarithmic interpolation can be carried out between the frequency reference points of the table. Selection is via the ENTER key which is toggled between LIN and LOG (toggle function).

The following diagrams indicate the effect of the interpolation on the calculated characteristic:



Fig. 2.4-2 Linear frequency axis and linear interpolation



Fig. 2.4-3 Logarithmic frequency axis and logarithmic interpolation



Fig. 2.4-4 Logarithmic frequency axis and linear interpolation

***Comment* - Entry of a comment**

The comment can be freely selected. It can have a maximum number of 50 characters.

The *TRD FACTOR VALUES* softkey activates the entry for the reference values of the transducer factor.

The selection bar marks the first reference value. The desired reference values have to be entered in ascending frequency sequence.
After entering the frequency the selection bar automatically jumps to the corresponding level value.

After entering the first reference value the table can be edited. The two *INSERT LINE* and *DELETE LINE* softkeys are displayed. Individual values are changed at a later time by marking the field and by entering the new value.

The *INSERT LINE* softkey inserts a free line above the marked reference value. When entering a new reference value into this line watch out for the ascending frequency sequence.

The *DELETE LINE* softkey deletes the marked reference value (the whole line). The following reference values move up.

The *SAVE TRD FACTOR* softkey saves the changed table in a file on the internal hard disk.

If a transducer factor with the same name already exists, a corresponding query is performed beforehand.

If the factor to be newly saved is currently switched on, the new values will immediately be valid. If a transducer set is switched on comprising the factor, the values will only be used when the set is switched on next time.

2.4.6.1.3 New Entry and Editing of Transducer Sets

A transducer set is characterized by:
- maximum 10 ranges (*Ranges*) in which different transducer factors can be active
- the combination of several transducer factors per range (*Factor*)
- a transducer-set name *(Name)*

The *EDIT TRD SET* and *NEW FACTOR/SET* softkeys both open the submenu for editing and entering new transducer factors. A precondition for the *NEW FACTOR/SET* softkey is that the selection bar is located in the table *TRANSDUCER SET*.



The table with the data of the marked set (the *EDIT TRD SET* softkey) or an empty table in which the following entries are preset (the *NEW FACTOR/SET* softkey) is displayed:

Unit: dB
Break: NO

The characteristics of the set can be entered in the header field of the table, the subranges in the columns of the set.

Name	Entry of the name
Unit	Selection of unit
Break	Activating the query when changing the subrange
Comment	Entry of a comment
Start	Entry of the start frequency of the subrange
Stop	Entry of the stop frequency of the subrange
Sel Fac	Selection of the transducer factors for the subrange

An overwritten transducer set remains stored in the background as long as the edited factor is stored with the *SAVE TRD SET* softkey or until the table is closed. A set overwritten by mistake can be restored by leaving the entry.

The *TRD SET NAME* softkey activates the entry of the transducer set characteristics in the header field of the table.

***Name* - Entry of name**

A maximum of 8 characters is permissible for the name. The characters have to comply with the convention of DOS file names. The unit automatically stores all transducer sets with the extension .TDS.

If an existing name is changed, the set stored under the previous name is retained and will not be overwritten automatically with the new name. The previous set can be deleted at a later time using *DELETE FACTOR/SET*. Thus, sets can be copied.

***Unit* - Selection of unit**

The unit of the transducer set is selected from a selection box activated by the *TRANSD SET UNIT* softkey.
The unit should be selected prior to the entry as it determines the settable transducer factors. The preset unit for new sets is "dB". The unit can no longer be changed when editing a set as the set of selected transducer factors will otherwise become inconsistent.



***Break* - Activation of query when changing a subrange**

The sweep can be stopped if the user changes the subrange and selects a new subrange of the transducer. A message informs the user that the limit has been attained. He can continue the sweep or switch off the transducer.
The interruption is activated by setting Break to ON. Selection is by the ENTER key which toggles between ON and OFF (toggle function).

***Comment* - Entry of a comment**

The comment can be freely selected. It can have a maximum number of 50 characters.

Softkey *TRANSD SET RANGES* activates the entry of subranges and the associated transducer factors. The selection bar marks the frequency values last active.

***Start* - Entry of start frequency of subrange**
***Stop* - Entry of stop frequency of subrange**

The individual subranges have to be linked without a gap. That is why the start frequency is already defined from the second subrange (= stop frequency of previous range).

After entering the first frequency value the table can be edited. The two *INSERT LINE* and *DELETE LINE* softkeys are displayed. Some values are changed at a later time by marking the field and by entering the new value. It should be noted that both the stop frequency of a particular subrange and the start frequency of the subsequent subrange are changed to the same extent.

***Sel fac*- Selection of factors for the subrange**

A check sign in column *Sel Fac* (select factor) indicates whether one or several transducer factors were selected for the subrange.

The permissible transducer factors for the marked subrange can be selected in a selection box. Only factors matching with the unit of the set and fully covering the selected subrange are permissible.
After each change of range limits, FSE thus checks the factor list and, if required, rebuilds it.
After reducing the start frequency or increasing the stop frequency of a range it may happen that the factors defined for this range no longer fully cover the range. These factors are deleted for this range when the transducer factor table is opened next time.

A maximum of 4 transducer factors can be switched on at the same time in each subrange. If none of them is switched on, 0 dB is assumed as a factor for the whole subrange.



The *INSERT LINE* softkey inserts a free line above the marked subrange.

The *DELETE LINE* softkey deletes the marked subrange (whole line). The following subranges move up.

In both cases FSE checks that the ranges follow each other without a gap.

The *SAVE TRD SET* softkey saves the changed table in a file on the internal hard disk. If a transducer name with the same name already exists, a corresponding query is performed beforehand:



After pressing ENTER, the data set is overwritten on the hard disk.
If the saved set is switched on, the new values will be used immediately.



The *PAGE UP* and *PAGE DOWN* soft keys set the table to the next or previous page.

The soft keys are locked during selection of factors in the right table.

2.4.6.2 External Reference Oscillator

In general, the FSE can generate all internal oscillators from either the internal or an external reference oscillator. A 10 MHz quartz-controlled oscillator is used as the internal reference. A reference oscillator output is also available at the rear panel via the EXT REF IN/OUT connector.
This output can be used, e.g., to synchronize other instruments to the FSE. This connector can also be converted to an input connector for application of an external frequency standard. The FSE requires that the frequency of the external standard be entered so that the internal oscillators can be synchronized to it.

CONFIGURATION SETUP Menu:

The *REFERENCE INT EXT* soft key switches between the internal and external references.

The *EXT REF FREQUENCY* soft key activates the entry of the frequency of the external source.
Range of input values is 1 MHz to 16 MHz in 1 MHz steps.

2.4.6.3 Enabling Firmware Options

CONFIGURATION SETUP menu:

The *OPTIONS* soft key opens a submenu for entering keywords for new firmware options (Application Firmware Modules). Options which are already available are indicated in a table that is opened when the menu is called.



The *ENABLE OPTION* soft key activates the entry of a keyword for a firmware option.

One or several keywords may be specified in the entry field. When a valid keyword is entered, the message OPTION KEY OK appears in the info line and the option is written into the FIRMWARE OPTIONS table.

The FIRMWARE OPTIONS table can also be displayed using the *FIRMWARE OPTIONS* soft key in the *INFO* menu.

If a keyword is invalid the message OPTION KEY INVALID is displayed in the info line.

2.4.6.4 Programming the Interface Configuration and Time

The *GENERAL SETUP* soft key branches to a sub-menu in which the basic setup of general instrument parameters may be performed. In addition to the configuration of the digital interfaces (*IECBUS, COM, LPT* and *MOUSE*), the date and time, the selection of keyboard language as well as the configuration of the *USER PORTS* may be entered.

The current settings are displayed in tabular form on the display screen where they may then be edited.

Note: *Interface LPT cannot be configured. If the option FSE-B15, computer function, is installed, LPT1 can be used for printing in both the measurement instrument mode and the computer mode. However, it can only be used for one mode at a time.*

CONFIGURATION SETUP menu:



2.4.6.4.1 IEC Bus Address Selection

CONFIGURATION SETUP-GENERAL SETUP submenu:

The *GPIB ADDRESS* soft key activates the entry of the IEC Bus address.

Permitted addresses are 0 through 30. The default setting is address 20.

2.4.6.4.2 Switching the Beeper ON/OFF

CONFIGURATION SETUP-GENERAL SETUP submenu:



The *KEY CLICK ON/OFF* soft key switches the beeper on or off. The beeper acknowledges each key stroke with a beep.

2.4.6.4.3 User Port Configuration

The instrument provides two parallel interfaces, each of which is 8 bits wide. Over these ports, arbitrary bit patterns can be output or input. The interfaces are designated *USER PORT A* and *USER PORT B*.

CONFIGURATION SETUP-GENERAL SETUP submenu:

The USER PORT A and *USER PORT B* soft keys activate the columns PORT A and PORT B, respectively, in the USERPORTS table for entry of the parameters for both of the parallel interfaces in the instrument. Because the two interfaces are configured in the same manner, how to configure an interface is described in the following using *USER PORT A*.

The following parameters need to be configured in the table:

Direction	Direction of data transmission
Value	Indication/entry of current value



***Direction* – Direction of data transmission**

The *DIRECTION* parameter determines in which direction the interface transmits data.

INPUT	read operation
OUTPUT	write operation



***Value* – Indication/Entry of current value**

The *VALUE* parameter shows the current value of the data at the port for data input as well as for data output. The displayed data is in binary format with the least significant bit (LSB) on the right.

If the port is configured as an *OUTPUT* then, the displayed value can be edited. Data entry must also be in binary format (i.e., only the digits 0 and 1 are accepted).



2.4.6.4.4 Serial Interface Configuration

CONFIGURATION SETUP-GENERAL SETUP submenu:

The *COM PORT 1* and *COM PORT 2* soft keys activate the columns COM1 and COM2, respectively, for entry of the serial interface parameters. Since the two interfaces are configured in the same manner, how to configure an interface is described in the following using *COM PORT 1*.

The following parameters need to be configured in the table:

Baud rate	data transmission rate
Bits	number of data bits
Parity	bit parity check
Stop bits	number of stop bits
HW-Handshake	hardware handshake protocol
SW-Handshake	software handshake protocol
Owner	assignment to the measuring instrument or computer
Protocol	transmission protocol



Note: *A serial interface (COM1 or COM2) cannot be used for another purpose if a mouse is connected to it.*

***Baud* – Data transmission rate**

Allowed are the indicated values between 110 and 19200 baud. The default setting is 9600 baud.



***Bits* – Number of data bits per word**

For the transmission of text without German umlauts (Ä, ä, Ü, ü, Ö, ö) and special characters, 7 bits are adequate. For binary data as well as text with special characters or umlauts, 8 bits must be selected (default setting).

***Parity* – Bit parity check**

NONE no parity check (default setting)

EVEN even parity check

ODD odd parity check

***Stop bits* – Number of stop bits**

Available are 1 and 2. The default setting is 1 stop bit.



***HW-Handshake* – Hardware handshake protocol**

The integrity of data transmission can be improved through the use of a hardware handshake protocol which effectively prevents uncontrolled transmission of data and the resulting possible loss of data bytes. In the hardware handshaking procedure, additional interface lines are used to transmit acknowledge signals with which the data transmission can be controlled and, if necessary, stopped until the receiver is ready to receive data again.

A prerequisite for handshaking is, however, that the interface lines (DTR and RTS) are provided between sender and receiver. For a simple, 3-wire connection, this is not the case and hardware handshake cannot be realized here.

Default setting is *NONE*.



***SW-Handshake* – Software handshake protocol**

Besides the hardware handshake procedure using interface lines, it is also possible to achieve the same effect by using a software handshake protocol. Here, control bytes are transmitted in addition to the normal data bytes. These control bytes can be used, as necessary, to stop data transmission until the receiver is ready to receive data again.

In contrast to hardware handshaking, software handshaking can be realized even for a simple, 3-wire connection.

One limitation is, however, present in software handshaking. Software handshaking cannot be used for the transmission of binary data since, the control characters XON and XOFF require bit combinations that are also used for binary data transmission.

Default setting is *NONE*.

***Owner* – Assignment of the interface**

When the processor option FSE-B15 is installed, the serial interface can be assigned alternatively to the instrument measurement section, the DOS section or to both sections of the FSE .

If the interface is assigned to only one section of the instrument, it is not available to the other section.

INSTRUMENT	The interface is assigned to the instrument measurement section. Outputs to the interface from the computer are not possible and, so to say, land nowhere.
DOS	The interface is assigned to the computer section. It cannot be used by the instrument measurement section. This means that hardcopy or remote control of the instrument via the interface is not possible. An attempt to start a print job via the interface results in an error message. The *PROTOCOL* parameter has no meaning in this mode.
INTR AND DOS	The interface is allocated to both instrument sections. It may be used alternately by each section. This means that a hardcopy job from the measurement section and a data transfer from the computer are not possible at the same time. This would lead to a mixing of the data streams. The set interface parameters, with the exception of *PROTOCOL*, are valid for both instrument sections. The *PROTOCOL* parameter is only of interest for the measurement section.



Note: *DOS programs cannot independently recognize changed interface parameter settings.*

***Protocol* – Transmission protocol**

The parameter allows the selection of special transmission protocols for measurement functions. The interface can be configured for:

- remote control as single instrument
- printer output (hardcopy)



2.4.6.4.5 Setting Date and Time

CONFIGURATION SETUP-GENERAL SETUP submenu:

The *TIME* soft key activates the entry of time for the internal real time clock . In the corresponding dialog box, the time is partitioned into two input fields so that hours and minutes can be entered independently.

The *DATE* soft key activates the entry of the date of the internal real-time clock. In the corresponding dialog box, the date is partitioned into 3 input fields so that day, month and year can be input separately.

For the selection of the month, pressing a units key opens a list of abbreviations wherein the desired month can be selected.



2.4.6.4.6 Mouse Configuration

How to connect a mouse is described in chapter 1, section "Connecting a Mouse", the operation of the instrument with a mouse is described in chapter 2, section "Mouse and External Keyboard Control".

Caution:
The keyboard may only be connected when the instrument is switched off (STANDBY). Otherwise, correct operation of the keyboard cannot be guaranteed.

CONFIGURATION SETUP-GENERAL SETUP submenu:

The *MOUSE* soft key activates the *MOUSE* table for configuration of the mouse.

The following parameters need to be configured in the table:

Interface	Selection of interface
Owner	Assignment of mouse



***Interface* – Selection of the interface**

If one of the serial interfaces is selected *(COM PORT 1* or *COM PORT 2)*, its interface parameters are automatically reconfigured so that mouse operation is possible.

NOT CONNECTED	No connection
PS/2	MOUSE connector on the rear panel
COM PORT 1	COM1 connector on the rear panel
COM PORT 2	COM2 connector on the rear panel



***Owner* – Assignment of the mouse**

If the processor option FSE-B15 is installed, the mouse can alternately be assigned to the instrument measurement section, the computer section or to both sections simultaneously.

If the mouse is assigned to one section it is not available to the other section.

INSTRUMENT	The mouse is assigned to the instrument measurement section.
DOS	The mouse is assigned to the computer section.
INTR AND DOS	The mouse is assigned to both sections.



2.4.6.4.7 External Keyboard Configuration

How to connect a keyboard is described in chapter 1, section "Connecting an External Keyboard", the operation of the instrument with an external keyboard is described in chapter 2, section "Mouse and External Keyboard Control".

Caution:
The keyboard may only be connected when the instrument is switched off (STANDBY). Otherwise, correct operation of the keyboard cannot be guaranteed.

CONFIGURATION SETUP-GENERAL SETUP submenu:

The *EXTERNAL KEYBOARD* soft key activates the *EXTERNAL KEYBOARD* table for configuration of the external keyboard.

Connection Activation of the keyboard connection

Language Language definition for measurement instrument operation



***Connection* – Activating the connection**

Activating the connection mainly determines whether or not the help line editor is available.

CONNECTED A keyboard is connected. When an alphanumeric entry window is opened, the help line editor is no longer displayed automatically because it is no longer needed for editing.

NOT CONNECTED The help line editor is opened automatically when alphanumeric parameters are edited.



***Language* – Language definition for measurement instrument operation**

Available are US-American, German and French.



Note: *The language definition of the keyboard in DOS mode is independent of this setting and is determined by the appropriate MS-DOS command.*

2.4.6.5 Service Functions

The service menu offers a variety of additional function which are used in maintenance and/or trouble shooting. The service functions are not necessary for normal measurements, however, incorrect use can impair the functionality and/or data integrity of the FSE. Therefore, many of the functions can only be used after entering a password.

CONFIGURATION SETUP menu:



The *INPUT RF* and *INPUT CAL* soft keys are mutually exclusive selection switches. Only one switch can be active at any one time. They switch the input to the FSE between the *INPUT RF* connector (normal position) and the internal calibration source (120 MHz, -40 dBm).



After *PRESET*, *RECALL* or FSE power on, the *INPUT RF* is always selected.

The *NOISE SOURCE* soft key switches on a noise source which is connected to the NOISE SOURCE connector on the instrument's rear panel.

The dc voltages on the connector are described in Annex A, section A.13.

CONFIGURATION SETUP SERVICE menu:

The *REFERENCE ADJUST* soft key opens a submenu used to adjust the frequency precision of the reference oscillator.
The value should be modified only after the frequency precision was checked and found to be erroneous (setting range 0 ... 4095).

For more information about how to perform the adjustment of the frequency precision refer to chapter Kapitel 4 (Maintanance and Troubleshooting).
The modified reference value is preserved when the menu is closed.

The current adjustment value can be permanently stored in an EEPROM in the instrument.

Caution: *As the specifications of the whole instrument depend directly on the setting of the reference oscillator (frequency precision), storing incorrect adjustment values should be avoided.*

Note: *If no adjustment value has been stored (REFERENCE PROG soft key) before the analyzer is switched off and on again, the factory-set value of the reference frequency or the value that has been programmed last will be used.*



The *REFERENCE* soft key adjusts the frequency precision of the reference oscillator.



The *REFERENCE PROG* soft key stores the current adjustment value in an EEPROM in the instrument.

The *ENTER PASSWORD* soft key allows the entry of a password.

The FSE contains a variety of service functions which, if incorrectly used, can impair the functionality of the analyzer. These functions are normally not accessible and are only usable after the entry of a password (*ENTER PASSWORD).*

2.5 Status Display-Remote/Manual Control – *STATUS Key Group*

The *SRQ* LED, the *REMOTE* LED and the *LOCAL.* key are contained in the *STATUS* key group.

- The *SRQ* LED indicates that a service request from the instrument has been asserted on the IEC Bus.
- The *REMOTE* LED indicates that the instrument is under remote control.
- The *LOCAL* key switches the instrument from remote to manual control, with the assumption that the remote controller has not previously set the LOCAL LOCKOUT function.

A change in the control mode consists of:

- **Enabling the Front Panel Keys**
  Under remote control, the soft-key menu is turned off and all keys, with the exception of *PRESET* and *LOCAL*, are disabled. Returning to manual mode enables all inactive keys. The soft key menu which is displayed is the main menu of the current mode.

- **Turning off the *REMOTE* LED**

- **Generating the message OPERATION COMPLETE**
  If, at the time of pressing the *LOCAL* key, the synchronisation mechanism via *OPC, *OPC? or *WAI is active, the currently running measurement procedure is aborted and synchronisation is achieved by setting the corresponding bits in the registers of the status reporting system.

- **Setting Bit 6 (User Request) of the Event Status Register**
  With a corresponding configuration of the status reporting system, this bit immediately causes the generation of a service request (*SRQ*) which is used to inform the software that the user wishes to return to front-panel control. This information can be used, e.g., to interrupt the control program so that the user can make necessary manual corrections to instrument settings. This bit is set each time the *LOCAL* key is pressed and is independent of whether or not the instrument is under remote or manual control.

- The *LOCAL* key aborts a running macro. The continuation of the macro is not possible.

This page is intentionally left blank.

2.6 Measurement Documentation – *HARDCOPY* Key Group

2.6.1 Printing Data – *START* Key

The *START* key initiates the printing of measurement/ instrument status data. The FSE can distinguish between two different output devices, each of which may be individually configured, e.g., a laser printer and a plotter. All documents are printed on the output device which is currently active.

Pressing the *HARDCOPY START* key initiates the print job. The printer parameters defined in the *HARDCOPY SETTINGS* menu are used for setting up the printer configuration. After pressing the *START* key, all of the display items to be printed are written to the printer buffer memory. Since the printer runs in the background, the instrument may be operated immediately after pressing the *START* key.

With *COPY SCREEN* selected in menu *HARDCOPY SETTINGS*, all the diagrams with traces and status displays are printed as they occur on the screen. Softkeys, open tables and data entry fields are not printed out. Function *COPY TRACE* allows to print out individual traces. With *COPY TABLE* tables can be printed out.

If the *FILE* option in the *HARDCOPY DEVICE* submenu of the *HARDCOPY SETTINGS* menu is selected then, upon pressing *HARDCOPY START*, the file name to which the output data are to be written is requested. For this an entry field is opened for entering the file name. If no external keyboard is connected, the help line editor is activated.

If the *START* key is pressed again while a print job is in progress, a new print job will be started directly after completion of the first one. It is not possible to process more than two hardcopies at the same time. With *START* pressed again, the following warning appears on the display screen:

Pressing the *OK* key causes the active print jobs to be interrupted. Selecting *CANCEL* erases the warning and the print job continues.

While a print job is in progress, problems may occur in the output device. If, while printing, the output device issues a PAPER OUT message, i.e., no more paper is available, the user will be prompted by the following message



to load paper into the output device. The print job will then be either continued (CONTINUE selected) or aborted (ABORT selected).
Similar SYSTEM MESSAGES appear, e.g., if the IEC Bus address of the printer is incorrectly set , the printer does not respond, etc.

Switchover between b/w and coloured printouts is possible with softkey *COLOR ON/ OFF* provided that the printer connected is able to output such prints. The colours of the printout correspond exactly to those of the screen, ie a red trace will be output in red.
To change the colours of the objects on the printout, the screen colours have to be changed correspondingly in menu *DISPLAY*, submenu *CONFIG DISPLAY*. One exception is the colour of the background and the colour of the diagrams. The output background is always white irrespective of the screen colour and the diagrams are always black.
If several traces are to be output one after the other on the same sheet different colours can be chosen for each trace with the aid of softkey *TRC COLOR AUTO INC* (Trace Color Auto Increment).

2.6.2 Printing Configuration – *SETTINGS* Key

HARDCOPY SETTINGS menu:



The *SETTINGS* key opens the menu to define the output configuration for diagrams and measurement curves to the various output channels, e.g., printer, plotter or files.

The recommended procedure for configuring the output data is as follows:

- Configure the desired output device and select the interface over which the output is to take place by using the *HARDCOPY DEVICE* soft key.
- Select the display items to be printed via the *COPY SCREEN, COPY TRACE soft keys.*
- Select between coloured and b/w printouts via softkeys *COLOR ON/ OFF* and *TRC COLOR AUTO INC*
- Enter commentary applicable to the diagram or add a title for the overall print-out by using the *ENTER TEXT* soft key.
- Select the page format (*QUADRANT, FULL PAGE*) through use of the *SELECT QUADRANT* soft key.

The *COPY SCREEN, COPY TRACE* and *COPY TABLE* soft keys are selection switches, i.e., only one function can be enabled at any one time. The push buttons are used for selection only and do not initiate a print job. The actual printing of data is initiated by the *HARDCOPY START* key.

2.6.2.1 Selection of Displayed Elements and Colour Settings

HARDCOPY SETTINGS menu:



With softkey *COPY SCREEN* the output of test results is selected.

All the diagrams, traces, markers, marker lists, display lines, limit lines etc. are printed out as long as they are displayed on the screen. All the softkeys, tables and open data entry fields are not printed out. Moreover, comments, title, date, and time entered at the bottom margin of the printout are output. The logo appears at the top left of the printout.

Using the *COPY TRACE* soft key, all curves visible on the display screen are printed out without auxiliary information. Specifically, no markers or display lines are printed.

Using the *COPY TABLE* soft key, all tables visible on the display screen are printed out.

With softkey *COLOR ON/ OFF* a coloured or b/w printout can be selected.

After having changed the printer driver or the hardcopy device (in submenu, *HARDCOPY SETTINGS*) the softkey is automatically switched to *ON*.
One exception is printer driver HP PCL4 which only supports b/w printouts. In this case, the softkey cannot be operated.

Softkey *TRC COLOR AUTO INC* automatically switches the colours of the traces on to the next printout. On the second printout, trace 1 has the colour of trace 2, trace 2 the colour of trace 3 etc. The fourth printout starts with the first colour. With the softkey switched off, the colours of the traces are reset to their original state.

When changing the printer driver or the hardcopy device (both in submenu *HARDCOPY SETTINGS*) as well as the selection b/w printout (softkey *COLOR ON/ OFF* in position *OFF*), softkey *TRC COLOR AUTO INC* is switched off.

2.6.2.2 Selection of Hardcopy Format

HARDCOPY SETTINGS-SELECT QUADRANT submenu:



With the functions of the *SELECT QUADRANT* menu, the location of the display screen graphics on the printed page can be selected.

The *FULL PAGE* soft key switches quadrant printing off, i.e., printing now takes place at full size. The information as to which quadrant was last selected is also lost. *FULL PAGE* is the default setting.





The *UPPER LEFT, LOWER LEFT* as well as *UPPER RIGHT, LOWER RIGHT* soft keys select the page quadrants where the printed data will be positioned. In this case, the actual size of the data printed on the page is reduced to 25% of normal size. This reduction is independent of how the graphics are distributed on the display screen. Thus, for two measurement windows (*SPLIT SCREEN*), both measurement diagrams shown on the display are placed in the chosen quadrant. Thus, up to a maximum of 8 measurement windows can be printed on one page. (4 print commands for a *SPLIT SCREEN* display, each to a different quadrant)

2.6.2.3 Entry of Comment Text

HARDCOPY SETTINGS-ENTER TEXT submenu:



With the functions of the *ENTER TEXT* menu, commentary for individual windows can be entered. The comment text appears in the print-out, but does not appear on the display screen.

If a comment is not to appear on the printout, it has to be deleted. By pressing *PRESET,* all comments will be deleted.

The *COMMENT SCREEN A* soft key opens an entry field in which a comment of two lines (60 characters per line) can be entered pertinent to the applicable window. If the user enters more than 60 characters, the excess characters appear on the second line on the print-out. Note: at any point, a manual line-feed can be forced by entering the @ character. The commentary is printed below the corresponding diagram. The *COMMENT SCREEN B* key has the same effect in measurement window 2.



The *TITLE* soft key activates a single line entry box for entering a title for the complete print-out with a maximum of 60 characters.

2.6.2.4 Selection and Configuration of the Output Device

HARDCOPY SETTINGS-HARDCOPY DEVICE submenu:



The *HARDCOPY DEVICE* soft key switches to the sub-menu which is used for the selection/configuration of the two output devices and for the connection of the devices to an output medium.

When the sub-menu is called, the corresponding table is simultaneously displayed. The *SETTINGS DEVICE 1* soft key is active and the selection bar is located at the *DEVICE/LANGUAGE* line in the corresponding column of the table.



The FSE permits two different output devices to be configured. One of the devices is defined as the active device and can be used for hardcopies.

After calling the menu, the *SETTINGS DEVICE 1* soft key is active and permits the selection and configuration of the output device DEVICE 1. The selection bar is placed the corresponding column of the table. The *SETTINGS DEVICE 2* soft key is used to configure DEVICE 2.

The actual selection of the active output device takes place with the *ENABLE DEV1 DEV2* soft key in the *HARDCOPY DEVICE* sub-menu.

Device/Language

The selection of the output device/language for DEVICE 1 and DEVICE 2 is made in this line.



Sequence, number and name of available devices depends on the driver files stored on the harddisk:

Data format for printout on a plotter

HPGL	standard HPGL format
HPGL_LS	output of the traces with variable Line_styles
HP7470	plotter hp7470 (reduced HPGL format)
HP7470LS	special HP7470format allowing output of the traces with variable Line_styles

Data format for HP-deskjet series

DESKJ	black/white
DESKJ_H	black/white, high resolution
DESKJC3:	Color (3 color cartridges only) e. g. Deskjet 500)
DESKJC3H:	Color (3 color cartridges only), high resolution
DESKJ_C:	Color (3 color cartridges + black cartridge) e. g. Deskjet 560)
DESKJ_CH:	Color (3 color cartridges + black cartridge) , high resolution

Data format for a 24-pin printer

EPSON24	data format for Epson-compatible 24-needle printers, black/white, e. g. Epson LQ-series, R&S PDN
EPSON24C	data format for Epson-compatible 24-needle color printers, e. g. Epson Stylus Color, R&S PDN Color

Data formats for laser and ink-jet printers

HPPCL4	black/white with 300DPI resolution
HPPCL4HI	black/white, high resolution
HPPCL5	black/white with 300DPI resolution
LASERJ	data format for HP-laserjet starting with series III
PCL4	black/white
PCL4_H	black/white, high resolution
PCL4_C	color (3 color cartridges + black cartridge)
PCL4_CH	color (3 color cartridges + black cartridge), high resolution
PCL4_C3	color (3 color cartridges only)
PCL4_C3H	color (3 color cartridges only) , high resolution

Data format PostScript

POSTSCR	a printer language (PostScript)

Data formats for output files

WMF	WINDOWS Metafile format
PCX	pixel graphics (e. g. Paintbrush)

Connection

The output channel to which the output device is connected is defined in this line.



By selection of the *FILE* channel, the printer output can be sent to a file. In this case, pressing *HARDCOPY START* results in a prompt for the entry of a file name.

If COM1 or COM2 is selected, recording must be set to HARDCOPY (*CONFIGURATION SETUP - GENERAL SETUP* submenu).

Output channels which, at first glance, do not appear to make sense, are also permitted because, in some cases, adapters are available which allow these devices to be connected to the interface. For example, adapters for RS232 ↔ IECBUS are available.

GPIB Address

The IEC Bus address of the output device is set in this line .



The entry field in the GPIB line can only be opened when GPIB 1 was selected as an output channel in the connection line. Otherwise, this field is blank and can not be reached with the cursor keys.

Orientation

In this line, the print format of the output page is set to either vertical (= PORTRAIT) or horizontal (= LANDSCAPE).



Device Reset

This line defines if the output device is to be reset (*DEVICE RESET ON*) before the actual print job is started or not (*DEVICE RESET OFF*). Resetting the output device causes, e.g., the loss of any settings which are made directly on the output device. For example, the definition of the drawing range for plotters or the print resolution for printers. The default setting at delivery is, therefore, *DEVICE RESET OFF*



Formfeed

This line of the table determines whether a formfeed is made (*FORMFEED ON*) at the completion of the print job or not (*FORMFEED OFF*). The entry field in this line can only be selected when the output device permits a formfeed. Therefore, for plotters, it is set to OFF and cannot be changed.



Paperfeed

This line of the table determines which paper holder is to be used for the print job. The input field of this line can only be selected when the output device permits a selection between endless and single-sheet paper types. Therefore, for plotters it is set to OFF and cannot be changed.



MANUAL FEED implies selection of the single-sheet mode so that, after pressing *HARDCOPY START,* the print job is stopped after each page and the user is prompted by the message



to load a new page in the output device. The print job is then either continued (CONTINUE selected) or stopped (ABORT selected).

The *ENABLE DEV1 / DEV2* soft key determines the active output device. The default output device is DEVICE 1, i.e., all output takes place on DEVICE 1.

2.7 Saving and Recalling Data Sets – *MEMORY* Key Group

The keys in the *MEMORY* group call the following functions:

- Functions for management of storage media (*CONFIG*). Included are among others functions for listing files, formatting storage media, copying, and deleting/renaming files.
- Storage/loading functions for storing (*SAVE*) instrument settings such as instrument configurations (measurement/display settings, etc.) and measurement results from working memory to permanent storage media, or to load (*RECALL*) stored data into working memory.

The FSE is capable of internally storing complete instrument settings with instrument configurations and measurement data in the form of data sets. The respective data are stored on the internal hard disk or, if selected, on a floppy. The hard-disk and floppy-disk drives are assigned logical names as usual in PC applications:

floppy disk	A:
hard disk	C:

In addition to the saving and recalling of complete instrument settings, it is also possible to save/recall subsets of settings. Configuration data and measurement values are stored in separate files. These files have the same name as the data set but however have a different extension. A data set thus consists of several files which have the same name but different extensions (see table 2.7-1).

When saving or loading a data set, the subsets which are to be saved or loaded can be selected in the corresponding menus. This makes it easy to reconstruct specific instrument settings.

When saving and loading data via the *SAVE* and *RECALL* menus, data subsets are selected in a table in the sub-menu *SEL ITEMS TO SAVE/RECALL*. The relationship between the designations in the table and the contents of the data subsets is shown in table 2.7-1.

The saved files of the data sets can be copied from one storage medium (e.g. drive C:) to another storage medium (e.g. drive A:) or to another directory using the functions found in the *MEMORY CONFIG* menu. File names and extensions must however not be changed. The relationship between the data subsets and the extensions is shown in table 2.7-1.

Table 2.7-1 Relationship between extensions, contents and designations of data subsets

	Extension	Contents	Designation in the table SEL ITEMS TO SAVE/RECALL
Configuration data:	.SET	current settings of the measurement hardware and the related title, if present	HARDWARE SETTINGS
	.LIN	data-point tables for the active limit lines	LINES
	.LIA	all limit lines	ALL LINES
	.CFG	current configuration of general instrument parameters	GENERAL SETUP
	.HCS	configuration for hardcopy output	HARDCOPY
	.TCI	Tracking generator settings (only with option FSE-B8/9/10/11)	SOURCE CAL
	.TS1 .TS2	Settings for source calibration (only with option FSE-B8/9/10/11)	SOURCE CAL
	.TC1 .TC2	Correction data for source calibration (only with option FSE-B8/9/10/11)	SOURCE CAL
	.TS	active transducer set	TRANSDUCER
	.TSA	all transducer sets	ALL TRANSDUCER
	.TF	transducer factor	TRANSDUCER
	.TFA	all transducer factors	ALL TRANSDUCER
	.COL	user-defined color settings	COLOR SETUP
Measurement results:	.TR1....4	measurement data trace 1 to trace 4	TRACE1...4

2.7.1 Configuration of Memory – *CONFIG Key*

MEMORY CONFIG menu:

The *CONFIG* key opens a menu for managing storage media and files.

Table *Drive Management* displays the name and label of the storage medium as well as the available storage area.

Table *File Management* displays the files of the current directory and indicates if any subdirectories are present.

If a directory name is selected, the FSE automatically changes to this directory. Selection of the entry '..' moves the FSE to the next higher directory level.

Note: *It is not possible to change menus as long as a file operation is running.*



The *EDIT PATH* soft key activates the input of the directory which will be used in subsequent file operations.

The new path is included in the *FILE MANAGEMENT* table.

The *COPY* soft key activates the input of the destination of the copy operation.

By entering a predefined disk drive (e.g. C:), a file can also be copied to another storage medium. The files/directories selected by the cursor are copied after the input is confirmed by pressing the *ENTER* key.

The *DELETE* soft key deletes the selected files.
To prevent accidental deletion of data, confirmation by the user is requested.

The *RENAME* soft key activates the entry of a new name for the selected file or directory.

The *MAKE DIRECTORY* soft key creates directories/sub-directories. Sub-directories are recommended for sorting files on the storage medium so that the structure is easier to comprehend.

The entry of an absolute path name (e.g.; "\USER\MEAS") as well as the path relative to the current directory (e.g., "..\MEAS") is possible.

The *SORT MODE* soft key activates the selection of the criteria according to which the files listed in the *FILE MANAGEMENT* table may be sorted.



Directory names are located at the top of the list after the entry for the next higher directory level ("..").

The *PAGE UP* or *PAGE DOWN* soft key sets the *FILE MANAGEMENT* table to the next or the previous page.

The *FORMAT DISK* soft key formats diskettes located in drive A:.
To prevent accidental destruction of diskette data, confirmation by the user is requested.

2.7.2 Saving Data Sets – *SAVE Key*

The *SAVE* key activates a menu which contains all functions necessary for saving instrument data.

- Entry of the name of the data set which should be saved. Confirmation of the entry initiates a save operation to store the data set.

  Data set names may contain both alphabetical and numeric characters, in the simplest case only numbers. The simplest example for the input of a data set name is illustrated by the following key strokes:

  <SAVE> <1> <units key>
- Entry of the directory in which the data set should be saved
- Input of data set description
- Selection of the data subsets to be saved (sub-menu SEL ITEMS TO SAVE)
- Indication of all available data sets
- Deletion of all available data sets

MEMORY SAVE menu



The *SAVE DATA SET* table shows the current settings regarding the data set:

Name	name of data set
Path	directory in which the data set will be saved
Items	indicates whether the default selection of the data subset (DEFAULT) or a user-defined selection (SELECTED) will be saved
Comment	Commentary regarding the data set

The *EDIT NAME* soft key for entering the name of the data set to be saved is activated automatically.

2.7.2.1 Selecting the Data Set for Storage

MEMORY SAVE menu:

The *EDIT NAME* soft key activates the entry of the name of the data set to be saved.

Data entry is concluded by pressing one of the units keys which initiates a save operation to store the data set.

The *EDIT PATH* soft key activates the input of a directory name where the data sets are to be stored.

The *EDIT COMMENT* soft key activates the entry of commentary concerning the current data set. A total of 60 characters are available for this purpose.

The *DATA SET LIST* soft key opens the *DATA SET LIST/CONTENTS* table. In addition, the *DATA SET CLEAR* and *DATA SET CLEAR ALL* soft keys are displayed.



The *DATA SET LIST* column lists all of the data sets which are stored in the selected directory.

The *CONTENTS* and *COMMENT* lines in the *DATA SET CONTENTS* column indicate the saved data subsets and the commentary for the currently selected data set.

Note: *The current instrument configuration can be easily stored under the name of an existing data set:*

- *Press a units key after selecting a data set*

  The name and the selection of the data subsets for the currently selected data set will be placed in the SAVE DATA SET table. The DATA SET LIST table is closed and, instead, the entry field for the EDIT NAME function with the name of the selected data set is opened.

- *Press a units key.*
  The current instrument configuration is saved as a data set under this name.

The *DATA SET CLEAR* soft key deletes the marked data set.

The *DATA SET CLEAR ALL* soft key deletes all data sets in the current directory.

Since, in this case, all available data sets are lost, confirmation by the user is required.



The *PAGE UP* or *PAGE DOWN* soft key sets the *DATA SET LIST* table to the next or previous page.

2.7.2.2 Selecting the Data subset for Storage

The *SEL ITEMS TO SAVE* soft key opens a sub-menu for selection of the data subsets.

MEMORY SAVE-SELECT ITEMS TO SAVE sub-menu:



The *ITEMS TO SAVE* table displays the selectable data subsets:

General Setup	current configuration of general instrument parameters
HW-Settings	current measurement hardware settings
Trace1...4	measurement data trace 1 to trace 4
Active Lines	active limit lines
All Lines	all limit lines
Color Setup	user-defined color settings
Hardcopy Setup	configuration for hardcopy output
Macros	macros
Active Transducer	active transducer
All Transducer	all transducer

The *SELECT ITEMS* soft key moves the selection bar to the first line, left column of the table.

The *ENABLE ALL ITEMS* soft key marks all entries in the *ITEMS TO SAVE.* table.

The *DISABLE ALL ITEMS* soft key unmarks all entries in the *ITEMS TO SAVE* table.

The *DEFAULT CONFIG* soft key establishes the default selection of the data subset to be saved and outputs *DEFAULT* in the *ITEMS* field of the *SAVE DATA SET* table.

2.7.3 Recalling of Data Sets – *RECALL* Key

The *RECALL* key activates a menu which contains all functions necessary for recalling data sets.

- Entry of the name of the data set which should be recalled. Confirmation of the entry initiates a load operation to recall the data set.
- Entry of the directory in which the data set is stored
- Display of data set description
- Selection of a data set which will be automatically loaded upon power-up
- Indication of all available data sets
- Deletion of all available data sets
- Selection of the data subsets which should be loaded (configurations, measurement and calibration data, sub-menu SEL ITEMS TO RECALL)

Any settings not restored when data subsets are loaded will remain unchanged in the instrument. During recall operations, the FSE recognises which data subsets are present in the recalled data set and offers only the corresponding settings for selection in the *SELECT ITEM* sub-menu.

A new instrument data set can be easily constructed from several existing data sets: the desired data subsets are selected and recalled out of various data sets in several *RECALL* operations. When the desired configuration is completed, the new data set can be saved under a new name.

MEMORY RECALL menu:



The *RECALL DATA SET* table shows the current settings regarding the data set:

Name	name of data set
Path	directory in which the data set is located
Items	indicates whether the default selection of the data subset (DEFAULT) or a user-defined selection (SELECTED) will be loaded
Comment	commentary regarding the data set

The *EDIT NAME* soft key for entering the name of the data set to be loaded is activated automatically.

2.7.3.1 Selecting the Data Set for Recalling

MEMORY RECALL menu:

The *EDIT NAME* soft key activates the entry of a data set name.
The data input is terminated by pressing one of the units keys which simultaneously initiates the data set recall operation.

The *EDIT PATH* soft key activates the entry of a directory name in which the data set is located.

The *AUTO RECALL* soft key activates the selection of a data set which is automatically loaded when the instrument is powered on. To this end the table *DATA SET LIST/CONTENT* is opened (analog to *DATA SET LIST).*



The *DATA SET LIST* column displays all data sets present in the selected directory.

The *CONTENTS* and *COMMENT* lines in the *AUTO RECALL CONTENTS* column indicate the saved data subsets and the commentary for the currently selected data set.

In addition to the data sets stored by the user, the data set *FACTORY*, which specifies the settings of the instrument before it was last switched off (Standby), is always present.

If a data set other than *FACTORY* is chosen then, at the time of instrument power on, the available data subsets of the selected data set are recalled. The data subsets which are not present in this data set are taken from the *FACTORY* data set.

Note: *The specified data set is also loaded upon PRESET if AUTO RECALL is active. The preset settiongs can thus be arbitrarily modified.*

see Chapter "Saving Data Sets"

see Chapter "Saving Data Sets"

see Chapter "Saving Data Sets"

The *PAGE UP* or *PAGE DOWN* soft key sets the *DATA SET LIST* table to the next or previous page.

2.7.3.2 Building a Data Set

The *SEL ITEMS TO RECALL* soft key opens a sub-menu to select data subsets.

MEMORY RECALL-SELECT ITEMS TO RECALL sub-menu:



The *ITEMS TO RECALL* table displays the selectable data subsets:

General Setup	current configuration of general instrument parameters
HW-Settings	current measurement hardware settings
Trace1...4	measurement data trace 1 to trace 4
Lines	data point tables for the active limit lines
Color Setup	user-defined color settings
Hardcopy Setup	configuration for hardcopy output
Macros	macros
Transducer	transducer factor, transducer set

The *SELECT ITEMS* soft key activates the *ITEMS TO RECALL* table and sets the selection bar to the first line, left column of the table.



The *ENABLE ALL ITEMS* soft key marks all entries in the *ITEMS TO RECALL* table.

The *DISABLE ALL ITEMS* soft key unmarks all entries in the *ITEMS TO RECALL* table.



The *DEFAULT CONFIG* soft key establishes the default selection of the data subset to be recalled and outputs *DEFAULT* in the *ITEMS* field of the *RECALL DATA SET* table.

2.8 Macros – *USER Key*

The FSE menus are so designed that the analyzer can be easily applied to most of the usual measurement tasks with a minimum number of key operations. However, the *USER* menu also permits a tailored adaptation of any necessary setup and measurement functions needed for special applications. Here, a sequence of key operations, which may occur repeatedly, can be listed in the *USER* menu as a key macro, then stored in memory and recalled as required by the application.

2.8.1 Fundamentals

Macros are defined as arbitrary key sequences which need to be defined only once and then can be recalled as often as desired. Through the use of macros, often-needed measurement functions or instrument setups, which may require a large number of key operations, can be easily performed. The writing of macros is possible only under manual control. Macro generation is not possible under remote control (e.g. via the IEC Bus interface).

A total of 7 different macros can be programmed and assigned to the individual soft keys of the *USER* menu. Each macro has a title (arbitrarily defined by the user) which is also used as a label for the corresponding soft key. To indicate that a macro has not yet been programmed, the soft-key label appears in parenthesis (e.g. (MACRO 1)). After a key-sequence macro has been defined, the parenthesis are removed and the softkey is replaced by the titel specified by the user.

A macro is executed by pressing the corresponding soft key.

During execution of macros, the key actions are repeated in exactly the **same sequence** as they were programmed. The sequential execution of a macro may be interrupted by using the PAUSE instruction. As soon as a macro is interrupted, adjustments on the Unit Under Test (UUT) may be made, etc. The interrupted macro is allowed to continue by pressing *CONTINUE* in the message window and is aborted by pressing ABORT.



A running macro can be aborted by pressing the *LOCAL* key. At this time, the following message is displayed:



During the time a macro is executing, manual operations on the instrument are not possible, and the soft-key panel is disabled. After interruption or conclusion of a macro, the applicable soft-key panel is enabled (i.e., menu state at the conclusion of the macro).

2.8.2 Starting Macros

USER menu



The USER key opens a menu for selection and starting of macros. The macros can be defined in the *DEFINE MACRO* submenu.



The *MACRO 1* to *7* soft keys start the execution of the macros.

2.8.3 Defining Macros

In the *DEFINE MACRO* menu, all necessary soft keys needed for macro management are available. Included are functions for starting and ending macro programming, editing of a macro title, etc.

USER DEFINE MACRO menu



The *DEFINE MACRO* soft key calls the sub-menu to define the macros.

The *SELECT MACRO* soft key is active and opens the box to select the macro to be edited. In case no selection is made, *MACRO 1* is automatically selected.

The *RECORD ON/OFF* starts or stops the recording of the macro.

ON All key actions are recorded until the soft key is changed to *OFF* . To indicate that macro record is enabled, the enhancement label MAC is displayed.

The number of actions which can be stored in a macro is limited. If the limit is exceeded, the error message "Macro too long. Recording aborted" is output and the recording operation is aborted, however, the actions already recorded do remain stored.

OFF The recording is stopped. The key actions are stored under the macro chosen by the *SELECT MACRO* soft key.



The *DEFINE PAUSE* soft key inserts a pause instruction into the macro sequence which is being recorded. A running macro will pause when it reaches this instruction, at which point settings on the unit under test could for example be made. *CONTINUE* in the message window is used to continue the macro execution.

The *DELETE MACRO* soft key deletes the macro which was previously selected by the *SELECT MACRO* soft key. The soft key of the deleted title now carries its default label (*MACRO X*, X = macro number)

The *MACRO TITLE* soft key activates the entry of the title for the selected macro .

Because the macro title is used for labelling the corresponding soft key, a maximum of only 20 characters is allowed. All text after the 10 th character is written to the second line. However, entering the character @ forces a new line at any point in the soft key title.

The *SELECT MACRO* soft key open the selection box with a list of all 7 macros. All soft-key functions of this menu are related to this macro.



2.9 Analyzer Mode

2.9.1 Frequency and Span Selection – *FREQUENCY Key Group*

The *FREQUENCY* key group is used to specify the frequency axis of the active measurement window. The frequency axis can be defined either by the start and stop frequency or by the center frequency and span. For the case when two measurement windows (*SPLIT-SCREEN)* are displayed simultaneously, data entered are always related to the window selected in the *SYSTEM-DISPLAY* menu.
After pressing one of the keys *CENTER*, *SPAN*, *START* or *STOP*, the value of the corresponding parameter can be defined in the appropriate dialog window. At the same time, a soft key menu appears, which allows selecting the optional parameters.

2.9.1.1 Start Frequency – *START* Key

FREQUENCY – START menu:



The *START* key opens a menu which displays the various options for setting the start frequency of the sweep. The *START MANUAL* soft key is automatically active and opens the entry window for manual input of the start frequency. At the same time, the coupling of the parameters is set to *STOP FIXED*

The *STOP FIXED, SPAN FIXED* and *CENTER FIXED* soft keys are mutually exclusive selection switches. Only one of these switches may be active at any one time. The frequency coupling selected by the soft keys defines which of the dependent parameters stop frequency, center frequency and span is to remain constant when a change in the start frequency is made.

The *FREQ AXIS LIN/LOG* softkey switches between linear and logarithmic scaling of the frequency axis.

The *START MANUAL* soft key activates manual entry of the start frequency.

The allowed range of values for the start frequency is:

$0\ Hz <= f_{start} <= f_{max} - minspan/2$

f_{start} start frequency
minspan smallest selectable span)
f_{max} max. frequency

If the *STOP FIXED* key is active, the stop frequency remains constant when the start frequency is changed. The center frequency is adjusted to the new frequency range. *STOP FIXED* coupling is the default setting.

If the *SPAN FIXED* soft key is active, the span remains constant when the start frequency is changed. The stop frequency is adjusted to the new frequency range.

If the *CENTER FIXED* soft key is active, the center frequency remains constant when the start frequency is changed. The stop frequency is adjusted to the new frequency range.

The *FREQ AXIS LIN/LOG* softkey switches between linear and logarithmic scaling of the frequency axis.

When the log scale is used, the following restrictions apply:

- For the start/stop frequency ratio the following holds:

$$\frac{Stopfrequency}{Startfrequency} \geq 1.4$$

  At ratios below 1.4, a linear frequency scale is automatically selected.

- Up to six decades can be set.

$$\frac{Stopfrequency}{Startfrequency} \leq 10^6$$

  When the start or stop frequency is changed, the stop or start frequency is adapted to the settable range, as required.

- A frequency offset is not allowed.
- The *CHANNEL POWER, C/N, C/N0, ADJACENT CHAN POWER* and *OCCUPIED PWR BANDW* measurements are disabled.

Note: *The function of a limit line is influenced by the* FREQ AXIS LIN/LOG *setting at the time of the definition.*
Limit lines are entered as tabulated values (level and frequency). Most regulations and standards prescribe the linking of values by straight lines both for the linear and logarithmic display. When the limit line is defined with the desired frequency scale selected, this is automatically taken into account (linear interpolation).
To be able to use the correct limit values among the tabulated values after a scale switchover, the limit line is recalculated after the switchover.

2.9.1.2 Stop Frequency – *STOP* Key

FREQUENCY – STOP menu:



The *STOP* key opens a menu which displays the various options for setting the stop frequency of the sweep .

The *STOP MANUAL* soft key is automatically active and opens the entry window for manual input of the stop frequency. At the same time, parameter coupling is set to *START FIXED*.

The *START FIXED, CENTER FIXED* and *SPAN FIXED* soft keys are mutually exclusive selection switches. Only one switch can be active at any one time. The soft keys are used to select the frequency coupling. The frequency coupling defines which of the dependent parameters start frequency, center frequency or span is to remain constant when the stop frequency is changed.

The *STOP MANUAL* soft key activates the manual entry window for the stop frequency.

The allowed range of values for the stop frequency is:

$minspan \leq f_{stop} \leq f_{max}$

f_{stop}	stop frequency
minspan	smallest selectable span (10Hz)
f_{max}	max. frequency

If the *START FIXED* soft key is active, the start frequency remains constant when the stop frequency is changed. The center frequency is adjusted to the new frequency range. The *START FIXED* coupling is the default setting.

If the *CENTER FIXED* soft key is active, the center frequency remains constant when the stop frequency is changed. The start frequency is adjusted to the new frequency range.

If the *SPAN FIXED* soft key is active, the span remains constant when the stop frequency is changed. The start frequency is adjusted to the new frequency range.

The *FREQ AXIS LIN/LOG* softkey switches between linear and logarithmic scaling of the frequency axis (see START key).

2.9.1.3 Center Frequency – *CENTER* Key

FREQUENCY – CENTER menu:

The *CENTER* soft key opens a menu which displays the various options for setting the center frequency of the sweep.

The *CENTER MANUAL* soft key is automatically active and opens the entry window for manual input of the center frequency. At the same time, the coupling of the parameters is set to *SPAN FIXED*.

The *START FIXED, STOP FIXED* and *SPAN FIXED* soft keys are mutually exclusive selection switches. Only one switch can be active at any one time. The soft keys are used to select the frequency coupling. The frequency coupling defines which of the dependent parameters start frequency, stop frequency or span remains constant when the center frequency is changed.

The *CENTER MANUAL* soft key activates the manual entry window for entering the center frequency.

The allowed range of values for the center frequency is:

for the frequency domain (span > 0):

$0\ Hz <= f_{center} <= f_{max} - minspan/2$

and for the time domain (span = 0)

$0\ Hz \leq f_{center} \leq f_{max}$

f_{center} center frequency
minspan smallest selectable span (10Hz)
f_{max} max. frequency

If the *SPAN FIXED* soft key is active, the span remains constant when the center frequency is changed. The start and stop frequency are adjusted to the new frequency range. *SPAN FIXED* coupling is the default setting.

If the *START FIXED* soft key is active, the start frequency remains constant when the center frequency is changed. The span is adjusted to the new frequency range.

If the *STOP FIXED* soft key is active, the stop frequency remains constant when the center frequency is changed. The span is adjusted to the new frequency range.

The *FREQUENCY OFFSET* soft key activates the entry window for an arithmetical frequency offset which is added to the frequency axis labelling. The allowable range of input values is -100 GHz to 100 GHz. The default setting is 0 Hz.

The *FREQ AXIS LIN/LOG* softkey switches between linear and logarithmic scaling of the frequency axis (see START key).

2.9.1.4 Center Frequency Step Size

The *STEP* key in the *DATA VARIATION* key group opens a menu for setting the step size of the center frequency. The step size can be coupled to the span (frequency domain) or the resolution bandwidth (time domain) or it can be manually set to a fixed value.

In order to change the step size, the entry window for the center frequency must already be active. After pressing the *STEP* key, the *CENTER STEP* menu appears. The soft keys are presented according to the selected domain (frequency or time).

The soft keys are mutually exclusive selection switches. Only one switch can be active at any one time.

Control is returned to the *FREQUENCY CENTER* menu via the menu key.

DATA VARIATION - STEP menu for span ≠ 0 for span = 0



Frequency domain: The *AUTO 0.1 * SPAN* soft key sets the step size of the center frequency entry to 10% of the span.

Time domain: The *AUTO 0.1 * RBW* soft key sets the step size of the center frequency entry to 10% of the resolution bandwidth

*AUTO 0.1 * RBW* is the default setting.

Frequency domain: The *AUTO 0.5 * SPAN* soft key sets the step size of the center frequency entry to 50% of the span.

Time domain: The *AUTO 0.5 * RBW* soft key sets the step size of the center frequency entry to 50% of the resolution bandwidth

Frequency domain: The *AUTO X * SPAN* soft key activates the entry of the factor defining the center frequency step size as a % of span.

Time domain: The *AUTO X * RBW* soft key activates the entry of the factor defining the center frequency step size as a % of the resolution bandwidth.

Values between 1 and 100% in steps of 1% are acceptable. The default setting is 10%.

The *STEPSIZE MANUAL* soft key activates the entry window for the input of a fixed step size.

The *STEPSIZE = CENTER* soft key sets the step size coupling to *MANUAL* and the step size to a value equal to the center frequency. This function is especially useful during measurements of the signal harmonic content, because, when entering the center frequency, the center frequency of another harmonic is selected with each stroke of the *STEP* key.

2.9.1.5 Frequency Span – *SPAN* Key

FREQUENCY – SPAN menu:



The *SPAN* key opens a menu which displays various options for the selection of sweep span.

The *SPAN MANUAL* soft key is automatically active and opens the entry window for manual input of the span. At the same time, the parameter coupling is set to *CENTER FIXED.*

The *START FIXED, CENTER FIXED* and *STOP FIXED* soft keys are mutually exclusive selection switches. Only one switch can be active at any one time. The frequency coupling is selected with these soft keys. The frequency coupling defines which of the dependent parameters start frequency, center frequency or stop frequency is to remain constant when the span is changed

The *SPAN MANUAL* soft key activates the manual entry of the span.

The allowed range of input values for span are:
time domain (span = 0):

0 Hz

frequency domain (span > 0):

$minspan \leq f_{span} \leq f_{max}$

f_{span}	frequency span
minspan	smallest selectable span (10Hz)
f_{max}	max. frequency

The *ZERO SPAN* soft key sets the span value to 0 Hz. The x axis becomes the time axis. The axis labelling corresponds to the sweep time (on the left, 0 ms, on the right, the current sweep time (SWT)).

The *FULL SPAN* soft key sets the span value to the maximum span of the FSE.

The *LAST SPAN* soft key switches the instrument between a detailed measurement (given: center frequency and span) mode and an overview measurement (*FULL SPAN*) mode.

The *FULL SPAN* soft key modifies the center frequency as well as the selected span. The *LAST SPAN* soft key cancels this change.

If the *START FIXED* soft key is activated, the start frequency remains constant when the span is changed. The center and stop frequency are adjusted to the new span.

If the *CENTER FIXED* soft key is activated, the center frequency remains constant when the span is changed. The center and stop frequency are adjusted to the new span. The *CENTER FIXED* coupling is the default setting.

If the *STOP FIXED* soft key is activated, the stop frequency remains constant when the span is changed. The center and start frequency are adjusted to the new span.

The *FREQ AXIS LIN/LOG* softkey switches between linear and logarithmic scaling of the frequency axis (see START key).

2.9.1.6 Display Zoom

FREQUENCY SPAN- ZOOM submenu:



The *ZOOM* soft key activates the zoom mode and opens a sub-menu to define the zoom span.

Two frequency lines, which show and define the frequency range to be zoomed, appear in the active measurement window when the zoom mode is switched on. The default setting is a zoom span of 10% to the left and 10% to the right of the center frequency. The zoomed display is shown in the second measurement window.
The settings for the second measurement window are taken from the original window. The second measurement window thus becomes the active measurement window and its settings can now be changed.

If only one window is active when the zoom function is selected, *SPLIT SCREEN* mode is automatically switched on.

The zoom span can be edited by using the soft keys of the sub-menu to change the position of the frequency lines.

The soft key ZOOM OFF switches off the zoom.

The *MOVE ZOOM WINDOW* soft key shifts the full zoom window. The window can shifted until the upper frequency line has reached the stop frequency or the lower frequency line has reached the start frequency of the original window.

The *MOVE ZOOM START* soft key shifts the lower frequency line. Thus, the start frequency of the zoomed display can be modified. The frequency line can be shifted down to the start frequency of the original window or up to the upper frequency line (= zero span).

The *MOVE ZOOM STOP* soft key shifts the upper frequency line. Thus, the stop frequency of the zoomed display can be modified. The frequency line can be shifted up to the stop frequency of the original window or down to the lower frequency line (= zero span).

The *ZOOM OFF* soft key switches the zoom function off and then returns control to the main menu.
The frequency lines for indicating the zoom range are deleted, *SPLIT SCREEN* mode remains active, the settings of both measurement windows are retained and the coupling of the two measurement windows is cancelled.

2.9.2 Level Display and RF Input Configuration – *LEVEL Key Group*

The *REF* and *RANGE* keys are used to set the reference level (= maximum RF input level, = overload limit), the maximum level (= upper grid level) , and the display range of the active window. The *INPUT* key sets the characteristics of the RF input (input impedance and input attenuation).

2.9.2.1 Reference Level – *REF* key

In addition to the reference level (maximum RF input level), the FSE provides a function to define a maximum level (uppermost grid line on the display):
For a spectrum analyzer, the upper boundary of the measurement diagram (maximum level) is also the limit of its dynamic range (reference level). This means, that a signal which goes beyond the upper grid line also overdrives the analyzer.

For compensation of frequency or antenna characteristics, transducer factors can be applied to increase the signal level. In this case, the calculated values can be above the reference level without actually being physically applied to the instrument. In order to display these signals on the grid, an upper grid level which is different from the reference level of the analyzer can be entered.

LEVEL REF menu:



The *REF* key opens a menu to set the reference level and the input attenuation for the active measurement window .

The *REF LEVEL* soft key is automatically active with the menu called up and opens the entry window for manual input of the reference level.

At the same time various settings concerning the level and the attenuation display can be made.

The functions for setting the attenuation are identical to those under the *INPUT* key and are described in Section 2.9.2.4.

The *REF LEVEL* soft key activates the entry of the reference level. The input is made in the currently active units (dBm, dBµV, etc.).

If the *MAX LEVEL MANUAL* softkey is active, a change of the reference level causes an equal amount of change in maximum level Thus, the separation between the overload limit of the analyzer to the upper grid edge remains the same. Thus, with only one entry, it is possible to make a change to the display and simultaneously to perform an adjustment to the amplifier.

The *REF LEVEL OFFSET* soft key activates the entry of an arithmetic offset (±200 dB in 0,1 dB steps) to the level. The offset is added to the measured level dependent upon the selected units. The scaling of the y axis is changed accordingly.

The *GRID ABS/REL* soft key switches between absolute and relative scaling of the level axis. *GRID ABS* is the default setting.

For absolute scaling the labelling of the level lines is referenced to the absolute value of the reference level.

For relative scaling, the upper line of the grid is always at 0 dB and the scale units are in dB. In contrast, the reference level is always displayed in the set units (dBm, dBµV,..).

The soft key is not displayed for setting *LIN / %* (linear scaling, labelling in %) in the *LEVEL-RANGE* menu since the % unit itself implies a relative scale.

The *MAX LEVEL MANUAL* and *MAX LEVEL AUTO* soft keys are mutually exclusive selection switches. Only one switch can be active at one time. The soft keys are used to select whether reference level and maximum level are identical or not:

When *MAX LEVEL AUTO* soft key is active, the reference level and maximum level are identical.
In this case, the reference level is displayed above the upper left corner of the grid in the corresponding function field.

MAX LEVEL AUTO is the default setting.

If the *MAX LEVEL MANUAL* soft key was active prior to pressing the *MAX LEVEL AUTO* soft key, the upper boundary of the grid is set to the reference level.

The *MAX LEVEL MANUAL* soft key activates the entry of the maximum level. The range of input values is ± 200dBm with 0.1 dB resolution.

If the *MAX LEVEL MANUAL* soft key is activated, the maximum level is displayed in addition to the reference level to the right above the grid.

2.9.2.2 Display Units

In general, a spectrum analyzer measures the signal voltage at the RF input. The level display is calibrated in rms values of an unmodulated sine wave signal. In the initial state, the level is displayed at a power of 1 milliwatt (= dBm). Via the known input resistance of 50Ω, a conversion can be made to other units. The units dBm, dBµV, dBµA, dBpW, V, A and W are directly convertible and can be selected in the *REF UNIT* menu.
Units dB../MHz have a special status. They are applicable for broadband pulse signals. The measured pulse voltage or the pulse current is referred to 1 MHz bandwidth. This conversion is not useful for narrowband or sinewave signals.
If the antenna coded connector on the front panel is used, the coded unit there determines the possible display units. Connecting to the coded connector deactivates the settings of the *UNIT* menu.
By certain codings it is nevertheless possible to select a conversion of the unit in the menu. The dependencies between the unit of the antenna coded connector and the unit which is to be selected for the display are given in the soft key description.

The default coding defined by the connector can be switched off using the *PROBE CODE ON/OFF* soft key. In this case, the unit can be set with the corresponding unit soft keys (dBm, dBµV, ...) even if a coded connector is plugged in. The coded entries in the connector are then ignored.

Note: *The units dBµV/m and dBµA/m can only be set via the unit of a transducer or via the unit of the coded connector.*

LEVEL REF UNIT submenu:



The *UNIT* soft key opens a sub-menu in which the desired units for the level axis can be selected and the coding of the antenna coded connector can be switched on and off.

The selected units are valid for both displays when two measurement windows are displayed.

The unit soft keys are mutually exclusive selection switches. Only one of these switches may be active at any one time.

The *dBm, dBµV, dBmV, dBµA, dBpW* soft keys set the display units to the corresponding logarithmic units. The dBm unit is the default unit in analyzer mode.

The units *dBm, dBµV, dBmV, dBµA* cannot be selected when the coded antenna connector or the used transducer defines a unit.

Only for coding dB, the conversion to the desired units is permitted.



The *dB*/MHz* softkey activates/disactivates the display of results in units relative to the bandwidth. Those units can be derived from the logarithmic units *dBµV, dBµV/m, dBµA* and *dBµA/m.*

This leads to the following relative units:

dBmV ⇒ *dBmV/MHz*
dBµV ⇒ *dBµV/MHz*
dBµV/m ⇒ *dBµV/mMHz*
dBµA ⇒ *dBµA/MHz*
dBµA/m ⇒ *dBµA/mMHz*

Switching over is possible also if a coded antenna connector or a transducer fixes the unit to be used.

Conversion to 1 MHz is via the pulse bandwidth of the selected resolution bandwidth B_{imp} according to the following equation (example for *dBµV)* :

$$P\ /\ (dB\mu V\ /\ MHz) = 20 \cdot \log \frac{B_{imp}\ /\ MHz}{1MHz} + P\ /\ (dB\mu V),$$

where P = display level

The dBµV/MHz unit can be combined with the following coded connector or transducer units

dB (the unit dBµV/MHz remains)

µV/m (yields the display unit dBµV/mMHz)

analogous for dBµA/MHz:

dB and µA (the unit dBµA/MHz remains)

Other combinations are not allowed.

The *VOLT, AMPERE, WATT* soft keys set the display units to the corresponding linear units.

The units *VOLT, AMPERE, WATT* cannot be selected when the coded antenna connector or the transducer table defines one of the following as units:

- µV/m
- µA

For coding dB, the conversion to the desired units is permitted.

The *PROBE CODE ON/OFF* soft key enables or disables the units defined by the coded connector.

2.9.2.3 Level Range – *RANGE* Key

LEVEL RANGE menu:



The *RANGE* key calls a menu in which the range, linear or logarithmic the display scale, absolute or relative and the level units for the active window can be selected.

The display range of the analyzer can be set in 10 dB steps from 10 to 200 dB. The default setting is 100 dB.

The most often used settings (120 dB, 100 dB, 50 dB, 20 dB and 10 dB) are each directly selectable by a soft key.
All other ranges are chosen with the *LOG MANUAL* soft key.

After pressing the *RANGE* key, the *LOG MANUAL* entry window is enabled if the display range is not set to *LIN.*

The *LOG MANUAL* soft key activates the entry of the level display range. Display ranges from 10 to 200 dB are allowed in 10-dB steps. Values which are not permissible are rounded to the next valid number.



The *LINEAR/dB* soft key switches the display range of the analyzer to linear scaling. The horizontal lines are labelled according to the selection *GRID ABS/REL* in dB* or *.



The *LINEAR/%* soft key switches the display range of the analyzer to linear scaling. The horizontal lines are labelled in %. The grid is divided into decades.



The *GRID ABS/REL* soft key switches between absolute and relative scaling of the level axis. *GRID ABS* is the default setting.

ABS The labelling of the level lines is referenced to the absolute value of the reference level.

REL The upper line of the grid is always at 0 dB and the scale units are in dB. In contrast, the reference level is always displayed in the set units (dBm, dBµV,..).

The soft key is not displayed for setting *LIN / %* (linear scaling, labelling in %) since the % unit itself implies a relative scale.

2.9.2.4 RF Input Configuration – *INPUT* Key

In addition to manual entry of the input attenuation, the FSE provides an option which allows the RF attenuation, dependent on the selected reference level, to be automatically set. Thus, it is guaranteed that an optimum combination of RF attenuation and IF amplification is always used. For the automatic selection process, three modes are provided. The *AUTO LOW NOISE* mode selects the amplification/attenuation combination so that the display of noise on the FSE is at a minimum. The signal/noise ratio is maximised. The *AUTO LOW DISTORTION* mode is tuned for minimisation of the internally generated interference products. This causes, however, a lower signal/noise ratio. The *ATTEN AUTO NORMAL* mode is a compromise between low noise and low distortion.

INPUT menu:





The *INPUT* key opens the menu for configuring the RF input. It contains the input attenuator and mixer level for matching the RF input to the input signal.

The *RF ATTEN MANUAL*, *ATTEN AUTO NORMAL*, *ATTEN AUTO LOW NOISE* and *ATTEN AUTO LOW* soft keys are mutually exclusive selection switches. only one can be active at any one time.

The *INPUT SELECT* soft key calls a submenu for selection of the input impedance.

The *RF ATTEN MANUAL* soft key activates the entry of an attenuation factor independent of the reference level.

The attenuation can be modified in 10 dB steps between 0 and 70 dB.

Other inputs will be rounded to the next lower integer value.

If the defined reference level cannot be set for the given RF attenuation, the reference level will be adjusted accordingly and the warning "Limit reached" will be output.

The *ATTEN AUTO NORMAL* soft key sets the RF attenuation automatically independent of the selected reference level.

The *ATTEN AUTO LOW NOISE* soft key sets the RF attenuation always 10dB lower than in the *RF ATTEN AUTO* mode. Therefore, for 10 dB RF attenuation, the maximum reference level is -10 dBm. For reference levels which are lower, at least 10 dB is always set (see above).

Setting Low Noise means that the indicated inherent noise level is low. This setting is recommended if signals with a low level have to be measured as the highest S/N ratio is then obtained.

The *ATTEN AUTO LOW DIST* soft key sets the RF attenuation 10 dB higher than in *RF ATT AUTO* mode. This means that for 10 dB RF attenuation, the maximum reference level is -30 dBm (-40 dBm at the mixer).

This setting is recommended whenever a small signal is to be measured in the presence of larger signals. Here, the intermodulation-free range of the FSE is large and the internal distortion products are minimised.

The *MIXER LEVEL* soft key activates the entry of the maximum mixer level attainable for a given reference level. At the same time it enables soft keys *ATTEN AUTO LOW NOISE* and *ATTEN AUTO LOW DIST* .

Range of input values is -10 to -100 dBm

INPUT INPUT SELECT submenu:



The *INPUT SELECT* soft key calls a submenu for selection of the input impedance of the RF input.

The basic setting is 50 Ohm. By connecting an impedance converter RAM or RAZ ahead, the 50-Ohm input can be transformed to 75 Ohm. FSE automatically takes the corresponding correction values for the level display into account.

The soft keys used to select the input impedance are selection switches. Only one of them can be active at any one time

The *RF INPUT 50 OHM* soft key sets the input impedance to 50 Ohm (= default setting). All level indications are referenced to 50 Ohm.

The *RF INPUT 75 OHM/RAM* soft key sets the input impedance of the FSE to 75 Ohm including the matching element RAM. All level indications are referenced to 75 Ohm.

The *RF INPUT 75 OHM/RAZ* soft key sets the input impedance of the FSE to 75 Ohm including the matching element RAZ. All level indications are referenced to 75 Ohm.

2.9.3 Marker Functions – *MARKER Key Group*

The markers are used for marking points on measurement curves, reading out measurement values and for quickly selecting a display screen segment. Preselected measurement routines can be called by pressing a key in the marker menu. The FSE provides four markers and four delta markers per measurement window. The currently activated marker can be shifted with the cursor keys, the roll-key or the soft keys. The soft keys are defined according to the type of display representation selected (frequency or time domain).

The marker which can be moved by the user is defined as the **active marker**.

Examples:



The measurement values of the active marker (also called **marker values**) are displayed in the marker field. In the **marker info list**, the measurement values from all enabled markers are sorted in ascending order. The marker info list can be switched off with the *MARKER INFO* soft key so that only the values for the active marker are shown.

The summary markers have a special function. They read out the rms or average value of the current trace or the trace averaged over several sweeps in the marker info list. These markers are not displayed.

2.9.3.1 Main Markers– *NORMAL Key*

The *NORMAL* key calls a menu which contains all standard functions. The current state of the markers is indicated by a colored illumination of the soft keys. If no marker is enabled prior to pressing the *NORMAL* key, *MARKER 1* will be enabled as the reference marker and a peak search on the measurement curve is carried out (assumption: at least one measurement curve is active). Otherwise, the peak search is omitted and the entry window for the reference marker is activated.

The marker field at the upper left of the display screen shows the marker location (here, frequency), the level and the currently selected measurement curve.



MARKER NORMAL menu:





The *MARKER 1* to *MARKER 4* soft keys switch the corresponding marker on/off or activate it as the reference marker. If the marker is activated as a reference marker, an entry field for manually setting the position of the reference marker is opened simultaneously. If the marker is disabled, the soft key is not illuminated. Enabled markers and the reference marker are indicated by illuminating the corresponding soft keys in different colors.(In the instrument default state, the active reference marker is displayed in red and enabled markers are displayed in green.)

Operating example:

MARKER 1 is shown as the reference marker by the colored background illumination. *MARKER 2* through *MARKER 4* are turned off.



Pressing the *MARKER 3* soft key switches *MARKER 3* on and it becomes the reference maker. The previous reference marker remains enabled and the soft key remains illuminated. However, the entry mode for this marker is not now active. Instead, the entry window for *MARKER 3* is opened and the position of *MARKER 3* can be shifted.



The information in the marker field also changes to describe the new reference marker.





Pressing the current reference marker (*MARKER 3)* soft key again switches *MARKER 3* off. If at least one marker is enabled, the marker with the smallest number will be selected as the new reference marker (in the example, *MARKER 1*). Switching off the last active marker also deletes are delta markers.

When several measurement curves (traces) are being displayed, the marker is set to the maximum value (peak) of the active curve which has the lowest number (1 to 4). In case a marker is already located there, it will be set to the frequency of the next highest level (next peak).

When the split screen display mode is active, the marker will be placed in the active window (for *SCREEN A*: trace 1 or 3, for *SCREEN B*: trace 2 or 4). Since markers are attached to a measurement curve, the marker can only be enabled when at least one curve in the corresponding window is visible .

If a measurement curve is turned off, the corresponding markers and marker functions are also erased. If the curve is switched on again (*VIEW, CLR/WRITE*;..), these markers along with coupled functions will be restored to their original positions. A prerequisite for the restoration of the marker positions is that individual markers have not been used on another measurement curve or that the sweep data (start/stop frequency for span > 0 or sweep time for span = 0) have not been changed.

If a marker (or, delta marker) necessary for a marker function is not available, it will be automatically checked whether or not the enabling of the corresponding marker is possible (see above). If this is not the case, a warning is issued.

The activation of the desired marker function is then not possible.

On the other hand, if the marker can be enabled, a peak search is automatically performed. Thereafter, the desired marker function can be executed.

MARKER NORMAL menu:

The *ALL MARKER OFF* soft key switches off all markers (reference and delta markers). Similarly, it switches off all functions and displays correlated with the markers/delta markers (signal count, signal track, marker zoom, N dB down, shape factor, marker list and marker info).

After each sweep, the *SIGNAL TRACK* soft key starts a search for the maximum signal level on the display screen (*PEAK SEARCH)* and then sets the center frequency to this signal (*MARKER ->CENTER).*

If a threshold line is enabled, only signals above the threshold level are considered. If no signal is over the threshold, the center frequency remains constant until a signal is available which is over the threshold.

If no marker is switched to the active trace, the next unused marker is automatically activated and positioned by the peak search routine.

In order to reduce the search range, it is possible to apply the *SEARCH LIMIT ON/OFF* function (see section: "Search Functions"). If the center frequency is changed, the position of the frequency line relative to the center frequency remains the same, ie its absolute position is correspondingly changed.

The soft key is only available in the frequency domain (spectrum) display mode (span > 0.)

The *MARKER ZOOM* soft key expands the area around the active marker. With the zoom function, more details of the spectrum can be seen. The desired display range can be defined in an entry window.

The following sweep is stopped at the position of the reference marker. The frequency of the signal is counted and the measured frequency becomes the new center frequency. The zoomed display is then configured and the new settings are used by the FSE for further measurements.

As long as switching to the new frequency display range has not yet taken place, pressing the soft key will abort the procedure.

If no marker is activated when the soft key is pressed, then *MARKER 1* is automatically activated and set to the highest peak in the measurement window.

If an instrument setting is changed after selection of *MARKER ZOOM*, the function is aborted.

The *MARKER ZOOM* soft key is only available in the frequency domain (span > 0).

The *MARKER INFO* soft key opens the display of several markers within the grid. In the upper right corner of the grid, a maximum of 4 markers/delta markers with the marker symbols Δ/∇, marker number (1 to 4), position and measurement value are listed. For the output of the marker position, the number or displayed characters will be limited as required.

If the number of lines available is not enough for all the enabled markers and delta markers, first the markers and then the delta markers are entered into the info list

In the *SPLIT SCREEN* display, the info list is partitioned into 2 partial lists and assigned to the corresponding measurement window (*SCREEN A* and *SCREEN B*). The info list for *SCREEN A* contains the markers which are assigned to trace 1 or trace 3. The info list for *SCREEN B* contains the markers which are assigned to trace 2 and trace 4.

For the two measurement windows, it is not possible to turn the *MARKER INFO* function selectively on/off .

2.9.3.1.1 LF Demodulation

The FSE provides demodulators for AM and FM signals. With these demodulators, a displayed signal can be identified acoustically through the use of the internal loudspeaker or with external headphones. The frequency at which the demodulation is enabled is coupled to the markers. The sweep stops at the frequency determined by the set marker for the selected time and the RF signal is demodulated.

During a measurement in the time domain (span = 0) the demodulation is switched on continuously.

MARKER NORMAL-MARKER DEMOD submenu:

The *MARKER DEMOD* soft key calls a sub-menu in which the type of demodulation desired, the duration of the demodulation and the loudness may be selected

The *MKR DEMOD ON/OFF* soft key switches the demodulation on/off. When the demodulation is on, the sweep is stopped at all marker frequencies, assuming the signal is over the threshold, and the signal is demodulated for the duration of the defined stop time. A total of four stopping points (four markers) can be programmed.

If no marker is set when the demodulation is switched on, the FSE switches the first marker on (*MARKER 1*) and sets it to the largest signal.

The *MKR STOP TIME* soft key activates the entry window for setting the stop time.

The FSE stops the sweep at the marker or the marker for the duration of the defined stop time and then switches the demodulation on (see also *MKR DEMOD ON/OFF*).



The *AM* and *FM* are selection switches of which only one can be activated at any one time. They are used to set the desired demodulation type, FM or AM. The default setting is AM.

The *VOLUME* soft key opens the entry window for setting the loudness. The volume can be set between 0 and 100%.

2.9.3.1.4 Channel Power Measurements

A modulated carrier is almost always used (exception e.g.,: SSB-AM) for high-frequency transmission of information. As a result carrier modulation with information, the modulated carrier now occupies a frequency spectrum which is defined by the modulation, the transmission data rate and the filtering of the signal. Each carrier is assigned, within a transmission band, to a channel corresponding to these parameters. In order to make error-free transmission possible, each transmitter must adhere to the specified transmission parameters. Among others, these are:

- output power,
- occupied bandwidth, i.e., the bandwidth within which a defined percentage of the power must be contained and
- power output in the neighboring channels.

Using the power measurement function, the FSE is capable of measuring all the specified parameters with high precision and at high speed.

The settings for the power measurements are performed in the left-hand supplementary menu *MARKER NORMAL*.

MARKER NORMAL menu:



The following measurements can be made:

- channel power (*CHANNEL POWER*)
- signal / noise power (*C/N*)
- signal / noise power density (*C/No*)
- adjacent channel power (*ADJACENT CHAN POWER*)
- occupied bandwidth (*OCCUPIED PWR BANDWIDTH*)

The channel power and the adjacent channel power can be measured either relative (*CP/ACP REL*) to the power in the utilised channel or in absolute terms (*CP/ACP ABS*).

Channel configuration is via sub menu *POWER MEAS SETTINGS*.

The above mentioned power measurements can be carried out alternately.

2.9.3.1.4.1 Channel Configuration

For all power measurements, a specified channel configuration is assumed which is, e.g. oriented on a specific radio communications system.
The channel configuration is defined by the nominal channel frequency (= center frequency of the FSE), the channel bandwidth (*CHANNEL BANDWIDTH*) and the channel spacing (*CHANNEL SPACING*).
The channel is indicated on the display screen by vertical lines located at a half-channel bandwidth to the left and to the right of the channel frequency.
For the adjacent channel power measurement, the adjacent channels are also indicated by vertical lines. The lines of the utilised channel are labelled with CO for easier recognition.
Depending on the radio communication service, the power of the 1st alternate channel and/or 2nd alternate channel can be measured in addition (soft key *SET NO.OF ADJ CHAN'S*).

With the *ACP STANDARD* soft key, the channel configuration can be set automatically according to the regulations of different digital mobile-radio standards.
For some standards, the channel power has to be evaluated by means of a root-cosine filter corresponding to the transmit filter. This filter is switched on automatically if the corresponding standards are selected but can be switched off manually (soft key *CH FILTER ON/OFF*).

MARKER NORMAL - POWER MEAS SETTINGS submenu:



The *POWER MEAS SETTINGS* soft key calls the sub-menu for the definition of the channel configuration.



The *SET NO. OF ADJ CHAN'S* soft key activates the input of number ±n adjacent channels to be considered for adjacent channel power measurement

The individual powers are indicated separately. Example n=3:

```
CH0 Pwr  -20.00 dBm
ACP UP   -45.23 dBm
ACP LOW  -52.11 dBm
ALT1 UP  -60.04 dBm
ALT1 LOW -61.00 dBm
ALT2 UP  -63.34 dBm
ALT2 LOW -64.00 dBm
```

1, 2 or 3 adjacent channels are possible. ALT1 and ALT2 (Alternate Channel Power) indicate the channel power at ± 2 × channel spacing and ± 3 × channel spacing from the center of the channel.

The *ACP STANDARD* soft key activates the selection of a digital mobile-radio standard. The parameters for the adjacent channel power measurement are set according to the regulations of the selected standard.



The following standards can be selected:

NADC (IS-54 B)
TETRA
PDC (RCR STD-27)
PHS (RCR STD-28)
CDPD
CDMA800FWD
CDMA800REV
CDMA1900REV
CDMA1900FWD

The selection of a standard influences the following parameters:

- channel spacing
- channel bandwidth
- modulation filter
- resolution bandwidth
- video bandwidth
- detector

Trace Maths and Trace Averaging are switched off.
The reference level is not influenced by automatic matching. It has to be set for an optimum dynamic range so that the signal maximum is in the vicinity of the reference level.

The basic setting *ACP STANDARD NONE*.



The *CH FILTER ON/OFF* soft key switches a modulation filter for the channel power and adjacent channel power measurement on or off.

When selecting the digital mobile-radio standards NADC and TETRA using the *ADC STANDARD* soft key, the soft key is automatically set to ON. When the other standards are selected, weighting is not selectable and the soft key is not available.

CH FILTER ON — The channel bandwidth is defined by the filter weighting alone. Therefore, the *CHANNEL BANDWIDTH* soft key cannot be operated.

The activated modulation filter influences the channel and adjacent channel power measurement.

Within the definition range of the filter, the individual pixels are weighted with the calculated filter attenuation as a function of the spacing to the channel center. The weighted display points are then added to the total channel power.

CH FILTER OFF — No modulation filter is switched on.

CHANNEL BANDWIDTH

The *CHANNEL BANDWIDTH* soft key opens an entry window for setting the channel bandwidth for the transmission channel and the corresponding adjacent channels.

For all channels, the default setting is 14 kHz.

ACP CHANNEL BW	
CHAN	BANDWIDTH
CH	14 kHz
ADJ	14 kHz
ALT1	14 kHz
ALT2	14 kHz

Note: *If the bandwidth of one channel is changed, the new value is also assigned to all subsequent channels in the table. The bandwidths for the individual channels can be set independently, however, by overwriting the table from the top to the bottom.*

CHANNEL SPACING

The *CHANNEL SPACING* soft key opens an table for defining the channel spacing. The channel spacing is the spacing of the center frequency of a given channel relative to the center of the transmission channel.

The default setting for channel spacing is 20 kHz.

CHANNEL SPACING	
CHAN	SPACING
ADJ	20 kHz
ALT1	40 kHz
ALT2	60 kHz

Note: *Channel spacings can be selected separately for each channel. If a spacing value is changed in the table, the following values are changed automatically.*

EDIT ACP LIMITS

The *EDIT ACP LIMITS* opens a table for defining the limits for ACP-measurement.

ACP LIMITS			
CHAN	CHECK	LOWER CHANNEL LIMIT	UPPER CHANNEL LIMIT
ADJ	✓	-50 dB	-50 dB
ALT1	✓	-60 dB	-60 dB
ALT2			

The limit values are defined either in units of dB (for*CP/ACP REL*) or in dBm (for *CP/ACP ABS*).

Note: *Measured values that exceed one of the limits are marked with an preceding asterisk.*

LIMIT CHECK

The *LIMIT CHECK* soft key switches on or off the limit check of the ACp measurement.

% POWER BANDWIDTH

The *% POWER BANDWIDTH* soft key opens an entry window for defining the percentage of the power with respect to the total power in the displayed frequency range. This defines the occupied bandwidth (percent of the total power).

The permitted range is 10 % - 99,9 %

2.9.3.1.4.2 Channel Power Measurement

The *CHANNEL POWER* measurement is performed by an integration of the measurement points within the channel bandwidth. The channel is marked by two vertical lines to the left and to the right of the center frequency as defined by the channel bandwidth (see Fig. 2.9-1).



Fig. 2.9-1 Determination of the channel width

MARKER NORMAL menu:

The *CHANNEL POWER* soft key initiates the calculation of the power in the measurement channel. The display takes place in the units of the y axis, e.g., in dBm, dBµV.

The calculation is performed by summing the power at the pixels within the specified channel.

The measurement is either absolute or relative to a reference power (see the *CP/ACP ABS/ REL* soft key).

The *CP/ACP ABS/REL* soft key (Channel Power/Adjacent Channel Power Absolute /Relative) switches between an absolute and relative display of the power measured in the channel or adjacent channel.

Channel power measurement

CP ABS — The absolute value of the power is displayed in the unit of the Y axis, eg in dBm, dBV.

CP REL — The power of a freely selected channel is measured. This power is set in relation to the power of a reference channel. The reference channel power is selected beforehand using the *SET CP REFERENCE* soft key, ie:

1. Declare the power in the currently measured channel as the reference value using the *SET CP REFERENCE* soft key.
2. Set the channel of interest by changing the channel frequency (FSE center frequency).

   In case of linear scale of the Y axis the relative power (CP/CP_{ref}) of the new channel is displayed in addition to the reference channel. In case of dB scale, the logarithmic ratio $20 \times \log (CP/CP_{ref})$ is displayed.

Thus, the relative channel power measurement can also be used for universal adjacent channel power measurements.

Example:
Measurement of the 1597-QCDMA adjacent channel power. The useful channel and the adjacent channels have different bandwidths (1.23 MHz or 30 kHz).

Adjacent channel power measurement

The power of the adjacent channels is measured. The reference value is the power of the useful channels (see measurement of the adjacent channel power). The useful channel is marked by two vertical lines that are labelled with C0.

ACP ABS — The powers of the useful channel and of the adjacent channels are displayed as absolute values in the unit of the Y axis.

ACP REL — The logarithmic ratio $20 \times \log (CP/CP_0)$ of the powers of the adjacent channels to the useful channel is displayed

The soft key is not available for *OCCUPIED PWR BANDWIDTH*, *C/N* and *C/N0*

.

For an activated *CHANNEL POWER* power measurement, the *SET CP REFERENCE* soft key sets the reference value to the currently measured channel power.

2.9.3.1.4.3 Signal / Noise Power Measurement

MARKER NORMAL menu:

The *C/N* (Carrier to Noise) soft key calculates the ratio of carrier power to noise power and the power of interference signals in the channel defined under *POWER MEAS SETTING*. For the measurement, a marker must be set to the carrier of interest.

The unit of C/N is dB when the display is logarithmic. When the display is linear, C/N is shown without a unit.



The C/N_0 soft key starts the C/N_0 measurement.
In contrast to the *C/N* measurement, C/N_0 calculates the ratio of carrier power to noise and interference signals based on a 1 Hz bandwidth in the channel defined under *POWER MEAS SETTING*.

The unit of C/No is dB/Hz when the display is logarithmic and 1/Hz when the display is linear.

Measurement procedure:

1. Activate a marker and position it to the peak of the carrier signal (e.g., with the *Marker -> Peak* soft key).
2. Select With the desired frequency range (channel) with the *FREQUENCY CENTER* and *CHANNEL BANDWIDTH* (*POWER MEAS SETTING* sub-menu) soft keys.
3. Press the *C/N* or C/N_0 soft key. The marker is set to reference fixed and activates each measurement. It must be observed that the carrier is either located outside of the measurement channel or turned off at the UUT (Unit Under Test).
4. Press the ADJUST CP SETTINGS soft key to active the default settings with modified channel parameters.

The measurement values for C/N or C/N_0 are displayed in the marker info field.

Notes: – *If no carrier marker was set, only N or N_0 with the appropriate units is displayed.*
– *Is the carrier located inside the measurement channel, C/C+N or $C/C+N_0$ will be displayed*

Example:

The signal-to-noise ratio of the carrier (f = 199.9 MHz) in the channel with +100 kHz separation from 200 MHz (channel center frequency) is to be measured. The channel bandwidth is 150 kHz.

1. Using the *CENTER* key, set the center frequency to the channel center frequency 200 MHz.
2. Using the *SPAN* key, set the span, e.g., to 1 MHz (carrier must be visible).
3. Using the *MARKER NORMAL* key, activate *MARKER 1* (If Marker 1 was not yet active, the function *MARKER→ PEAK* is automatically executed. In this case, skip step 4.)
4. Using the *MARKER→ PEAK* key, set *MARKER 1* on the carrier (assumption: the 200 MHz carrier has the highest level in the selected span).
5. Press the *MARKER NORMAL* key and change to the left-hand supplementary menu.
6. Using the *POWER MEAS SETTING* soft key, call the sub-menu for defining the measurement channel.
7. Using the *CHANNEL BANDWIDTH*: soft key, set the bandwidth to 150 kHz (The channel spacing does not need to be entered for this measurement). Then press ⇑ menu change key.
8. Using the *C/N* soft key, start the C/N measurement. In the marker info field, the outputs *CHANNEL CENTER, CHANNEL BANDWIDTH* as well as the corresponding C/N measurement values appear. *MARKER 1* is also set to reference fixed.
9. Using the *ADJUST CP SETTINGS* soft key, activate the default settings with modified channel parameters (channel bandwidth = 150kHz) for the correct C/N measurement (span = 2 × channel bandwidth = 300 kHz, RBW = 3 kHz, VBW = 10 kHz, detector: sampling).

Two vertical lines mark the channel 200 MHz ± 75 kHz in which the noise measurement is performed (see Fig. 2.9-2). The reference value is the measurement from *MARKER 1* (Reference Fixed).



Fig. 2.9-2 Example: measurement of the signal/noise power

2.9.3.1.4.4 Adjacent Channel Power

MARKER NORMAL menu:

The *ADJACENT CHAN POWER* soft key starts the measurement of the adjacent channel power.
The *ADJACENT CHAN POWER* measures the power which the transmitter delivers to the two adjacent channels (upper channel , lower channel). The measurement values are displayed according to the setting of the *CH/ACD ABS/REL* soft key as absolute values in the scale of the X axis (see Fig.) or as a logarithmic ratio of adjacent channel to useful channel in dB (20 × log (CP/CP_0).

If the power of the other neighbouring channels is to be measured in addition to the adjacent channel power, the number of adjacent channels can be extended (on one side only) using *SET NO. OF ADJ CHAN'S* in the submenu *POWER MEAS SETTINGS*.

A prerequisite for the correct measurement of the adjacent channel power is the correct setting of the FSE center frequency, the channel bandwidth and the channel spacing.
The *CHANNEL SPACING* and *CHANNEL BANDWIDTH* are defined in the *POWER MEAS SETTINGS* sub-menu.
For an activated measurement of adjacent channel power, the analyzer itself optimally sets all other values (span, resolution bandwidth, detector, etc.) after the *ADJUST CP SETTINGS* soft key is pressed. The carrier power in the utilised channel, the power (absolute or relative to the utilised channel) in the upper and lower adjacent channels as well as the largest of the two power values and the channel raster with channel spacing and bandwidth are displayed as the result of the measurement. The C0 lines mark the bandwidth of the carrier channel. Other unlabelled frequency lines mark the adjacent channels (see Fig. 2.9-3). With *SET NO. OF ADJ CHAN'S 2* selected, the other two neighbouring channels (1st Alternate Channels) are displayed as well, with *SET NO. OF ADJ CHAN'S 3* selected, an additional channel each (2nd Alternate Channels).
The measurement values are updated and displayed until the *ADJACENT CHAN POWER* soft key is pressed again and the measurement of the adjacent channel power is stopped.



Fig. 2.9-3 Measurement of the adjacent channel power.

If the limit check is activated for ACP measurements, the result of the limit check (PASSED/FAILED) is displayed as well as an asterisk preceding each measured ACP power that exceeded one of the limits.

Note: *The limit check is activated and the limits are defined in the POWER MEAS SETTINGS menu.*

2.9.3.1.4.5 Occupied Bandwidth Measurement

An important characteristic of a modulated signal is the bandwidth which it occupies. The occupied bandwidth must be limited in a radio communications system so that disturbance-free transmission in adjacent channels is possible. The occupied bandwidth is defined as the bandwidth in which a defined percentage of the total transmitter power is contained. The percentage of the power can be set between 10 and 99% in the FSE.

MARKER NORMAL menu:



The *OCCUPIED PWR BANDW* (occupied power bandwidth) soft key starts the measurement for determining the occupied bandwidth.
In the spectrum display mode, the bandwidth is determined in which a predefined percentage of the power in the displayed bandwidth is contained. (selectable in the *POWER MEAS SETTINGS* sub-menu with the : *% POWER BANDWIDTH* soft key). The occupied bandwidth is output to the marker display field and marked on the measurement curve with temporary markers.

Measurement principle:

For example, the bandwidth is to be found in which 99% of the signal power is contained. The routine calculates first the total power of all displayed points (pixels) of the measurement curve. In the next step, the measurement points from the right edge of the measurement curve are integrated until 0.5% of the total power is reached. Then the FSE integrates, in an analog fashion, from the left edge of the measurement curve until 0.5% of the power is reached. The delta marker is positioned at this point. Thus, 99% of the power is located between the two markers. The difference between the two frequency markers is the occupied bandwidth which is displayed in the marker info field.

A prerequisite for the correct operation of the measurement is that **only** the signal to be measured is visible on the display screen of the FSE. An additional signal would falsify the measurement.

In order to be able to perform correct power measurements, especially for noisy signals, and thus to achieve the correct occupied bandwidth, the selection of the following parameters should be observed:

RBW	<< occupied bandwidth (≤ approx. 1/20 of the occupied bandwidth, for voice communications, typ. 300 Hz or 1 kHz)
VBW	≥ 3 x RBW
detector	sampling
span	≥ 2 to 3 x occupied bandwidth

According to the application or other measurement guidelines, it may be necessary or reasonable to average a definite number of sweeps in order to achieve a usable value for the occupied bandwidth.
This is provided by the *TRACE* (1....4) key group and the averaging function. With the *SWEEP COUNT* soft key, the number of averages is defined.
Some measurement instructions (e.g. PDC, RCR, STD-27B) require the occupied bandwidth to be measured by means of a peak detector. In this case, the detector of the FSE must be corrected appropriately.

2.9.3.1.4.6 Parameters for Channel Power Measurements / Configuration

For the correct measurement of channel power, C/N, C/N0, adjacent channel power and occupied bandwidth, it is recommended that an automatic optimisation of the analyzer settings be performed after enabling the corresponding measurement and selecting the channel configuration (channel power settings).

MARKER NORMAL menu:

The *ADJUST CP SETTINGS* soft key optimises automatically the settings of the analyzer for the selected power measurement (see below).

Thus, all relevant analyzer settings for a power measurement within a defined frequency range (channel bandwidth) are optimally set including:

- span
- resolution bandwidth
- video bandwidth
- detector

dependent upon the channel configuration (channel bandwidth and, if needed, channel spacing).

The trace mathematical functions and trace averaging are switched off.

The reference level is not influenced by the automatic optimisation routine. The reference level is to be so adjusted that the signal maximum is located near the reference level.

The optimisation is performed only once, however, if necessary, the instrument settings may be changed later.

Span

The span should cover at least the frequency range that is to be observed. For measurements of channel power, C/N and C/N0, this is the channel bandwidth. For adjacent channel power measurements, this is the utilised channel bandwidth and the adjacent channels located within the channel spacing.
If the span is large compared to the observed frequency band(s), then only a few points on the measurement curve are available for the measurement.

The *ADJUST CP SETTINGS* soft key sets the span as follows:

2 × channel bandwidth	for channel power, C/N, C/No
	or
2 × channel spacing + channel width	for adjacent channel power
4 × channel bandwidth	for adjacent channel power and NO. OF ADJ CHAN'S 2
6 × channel spacing + channel width	for adjacent channel power and NO. OF ADJ CHAN'S 3

For measurements of the occupied bandwidth, the span is not influenced.

Resolution bandwidth (RBW)

In order to achieve acceptable speed as well as the necessary selection (to suppress spectral components outside of the frequency range to be measured and, especially the adjacent channels), the resolution bandwidth should not be chosen too broad or too narrow.
If the resolution bandwidth is too narrow, the measurement speed becomes very slow and it is possible that relative spectral components are not displayed (due to the sampling detector necessary for power measurements and the finite number of points).
On the other hand, the resolution bandwidth should not be so broad that, due to insufficient selection, spectral components outside of the observed frequency range (from adjacent channel) falsify the measurement results.

The *ADJUST CP SETTINGS* soft key sets the resolution bandwidth (RBW) dependent upon the channel bandwidth as follows:

RBW ≤ 1/40 of the channel bandwidth. The largest possible RBW, with due regard to the 1, 2, 3, 5 step size and the requirement RBW ≤ 1/40 will be selected.

The RBW is not influenced by measurements of the occupied bandwidth.

Video bandwidth (VBW)

Since a power measurement of the noise components is also necessary (otherwise, errors occur due to the logarithmic characteristics of the spectrum analyzer), the video bandwidth should be chosen substantially larger than the resolution bandwidth.

The *ADJUST CP SETTINGS* soft key adjusts the video bandwidth (VBW) dependent upon the channel bandwidth as follows:

VBW ≥ 3* RBW. The smallest VWB with regard to the available 1, 2, 3, 5 step size is selected.

Grid scale

The *ADJUST CP SETTINGS* soft key sets the grid scale to the 100-dB range. Thereby, a wide dynamic range in channel power measurements is achieved.

Detector

The *ADJUST CP SETTINGS* soft key selects the sampling detector.
The sampling detector is to be selected, above all, for correct power measurements of noisy signals within the observed frequency range.

2.9.3.1.5 Marker Step Size

DATA VARIATION – STEP menu:



The *STEP* key in the *DATA VARIATION* key group opens a menu to match the marker step size to each individual application. In order to change the step size, the marker entry mode must already be active.

Control is returned to the *MARKER NORMAL* menu via the menu key.

The *STEPSIZE AUTO* soft key sets the marker step size to *AUTO*. In this case, the step size is exactly 10% of the grid. A one-raster movement of the roll-key corresponds to one pixel.

STEPSIZE AUTO is the default setting.

The *STEPSIZE MANUAL* soft key activates the entry window for defining a fixed value for the marker step size.

Pressing the step key shifts the marker position by the selected step size. The resolution of the roll-key is always one pixel per raster.

The *MKR TO STEPSIZE* soft key sets the marker step size to the current marker frequency or marker time.

In the frequency domain, this function is well suited to harmonic measurements. The marker is set to the largest signal using the peak search function. After activation of the *MKR TO STEPSIZE* function, the marker is set to the corresponding harmonic of the signal each time the cursor key or is pressed when entering the marker position (see also Chapter 2, section "Measurement Examples").

The *DELTA TO STEPSIZE* soft key sets the marker step size to the difference between the reference marker and the last active delta marker.

The soft key is only available when at least one delta marker is enabled.

2.9.3.2 Delta Markers – *DELTA Key*

The delta markers are used to measure a level or frequency referred to a reference marker. They are always referenced to the marker whose position was last changed. A delta marker is displayed as an empty △ symbol. The reference marker is displayed as a filled ▼ symbol.

MARKER DELTA menu:



The *DELTA* key switches a delta marker on and calls the menu for its control. If no marker is enabled, *MARKER 1* is automatically activated when the delta marker is switched on. The delta marker activated to entry mode is shown on the display screen as a filled ▲ symbol.

The *DELTA 1 to 4* soft keys are used to enable delta markers 1...4. The control of the delta markers corresponds to that of the markers. After a delta marker has been enabled, all entries are now applicable to this marker. The main marker must be activated anew if its position is to be changed.

The delta marker field on the display screen contains the delta marker number, the difference frequency from the delta marker to reference marker and the level difference between the active delta markers and reference markers.

The indicated differences are, in general, referred to the reference marker. If the *PHASE NOISE* or *REFERENCE FIXED* functions are enabled, the reference values under *REFERENCE POINT* are applicable.

The *DELTA ABS REL* soft key switches between relative and absolute entry modes for the delta-marker frequency.

In the *REL* position, the delta marker frequency is entered relative to the reference marker. In this case, the entry mode for the delta-marker frequencies is also relative.

In the *ABS* position, the entry of the delta-marker frequency is in terms of absolute frequency.

The default setting is *REL*.

The *ALL DELTA OFF* soft key switches off all active delta markers and any associated functions (e.g. *REFERENCE FIXED*, *PHASE NOISE*).

The *REFERENCE FIXED* soft key enables/disables relative measurements with respect to a fixed, measurement-curve-independent reference value.

The information in the delta-marker field on the display screen is referenced to this fixed reference value. For the generation of the marker lists using *MARKER INFO* list, the delta markers are also output relative to a fixed reference. In the lists, the *REFERENCE POINT* is tagged by the number of the reference marker (only one enabled)

When *REFERENCE FIXED* is enabled, the current settings of the reference marker become the reference values. If no marker is active, *MARKER 1* (with peak search) is activated. After transferring the reference values, all markers are deleted, and the active delta marker is set to the position of the reference value. Additional delta markers can be switched on.

The reference value can be subsequently changed

1. by shifting it in the *REFERENCE POINT* sub-menu.
2. by starting a search:
   In the *MARKER NORMAL* menu the *REF POINT* is handled as a reference marker (even though it is not bound to the measurement curve). This means, that it will be shown as enabled and can also be changed in position. The co-ordinates of the *REF POINT* are overwritten by the marker values (they lie, by definition, on the measurement curve). Thus, it is possible, even for an enabled *REFERENCE FIXED*, to define a new reference point function with search functions.

The *REFERENCE FIXED* function is particularly useful for measurements which are performed relative to a reference signal that is not available during the whole measurement time (e. g. harmonics measurements, see section 2.1.2.4).

MARKER DELTA- REFERENCE POINT submenu:



The *REFERENCE POINT* soft key opens a sub-menu in which the reference value the *REFERENCE FIXED* and *PHASE NOISE* functions can be modified.

The position of the reference value is indicated by two additional display lines (horizontal and vertical). In addition, an offset level may be defined which is added to each difference during output.

The soft key is only available when the *REFERENCE FIXED* or *PHASE NOISE* function is switched on.

The *REF POINT LEVEL* soft key activates an entry box for setting the reference level relevant to the *REFERENCE FIXED* or *PHASE NOISE.* functions.



The *REF POINT FREQUENCY* soft key activates the entry box for the input of a reference frequency for the *REFERENCE FIXED* or *PHASE NOISE.* functions.

The *REF POINT LVL OFFSET* soft key activates the entry box for the entry of an additional offset level during output when the *REFERENCE FIXED* or *PHASE NOISE.* functions are enabled.

The offset level is set to 0 dB when the *REFERENCE FIXED* or *PHASE NOISE.* functions are switched on.

The *REF POINT TIME* soft key activates the entry box for the input of a reference time for the *REFERENCE FIXED* function in the time domain (span = 0).

The entry of a reference time for the *PHASE NOISE* function is not possible.

2.9.3.2.1 Phase Noise Measurement

MARKER DELTA menu:

The *PHASE NOISE* soft key switches the *PHASE NOISE* function on/off.

Enabling the *PHASE NOISE* function causes the frequency and level of the reference marker to be transferred as reference values, that means, the *REFERENCE FIXED* function is activated.

The difference between this reference point and the active delta markers is determined. The correction factors for bandwidth and the logarithmic converter are automatically taken into consideration. The sampling detector is also enabled to allow the effective noise power to be displayed. The measured values are displayed in the delta marker field in units of dBc/Hz.

If several delta markers are enabled, only the measurement value output of the active marker is shown in the marker field. Using *MARKER INFO* and *MARKER LIST* the measurement data of all delta markers can be displayed.

If no marker is present when the *PHASE NOISE* function is enabled, *MARKER* 1 is automatically switched on (peak search), and the marker values are saved as reference values. The reference value can be changed later in the *NORMAL* menu, *SEARCH* menu or *REFERENCE POINT* sub-menu (see *REFERENCE FIXED* soft key).

Turning on an additional marker causes the *PHASE NOISE* function to be disabled.

2.9.3.2.2 Delta-Marker Step Size - *STEP Key*

STEP-DELTA STEP menu:

The *STEP* key in the *DATA VARIATION* key group opens a menu to match the step size of the individual delta markers to the specific application. In order to change the step size, the entry mode for a delta marker must already be active.

Control is returned to the DELTA MARKER menu via the menu key.

The *STEPSIZE AUTO* soft key sets the delta marker step size to *AUTO*. In this case, the step size of the delta marker is exactly 10% of the grid. The roll-key corresponds to 1/500, i.e., for each rotational pulse, the delta marker is shifted one pixel position.

The *STEPSIZE MANUAL* soft key permits the entry of a fixed value for the delta marker step size.

Pressing the step-key shifts the marker position by the selected step size. The roll-key resolution, however, always remains constant at 1 pixel.

The *DELTATO STEPSIZE* soft key sets the delta marker step size to a quantity equal to the difference between the delta and reference markers.

The soft key is only presented when at least one delta marker is switched on.

2.9.3.3 Search Functions – SEARCH Key

The FSE offers numerous functions useful for peak/min. peak searching. The search functions can be used for marker as well as delta marker functions.

The setups applicable to the available search functions are performed in the *MARKER-SEARCH* menu.

The search functions are always related to the currently active marker. If the *SEARCH* key is pressed while the marker entry mode is active, then all search functions are related to the current reference marker. If the entry mode of a delta marker is active, then the functions will be applied to the corresponding delta marker. For the case where no marker is active, *MARKER* 1 will be automatically enabled (with peak search). The *ACTIVE MKR / DELTA* soft key allows toggling between the active marker and the active delta marker.

If the threshold line is turned on, the peak/min. search functions will only evaluate signals which have a level above/below the selected threshold. In addition, the search range can also be limited (*SEARCH LIM ON/OFF* soft key) by the frequency/time lines (*FREQUENCY LINE 1/2, TIME LINE 1/2*).

For all peak search functions, the first local oscillator is omitted at 0 Hz if it happens to be displayed.

In the time domain display, the summary markers can be activated and set in addition to the search functions in menu *MARKER-SEARCH*.

MARKER SEARCH menu:



The *ACTIVE MKR / DELTA* soft key toggles between the active marker and the active delta marker.

If *DELTA* is illuminated, the following search functions are performed with the active delta marker.

Note: *Switching between marker and delta marker entry modes may also be performed using the NORMAL and DELTA keys.*

The *SELECT MARKER* soft key activates the selection of the marker/delta markers. The selection box lists the currently enabled markers/delta markers.





The *PEAK* soft key sets the active marker/delta marker to the maximum displayed value on the corresponding trace.

The *NEXT PEAK* soft key sets the active marker/delta marker to the next lower peak value on the corresponding curve.

The *NEXT PEAK RIGHT* soft key sets the active marker to the next peak to the right of the current marker position.

The *NEXT PEAK LEFT* soft key sets the active marker to the next peak to the left of the current marker position.

The *MIN* soft key sets the active marker to the lowest displayed peak on the corresponding measurement curve.

The *NEXT MIN* soft key sets the active marker to the next higher of the low peaks on the corresponding measurement curve.

The *NEXT MIN RIGHT* soft key set the active marker to the next low peak to the right of the current marker position.

The *NEXT MIN LEFT* soft key sets the active marker to the next low peak to the left of the current marker position.



The *EXCLUDE LO ON/OFF* softkey switches between a restriced (*ON*) and an unrestricted search range (*OFF*).

ON Because of non-ideal input mixer, the first LO of any analyzer can be seen at 0 Hz. The search functions can possibly respond to this LO level, in particular in the preset setting (FULL SPAN). To avoid this, the search range is restricted according to the following formula:

$$\text{Search range} \geq 6 \times \text{resolution bandwidth}$$

OFF No restriction to the search range. The search functions find also signals below the frequency limit quoted above.

The *PEAK EXCURSION* soft key activates the entry box which sets the minimum amount a signal level must decrease/increase before it is recognised by the search functions (except PEAK and MIN) as a maximum or minimum.

Input values from 0 dB to 80 dB are allowed with a resolution of 0.1 dB.

The peak excursion is preset to 6 dB. This is completely sufficient for the functions *NEXT PEAK* (or *NEXT MIN*) as always the next smaller (or higher) signal is searched four.

Functions *NEXT PEAK LEFT* and *NEXT PEAK RIGHT* (or *NEXT MIN LEFT and NEXT MIN RIGHT*) search for the next relative maximum (or minimum) independent of the current signal amplitude.
As for wide bandwidths, the set 6-dB level change is already reached by the noise indication of the analyzer, the noise values are also identified as peak. In this case, *PEAK EXCURSION* has to be selected with a higher value than the difference between the highest and lowest noise indication values.

The following example shows the effect of different *PEAK EXCURSION* settings.



Fig. 2.9-4 Example for level measurements at different peak excursion settings

Maximum relative level change of the measured signals:

Signal 2:	42dB
Signal 3	30dB
Signal 4:	46dB

Setting **Peak Excursion 40dB** causes signal 2 and 4 to be detected with *NEXT PEAK* or *NEXT PEAK RIGHT*. Signal 3 is not detected since it is only decreased by 30 dB before the level rises again.

Order of signals found:

PEAK:	Signal 1
NEXT PEAK:	Signal 2
NEXT PEAK:	Signal 4

or

PEAK:	Signal 1
NEXT PEAK RIGHT:	Signal 2
NEXT PEAK RIGHT:	Signal 4

Setting **Peak Excursion 20dB** causes signal 3 to be detected since its highest level change of 30 dB is now higher than the set peak excursion.

Order of signals found:

PEAK:	Signal 1
NEXT PEAK:	Signal 2
NEXT PEAK:	Signal 4
NEXT PEAK:	Signal 3

or

PEAK:	Signal 1
NEXT PEAK RIGHT:	Signal 2
NEXT PEAK RIGHT:	Signal 3
NEXT PEAK RIGHT:	Signal 4

Setting **Peak Excursion 6dB** recognizes all the signals, *NEXT PEAK RIGHT* does not work as required.

Order of signals found:

PEAK:	Signal 1
NEXT PEAK:	Signal 2
NEXT PEAK:	Signal 4
NEXT PEAK:	Signal 3

or

PEAK:	Signal 1
NEXT PEAK RIGHT:	Marker in noise between signal 1 and signal 2
NEXT PEAK RIGHT:	Marker in noise between signal 1 and signal 2

The *SEARCH LIMIT ON/OFF* soft key switches between a limited (*ON*) and unlimited (*OFF*) search range.

For peak and min. search functions, the search range can also be limited by the frequency and time lines (FREQUENCY LINE 1, 2/TIME LINE 1, 2). If *SEARCH LIMIT = ON,* the appropriate signal level will only be searched for between the specified frequency/time lines.

The default setting is *SEARCH LIMIT = OFF.*

When only one line is enabled, frequency/time line 1 is defined as the lower limit and the upper limit is defined by the stop frequency. If frequency/time line 2 turned on, then it determines the upper limit.

For the case in which no line is active the search range is unlimited.

The *N dB DOWN* soft key automatically activates the temporary markers T1 and T2 which are located n dB below the active reference marker. The marker T1 is located to the left, the marker T2 is located to the right of the reference marker. The value n can be entered in an entry window. The default value is 6 dB.

The frequency difference between the two temporary markers is shown in the level output field on the display screen.
If, e.g., due to the noise level, it is not possible to find the frequency difference for the n dB value, a broken line is displayed in the level output field.

Entry mode is switched to the reference marker for the case in which the delta maker entry mode is to be active. The position of the reference marker can be changed in the usual way (numeric input, step-keys, roll-key, peak search, etc.).
Pressing the *N dB DOWN* soft key again switches the function off, however, the entry function for the reference marker remains turned on.



The *SHAPE FACT 60dB/3dB*.and *SHAPE FACT 60dB/6dB* soft keys activate the automatic measurement of the form factor for the displayed signals.

For this purpose, four temporary markers are used. The markers T1 to T4 indicate, in increasing order, the 3 dB/6 dB positions below the reference marker level.

In the level output field, the relationship between the two frequency differences Δf_{60dB} / Δf_{3dB} and Δf_{60dB} / Δf_{6dB} are displayed

The display of the measurement value takes place in the marker field. When the level differences cannot be determined, the measurement value is marked as invalid. The update of the shape-factor display takes place at the end of sweep.

The entry mode is switched to the reference marker if the delta marker entry mode is to be active. The position of the reference marker can be changed in the usual way (numeric input, step-keys, roll-key, peak search, etc.).

The *SHAPE FACTOR* function is turned off by pressing *SHAPE FACTOR* soft key once again, or by enabling another marker.

The *SHAPE FACTOR* function is available only in the frequency domain.

2.9.3.3.1 Summary Marker

The summary markers are available for measurements in the time domain (SPAN = 0).

Unlike the markers and delta markers, the *summary markers* are not used to mark the pixels of a trace. They activate a measurement of the rms value (*RMS*) or of the average value (*MEAN*) of the whole trace. The result is displayed in the marker info field.

The measured values are either updated after every sweep or averaged according to a defined number of sweeps (*AVERAGE ON/OFF* and *SWEEP COUNT*). In case of maximum peak evaluation (*PEAK HOLD ON*) the measured values are held until the occurrence of the next higher value.

Example:
Marker info field switched on with summary marker: *MEAN, AVERAGE ON* and *PEAK HOLD ON*

```
MEAN HOLD      2.33 Watt
MEAN AV        2.29 Watt
```

The evaluation range can be limited with the function *SEARCH LIMITS ON* and the time lines (*TIME LINE1,2*), eg when measuring the average power of a sampled signal from the beginning to the end of a burst.

With the summary marker switched on, the sampling detector is activated (*TRACE-DETECTOR-AUTO*).

MARKER SEARCH menu

The *SUM MKR* soft key activates the summary marker

The measurement, rms or average value and the settings for maximum peak evaluation and averaging is selected in the submenu *SUMMARY MARKER*.

The soft key is only available in the time domain.

MARKER SEARCH menu



The *SUMMARY MARKER* soft key calls up the submenu for selecting the summary marker measurements.

The soft key is only available in the time domain.

The *RMS* soft key selects the measurement of the rms value of the signal per sweep.

In case of maximum peak evaluation the highest rms value since the activation of *PEAK HOLD ON* is displayed.

In case of *AVERAGE ON* the rms values of a trace are averaged and displayed over several sweeps.

The number of sweeps is set with the *SWEEP COUNT* soft key. If *PEAK HOLD = ON* is active at the same time, the display is held until the occurrence of the next higher average value.

The *MEAN* soft key selects the measurement of the average value of the signal per sweep.

Thus, the mean power can be measured, for example during a GSM burst.

In case of maximum peak evaluation, the highest average value since the activation of *PEAK HOLD ON* is displayed.

In case of *AVERAGE ON*, the average values of a trace are averaged and displayed over several sweeps.

The number of sweeps is set with the *SWEEP COUNT* soft key. If *PEAK HOLD = ON* is active at the same time, the display is held until the occurrence of the next higher average value.

The *PEAK HOLD ON/OFF* soft key switches the maximum peak evaluation on and off.

For all active summary markers, the displays are updated after each sweep only if higher values have occurred.

The measured values can be reset by switching the *PEAK HOLD ON / OFF* soft key on and off again.

The *AVERAGE ON/OFF* soft key switches the averaging of the summary markers on and off.

The measured values can be reset by switching the *AVERAGE HOLD ON / OFF* soft key on and off again.

The *SWEEP COUNT* soft key activates the entry of the number of sweeps in the *SINGLE SWEEP* mode.

The permissible range of values is 0 to 32767.

In case of *AVERAGE ON*:

If an averaging has been selected, SW*EEP COUNT* also determines the number of measurements required for averaging.

SWEEP COUNT = 0	10 measured values are required for running averaging.
SWEEP COUNT = 1	No averaging is carried out.
SWEEP COUNT > 1	An averaging is carried out over the set number of measured values.

In the *CONTINUOUS SWEEP* mode averaging is performed until the number of sweeps set under *SWEEP COUNT* is attained and then running averaging is performed.

The maximum peak evaluation is infinite independent of the entry under *SWEEP COUNT.*

Note: *This setting is equivalent to the settings of the number of sweeps of menus TRACE and SWEEP-SWEEP.*

The *ALL SUM MKR OFF* soft key switches all the summary markers off.

2.9.3.4 Instrument Parameter Changes via Markers – MKR → Key

*MARKER MKR →*menu:



The *MKR →* menu offers functions through which instrument parameters can be changed with the aid of the currently active marker. Exactly as in the *SEARCH* menu, these functions can also be applied to the delta markers.

The choice between marker and delta marker is made according to the currently active frequency entry mode for the marker/delta marker. If no entry mode is active, the marker with the lowest number will be activated as the reference marker.

The *ACTIVE MKR /DELTA* soft key toggles between the active marker and the active delta marker.

If *DELTA* is illuminated, the following marker functions are carried out with the active delta marker.

Note: *Switching between marker and delta marker can also be done with the NORMAL and DELTA keys.*



To simplify control, the *PEAK* search function (see section "Search Functions - *SEARCH Key")* is also available in the *MRK→* menu. Thus, the most important functions *MARKER→PEAK*, *MKR→CENTER* and *MKR→REF LEVEL* can be selected in one menu.

The *MKR→CENTER* soft key sets the center frequency for the current marker/delta marker .

The soft key is not available in the time domain.

The *MKR→REF LEVEL* soft key sets the reference level to that of the current marker.

The *MKR→CF STEPSIZE* soft key sets the step size for the center frequency entry mode to the current marker frequency, and also sets step-size adaptation to *MANUAL*. The *CF STEP SIZE* remains at this value until the center frequency entry mode in the STEP menu is switched from *MANUAL* to *AUTO* again.

The *MKR→CF STEPSIZE* function is, above all, helpful in the measurement of harmonics with large dynamic range (narrow bandwidth and narrow span).

The soft key is not available in the time domain.

The *MKR→START* soft key sets the start frequency to the current marker frequency.

The soft key is not available in the time domain.

The *MKR→STOP* soft key sets the stop frequency to the current marker frequency.

The soft key is not available in the time domain.

The *MKR→TRACE* soft key opens a selection window through which the marker can be set to a new measurement curve. The traces available for selection appear in the window.

2.9.4 Setup of Display and Limit Lines – *LINES* Key Field

2.9.4.1 Display Lines – *D LINES Key*

Display lines are aids which, similar to markers, make the evaluation of measurement curve data more convenient. The function of display lines is similar to that of a movable scale which can be used to measure absolute and differential values on measurement curves.
In addition, the display lines can also be used to limit the range of search for marker functions.

The FSE provides four different types of display lines:

- two horizontal threshold lines for setting levels or for defining level search ranges – Display Line 1/2,
- two vertical frequency/time lines for indicating frequencies/times or for determining frequency or time search ranges – Frequency/Time Line 1/2,
- a threshold line which, for example, sets the search threshold for maximum levels (Peak Search) – Threshold Line
- a reference line which serves as the basis for mathematical correlation between measurement curves – Reference Line

For purposes of clarity, each line is annotated on the right side of the display diagram by the following abbreviations:

D1	Display Line 1	T1	Time Line 1
D2	Display Line 2	T2	Time Line 2
F1	Frequency Line 1	TH	Threshold Line
F2	Frequency Line 2	REF	Reference Line

The lines for level, threshold and reference are displayed as continuous, horizontal lines over the full width of the diagram. They are movable in the y-direction.
The lines for frequency and time are displayed as vertical, continuous lines over the total height of the diagram. They are movable in the x-direction.

For measurement operations in two separate windows, (Split Screen-Modus), the display lines are available independently in both windows. In the currently active window, the display lines can be activated and/or shifted. Lines previously defined in the currently inactive window remain unchanged.

The *LINES-D LINES* menu, used for switching on and setting the display lines, is dedicated to the chosen display in the active measurement window (span or time). For the display of a spectrum (span ≠ 0), the *FREQUENCY LINE 1* and *FREQUENCY LINE 2* soft keys appear, For the time display (span = 0), the *TIME LINE 1* and *TIME LINE 2* soft keys are displayed.

Note: *The soft keys for setting and switching the display lines on and off operate similar to a three-position switch:*

Initial condition: The line is switched off (soft key has grey background)

1st press: The line is switched on (soft key has red background) and data entry is activated. The position of the display line can be adjusted by using the roll-key, the step keys or through direct numerical inputs via the data-entry keypad. If some other arbitrary function is requested, the data-entry keypad is disabled. In this case, the display line remains switched on (soft key has green background).

2nd press: The display line is switched off (soft key has grey background).

Initial condition: The line is switched on (soft key has green background)

1st press: The line is switched on (soft key has red background) and data entry is activated. The position of the display line can be adjusted by using the roll-key, the step keys or through direct numerical inputs via the data-entry keypad. If any other arbitrary function is requested, the data-entry keypad is disabled. In this case, the display line remains switched on (soft key has green background).

2nd press: The display line is switched off (soft key has grey background).

Menu *LINES-D-LINES*



for Span ≠ 0	for Span = 0
DISPLAY LINES	DISPLAY LINES
DISPLAY LINE 1	DISPLAY LINE 1
DISPLAY LINE 2	DISPLAY LINE 2
THRESHOLD LINE	THRESHOLD LINE
REFERENCE LINE	REFERENCE LINE
or:	
FREQUENCY LINE 1	TIME LINE 1
FREQUENCY LINE 2	TIME LINE 2



The *DISPLAY LINE 1/2* soft keys switch the display lines on/off and activate the entry of the line location.

The display lines mark the selected levels in the measurement window.



The *THRESHOLD LINE* soft key switches the threshold line on/off and activates the entry of the line location.

The threshold line is a display line which defines a threshold value. This threshold value serves as a lower search limit for maximums/minimums in the marker functions (*MAX PEAK, MIN PEAK, NEXT PEAK* etc.). For signal tracking (*SIGNAL TRACK function*), this threshold value defines the lower search limit (see section "Marker Functions")..



The *REFERENCE LINE* soft key switches the reference line on/off and activates the entry of the line position.

The reference line serves as the basis for mathematical correlation between measurement curve data (see section "Mathematical Operations on Measurement Curves"



The *FREQUENCY LINE 1/2* soft keys switch the frequency lines 1/2 on/off and activate the entry of the line locations.

The frequency lines mark the selected frequencies in the measurement window or define search ranges (see section "Marker Functions").





The *TIME LINE 1/2* soft keys switch the time lines 1/2 on/off and activate the entry of line locations.

The time lines mark the selected times or define the search range (see section "Marker Functions").



2.9.4.2 Limit Lines – *LIMITS Key*

Limit lines are used to define amplitude curves or spectral distribution boundaries on the display screen which are not to be exceeded. They indicate, for example, the upper limits for interference radiation or spurious waves which are permissible from a Unit Under Test (UUT). For transmission of information in TDMA (e.g., GSM), the amplitude of the bursts in a time slot must adhere to a curve which must fall within a specified tolerance band. The lower and upper limits may each be specified by a limit line. Then, the amplitude curve can be controlled either visually or automatically for any violations of the upper or lower limits (GO/NOGO test).
The FSE instrument supports up to 300 limit lines, each of which may have a maximum of 50 data points. For each limit line, the following characteristics must be defined:

- The name of the limit line. The limit line data are stored under this name and can be examined in the table *LIMIT LINES*.
- The domain in which the limit line is to be used. Here, a distinction is made between the time domain (span = 0 Hz) and the frequency domain (span > 0 Hz).
- The reference of the interpolation points to the X-axis. The limit line may be specified either for absolute frequencies or times or for frequencies which are related to the set center frequency and times related to the time on the left edge of the diagram.
- The reference of the interpolation points to the Y-axis. The limit line can be selected either for absolute levels or voltages or referred to the set maximum level (Ref Lvl or Max Lvl). If the reference line is switched on, it is used as reference when relative setting has been selected.
- The type of limit line (upper or lower limit). With this information and the active limit checking function (*LIMIT CHECK*), the FSE checks for compliance with each limit.
- The limit line units to be used. The units of the limit line must be compatible with the level axis in the active measurement window.
- The measurement curve (trace) to which the limit line is assigned. For the FSE, this defines the curve to which the limit is to be applied when several traces are simultaneously displayed.
- For each limit line, a margin can be defined which serves as a threshold for automatic evaluation.
- In addition, commentary can be written for each limit line, e.g., a description of the application.

In the *LINES LIMIT* menu, the compatible limit lines can be enabled in the *LIMIT LINES* table. The *SELECTED LIMIT LINE* display field provides information concerning the characteristics of the marked limit lines. New limit lines can be specified and edited in the *NEW LIMIT LINE and EDIT LIMIT LINE* sub-menus, respectively.

LINES LIMIT menu



2.9.4.2.1 Limit Line Selection

The *SELECTED LIMIT LINES* table provides information about the characteristics of the marked limit line :

Name	name
Domain	frequency or time
Limit	upper/lower limit
X-Axis	linear or logarithmic interpolation
X-Scaling	absolute or relative frequencies/times
Y-Scaling	absolute or relative Y-units
Unit	vertical scale
Comment	commentary

The characteristics of the limit line are set in the *EDIT LIMIT LINE (=NEW LIMIT LINE)* sub-menu.



The *SELECT LIMIT LINE* soft key activates the *LIMIT LINES* table and the selection bar jumps to the uppermost name in the table.

The following informations are offered in the columns of the table:

Name	Enable the limit line.
Compatible	Indicates if the limit line is compatible with the measurement window of the given trace.
Limit Check	Activate automatic violation check for upper/lower limits.
Trace	Select the measurement curve to which the limit is assigned.
Margin	Define margin.

***Name and Compatible* - Enabling limit lines**

A maximum of 8 limit lines can be enabled at any one time. A check mark at the left edge of a cell indicates that this limit line is enabled. A limit line can only be enabled when it has a check mark in the *Compatible* column, i.e., only when the horizontal display (time or frequency) and vertical scales are ***identical*** to those of the display in the measurement window.

Lines with the unit dB are compatible to all dB(..) settings of the Y-axis.
If the trace assigned to a line is not switched on, the line is displayed in the window the trace would be displayed in.

Example:
In split screen mode, trace 2 is assigned measuring window B. A line assigned to trace 2 is always displayed in measurement window B.

If the scale of the y-axis or the domain (frequency or time axis) are changed, all non-compatible limit lines are automatically switched off in order to avoid misinterpretation. The limit lines must be enabled anew when the original display is re-displayed.

***Limit Check* - Activate automatic limit violation check**

When *LIMIT CHECK ON* is activated, a GO/NOGO test is performed. In the center of the diagram, a display window appears which indicates the results of the limit check test:

LIMIT CHECK: PASSED	No violations of active limits.
LIMIT CHECK: FAILED	One or more active limit lines were violated. The message contains the names of the limit lines which were violated or whose margins were not complied with.
LIMIT CHECK: MARGIN	The margin of at least one active limit lines was not complied with, however, no limit line was violated. The message contains the names of the limit lines whose margins were not complied with.

The following example shows three active limit lines:

```
LIMIT CHECK: FAILED

LINE VHF_MASK: Failed
LINE UHF2MASK: Margin
```

A check for violations of limit lines takes place only if the limit line of the assigned measurement curve (trace) is enabled.
If *LIM CHECK* is set to *OFF* for all active limit lines, then the limit line check is not executed and the display window is activated.

***Trace* - Select the measurement curve to which the limit line is assigned.**

The selection of the measurement curve (trace) takes place in an entry window. Allowed are the integer entries 1, 2, 3 or 4. The default setting is trace 1. If the selected limit line is not compatible with the assigned measurement curve, then the limit line is disabled. (display and limit check).

***Margin* - Setting a margin.**

The margin is defined as the signal-level distance to the limit line . When the limit line is defined as an upper limit, the margin means that the level is below the limit line. When the limit line is defined as a lower limit, the margin means that the level is above the limit line. The default setting is 0 dB (i.e., no margin).

The *COPY LIMIT LINE* soft key copies the data file describing the marked limit line and saves it under a new name. In this way, a new limit line can be easily generated by parallel translation or editing of an existing limit line. The name can be arbitrarily chosen and input via an entry window (max. of 8 characters).

Pressing the *DELETE LIMIT LINE* soft key erases the selected limit line. Before deletion, a message appears requesting confirmation.

The *X OFFSET* soft key is used to horizontally shift a limit line which has been specified for relative frequencies or times (X-axis). The soft key opens an entry window, where the value for shifting may be entered numerically or via the roll-key.

Note: *When changing the start or stop frequencies, the line on the display is only retained, if SPAN FIXED is set.*

The *Y OFFSET* soft key is used to vertically shift a limit line, which has relative values for the Y-axis (levels or linear units such as volt). The soft key opens an entry window where the value for shifting may be entered numerically or via the roll-key.

Pressing the *PAGE UP* soft key sets the limit line table to the next page.

Pressing the *PAGE DOWN* soft key sets the limit line table to the previous page.

2.9.4.2.2 Entry and Editing of Limit Lines

A limit line is characterized by

- its name
- the assignment of domain (frequency or time)
- the scaling in absolute or relative times or frequencies
- linear or logarithmic interpolation
- the vertical unit
- the vertical scaling
- the definition of the limit line as either upper or lower limit.
- the data points for frequency/time and level

At the time of entry, the FSE immediately checks that all limit lines are in accordance with certain guidelines. These guidelines must be observed if specified operation is to be guaranteed.

- The frequencies/times for each data point must be entered in ascending order, however, for any single frequency/time, twodata points may be input (vertical segment of a limit line).

  The data points are allocated in order of ascending frequency/time. Gaps are not allowed. If gaps are desired, two separate limit lines must be defined and then both enabled.

- The entered frequencies/times must not necessarily be selectable in FSE. A limit line may also exceed the specified frequency or time domains. The minimum frequency for a data point is 0 Hz, the maximum frequency is 200 GHz. For the time domain representation, negative times may also be entered. The allowable range is -1000 s to +1000 s.

- The minimum/maximum value for a limit line is -200 dB to +200 dB for the logarithmic or 10^{-20} to 10^{+20} or-99.9% to + 999.9% for the linear amplitude scales.

LINES LIMIT-EDIT LIMIT LINE menu



The *EDIT LIMIT LINE* and *NEW LIMIT LINE* soft keys both call the *EDIT LIMIT LINE* sub-menu used for editing limit lines. In the table heading, the characteristics of the limit line can be entered. The data points for frequency/time and level values are entered in the columns.

Name	Enter name.
Domain	Select domain.
Unit	Select units.
X-Axis	Selection of interpolation
X-Scaling	Entry of absolute or relative values for the X-axis
Y-Scaling	Entry of absolute or relative values for the Y-axis
Limit	Select upper/lower limit.
Comment	Enter comments.
Time/Frequency	Enter time/frequency for the data points.
Limit/dBm	Enter magnitudes for the data points.



The *NAME* soft key enables the entry of characteristics in the table heading.

***Name* - Enter name**

A maximum of 8 characters are permitted for each name. All names must be compatible with the MS DOS conventions for file names. The instrument stores all limit lines with the .LIM extension.

***Domain* - Select time or frequency domain**

A change in domain (frequency/time) is only permitted when the data point table is empty. The default setting is frequency.

***X-Axis* - Indication of interpolation**

Linear or logarithmic interpolation can be carried out between the frequency reference points of the table. Selection is via the ENTER key which is toggled between LIN and LOG (toggle function).

***Scaling* - selection of absolute or relative scaling**

The limit line can either be scaled in absolute (frequency or time) or relative units. Any of the unit keys may be used to toggle between *ABSOLUTE* and *RELATIVE*, the cursor must be positioned in the X-*Scaling* or the *Y-Scaling* line

X-Scaling ABSOLUTE	The frequencies or times are interpreted as absolute physical units.
X-Scaling RELATIVE	In the data point table, the frequencies are referred to the currently set center frequency. In time domain mode, the left boundary of the diagram constitutes the reference.
Y-Scaling ABSOLUTE	The limit values refer to absolute levels or voltages.
Y-Scaling RELATIVE	The limit values refer to the reference level (Ref Level) or, in case a reference line is set, to the reference line. Limit values with the units dB or % are always relative values.

The *RELATIVE* scaling is always suitable, if masks for bursts are to be defined in the time domain, or if masks for modulated signals are required in the frequency domain.
An X-offset with half the sweep time may be entered in order to shift the mask in the time domain into the center of screen.

***Unit* - Select the vertical scale units for the limit line**

The selection of units takes place in a selection box. The default setting is dBm.



***Limit* - Select upper/lower limit**

A limit line can be defined as either an upper or lower limit.

***Comment* - Enter comments**

Comments are arbitrary, however, they must be less than 40 characters long.

The *VALUES* soft key activates the entry of the data points in the table columns *Time/Frequency* and *Limit/dB*. Which table columns appear depends upon the *Domain* selection in the table heading.

The desired frequency/time data points are entered in ascending order (two repeated frequencies/time values are permitted).

The *INSERT VALUE* soft key creates an empty line above the current cursor position where a new data point may be entered. However, during the entry of new values, it is necessary to observe an ascending order for frequency/time.

The *DELETE VALUE* soft key erases the data point (complete line) at the cursor position. All succeeding data points are shifted down accordingly.



The *SHIFT X LIMIT LINE* soft key calls an entry window where the complete limit line may be shifted parallel in the horizontal direction.

The shift takes place according to the horizontal scale:

– in the frequency domain in Hz, kHz, MHz or GHz

– in the time domain in ns, µs, ms or s

In this manner, a new limit line can be easily generated based upon an existing limit line which has been shifted horizontally and stored (*SAVE LIMIT LINE* soft key) under a new name (*NAME* soft key).

The *SHIFT Y LIMIT LINE* soft key calls an entry window where the complete limit line may be shifted parallel in the vertical direction.

The shift takes place according to the vertical scale:

– for logarithmic units, relative, in dB

– for linear units, as a factor

In this manner, a new limit line can be easily generated based upon an existing limit line which has been shifted vertically and stored (*SAVE LIMIT LINE* soft key) under a new name (*NAME* soft key).



The *SAVE LIMIT LINE* soft key stores the currently edited limit line . The name can be entered in an input window (max. 8 characters)



Pressing the *PAGE UP* soft key displays the next page of data points.

Pressing the *PAGE DOWN* soft key displays the previous page of data points.

2.9.5 Trace Selection and Setup – *TRACE Key Group*

The FSE is capable of displaying up to four separate traces at the same time. A trace consists of a maximum of 500 pixels on the horizontal axis (frequency or time). If there are more measurement values than pixels available, then several measurement values are collected together in one pixel.

The traces are selected using keys 1 to 4 of the *TRACES* key group. When two measurement windows (*SPLIT SCREEN*) are displayed, traces 1 and 3 are assigned to the upper (*SCREEN A)* and traces 2 and 4 are assigned to the lower (*SCREEN B)* measurement window.

The traces can be individually enabled for a measurement and, after the measurement is completed, held fixed. Traces which are not enabled remain dark.

For each trace, the type of display is selectable. The traces can be overwritten (CLEAR/WRITE mode) at each measurement, averaged (AVERAGE mode) over several measurements, or a maximum/ minimum value from several measurements can be determined and displayed.

Individual detectors are selectable for the various traces. The auto-peak detector displays maximum and minimum values connected by a vertical line. The max-peak detector and min-peak detector display the maximum value/minimum value of the level within a pixel. The sampling detector displays the instantaneous value of the level at a pixel. The rms detector displays the power (rms value) of the measured values within a pixel, the average detector the average value.

2.9.5.1 Measurement Function Selection - *TRACE 1 to 4* key

The trace functions are partitioned as follows:

- type of trace display (CLEAR/WRITE, VIEW and BLANK)
- evaluation of the trace as a whole (AVERAGE, MAX HOLD and MIN HOLD)
- evaluation of the individual pixels of a trace (AUTOPEAK, MAX PEAK, MIN PEAK, SAMPLE, RMS and AVERAGE)

TRACE 1 menu



The *TRACE* keys 1...4 call a menu which presents the options for the selected trace.

In this menu, the method to be used for compressing the measurement data in the frequency or time domain to the 500 representable points of the display is determined.

At the beginning of the measurement, each trace can be displayed either completely new or based on previous measurement results.

Traces can be displayed, blanked and copied.

By applying mathematical functions, the traces can also be corrected.

The measurement detector for each of the display types may be chosen either directly or selected automatically by the FSE.

All activated traces are marked with a LED at the corresponding key (here, *TRACE 1).* The default setting is *TRACE 1* with *CLEAR / WRITE* selected. The remaining traces 2...4 are switched off (*BLANK*). For the split screen display, the selection of the trace automatically selects the corresponding screen for entry.

The *CLEAR/WRITE, MAX HOLD, MIN HOLD, AVERAGE, VIEW,* and *BLANK* are mutually exclusive selection switches.

The *CLEAR/WRITE* soft key activates the clear/write display mode.
The trace is displayed without additional trace evaluation. The trace memory is overwritten by each sweep. If more than one data point falls within a pixel, the trace is displayed in bar form with the maximum and minimum values in a pixel connected. In the clear/write display mode, all the available detectors are selectable. The autopeak detector is selected in the default mode (detector to *AUTO*).

After each *CLEAR/WRITE* soft key action, the FSE clears the selected trace memory and starts the measurement anew.



The *VIEW* soft key freezes the current contents of the trace memory and displays them on the display screen.

If the trace data were formed through *MAX HOLD*, *MIN HOLD* or *AVERAGE,* the sweep is restarted and the trace contents are cleared, after switching to these trace modes.

If a trace is frozen by *VIEW*, the instrument settings can be modified without modifying the displayed trace. The fact that the trace and the current instrument setting do not agree anymore is indicated by an enhancement label "*" at the right edge of the grid. The initial instrument setting can be restored using the *ADJUST TO TRACE* soft key in the *TRACE MATH* sub-menu.

If LEVEL RANGE or REF LEVEL is changed in the *VIEW* display mode, the FSE adjusts the measurement data to the changed display range. Thus, an amplitude zoom can be performed after the measurement so that details of the trace can be seen better.

The *BLANK* softkey removes the trace from the display screen. However, the trace data remain stored in memory and can be displayed again by *VIEW*. The markers for the blanked trace are also erased. If the trace is activated again (with *VIEW, CLEAR / WRITE, MAX HOLD, MIN HOLD, AVERAGE*) the markers will be restored to their original positions.

The *AVERAGE* soft key enables the trace averaging function. The average is taken from several foregoing measurements. The average can be calculated for each available detector. In case the detector is automatically selected by the FSE , the sampling detector is chosen.

After enabling the averaging mode, the first trace is recorded in *CLEAR/WRITE* mode with the selected detector. After the second sweep, the average is then formed for each succeeding sweep. Here, the average is formed over the samples/pixels, i.e., according to the LIN or LOG setting, over amplitudes or levels.

The average always starts anew when one of the AVERAGE soft keys is pressed. The trace memory is also cleared. This is also the case when the trace is switched from the setting *AVERAGE* to *VIEW* or *BLANK*

Description of the averaging procedure:

Averaging is carried out using the pixels which are derived from the measurement value samples. These pixels may in some cases be comprised of several combined measurement values. This means that the average is formed over linear amplitude values when the level display is linear and over levels when the level display is logarithmic. Because of this, the trace must be measured anew when changing between the LIN and LOG display mode. The settings *CONT/SINGLE SWEEP* and the running average apply to the average display analogously.

Two calculation procedures are available for averaging. For *SWEEP COUNT*= 0 , a running average is calculated according to the following equation:

$$TRACE = \frac{9 * TRACE + MEAS\_VALUE}{10}$$

Because of the distribution of the weighting between the new measurement value and the trace average, the measurement history has essentially no influence on the displayed trace after around 10 sweeps have taken place. For this setting, the signal noise is effectively reduced without the need for restarting the averaging process even if the signal is changed.

If, for *SWEEP COUNT* a value >1 is entered, the averaging takes place over the selected number of sweeps. In this case, the displayed trace is determined during averaging according to the following equation:

$$TRACE = \frac{(n-1) * TRACE + MEAS\_VALUE}{n}$$

where n is the number of the current sweep (n = 2 ... SWEEP COUNT). For the first sweep, an average is not calculated. The measurement values are stored directly in trace memory. With growing n, the displayed trace is increasingly smoothed since more individual trace data are available for averaging.
The average trace is stored in trace memory after the defined number of sweeps. Until this number of sweeps is reached, a preliminary average is displayed.

After completion of averaging, ie if the averaging length defined with *SWEEP COUNT* is attained, a running averaging is continued with *CONTINUOUS SWEEP* according to the following formula:

$$Trace = \frac{(N-1) \cdot Trace_{old} + meas.value}{N}$$, where Trace = new trace, $Trace_{old}$ = old trace, N = SWEEP COUNT

The display "Sweep 200 of 200" then remains constant until a new start is made.

In *SINGLE SWEEP* mode, *SWEEP START* initiates n single sweeps. The sweeps are stopped as soon as the selected number of sweeps is reached. The number of the current sweep and the total number of sweeps are shown in the display: "Sweep 3 of 200".

The *SWEEP COUNT* soft key activates the entry of the number of sweeps, over which an average is to be calculated.
The permitted range for SWEEP COUNT is 0 through 32767. For 0, the FSE performs a running average over 10 sweeps. For 1, no averaging takes place.

The default setting is 10 sweeps. The programming naturally influences the sweep duration. The number of sweeps which are used in the averaging process or the averaging time are valid **for all 4 traces**.

Note : *The setting of the SWEEP COUNT in the trace menu is equivalent to the setting in the sweep menu.*

The *MAX HOLD* soft key activates the max hold mode.
In this display mode, the FSE saves for each sweep the largest of the previously stored/currently measured values in the trace memory. The detector is set automatically to *MAX PEAK*. In this way, the maximum value of a signal can be determined over several sweeps.

This is especially useful in the measurement of modulated or pulsed signals. The signal spectrum is filled at each sweep until all signal components have been captured.

By pressing of the *MAX HOLD* soft key again, the trace memory is cleared and the maximum value accumulation begins anew.

If *MAX HOLD* is enabled, a new start is made after clearing the trace memory for each frequency change, (start frequency, stop frequency, center frequency or frequency span), a reference level change or switching between linear/logarithmic scales.

The *MIN HOLD* soft key activates the min hold mode.
In this display mode, the FSE saves for each sweep the smallest of the previously stored/currently measured values in the trace memory. The detector is set automatically to *MIN PEAK.* In this way, the minimum value of a signal can be determined over several sweeps. This function is, e.g., useful in making an unmodulated carrier in a mix of signals visible. Noise, interference signals or modulated signals are suppressed by the *MIN HOLD* function while a CW signal maintains a constant level.

Pressing the *MIN HOLD* soft key clears the trace memory and the minimum value function starts anew.

The *HOLD CONT* soft key defines whether the traces in the average mode and min hold/max hold mode are reset after some definite parameter changes.

OFF The traces are reset after some definite parameter changes.

ON This mechanism is switched off.

In general, parameter changes require a restart of the measurement before results are evaluated (e. g. with markers). For those changes that are known to require a new measurement (e. g. modification of the span), the trace is automatically reset so that erroneous evaluations of previous results are avoided.
This mechanism can be switched off for those exceptional cases where the described behavior is unwelcome.

The *COPY* soft key copies the contents of the display screen for the current trace to another trace memory. A table appears in which the desired copy procedure can be selected.



For only one window, the selected trace can be copied to any of the other trace memories since here, all four traces are displayed in one diagram with the same frequency boundaries.
In the split screen display, this is only possible as long as the frequencies of screen A and screen B are identical. If this is not the case, the selected trace can only be copied to the corresponding trace memory, i.e., trace 1 to trace 3 and trace 2 to trace 4 or vice versa. In this case, only the available trace is displayed.

After copying, the contents of the destination memory are lost. The destination memory now changes automatically to view mode with the new data.

2.9.5.2 Detector Selection

The FSE detectors are realised by pure digital techniques . The detectors available are the max-peak detector which delivers the maximum value from a number of sample values, the min-peak detector which delivers the minimum value from a number of sample values and the sampling detector. The sampling detector can transfer the sampled data without modification or can perform a data reduction by suppressing non-displayable values. For the peak detectors, the current value is compared with the maximum/minimum levels of the previously sampled data. When the number of samples defined by the instrument settings is reached, the samples are collected into the available pixels. Thus, each of the 500 pixels of the display represents 1/500 of the sweep range and contains, in compressed form, all of the individual measurements (frequency samples) in this sub-range. Even though the recording rate is high, there are no recording gaps thanks to the internal pipeline structure. According to the trace display mode, an optimised detector is automatically applied. Since the peak detectors and the sample detector are connected in parallel, a single sweep is sufficient for recording and displaying four traces with four detectors.

Peak value detectors (*MAX PEAK* / *MIN PEAK*)

Peak value detectors are implemented by digital comparators, which determine the largest of all positive (max peak) or the smallest of all negative (min peak) peak values of the levels measured at the different frequencies which are displayed in one of the 500 pixels. This is repeated for each pixel so that, for wide frequency spans and inspite of the limited display resolution, a large number of measurements can be taken into consideration for the display of the spectrum.

AUTOPEAK detector

The *AUTOPEAK* detector combines the two peak detectors. The max-peak detector and min-peak detector determine the maximum and minimum level at a displayed test point at the same time and display it as a common measurement value. The maximum and minimum level at a frequency point are joined with a vertical line.

SAMPLE detector

The *SAMPLE* detector transfers all sampled data without further evaluation and either displays them directly or, for reasons of speed (short sweep times), first writes them into a memory and subsequently processes them.

Data reduction, i.e., summing of measurement values of neighbouring frequencies or time samples is not performed here. If, during a sweep, more measurement values are generated than can be displayed, measurement values will be lost. Discrete signals can thus be lost

Therefore, the sampling detector can only be recommended for a ratio of span-to-resolution bandwidth of up to approximately 250. It is thereby guaranteed that no signal will be suppressed (example: span 1 MHz --> min. bandwidth 5 kHz).

RMS detector

The rms detector forms the rms value of the measured values within a pixel.
To this effect FSE uses the linear display voltage after the envelope detection. The linear values are squared, summed and the sum is divided through the number of samples (= root mean square). In case of logarithmic display, the logarithm is then formed from the square sum. In case of linear display the root mean square is displayed directly. Each pixel thus corresponds to the power of the measured values summed up in the pixel.
The rms detector supplies the power of the signal independent of the waveform (CW carrier, modulated carrier, white noise or pulse signal). The correction factors required by other detectors for the power measurement of the different signal classes are omitted.

Average detector

The average detector forms the average value of measured values within a pixel.
To this effect, FSE uses the linear display voltage after the envelope detection. The linear sample values are summed up and the sum is divided by the number of measurement samples (= linear average value). In case of logarithmic display, the logarithm is then formed from the average value. In case of linear display the average value is displayed directly. Each pixel thus corresponds to the average value of the measured values summed up in the pixel.
The average detector supplies the average value of the signal independent of the waveform (CW carrier, modulated carrier, white noise or pulse signal).

Note: *During a sweep, the FSE switches the first oscillator in steps which are smaller than approximately 1/10 of the bandwidth. This guarantees that the level of a signal is correctly measured. For narrow bandwidths and wide spans, a very large number of measurement values are generated. The number of frequency steps is, however, always a multiple of 500 (= number of displayable points). In the sampling mode, only every n^{th} value is displayed. The quantity n depends upon the number of measurement values, i.e on the span, resolution bandwidth and the measurement rate.*

TRACE 1-DETECTOR submenu



The *DETECTOR* soft key opens a submenu to select the detector.

The detector type may be independently selected for each trace. Mode *AUTO SELECT* sets the best suitable detector for the type of trace display (Clear Write, Max Hold oder Min Hold).

The soft keys are mutually exclusive selection switches.

The *AUTO SELECT* soft key (= default) selects the optimum detector dependent upon the trace mode (clear write, max hold, min hold).

Trace-mode	**Detector**
Clear/Write	Autopeak
Average	Sample
Max Hold	Max Peak
Min Hold	Min Peak

The *DETECTOR AUTOPEAK* soft key selects the autopeak detector.

The *DETECTOR MAX PEAK* soft key selects the max peak detector. It is recommended if pulse-shaped signals are to be measured.

The *DETECTOR MIN PEAK* soft key selects the min peak detector. Weak sinewave signals become clearly visible in noise by using this detector. For a composite signal made up of sinewave and pulse signals the pulse signals are suppressed.

The *DETECTOR SAMPLE* soft key selects the sample detector.

It is used if uncorrelated signals like noise are to be measured. The power can be determined by means of fixed correction factors for evaluation and the log amplifier.

The DETECTOR RMS softkey activates the rms detector.

The rms detector supplies the power of the signal independent of the waveform. To this effect the root mean square of all sampled level values is formed during the sweep of a pixel. The sweep time thus determines the number of averaged values so that the trace can be better averaged with increasing sweep time. The rms detector is thus an alternative for averaging over several sweeps (see TRACE AVERAGE).

In the time domain (SPAN = 0), the rms detector is only available for sweep times ≥ 5 ms. Moreover, the combination of the rms detector with the pretrigger function and the gaped sweep function is not permissible.

The video bandwidth has to be set to at least 10 times the resolution bandwidth (RBW) so that the rms value of the signal is not invalidated by video filtering.

The *DETECTOR AVERAGE* softkey activates the average detector.

In contrast to the rms detector, the average detector supplies the linear average of all sampled level values during the sweep of a pixel.

The same restrictions as those of the rms detector apply (see above).

2.9.5.3 Quasi Analog Display

Normally, measurement points are displayed interconnected by a continuous line. The leads to a continuous curve which is erased and rewritten for each new sweep. However, in the domain of analog measurement technology, display screen persistence leads to statistical emphasis which is related to the relative frequency of occurrence of a signal. Thus, on the display screen, frequently occurring events appear much brighter than rarely occurring curve segments.

Using the *ANALOG TRACE* function, the characteristics of an analog display are simulated. In this case, a measurement value is displayed as a single pixel on the display screen. This pixel is reset only by explicitly clearing the trace with *CLEAR / WRITE*. The overwriting of several sweeps is now possible and a frequency-of-occurrence distribution of the measurement values can be observed.

TRACE 1 side menu



The ANALOG TR ON/OFF softkey enables/disables the *ANALOG TRACE* function for each trace.

The measurement is always made with the selected detector.

2.9.5.4 Mathematical Functions for Traces

TRACE 1-TRACE MATH submenu:



The *TRACE MATH* soft key opens a sub-menu in which a differential curve for the selected trace is calculated.



The *T1-T2+REF*, *T1-T3+REF*, *T1-T3+REF* and *T1-REF* soft keys subtract the corresponding traces and add the set level to the difference. If the reference line is switched on (see key D LINES), the level value of the reference line instead of the reference level is added to the difference. Thus, the differential curve can be positioned anywhere on the screen by shifting the reference line. The difference of the two traces with respect to the reference line is displayed.

The *T1-REF* soft key subtracts the level of the reference line from the trace level.

To indicate that the trace has been obtained by a differential curve, a corresponding enhancement label is displayed at the right margin of the measurement value diagram (1-2, 1-3, 1-4, 1-R). In *TRACE 1* main menu, the *TRACE MATH* soft key is on a coloured background to show that the function is being used.

***Important**: For a display with two measurement windows, not all combinations are allowed if the sweep data for screen A and screen B are not the same. Only the traces allowed in the screen can be combined (in screen A, only trace 1 with trace 3; in screen B, only trace 2 with trace 4).*

The *TRACE MATH OFF* soft key switches the enabled differential curve off. The soft key is only available when a conversion function is enabled.

The *ADJUST TO TRACE* soft key restores the original instrument settings when the corresponding trace is set to *VIEW* and the current instrument settings are different than those of the trace data.

If a trace is frozen with *VIEW*, changes in the instrument settings can be made without influencing the trace. An asterisk(*) at the edge of the display screen indicates that the current instrument settings are different than those in effect when the trace was recorded. In this case, the *ADJUST TO TRACE* soft key is presented with which the original instrument setting can be restored.

2.9.6 Sweep Control – *SWEEP Key Group*

Using the *SWEEP* key group, the parameters are entered which determine the sweep characteristics. These are the coupled functions resolution bandwidth, video bandwidth and sweep time (*COUPLING* key), the trigger used for starting the sweep (*TRIGGER* key) and the type of sweep (*SWEEP* key).

2.9.6.1 Coupled Settings – *COUPLING* Key

The *COUPLING* key calls a menu for entering the sweep parameters resolution bandwidth *(RBW)*, video bandwidth *(VBW)* and sweep time *(SWT)*. The parameters can be set dependent upon the span (stop - start frequency), coupled to each other or arbitrarily defined by the user. The settings for the split screen display mode are valid only for the window which is active for entries.

The models of the FSE family offer the following resolution bandwidths:

- models 20: 10 Hz to 10 MHz in 1/2/3/5 steps
- models 30: 1 Hz to 10 MHz in 1/2/3/5 steps

The FSE resolution bandwidths up to 1 kHz have been implemented using digital filters with Gaussian characteristics. They behave like analog filters. The 1-kHz filter has been implemented both as a decoupled quartz filter and as a digital filter. One of the two filter types can be selected. The bandwidths from 2 kHz to 30 kHz have been implemented using decoupled quartz filters, the bandwidths between 50 kHz and 5 MHz using decoupled LC filters. These filters consist of 4 circuits for models 20 and 5 circuits for models 30. Moreover, the filters for models 20 and 30 differ in their shape factor: The 60 dB :3 dB shape factor of the 4-circuit filters is < 15, typ. 12; the shape factor of the 5-circuit filters is < 12, typ. 9.5.

The 10-MHz filter is a critically coupled LC filter.

For bandwidths up to about 1 kHz, the FFT-algorithm, as compared to other filter methods with identical settings, offers clear advantages with respect to the measurement time. This is due to the fact that for analog filters the time required for a given display range is proportional to (Span/RBW^2). The FFT-algorithm reduces that time to a value proportional to (Span/RBW).

FFT-filters are provided for models 30 and for bandwiths between 1 Hz and 1kHz as an alternative to the analog filters. This function is provided as an option (FSE-B5).
The video bandwidths are available in 1/2/3/5 steps between 1 Hz and 10 MHz. They can be set independent of the resolution bandwidth. Video bandwidths between 1 Hz and 10 kHz are available for resolution bandwidths up to 1 kHz and video bandwidths between 1 Hz and 10 MHz are available for resolution bandwidths greater than or equal to 2 kHz. The video filters are used to smooth the traces. Small video bandwidths in relation to the resolution bandwidth average out noise peaks pulse-like signals such that only the average value of the signals is displayed. A large video bandwidth in relation to the resolution bandwidth is therefore recommended when measuring pulsed signals (VBW ≥ 10 x RBW) so that the amplitude of pulses can be measured correctly.

2.9.6.1.1 Setting and Coupling the Coupling Resolution, Video Bandwidth and Sweep Time

SWEEP COUPLING menu



The *COUPLING* key calls a menu and a supplementary menu for setting the resolution bandwidth, video bandwidth, sweep time and their couplings.

The various *AUTO* soft keys are used to couple the functions. The coupling ratios are selected in the *COUPLING RATIO* sub-menu.

The various *MANUAL* soft keys request that the respective parameter be entered in the entry window. This parameter is not coupled to the other parameters.

The *RES BW AUTO* soft key couples the resolution bandwidth to the selected span. Changing the span causes automatic compensation of the resolution bandwidth.

Automatic coupling of resolution bandwidth to span is always recommended when, for the measurement problem on hand, a favorable setting of the resolution bandwidth in relation to the selected span is desired.

The coupling ratio is set in the *COUPLING RATIO* sub-menu.

The coupling is indicated by illumination of the soft key and the active *RBW* LED.

The *RES BW AUTO* soft key is only available in the frequency domain (span > 0 Hz). The soft key is blanked in the time domain.

The *RES BW MANUAL* soft key activates the manual entry mode for the resolution bandwidth.

The resolution bandwidth for models 20 can be set in 1/2/3/5 steps in the range between 10 Hz and 10 MHz. The nominal resolution bandwidth is the 3-dB bandwidth. For models 20 equipped with an FFT-filter (option FSE-B5) and for models 30 the lower limit of the bandwidth is 1 Hz.

For numerical inputs, the values are always rounded to the next valid bandwidth. For roll-key or the UP/DOWN key inputs, the bandwidth is adjusted in steps either upwards or downwards.

For manual input of the resolution bandwidth (coupling off), on the front panel remains off.

The *VIDEO BW AUTO* soft key couples the video bandwidth of the FSE to the resolution bandwidth. If the resolution bandwidth is changed, the video bandwidth is automatically adjusted.

The coupling of the video bandwidth is always recommended when the maximum sweep time for a selected resolution bandwidth is to be achieved. Lower video bandwidths require longer sweep times due to the longer settling time. Wider bandwidths reduce the signal/noise ratio.

The coupling ratio is set in the *COUPLING RATIO* menu.

The coupling is indicated by illumination of the soft key and the lighted *VBW* LED on the front panel.

The coupling of the video bandwidth to the resolution filter is also permitted for display in the time domain (span = 0).

The *VIDEO BW MANUAL* soft key activates the manual input mode for the video bandwidth.

The video bandwidth is selectable in 1/2/3/5 steps between 1 Hz and 10 MHz. For bandwidths up to 1 kHz, the maximum video bandwidth is 10 kHz, for larger resolution bandwidths, there is no restriction to the video bandwidth.

For numerical inputs, rounding is made to the next possible bandwidth. For roll-key or UP/DOWN entries, the bandwidth is switched in steps either downwards or upwards.

For manual input, the video bandwidth (coupling disabled) *VBW* LED on the front panel is turned off.

The *SWEEP TIME AUTO* soft key couples the sweep time to the span, video bandwidth (VBW) and resolution bandwidth (RBW). For a change in span, the resolution bandwidth or the video bandwidth is automatically matched to the sweep time. The FSE always selects the fastest sweep time which is possible without falsifying the level display.

The coupling is indicated by illumination of the soft key and turning on the *SWT* LED.

The soft key is only available in the frequency domain (span > 0 Hz). The soft key is blanked in the time domain.

The *SWEEP TIME MANUAL* soft key activates the manual input mode for the sweep time. At the same time, the coupling of the sweep is canceled and the *SWT* LED is turned off. Other couplings (*VIDEO BW, RES BW*) remain in effect.

In the frequency domain (span > 0 Hz) and for resolution bandwidths ≥ 1 kHz, the allowed sweep times range from 5 ms through 16000 s in steps of 5% of the sweep time at maximum. The digital resolution filters from 10 Hz to 1 kHz allow a minimum sweep time of 20 ms.

If an FFT-filter is used (models 20 with option FSE-B5 or models 30) the sweep time is fixed by the display range and resolution bandwidth selected and therefore can not be set.

For displays in the time domain (span = 0 Hz), the range of sweep times 1 µs to 2500 s is selectable in steps of 5% of the sweep time at maximum.

For numerical inputs, rounding is made to the next possible sweep time. For roll-key or UP/DOWN entries, the sweep time is switched in steps either downwards or upwards.

If the selected sweep time is too small for the selected span and bandwidth, measurement errors will occur. This happens because the available settling time for the resolution filter or the video filter is too short. In this case, the FSE outputs *UNCAL* on the display

The *COUPLING DEFAULT* soft key sets all coupled functions to *AUTO.* In addition, the ratio *RBW / VBW* is set to *SINE [1]* and the ratio *SPAN/RBW* is set to 50 in the *COUPLING RATIO* submenu (default setting, *COUPLING RATIO* soft key not illuminated).

The relevant soft keys are then illuminated.



The *RBW 1kHz ANA/DIG* soft key enables either the analog quartz filter (ANA) or the digital filter (DIG) for the instruments's resolution bandwidth of 1 kHz. In the default setting, the instrument uses the analog IF filter for the 1-kHz bandwidth.

The *RBW<=1kHz NORM/FFT* soft key switches between fixed filter and FFT-filter.

This soft key for models 30 of the FSE or for models 20 equipped with option FFT-filter (FSE-B5).

NORM For resolution bandwidths up to 1 kHz fixed IF-filters are used.

FFT An FFT is performed. To this end, the filtered IF-signal is digitalized by the 3-kHz resolution filters and then transformed into the spectral domain via FFT. The transformation range is equal to the selected display range but covers 4 kHz at maximum. If the display range is larger than the transformation range, serveral subsequent transformations are performed, the results are appended to each other in the spectral domain. This compensates for the frequency response of the 3-kHz preselection filter so that the amplitude response within the transformation range is offset. A flattop window seves as a window in the time domain so that a high amplitude precision with good selection is achieved.

Span:
- minimum display range: 50× resolution bandwidth selected
- maximum display range:
  Resolution bwidths > 20 Hz: 2 MHz (500 FFT-transf./sweep at maximum)
  Resolution bwidths < 20Hz: Reduction to 125 kHz at 1 Hz resolution bandwidth

Level display range:	100 dB at max. A larger display range implies that the trace is tilted at –100 dB from the reference level.
Sweep time:	fixed by the bandwidth selected and the display range. (Reason: an FFT-filter represents a block transformation). The sweep time can not be changed (soft key inactive).
Detector	All settings of the sample detector are fixed, no other detector can be selected (softkeys inactive)
Video bandwidth	not defined for FFT-transf. so that it can not be set (softkeys inactive).

Compared to fixed filters, FFT-filters lead to markedly reduced sweep times. For a display range of 50 kHz and a resolution bandwith of 100 Hz, e. g., the sweep time is reduced from 25 s to 520 ms. FFT-filters are particularly suitable for stationary signals (sinusoidal signals or signals that are continuously modulated in time). For burst signals (TDMA) or pulses, fixed filters should be preferred. The FFT is a block transformation so that the result depends on the time relation between the dataset to be transformed and the burst or pulse signal. A 'gated sweep' measurement for TDMA signals is therefore not provided if FFT-filters are used.



The *RBW / VBW PULSE* soft key sets the following coupling ratio:

video bandwidth = 10 x resolution bandwidth
or
video bandwidth = 10 MHz (= maximum video bandwidth).

This coupling ratio is always to be recommended when the amplitude of pulsed signal shape is to be measured. The IF filter characteristics alone determine the pulse shape. No additional weighting takes place via the video filter.

This setting is only effective for the *VBW AUTO* selection in the main menu.



The *RBW / VBW NOISE* soft key sets the following coupling ratio:
video bandwidth = resolution bandwidth/10

With this setting, noise and pulsed signals are suppressed in the video section. For noise signals, the FSE displays the average value.

This setting is only effective for the *VBW AUTO* selection in the main menu.

The *RBW / VBW MANUAL* soft key activates the coupling ratio for resolution bandwidth to video bandwidth.

The ratio of resolution bandwidth to video bandwidth can be set in the range from 0,001 to 1000.

This setting is only effective for the *VBW AUTO* selection in the main menu.

The *SPAN / RBW AUTO [50]* soft key sets the following coupling:
resolution bandwidth = span/50

This coupling corresponds to the default state.

This setting is only effective for the *RBW AUTO* selection in the main menu.

The *SPAN / RBW MANUAL* soft key activates the manual entry mode for the coupling of resolution bandwidth and span.

The ratio of resolution bandwidth to span can be in the range from 1 to 10000.

This setting is only effective for the *RBW AUTO* selection in the main menu.

2.9.6.2 Sweep Trigger – TRIGGER Key

SWEEP TRIGGER menu:



The *TRIGGER* key opens a menu for selection of the various trigger sources and the trigger polarity. The active trigger mode is indicated by illumination of the corresponding soft key.

For triggering modes in which the trigger threshold can be entered, the corresponding entry window is activated and, if appropriate, a horizontal trigger line is displayed.

The *FREE RUN, VIDEO, LINE, EXTERN* and *RF-POWER* soft keys are selection switches. Only one key can be enabled at any one time (illuminated). For sweep operations controlled by a gate signal, the *FREE RUN* setting is the only setting possible.

If triggering has taken place, the trigger LED is turned on at the beginning of the sweep and then turned off at the end of sweep.

To indicate that the FSE is set for triggering (= not free run), the enhancement label **TRG** is shown on the display. If two measurement windows are displayed, TRG appears next to the window which is configured for triggering.

The *FREE RUN* soft key activates the free-run sweep mode (default setting).

In free-run sweep mode there is no triggering at the start of sweep.

The *VIDEO* soft key activates triggering by the displayed voltage.

For the video triggering mode, a level line showing the trigger threshold is displayed. Using the level line, the threshold can be adjusted with the roll-key or the UP/DOWN keys.

The *LINE* soft key activates triggering derived from the mains (line) frequency. The power supply generates a trigger pulse at the line frequency which is used to trigger a new sweep.

The *EXTERN* soft key activates triggering via an external voltage (-5V...+5V) at the input connector *EXT TRIGGER/GATE* on the rear panel.

The trigger threshold can be set in an entry window within a range of -5V...+5V.

External triggering in the sweep mode "gated sweep" (*SWEEP SWEEP-EXT GATE ON)* is not possible, because the *EXT TRIG/GATE* connector is used to control the sweep. The soft key is not illuminated in these modes.

The *RF POWER* soft key activates triggering of the measurement via signals which are outside the measurement channel.

The FSE uses a level detector at the intermediate frequency. The detector threshold is approximately -20 dBm at the input mixer. This means that the actual trigger level at the RF input is approx. -20 dBm plus the set RF attenuation.

The bandwidth at the intermediate frequency is approximately 60 MHz for model FSEA, approx. 160 MHz for FSEB, FSEM and FSEK. Triggering takes place when the trigger threshold is exceeded within a 100 MHz bandwidth about the selected frequency. Thus, the measurement of noise emissions, e.g., for pulsed carriers, is possible. The carrier itself is suppressed via the selected resolution filter.

The *TRIGGER DELAY* soft key activates the entry window for delay time or a pretrigger.

The triggering is delayed or advanced relative to the trigger signal by the entered delay time. The delay time can be set in the range from -100 s to 100 s (default = 0 s).

Note: *A negative delay time (pretrigger) can be set in the time domain (SPAN < 0 Hz) only. The maximum permissible range and the maximum resolution of the pretrigger is limited by the set sweep time:*
max. range = - 499/500 x sweep time
max. resolution = sweep time/500.
Pretriggering is not possible when the rms or the average detector is activated.

The *SLOPE POS/NEG* soft key selects the trigger slope.

The sweep starts after a positive or negative edge of the trigger signal. The selected setting is illuminated.

The selection is valid for all trigger modes with the exception of *FREE RUN.*

The default mode is *SLOPE POS.*

2.9.6.3 Sweep Setup – SWEEP Key

SWEEP SWEEP menu:





The *SWEEP* key calls a menu in which the type of sweep (sweep mode) is determined. In split screen mode, the entries are valid only for the active measurement window.

In the menu, continuous or single sweep mode, gap-sweep settings or the external gate function can be selected.

The *CONTINUOUS SWEEP* and *SINGLE SWEEP* soft keys are selection switches. Only one soft key can be active (illuminated) at any one time.

The *CONTINUOUS SWEEP* soft key sets the continuous sweep mode. This means, that the sweep takes place continuously according to the trigger conditions.

In case of split screen display with different settings in each measurement window, screen A is swept first and then screen B. After pressing the soft key, the sweep is initialized and restarted.

CONTINUOUS SWEEP is the default setting of FSE.

The *SINGLE SWEEP* soft key starts a series of n sweeps according to the triggering definition. The number of sweeps, n, is determined by the *SWEEP COUNT* soft key.

In split screen display mode, the spans of each window are swept sequentially. If a displayed curve is averaged, the span is swept n times (n = sweep count). For n = 0, a single sweep takes place.

To indicate that the FSE is set for single sweep, the enhancment label **SGL** is shown on the display.

The *SWEEPTIME AUTO* and *SWEEPTIME MANUAL* soft keys activate the automatic or manual selection of the sweep time. These functions are identical to the entries in the *COUPLING* menu (see section 2.9.6.1.1).

The *SGL SWEEP DISP OFF* soft key switches off the display during a single sweep. The trace is displayed when the sweep has terminated.

The *SWEEP COUNT* soft key activates the entry of the number of sweeps performed by the FSE after the start of a single sweep. If trace average, max hold or min hold is switched on, this also fixed the number of averaging or minimum/maximum search procedures.

Example:
[**TRACE1**: *MAX HOLD*]
[**SWEEP**: *SWEEP COUNT*: {10} **ENTER**]
[*SINGLE SWEEP*]

The FSE performs the max hold function over 19 sweeps.

The permissible range for the sweep count is 0 through 32767. For sweep count = 0 or 1, a sweep is performed. For trace averaging *(AVERAGE)*, sweep count = 0 and continuous sweep, the FSE performs a running average over 10 sweeps in average mode. For sweep count = 1, no averaging takes place.

The default setting totals 10 sweeps.

Note: *The setting for the number of sweeps in the TRACE menu is equivalent to the setting in the SWEEP menu. In SINGLE SWEEP mode, the measurement is stopped after reaching the chosen number of sweeps.*

2.9.6.3.1 Gated Sweep

By using a gate in sweep mode and stopping the measurement while the gate signal is inactive, the spectrum for pulsed carriers can be displayed without overlaid frequency components caused by the on/off switching procedure. Similarly, the spectrum can also be examined for an inactive carrier. The sweep can be controlled by an external gate or by the internal power trigger.



Fig. 2.9-5 Pulsed signal GATE



Fig 2.9-6 TDMA-signal with GATE ON

The 'gated sweep' mode is activated by the *EXT GATE ON/OFF* soft key. The setting of the mode takes place in the *GATE SETTINGS* sub-menu.

SWEEP SWEEP menu:

The *EXT GATE ON / OFF* soft key switches the sweep mode with an internal or external gate on/off.

When *GATE ON* is selected, a signal applied to the rear panel connector *EXT TRIGGER/GATE* or the internal RF power detector controls the sweep of the analyzer. The sweep can be stopped and then continued. A switch from an edge triggered to a level triggered mode can also be made.



Fig. 2.9-7 Interaction of the parameters *GATE MODE*, *GATE DELAY* and *GATE LENGTH*

The soft key is only available in the frequency domain (span > 0).

GATE ON is only possible when the trigger mode is set to *FREE RUN* (*SWEEP TRIGGER* menu) .

To indicate that the FSE is set for sweep mode with external gate, the enhancement label GAT is shown on the display. GAT appears next to the window which is configured for sweep mode with external gate.

SWEEP SWEEP-EXT GATE SETTINGS sub-menu:



In the *GATE SETTINGS* sub-menu, all settings are made which are necessary for 'gated sweep' operation.

On switching to the time domain, the *GATE DELAY* and *GATE LENGTH* times are displayed by horizontal time lines which allow simple adjustment of the gate time.
The

The *GATE LEVEL* soft key activates the entry window for defining the threshold value of the external gate signal.

The threshold can be set between -5V and +5V.

The *GATE MODE LEVEL/EDGE* soft key selects the trigger mode. The sweep mode *GATE* can be operated either as level or as edge triggered.

For level triggering, the *GATE LENGTH* soft key is deactivated and can not be used.

The *GATE POL* soft key determines the polarity of the *EXT GATE* control line.

If level triggering with *GATE POL POS* is set, the sweep is stopped when the gate signal is a logic ´ 0 ' (input signal < gate level) at the *EXT TRIGGER/GATE* input and then, when the gate signal goes to a logic ' 1 ', the sweep is continued after a delay time of *GATE DELAY*.

For edge triggering and a change from ' 0 ' to ' 1 ', i.e., the positive edge of the *EXT TRIGGER/GATE* input signal, the sweep is continued after a delay of *GATE DELAY* for a duration which was set by the *GATE LENGTH* soft key.

The *GATE DELAY* soft key activates the entry window for setting the delay time between the gate signal and the continuation of the sweep.

Thus, e.g., delays between the gate signal and the stabilization of an RF carrier can be taken into consideration.

For the gate delay time, values can be selected between 1 µs and 100 s. The resolution is dependent upon the absolute value of the delay time:

Gate delay	Resolution
0 - 500 µs	1 µs
0.5 - 5 ms	5 µs
5 - 50 ms	50 µs
50 - 500 ms	500 µs
0.5 - 5 s	5 ms
5 - 50 s	50 ms
50 - 100 s	500 ms

In the time domain, a time line is displayed separated from the trigger point by the gate delay time. This simplifies the adjustment of the necessary delay time.

The values for *GATE DELAY* and *GATE LENGTH* are displayed by two time lines. The duration of the active sweep for span > 0 (continuation of sweep: GATE DELAY line, stopping of sweep: GATE LENGTH line) is described by these two lines. A change in parameters causes a shift of the corresponding line position. After switching to span > 0, the selected times for the gated sweep are effective.

For edge triggering, the *GATE LENGTH* soft key activates the entry window for defining the FSE sweep duration.

GATE LENGTH can be set to values between 1µs and 100 s. The resolution is dependent upon the absolute value of the gate length:

Gate length	Resolution
0 - 500 µs	1 µs
0.5 - 5 ms	5 µs
5 - 50 ms	50 µs
50 - 500 ms	500 µs
0.5 - 5 s	5 ms
5 - 50 s	50 ms
50 - 100 s	500 ms

In the time domain *(ZERO SPAN)*, a time line is displayed separated from the *GATE DELAY* time by the *GATE LENGTH* time.

The soft key is only available for the *GATE MODE EDGE* setting (edge triggering). It is disabled for the *GATE MODE LEVEL* setting (level triggering).

The *GATE EXTERN* soft key selects a signal applied to the *EXT TRIGGER/GATE* connector on the rear panel of the instrument as a gate source.

The *GATE RF POWER* soft key selects the internal RF power detector as a gate source.

Setting the Gate Times

SWEEP SWEEP- GATE SETTINGS - GATE ADJUST submenu:



The *GATE ADJUST* soft key opens a submenu comprising all soft keys that are used to set the parameters relevant for the 'gated sweep' function.

On pressing this soft key, the display is switched to the time domain (zero span setting) so that all necessary times can be checked by means of cursor lines.

The values for Res BW, Video BW and sweep time are taken from the corresponding settings in the frequency domain.

To make sure that the times can be set correctly corresponding to the conditions in the frequency domain, the settings for the resolution bandwidth and the video bandwidth should not be changed.

The sweep time must be selected such that, e. g., a full burst is displayed. It usually differs from the sweep time in the frequency range.

Finally, *GATE DELAY* and *GATE LENGTH* can be used to set the times in such a way that the desired section in the spectral range is covered.

On quitting the submenu, the original settings in the frequency range are restored so that the measurement can be directly performed with the required parameters.

Measurement example:

The modulation spectrum of a GSM or PCS1900 signal to be measured using the 'gated sweep' function. The signal is generated by the test sender SME03. Its RF-output is directly connected to the RF input of the FSE.

Settings on the SME03:

FREQ:	802 MHz
Level:	0 dBm: Return
Digital Mod:	Select: GMSK: Select
Source:	Select: PRBS: Select: Return
Level Attenuation:	Select: 60 dB: Return

The SME03 provides a GMSK-modulated TDMA-signal (GSM)

Operation steps on the FSE:

[PRESET]	
[CENTER:	{802} **MHz]**
[SPAN	{3.6} **MHz]**
[REF LVL:	{0} **dBm**: *RF ATTEN MANUAL*: {10} **dB]**
[COUPLING:	*RES BW MANUAL*: {30} **kHz]**
[TRACE 1:	*DETECTOR*: *RMS]*
[SWEEP:	*SWEEPTIME MANUAL*: {50} **ms**;
	GATE ON
	GATE SETTINGS: *GATE MODE EDGE: GATE POL POS: GATE RF POWER*
	GATE ADJUST: *SWEEPTIME MANUAL* {1} **ms**: *GATE DELAY* {300} **µs**: *GATE LENGTH*: {250} **µs]**

Note:	***[KEY]***	*Menu called by the KEY. All indications inside the bracket refer to this menu.*
	{Number}	*Numeric value to be entered for the corresponding parameter*
	SOFTKEY	*Soft key used to select a parameter or enter a value.*

The following figure shows the screen display for gate parameter setting: The vertical lines for gate delay (GL) and gate length (GL) can be adapted to the burst signal by entering numbers of by means of the rollkey.



Fig. 2.9-8 Setting the GATE DELAY and GATE LENGTH times in the time domain using the GD and GL lines

On quitting the menu *GATE ADJUST,* the FSE returns to spectral representation.

2.9.6.3.2 Sweep Blanking – Gap Sweep

For measurements in the time domain, the *GAP SWEEP* function offers a high degree of flexibility with regard to the display of measurement data. With the *PRE TRIGGER* soft key, it is possible to display measurements taken before the trigger time. With the *GAP TIME* soft key, the measurements within a predefined time range can be blanked. Thus, it is possible to display the rising and falling edge of a signal with high resolution on a single diagram.



Fig 2.9-9 Trace blanking in sweep mode.– Gap Sweep



Fig. 2.9-10 Display of a burst without gaps



Fig. 2.9-11 Display of a burst with a gap

The GAP SWEEP measurement is activated by the GAP SWEEP *ON/OFF* soft key. The mode settings are made in the GAP SWEEP *SETTINGS* sub-menu.

SWEEP SWEEP menu:

The *GAP SWEEP ON/OFF* soft key switches the *GAP SWEEP* measurement on/off.

The soft key is available only in the time domain.

SWEEP SWEEP-GAP SWEEP SETTINGS sub-menu:



The *GAP SWEEP SETTINGS* soft key opens a sub-menu in which the parameters for the gap can be selected.

The trigger time corresponds to t = 0. Events occurring before the trigger time are displayed in negative time.

The *TRIGGER LEVEL* soft key activates the entry window for trigger level.

This function corresponds to the setting in the trigger menu.

The *PRE TRIGGER* soft key activates the entry window for the pre-trigger time. The pre-trigger time defines the separation between the left edge of the grid and the trigger time (t = 0).
At the same time the gap sweep is switched on (exception : entry t = 0)

The minimum pre-trigger time is –100 s, the maximum pre-trigger time depends on the sweep time and the trigger to gap time (max = 100 s). The maximum resolution is 50 ns.

The *PRE TRIGGER* value can be entered in the frequency domain (span > 0) as well as in the time domain and *GAP SWEEP OFF* mode. It is, however, only effective when the *GAP SWEEP* measurement is enabled.

The *TRG TO GAP TIME* soft key opens an entry window for defining the distance between the trigger time and the beginning of the gap.

The *TRIGGER TO GAP TIME* range is from 0 to 100 s with a resolution of 50 ns. The length of the gap is defined by *GAP LENGTH*. If the *GAP LENGTH* is 0 s, the entered value of *TRG TO GAP TIME* is only stored.

The *TRG TO GAP TIME* value can be entered in the frequency domain (span > 0) as well as in the time domain and for the *GAP SWEEP OFF* mode. It has an effect on the measurement only after the *GAP SWEEP ON* is switched on.

The *GAP LENGTH* soft key activates the entry window for defining the gap within which the measurement values are to be blanked.

The beginning of the gap is defined by *TRG TO GAP TIME*.

GAP LENGTH can be set to values between 150 ns and 100 s in 1/2/3/5 steps. The resolution is dependent upon the absolute value of the gap length:

Gap length	**Resolution**
150 ns - 50 µs	50 ns
50 - 500 µs	500 ns
0.5 - 5 ms	5 µs
5 - 50 ms	50 µs
50 - 500 ms	500 µs
0.5 - 5 s	5 ms
5 - 50 s	50 ms
50 - 100 s	500 ms

The *GAP LENGTH* value can be entered in the frequency domain (span > 0) as well as in the time domain and for the *GAP SWEEP OFF* mode. It has an effect on the measurement only after the *GAP SWEEP ON* is switched on.

3 Remote Control

3.1 Introduction

The instrument is equipped with an IEC-bus interface according to standard IEC 625.1/IEEE 488.2 and two RS-232 interfaces. The connectors are located at the rear of the instrument and permits to connect a controller for remote control.

The option FSE-B15, (controller function) together with the option FSE B17 (2nd IEC-bus interface) may also be used as a controller (see Chapter 1, Section 1.8).
In addition, the instrument is equipped with an RSIB interface that allows instrument control by Windows applications WinWord and Excel or by Visual C++ and Visual Basic programs

The instrument supports the SCPI version 1994.0 (Standard Commands for Programmable Instruments). The SCPI standard is based on standard IEEE 488.2 and aims at the standardization of device-specific commands, error handling and the status registers (see Section "SCPI Introduction").

This section assumes basic knowledge of IEC-bus programming and operation of the controller. A description of the interface commands is to be obtained from the relevant manuals. The RSIB interface functions are matched to the function interface for IEC/IEEE-bus programming from National Instruments. The functions supported by the DLLs are listed in annex A.

The requirements of the SCPI standard placed on command syntax, error handling and configuration of the status registers are explained in detail in the respective sections. Tables provide a fast overview of the commands implemented in the instrument and the bit assignment in the status registers. The tables are supplemented by a comprehensive description of every command and the status registers. Detailed program examples of the main functions are to be found in annex D.

The program examples for IEC-bus programming are all written in Quick BASIC.

3.2 Brief Instructions

The short and simple operating sequence given below permits fast putting into operation of the instrument and setting of its basic functions. As a prerequisite, the IEC-bus address, which is factory-set to 20, must not have been changed.

1. Connect instrument and controller using IEC-bus cable.
2. Write and start the following program on the controller:

```
CALL IBFIND("DEV1", analyzer%)                  'Open port to the instrument
CALL IBPAD(analyzer%, 20)                       'Inform controller about instrument address
CALL IBWRT(analyzer%, "*RST;*CLS")              'Reset instrument
CALL IBWRT(analyzer%, 'FREQ:CENT 100MHz')       'Set center frequency to 100 MHz
CALL IBWRT(analyzer%, 'FREQ:SPAN 10MHz')        'Set span to 10 MHz
CALL IBWRT(analyzer%, 'DISP:TRAC:Y:RLEV -10dBm')
                                                'Set reference level to -10 dBm
```

The instrument now performs a sweep in the frequency range of 95 MHz to 105 MHz.

3. To return to manual control, press the *LOCAL* key at the front panel

This page is intentionally left blank.

3.3 Switchover to Remote Control

On power-on, the instrument is always in the manual operating state ("LOCAL" state) and can be operated via the front panel.
It is switched to remote control ("REMOTE" state)

IEC-bus	as soon as it receives an addressed command from a controller.
RS-232	as soon as it receives the command "@REM" from a controller.
RSIB	as soon as it receives an addressed command from a controller.

During remote control, operation via the front panel is disabled. The instrument remains in the remote state until it is reset to the manual state via the front panel or via remote control interfaces. Switching from manual operation to remote control and vice versa does not affect the remaining instrument settings.

3.3.1 Remote Control via IEC Bus

3.3.1.1 Setting the Device Address

In order to operate the instrument via the IEC-bus, it must be addressed using the set IEC-bus address. The IEC-bus address of the instrument is factory-set to 20. It can be changed manually in the *SETUP - GENERAL SETUP* menu or via IEC bus. Addresses 0 to 30 are permissible.

Manuell: Call *SETUP - GENERAL SETUP* menu
Enter desired address in table *GPIB ADDRESS*
Terminate input using one of the unit keys (=ENTER).

Via IEC bus:

```
CALL IBFIND("DEV1", analyzer%)                    'Open port to the instrument
CALL IBPAD(analyzer%, 20)                         'Inform controller about old address
CALL IBWRT(analyzer%, "SYST:COMM:GPIB:ADDR 18")   'Set instrument to new address
CALL IBPAD(analyzer%, 18)                         'Inform controller about new address
```

3.3.1.2 Indications during Remote Control

Remote control mode is indicated by the LED "REMOTE" on the instrument's front panel. In this mode the softkeys on the display are not shown.

3.3.1.3 Return to Manual Operation

Return to manual operation is possible via the front panel or the IEC bus.

Manually: Press the *LOCAL* key.

Notes:
- *Before switchover, command processing must be completed as otherwise switchover to remote control is effected immediately.*
- *The LOCAL key can be disabled by the universal command LLO (see annex A) in order to prevent unintentional switchover. In this case, switchover to manual mode is only possible via the IEC bus.*
- *The LOCAL key can be enabled again by deactivating the REN line of the IEC bus (see annex A).*

Via IEC bus:

```
...
CALL IBLOC(analyzer%)          'Set instrument to manual operation.
...
```

3.3.2 Remote Control via RS-232-Interface

3.3.2.1 Setting the Transmission Parameters

To enable an error-free and correct data transmission, the parameters of the unit and the controller should have the same setting. Parameters can be manually changed in menu *SETUP-GENERAL SETUP* in table *COM PORT 1/2* or via remote control using the command `SYSTem:COMMunicate:SERial1|2:....`

The transmission parameters of the interfaces COM1 and COM2 are factory-set to the following values: baudrate = 9600, data bits = 8, stop bits = 1, parity = NONE and protocoll = NONE.

Manually: Setting interface COM1|2

Call *SETUP-GENERAL SETUP* menu

Select desired baudrate, bits, stopbit, parity and protocoll in table *COM PORT 1/2*.

Terminate input using one of the unit keys (=ENTER).

3.3.2.2 Indications during Remote Control

See Section 3.3.1.2.

3.3.2.3 Return to Manual Operation

Return to manual operation is possible via the front panel or via RS-232 interface.

Manually: Press the *LOCAL* key.

Note:
- *Before switchover, command processing must be completed as otherwise switchover to remote control is effected immediately.*
- *The LOCAL key can be disabled by the universal command LLO (see annex A) in order to prevent unintentional switchover. In this case, switchover to manual mode is only possible via the IEC bus.*
- *The LOCAL key can be enabled again by sending the command "@LOC" via RS-232 (see annex A).*

Via RS-232:

```
...
V24puts(port, "@LOC");          Set instrument to manual operation.
...
```

3.3.2.4 Limitations

The following limitations apply if the unit is remote-controlled via the RS-232-C interface:

- No interface messages, some control codes are defined (see annex A).
- Only the Common Commands *OPC? can be used for command synchronization, *WAI and *OPC are not available.
- Block data cannot be transmitted.

3.3.3 Remote Control via RSIB Interface

To access the measuring instruments via the RSIB interface the RSIB.DLL should be installed in the control application directory. On the measuring instrument the DLL is already installed in the corresponding directory.
The control is performed via one of the Windows applications WinWord or Excel or with Visual C++ or Visual Basic programs. The local link to the internal controller is established with the name '@local'.

Via VisualBasic: RSDLLibfind ('@local', ibsta, iberr, ibcntl)

3.3.3.1 Indications during Remote Control

See Section 3.3.1.2.

3.3.3.2 Return to Manual Operation

The return to manual operation can be performed via the front panel (*LOCAL* key) or the RSIB interface.

Manually: Press the *LOCAL* key.

Note: *Before switchover, command processing must be completed as otherwise switchover to remote control is effected immediately.*

Via RSIB:

```
...
ud = RSDLLibloc (ud, ibsta, iberr, ibcntl);
...
```

3.4 IEC-Bus Messages

The messages transferred via the data lines of the IEC bus or the RSIB interface (see annex A) can be divided into two groups:

- **interface messages and**
- **device messages.**

Some control characters are defined for the control of the RS-232-interface (see annex A).

3.4.1 IEE/IEEE-Bus Interface Messages

Interface messages are transferred on the data lines of the IEC bus, the "ATN" control line being active. They are used for communication between controller and instrument and can only be sent by a controller which has the IEC-bus control. Interface commands can be subdivided into

- **universal commands and**
- **addressed commands.**

Universal commands act on all devices connected to the IEC bus without previous addressing, addressed commands only act on devices previously addressed as listeners. The interface messages relevant to the instrument are listed in annex A.

3.4.2 RSIB Interface Messages

The RSIB interface enables the instrument to be controlled by Windows applications. The interface functions are matched to the function interface for IEC/IEEE-bus programming from National Instruments.
The functions supported by interface are listed in annex A.

3.4.3 Device Messages (Commands and Device Responses)

Device messages are transferred on the data lines of the IEC bus, the "ATN" control line not being active. ASCII code is used. The device messages are more or less equal for the different interfaces.
A distinction is made according to the direction in which they are sent on the IEC bus:

– **Commands** are messages the controller sends to the instrument. They operate the device functions and request informations.
The commands are subdivided according to two criteria::

1. According to the effect they have on the instrument:

   Setting commands cause instrument settings such as reset of the instrument or setting the center frequency.

   Queries cause data to be provided for output on the IEC-bus, e.g. for identification of the device or polling the marker.

2. According to their definition in standard IEEE 488.2:

   Common Commands are exactly defined as to their function and notation in standard IEEE 488.2. They refer to functions such as management of the standar-dized status registers, reset and selftest.

   Device-specific commands refer to functions depending on the features of the instrument such as frequency setting. A majority of these commands has also been standardized by the SCPI committee (cf. Section 3.5.1).

– **Device responses** are messages the instrument sends to the controller after a query. They can contain measurement results, instrument settings and information on the instrument status (cf. Section 3.5.4).

Structure and syntax of the device messages are described in Section 3.5. The commands are listed and explained in detail in Section 3.6.

3.5 Structure and Syntax of the Device Messages

3.5.1 SCPI Introduction

SCPI (Standard Commands for Programmable Instruments) describes a standard command set for programming instruments, irrespective of the type of instrument or manufacturer. The goal of the SCPI consortium is to standardize the device-specific commands to a large extent. For this purpose, a model was developed which defines the same functions inside a device or for different devices. Command systems were generated which are assigned to these functions. Thus it is possible to address the same functions with identical commands. The command systems are of a hierarchical structure.
Fig. 3.5-1 illustrates this tree structure using a section of command system SOURce, which operates the signal sources of the devices. The other examples concerning syntax and structure of the commands are derived from this command system.
SCPI is based on standard IEEE 488.2, i.e. it uses the same syntactic basic elements as well as the common commands defined in this standard. Part of the syntax of the device responses is defined with greater restrictions than in standard IEEE 488.2 (see Section "Responses to Queries").

3.5.2 Structure of a Command

The commands consist of a so-called header and, in most cases, one or more parameters. Header and parameter are separated by a "white space" (ASCII code 0 to 9, 11 to 32 decimal, e.g. blank). The headers may consist of several key words. Queries are formed by directly appending a question mark to the header.

Note: *The commands used in the following examples are not in every case implemented in the instrument.*

Common commands

Common commands consist of a header preceded by an asterisk "*" and one or several parameters, if any.

Examples:

`*RST`	RESET, resets the device
`*ESE 253`	EVENT STATUS ENABLE, sets the bits of the event status enable register
`*ESR?`	EVENT STATUS QUERY, queries the contents of the event status register.

Device-specific commands

Hierarchy: Device-specific commands are of hierarchical structure (see Fig. 3.5-1). The different levels are represented by combined headers. Headers of the highest level (root level) have only one key word. This key word denotes a complete command system.

Example: `SENSe` This key word denotes the command system `SENSe`.

For commands of lower levels, the complete path has to be specified, starting on the left with the highest level, the individual key words being separated by a colon ":".

Example: `SENSe:FREQuency:SPAN:LINK STARt`

This command lies in the fourth level of the SENSe system. It determines which parameter remains unchanged when the span is changed. If LINK is set to STARt, the values of CENTer and STOP are adjusted when the span is changed.



Fig. 3.5-1 Tree structure the SCPI command systems using the SENSe system by way of example

Some key words occur in several levels within one command system. Their effect depends on the structure of the command, that is to say, at which position in the header of a command they are inserted.

Example: `SOURce:FM:POLarity NORMal`
This command contains key word POLarity in the third command level. It defines the polarity between modulator and modulation signal.

`SOURce:FM:EXTernal:POLarity NORMal`
This command contains key word POLarity in the fourth command level. It defines the polarity between modulation voltage and the resulting direction of the modulation only for the external signal source indicated.

Optional key words: Some command systems permit certain key words to be optionally inserted into the header or omitted. These key words are marked by square brackets in the description. The full command length must be recognized by the instrument for reasons of compatibility with the SCPI standard. Some commands are considerably shortened by these optional key words.

Example: `[SENSe]:BANDwidth[:RESolution]:AUTO`
This command couples the resolution bandwidth of the instrument to other parameters. The following command has the same effect:
BANDwidth`:AUTO`

Note: *An optional key word must not be omitted if its effect is specified in detail by a numeric suffix.*

Long and short form: The key words feature a long form and a short form. Either the short form or the long form can be entered, other abbreviations are not permissible.

Beispiel: `STATus:QUEStionable:ENABle 1= STAT:QUES:ENAB 1`

Note: *The short form is marked by upper-case letters, the long form corresponds to the complete word. Upper-case and lower-case notation only serve the above purpose, the instrument itself does not make any difference between upper-case and lower-case letters.*

Parameter: The parameter must be separated from the header by a "white space". If several parameters are specified in a command, they are separated by a comma ",". A few queries permit the parameters MINimum, MAXimum and DEFault to be entered. For a description of the types of parameter, refer to Section 3.5.5.

Example: `SENSe:FREQuency:STOP? MAXimum` Response: 3.5E9
This query requests the maximal value for the stop frequency.

Numeric suffix: If a device features several functions or features of the same kind, e.g. inputs, the desired function can be selected by a suffix added to the command. Entries without suffix are interpreted like entries with the suffix 1.

Example:. `SYSTem:COMMunicate:SERial2:BAUD 9600`
This command sets the baudrate of the second serial interface.

3.5.3 Structure of a Command Line

A command line may consist of one or several commands. It is terminated by a <New Line>, a <New Line> with EOI or an EOI together with the last data byte. Quick BASIC automatically produces an EOI together with the last data byte.

Several commands in a command line are separated by a semicolon ";". If the next command belongs to a different command system, the semicolon is followed by a colon.

Example:
```
CALL IBWRT(analyzer, "SENSe:FREQuency:CENTer 100MHz;:INPut:ATTenuation 10")
```

This command line contains two commands. The first command is part of the SENSe system and is used to specify the center frequency of the analyzer. The second command is part of the INPut system and sets the attenuation of the input signal.

If the successive commands belong to the same system, having one or several levels in common, the command line can be abbreviated. To this end, the second command after the semicolon starts with the level that lies below the common levels (see also Fig. 3.5-1). The colon following the semicolon must be omitted in this case.

Example:
```
CALL IBWRT(analyzer, "SENSe:FREQuency:STARt 1E6;:SENSe:FREQuency:STOP 1E9")
```

This command line is represented in its full length and contains two commands separated from each other by the semicolon. Both commands are part of the SENSe command system, subsystem FREQuency, i.e. they have two common levels.
When abbreviating the command line, the second command begins with the level below SENSe:FREQuency. The colon after the semicolon is omitted.

The abbreviated form of the command line reads as follows:

```
CALL IBWRT(analyzer,  "SENSe:FREQuency:STARt 1E6;STOP 1E9")
```

However, a new command line always begins with the complete path.

Example:
```
CALL IBWRT(analyzer,  "SENSe:FREQuency:STARt 1E6")
CALL IBWRT(analyzer,  "SENSe:FREQuency:STOP 1E9")
```

3.5.4 Responses to Queries

A query is defined for each setting command unless explicitly specified otherwise. It is formed by adding a question mark to the associated setting command. According to SCPI, the responses to queries are partly subject to stricter rules than in standard IEEE 488.2.

1 The requested parameter is transmitted without header.
Example: `INPut:COUPling?` Response: `DC`

2. Maximum values, minimum values and all further quantities, which are requested via a special text parameter are returned as numerical values.
Example: `SENSe:FREQuency:STOP? MAX` Response: `3.5E9`

3. Numerical values are output without a unit. Physical quantities are referred to the basic units or to the units set using the Unit command.
Example: `SENSe:FREQuency:CENTer?` Response: `1E6` for 1 MHz

4. Truth values <Boolean values> are returned as 0 (for OFF) and 1 (for ON).
Example: `SENSe:BANDwidth:AUTO?` Response: `1` for ON

5. Text (character data) is returned in a short form (see also Section 3.5.5).
Example: `SYSTem:COMMunicate:SERial:CONTrol:RTS?` Response(for standard): `STAN`

3.5.5 Parameters

Most commands require a parameter to be specified. The parameters must be separated from the header by a "white space". Permissible parameters are numerical values, Boolean parameters, text, character strings and block data. The type of parameter required for the respective command and the permissible range of values are specified in the command description (see Section 3.6).

Numerical values Numerical values can be entered in any form, i.e. with sign, decimal point and exponent. Values exceeding the resolution of the instrument are rounded up or down. The mantissa may comprise up to 255 characters, the exponent must lie inside the value range -32000 to 32000. The exponent is introduced by an "E" or "e". Entry of the exponent alone is not permissible. In the case of physical quantities, the unit can be entered. Permissible unit prefixes are G (giga), MA (mega), MOHM and MHZ are also permissible), K (kilo), M (milli), U (micro) and N (nano). It the unit is missing, the basic unit is used.

Example:
`SENSe:FREQuency:STOP 1.5GHz = SENSe:FREQuency:STOP 1.5E9`

Special numerical The texts MINimum, MAXimum, DEFault, UP and DOWN are interpreted as valuesspecial numerical values.

In the case of a query, the numerical value is provided.

Example: Setting command: `SENSe:FREQuency:STOP MAXimum`
Query: `SENSe:FREQuency:STOP?` **Response:** `3.5E9`

MIN/MAX MINimum and MAXimum denote the minimum and maximum value.

DEF DEFault denotes a preset value which has been stored in the EPROM. This value conforms to the default setting, as it is called by the *RST command

UP/DOWN UP, DOWN increases or reduces the numerical value by one step. The step width can be specified via an allocated step command (see annex C, List of Commands) for each parameter which can be set via UP, DOWN.

INF/NINF INFinity, Negative INFinity (NINF) Negative INFinity (NINF) represent the numerical values -9.9E37 or 9.9E37, respectively. INF and NINF are only sent as device reponses.

NAN Not A Number (NAN) represents the value 9.91E37. NAN is only sent as device response. This value is not defined. Possible causes are the division of zero by zero, the subtraction of infinite from infinite and the representation of missing values.

Boolean Parameters Boolean parameters represent two states. The ON state (logically true) is represented by ON or a numerical value unequal to 0. The OFF state (logically untrue) is represented by OFF or the numerical value 0. 0 or 1 is provided in a query.

Example: Setting command: `DISPlay:WINDow:STATe ON`
Query: `DISPlay:WINDow:STATe?` **Response:** `1`

Text

Text parameters observe the syntactic rules for key words, i.e. they can be entered using a short or long form. Like any parameter, they have to be separated from the header by a white space. In the case of a query, the short form of the text is provided.

Example: Setting command: `INPut:COUPling GROund`
Query: `INPut:COUPling?` Response `GRO`

Strings

Strings must always be entered in quotation marks (' or ").

Example: `SYSTem:LANGuage "SCPI"` or
`SYSTem:LANGuage 'SCPI'`

Block data

Block data are a transmission format which is suitable for the transmission of large amounts of data. A command using a block data parameter has the following structure:

Example: `HEADer:HEADer #45168xxxxxxxx`

ASCII character # introduces the data block. The next number indicates how many of the following digits describe the length of the data block. In the example the 4 following digits indicate the length to be 5168 bytes. The data bytes follow. During the transmission of these data bytes all End or other control signs are ignored until all bytes are transmitted..

3.5.6 Overview of Syntax Elements

The following survey offers an overview of the syntax elements.

:	The colon separates the key words of a command. In a command line the colon after the separating semicolon marks the uppermost command level.
;	The semicolon separates two commands of a command line. It does not alter the path.
,	The comma separates several parameters of a command.
?	The question mark forms a query.
*	The asterix marks a common command.
"	Quotation marks introduce a string and terminate it.
#	The double dagger (#) introduces block data
	A "white space (ASCII-Code 0 to 9, 11 to 32 decimal, e.g.blank) separates header and parameter.

3.6 Description of Commands

3.6.1 Notation

In the following sections, all commands implemented in the instrument are first listed in tables and then described in detail, separated according to the command system. The notation corresponds to the one of the SCPI standards to a large extent. The SCPI conformity information can be taken from the individual description of the commands.

Table of Commands

Command: In the command column, the table provides an overview of the commands and their hierarchical arrangement (see indentations).

Parameter: The parameter column indicates the requested parameters together with their specified range.

Unit: The unit column indicates the basic unit of the physical parameters.

Remark: In the remark column an indication is made on:
- whether the command does not have a query form,
- whether the command has only one query form
- whether this command is implemented only with a certain option of the instrument

Indentations

The different levels of the SCPI command hierarchy are represented in the table by means of indentations to the right. The lower the level is, the farther the indentation to the right is. Please observe that the complete notation of the command always includes the higher levels as well.

Example: `SENSe:FREQuency:CENTer` is represented in the table as follows:

`SENSe`	first level
`:FREQuency`	second level
`:CENTer`	third level

Individual description

In the individual description, the complete notation of the command is given. An example for each command, the *RST value and the SCPI information is written out at the end of the individual description.
The modes for which a command can be used are indicated by the following abbreviations:

A	Spectrum analysis
A-F	Spectrum analysis - frequency domain only
A-Z	Spectrum analysis - time domain only (zero span)
VA	Vector signal analysis (option FSE-B7)
VA-D	Vector signal analysis - digital demodulation (option FSE-B7)
VA-A	Vector signal analysis - analog demodulation (option FSE-B7)
BTS	GSM BTS analysis (option FSE-K11)
MS	GSM MS analysis (option FSE-K10)

Note: *The spectrum analysis (analyzer) mode is implemented in the basic unit. For the other modes, the corresponding options are required.*

Upper/lower case notation Upper/lower case letters serve to mark the long or short form of the key words of a command in the description (see Section 3.5.2). The instrument itself does not distinguish between upper and lower case letters.

Special characters

| A selection of key words with an identical effect exists for several commands. These key words are indicated in the same line, they are separated by a vertical stroke. Only one of these key words has to be indicated in the header of the command. The effect of the command is independent of which of the key words is indicated.

Example: `SENSe:FREQuency:CW|:FIXed`

The two following commands of identical meaning can be formed. They set the frequency of the constantly frequent signal to 1 kHz:

`SENSe:FREQuency:CW 1E3` = `SENSe:FREQuency:FIXed 1E3`

A vertical stroke in indicating the parameters marks alternative possibilities in the sense of "or". The effect of the command is different, depending on which parameter is entered.

Example: Selection of the parameters for the command

`INPut:COUPling AC | DC`

If parameter AC is selected, only the AC content is fed through, in the case of DC, the DC as well as the AC content.

[ ] Key words in square brackets can be omitted when composing the header (cf. Section 3.5.2, Optional Keywords). The full command length must be accepted by the instrument for reasons of compatibility with the SCPI standards.
Parameters in square brackets can optionally be incorporated in the command or omitted as well.

{ } Parameters in braces can optionally be incorporated in the command either not at all, once or several times.

Description of parameters Due to the standardization, the parameter section of SCPI commands consists always of the same syntactical elements. SCPI has specified a series of definitions therefore, which are used in the tables of commands. In the tables, these established definitions are indicated in angled brackets (<...>) and will be briefly explained in the following (see also Section 3.5.5, "Parameters").

<Boolean> This indication refers to parameters which can adopt two states, "on" and "off". The "off" state may either be indicated by the keyword **OFF** or by the numeric value 0, the "on" state is indicated by **ON** or any numeric value other than zero. Parameter queries are always returned the numeric value 0 or 1.

<numeric_value>

<num> These indications mark parameters which may be entered as numeric values or be set using specific keywords (character data).

The keywords given below are permitted:

MINimum	This keyword sets the parameter to the smallest possible value.
MAXimum	This keyword sets the parameter to the largest possible value.
DEFault	This keyword is used to reset the parameter to its default value.
UP	This keyword increments the parameter value.
DOWN	This keyword decrements the parameter.

The numeric values associated to MAXimum/MINimum/DEFault can be queried by adding the corresponding keywords to the command. They must be entered following the quotation mark.

Example: `SENSe:FREQuency:CENTer? MAXimum`

returns the maximum possible numeric value of the center frequency as result.

<arbitrary block program data>

This keyword is provided for commands the parameters of which consist of a binary data block.

3.6.2 Common Commands

The common commands are taken from the IEEE 488.2 (IEC 625-2) standard. Same commands have the same effect on different devices. The headers of these commands consist of an asterisk "*" followed by three letters. Many common commands refer to the status reporting system which is described in detail in Section 3.8.

Command	Designation	Parameter	Remark
*CAL?	Calibration Query		query only
*CLS	Clear Status		no query
*ESE	Event Status Enable	0 to 255	
*ESR?	Standard Event Status Query	0 to 255	query only
*IDN?	Identification Query	<string>	query only
*IST?	Individual Status Query	0 to 255	query only
*OPC	Operation Complete		
*OPT?	Option Identification Query		query only
*PCB	Pass Control Back	0 to 30	no query
*PRE	Parallel Poll Register Enable	0 to 255	
*PSC	Power On Status Clear	0 | 1	
*RST	Reset		no query
*SRE	Service Request Enable	0 to 255	
*STB?	Status Byte Query		query only
*TRG	Trigger		no query
*TST?	Self Test Query		query only
*WAI	Wait to continue		no query

***CAL?**

CALIBRATION QUERY triggers a calibration of the instrument and subsequently query the calibration status. Any responses > 0 indicate errors.

***CLS**

CLEAR STATUS sets the status byte (STB), the standard event register (ESR) and the EVENt-part of the QUEStionable and the OPERation register to zero. The command does not alter the mask and transition parts of the registers. It clears the output buffer.

***ESE 0 to 255**

EVENT STATUS ENABLE sets the event status enable register to the value indicated. Query *ESE? returns the contents of the event status enable register in decimal form.

***ESR?**

STANDARD EVENT STATUS QUERY returns the contents of the event status register in decimal form (0 to 255) and subsequently sets the register to zero.

***IDN?**

IDENTIFICATION QUERY queries the instrument identification.

The instrument identification consists of the following elements which are separated by commas:

Manufacturer
Device (analyzer model)
Serial number of the instrument
Firmware version number
Example: "Rohde&Schwarz, FSEA30, 825082/007, 1.67"

***IST?**

INDIVIDUAL STATUS QUERY returns the contents of the IST flag in decimal form (0 | 1). The IST flag is the status bit which is sent during a parallel poll (cf. Section 3.8.3.2).

***OPC**

OPERATION COMPLETE sets bit 0 in the event status register when all preceding commands have been executed. This bit can be used to initiate a service request (cf. Section 3.7).

***OPC?**

OPERATION COMPLETE QUERY writes message "1" into the output buffer as soon as all preceding commands have been executed (cf. Section 3.7).

***OPT?**

OPTION IDENTIFICATION QUERY queries the options included in the instrument and returns a list of the options installed. The options are separated from each other by means of commas.

Position	Option	
1	FSE-B3	TV Demodulator
2	FSE-B4	Low Phase Noise & OCXO
3	FSE-B5	FFT-Filter
4		reserved
5	FSE-B7	Vector Signal Analysis
6	FSE-B8	Tracking Generator 3.5 GHz
7	FSE-B9	Tracking Generator 3.5 GHz with I/Q modulator
8	FSE-B10	Tracking Generator 7 GHz
9	FSE-B11	Tracking Generator 7 GHz with I/Q modulator
10	FSE-B12	Output Attenuator for Tracking Generator
11		reserved
12		reserved
13	FSE-B15	DOS option
14		reserved
15		reserved
16		reserved
17		reserved
18		reserved
19	FSE-B21	External Mixer Output
20		reserved
21		reserved

Example: 0, FSE-B4, 0, 0, FSE-B7, 0, 0, 0, FSE-B11, FSE-B12, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0

***PCB 0 to 30**

PASS CONTROL BACK indicates the controller address which the IEC-bus control is to be returned to after termination of the triggered action.

***PRE 0 to 255**

PARALLEL POLL REGISTER ENABLE sets parallel poll enable register to the value indicated. Query *PRE? returns the contents of the parallel poll enable register in decimal form.

***PSC 0 | 1**

POWER ON STATUS CLEAR determines whether the contents of the ENABle registers is maintained or reset in switching on.

*PSC = 0 causes the contents of the status registers to be maintained. Thus a service request can be triggered in switching on in the case of a corresponding configuration of status registers ESE and SRE.

*PSC ≠ 0 resets the registers.

Query *PSC? reads out the contents of the power-on-status-clear flag. The response can be 0 or 1.

***RST**

RESET sets the instrument to a defined default status. The command essentially corresponds to pressing the [PRESET] key. The default setting is indicated in the description of the commands.

***SRE 0 to 255**

SERVICE REQUEST ENABLE sets the service request enable register to the value indicated. Bit 6 (MSS mask bit) remains 0. This command determines under which conditions a service request is triggered. Query *SRE? reads the contents of the service request enable register in decimal form. Bit 6 is always 0.

***STB?**

READ STATUS BYTE QUERY reads out the contents of the status byte in decimal form.

***TRG**

TRIGGER triggers a measurement. This command corresponds to `INITiate:IMMediate` (cf. Section "TRIGger subsystem", as well).

***TST?**

SELF TEST QUERY triggers all selftests of the instrument and outputs an error code in decimal form.

***WAI**

WAIT-to-CONTINUE only permits the servicing of the subsequent commands after all preceding commands have been executed and all signals have settled (cf. Section 3.7 and "*OPC" as well).

3.6.3 ABORt Subsystem

The ABORt subsystem contains the commands for aborting triggered actions. An action can be triggered again immediately after being aborted. All commands trigger events which is why they are not assigned any *RST value.

COMMAND	PARAMETERS	UNIT	COMMENT
ABORt	--	--	no query

ABORt

This command aborts a current measurement and resets the trigger system.

Example: "ABOR;INIT:IMM"

Features: *RST value: 0
SCPI: conforming

Modes: A, VA, BTS, MS

3.6.4 CALCulate Subsystem

The CALCulate subsystem contains commands for converting instrument data, transforming and carrying out corrections. These functions are carried out subsequent to data acquistion, i.e., following the SENSe subsystem.

In the split-screen representation, a distinction is made between CALCulate1 and CALCulate2:

CALCulate1 ≙ screen A;

CALCulate2 ≙ screen B

3.6.4.1 CALCulate:DELTamarker Subsystem

The CALCulate:DELTamarker subsystem checks the delta-marker functions in the instrument.

COMMAND	PARAMETERS	UNIT	COMMENT
CALCulate<1|2>			
:DELTamarker<1 to 4>			
[:STATe]	<Boolean>	--	
:MODE	ABSolute|RELative		
:AOFF			no query
:TRACe	<numeric_value>	--	
:X	<numeric_value>	HZ | S | SYM	
:RELative?	--	--	query only
:Y?	--	--	query only
:MAXimum			
[:PEAK]	--	--	no query
:APEak	--	--	no query (option vector analysis)
:NEXT	--	--	no query
:RIGHt	--	--	no query
:LEFT	--	--	no query
:MINimum			
[:PEAK]	--	--	no query
:NEXT	--	--	no query
:RIGHt	--	--	no query
:LEFT	--	--	no query
:FUNCtion			
:FIXed			
[:STATe]	<Boolean>		
:RPOint			
:Y	<numeric_value>	DBM	
:OFFSet	<numeric_value>	DB	
:X	<numeric_value>	HZ |S | SYM	
:PNOise			
[:STATe]	<Boolean>		
:RESult?	--	--	query only
:STEP			
[:INCRement]	<numeric_value>	HZ |S | SYM	
:AUTO	<Boolean>	--	

CALCulate<1|2>:DELTamarker<1 to 4>[:STATe] ON | OFF

This command switches on or off the selected delta marker. If no indication is made, delta marker 1 is selected automatically.

Example: "CALC:DELT3 ON"

Features: *RST value: OFF
SCPI: device-specific

Modes: A, VA, BTS, MS

CALCulate<1|2>:DELTamarker<1 to 4>:MODE ABSolute | RELative

This command switches over between relative and absolute input of frequency of the delta marker.

Example: "CALC:DELT:MODE ABS"

Features: *RST value: REL
SCPI: device-specific

Modes: A, VA, BTS, MS

In the RELative mode, the frequency of the delta marker is programmed relative to the reference marker. In the ABSolute mode, the frequency is defined by the absolute values.

CALCulate<1|2>:DELTamarker<1 to 4>:AOFF

This command switches off all active delta markers.

Example: "CALC:DELT:AOFF"

Features: *RST value: -
SCPI: device-specific

Modes: A, VA, BTS, MS

CALCulate<1|2>:DELTamarker<1 to 4>:TRACe 1 to 4

This command assigns the selected delta marker to the indicated measuring curve.

Example: "CALC:DELT3:TRAC 2"

Features: *RST value: -
SCPI: device-specific

Modes: A, VA, BTS, MS

CALCulate<1|2>:DELTamarker<1...4>:X 0 ... MAX (frequency | sweep time | symbols)

This command positions the selected delta marker to the indicated frequency (span > 0) or time (span = 0). The query always returns the absolute value of frequency or time.

Example: "CALC:DELT:X 10.7MHz"

Features: *RST value: -
SCPI: device-specific

Modes: A, VA, BTS, MS

The SYM unit is only valid in Vector Signal Analysis mode.

CALCulate<1|2>:DELTamarker<1 to 4>:X:RELative?

This command queries the frequency (span > 0) or time (span = 0) of the selected delta marker relative to the reference marker.

Example: "CALC:DELT:X:REL?"

Features: *RST value: -
SCPI: device-specific

Modes: A, VA, BTS, MS

CALCulate<1|2>:DELTamarker<1 to 4>:Y?

This command queries the value of the selected marker.

Example: "CALC:DELT:Y?"

Features: *RST value: -
SCPI: device-specific

Modes: A, VA, BTS, MS

In complex presentations (vector signal analysis - polar diagrams), the real and the imaginary component as well as magnitude and phase are output separated by a comma.

CALCulate<1|2>:DELTamarker<1 to 4>:MAXimum[:PEAK]

This command positions the delta marker to the current maximum value in the trace memory.

Example: "CALC:DELT:MAX"

Features: *RST value: -
SCPI: device-specific

Modes: A, VA, BTS, MS

This command is an event which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:DELTamarker<1 to 4>:MAXimum:APEak

This command positions the delta marker to the maximum absolute value of the trace.

Example: "CALC:DELT:MAX:APE"

Features: *RST value: -
SCPI: device-specific

Modes: VA

This command is an event which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:DELTamarker<1 to 4>:MAXimum:NEXT

This command positions the delta marker to the next smaller maximum value in the trace memory.

Example: "CALC:DELT:MAX:NEXT"

Features: *RST value: -
SCPI: device-specific

Modes: A, BTS, MS

This command is an event which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:DELTamarker<1 to 4>:MAXimum:RIGHt

This command positions the delta marker to the next smaller maximum value to the right of the current value (i.e., in ascending X direction) in the trace memory.

Example: "CALC:DELT:MAX:RIGH"

Features: *RST value: -
SCPI: device-specific

Modes: A, BTS, MS

This command is an event which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:DELTamarker<1 to 4>:MAXimum:LEFT

This command positions the delta marker to the next smaller maximum value to the left of the current value (i.e., in descending X direction) in the trace memory.

Example: "CALC:DELT:MAX:LEFT"

Features: *RST value: -
SCPI: device-specific

Modes: E, A

This command is an event which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:DELTamarker<1 to 4>:MINimum[:PEAK]

This command positions the delta marker to the current minimum value in the trace memory.

Example: "CALC:DELT:MIN"

Features: *RST value: -
SCPI: device-specific

Modes: A, VA, BTS, MS

This command is an event which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:DELTamarker<1 to 4>:MINimum:NEXT

This command positions the delta marker to the next higher minimum value in the trace memory.

Example: "CALC:DELT:MIN:NEXT"

Features: *RST value: -
SCPI: device-specific

Modes: A, BTS, MS

This command is an event which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:DELTamarker<1 to 4>:MINimum:RIGHt

This command positions the delta marker to the next higher minimum value to the right of the current value (ie in ascending X direction).

Example: "CALC:DELT:MIN:RIGH"

Features: *RST value: -
SCPI: device-specific

Modes: A, BTS, MS

This command is an event which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:DELTamarker<1 to 4>:MINimum:LEFT

This command positions the delta marker to the next higher minimum value to the left of the current value (ie in descending X direction).

Example: "CALC:DELT:MIN:LEFT"

Features: *RST value: -
SCPI: device-specific

Modes: A, BTS, MS

This command is an event which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:DELTamarker<1 to 4>:FUNCtion:FIXed[:STATe] ON | OFF

This command switches the relative measurement to a fixed reference value on or off.

Example: "CALC:DELT:FUNC:FIX ON"

Features: *RST value: OFF
SCPI: device-specific.

Modes: A, VA-D, BTS, MS

The reference value is independent of the current trace.

CALCulate<1|2>:DELTamarker<1 to 4>:FUNCtion:FIXed:RPOint:Y <numeric_value>

This command defines a new fixed reference value for the relative measurement.

Example: "CALC:DELT:FUNC:FIX:RPO:Y -10dBm"

Features: *RST value: - (FUNction:FIXed[:STATe] is set to OFF)
SCPI: device-specific

Modes: A, VA

The reference value is independent of the current trace.

CALCulate<1|2>:DELTamarker<1 to 4>:FUNCtion:FIXed:RPOint:Y:OFFSet <numeric_value>

This command defines an additional level offset for the relative measurement.

Example: "CALC:DELT:FUNC:FIX:RPO:Y:OFFS 10dB"

Features: *RST value: 0 dB
SCPI: device-specific

Modes: A, VA

The level offset is included in the output of the level value.

CALCulate<1|2>:DELTamarker<1 to 4>:FUNCtion:FIXed:RPOint:X <numeric_value>

This command defines the new fixed reference frequency, time or symbols for the relative measurement.

Example: "CALC:DELT:FUNC:FIX:RPO:X 10.7MHz"

Features: *RST value: - (FUNction:FIXed[:STATe] is set to OFF)
SCPI: device-specific

Mode: A

The reference value is independent of the current trace. With span = 0, the reference time, otherwise the reference frequency is defined.

CALCulate<1|2>:DELTamarker<1 to 4>:FUNCtion:PNOise[:STATe] ON | OFF

This command switches the measurement of the phase noise on or off.

Example: "CALC:DELT:FUNC:PNO ON"

Features: *RST value: OFF
SCPI: device-specific

Mode: A

When the phase noise is measured, the correction values for the bandwidth and the log amplifier are automatically considered. The measurement uses the reference values defined by FUNCtion:FIXed:RPOint:X or :Y.

CALCulate<1|2>:DELTamarker<1 to 4>:FUNCtion:PNOise:RESult?

This command queries the result of the phase noise measurement.

Example: "CALC:DELT:FUNC:PNO:RES?"

Features: *RST value: -
SCPI: device-specific

Modes: A, BTS, MS

This command is only a query which is why it is not assigned an *RST value.

CALCulate<1|2>:DELTamarker<1 to 4>:STEP[:INCRement] <numeric_value>

This command defines the delta marker step width.

Example: "CALC:DELT:STEP 10kHz" (frequency domain)
"CALC:DELT:STEP 5ms" (time domain)

Features: *RST value: - (STEP is set to AUTO)
SCPI: device-specific

Mode: A

CALCulate<1|2>:DELTamarker<1 to 4>:STEP:AUTO ON | OFF

This command switches the automatic adaptation of the marker step width on or off.

Example: "CALC:DELT:STEP:AUTO OFF"

Features: *RST value: ON
SCPI: device-specific

Mode: A

With AUTO ON, the step width is 10% of the span.

3.6.4.2 CALCulate:DLINe Subsystem

The CALCulate:DLINe subsystem checks the display lines in the instrument, i.e., the level, frequency and time lines (depending on the X-axis) as well as threshold and reference lines.

COMMAND	PARAMETERS	UNIT	COMMENT
CALCulate<1|2>			
:DLINe<1|2>	<numeric_value>	DBM | DB | DEG | RAD | S | HZ | PCT	
:STATe	<Boolean>		
:THReshold	<numeric_value>	DBM | DB | DEG | RAD | S | HZ | PCT	
:STATe	<Boolean>		
:RLINe	<numeric_value>	DBM | DB | DEG | RAD | S | HZ | PCT	
:STATe	<Boolean>		
:FLINe<1|2>	<numeric_value>	HZ	
:STATe	<Boolean>		
:TLINe<1|2>	<numeric_value>	S | SYM	
:STATe	<Boolean>		

CALCulate<1|2>:DLINe<1|2> MINimum to MAXimum (depending on current unit)

This command defines the position of the display line.

Example: "CALC:DLIN -20dBm"

Features: *RST value: - (STATe to OFF)
SCPI: device-specific

Modes: A, VA, BTS, MS

The display lines mark the given level in the display.

The units DEG, RAD, S, HZ, and PCT are only valid in conjunction with option Vector Signal Analysis, FSE-B7.

CALCulate<1|2>:DLINe<1|2>:STATe ON | OFF

This command switches the display line on or off.

Example: "CALC:DLIN2:STAT OFF"

Features: *RST value: OFF
SCPI: device-specific

Modes: A, VA, BTS, MS

CALCulate<1|2>:THReshold MINimum to MAXimum (depending on current unit)

This command defines the position of the thresholds.

Example: "CALC:THR -82dBm"

Features: *RST value: - (STATe to OFF)
SCPI: device-specific

Modes: A, VA, BTS, MS

For marker scan functions MAX PEAK, NEXT PEAK etc., the threshold serves as the lowest limit for maximum or minimum search.

The units DEG, RAD, S, HZ, and PCT are only valid in conjunction with option Vector Signal Analysis, FSE-B7.

CALCulate<1|2>:THReshold:STATe ON | OFF

This command switches the threshold on or off.

Example: "CALC:THR:STAT ON"

Features: *RST value: OFF
SCPI: device-specific

Modes: A, VA, BTS, MS

CALCulate<1|2>:RLINe MINimum to MAXimum (depending on the current unit)

This command defines the position of the reference line.

Example: "CALC:RLIN -10dBm"

Features: *RST value: - (STATe to OFF)
SCPI: device-specific

Modes: A, VA, BTS, MS

The reference line serves as a reference for the arithmetic operation of traces.

The units DEG, RAD, S, HZ, and PCT are only valid in connection with option FSE-B7, Vector Signal Analysis.

CALCulate<1|2>:RLINe:STATe ON | OFF

This command switches the reference line on or off.

Example: "CALC:RLIN:STAT ON"

Features: *RST value: OFF
SCPI: device-specific

Modes: A, VA, BTS, MS

CALCulate<1|2>:FLINe<1|2> 0 GHz to f_{max}

This command defines the position of the frequency lines.

Example: "CALC:FLIN2 120MHz"

Features: *RST value: - (STATe to OFF)
SCPI: device-specific

Modes: A-F, VA, BTS, MS

The frequency lines mark the given frequencies in the display. Frequency lines are only valid for a SPAN >0.

CALCulate<1|2>:FLINe<1|2>:STATe ON | OFF

This command switches the frequency line on or off.

Example: "CALC:FLIN2:STAT ON"

Features: *RST value: OFF
SCPI: device-specific

Modes: A-F, VA, BTS, MS

CALCulate<1|2>:TLINe<1|2> 0 to 1000s

This command defines the position of the time lines.

Example: "CALC:TLIN 10ms"

Features: *RST value: - (STATe to OFF)
SCPI: device-specific

Modes: A-Z, VA, BTS, MS

The time lines mark the given times in the display. Time lines are only valid for a SPAN = 0.

CALCulate<1|2>:TLINe<1|2>:STATe ON | OFF

This command switches the time line on or off.

Example: "CALC:TLIN2:STAT ON"

Features: *RST value: OFF
SCPI: device-specific

Modes: A-Z, VA, BTS, MS

3.6.4.3 CALCulate:FEED Subsystem

The CALCulate:FEED subsystem selects the measured data in operating mode vector signal analysis. This sub system is only valid in connection with option FSE-B7, Vector Signal Analysis.

COMMAND	PARAMETERS	UNIT	COMMENT
CALCulate<1|2> :FEED	<string>		Vector Signal Analysis no query

CALCulate<1|2>:FEED <string>

This command selects the measured data that are to be displayed.

Parameter: <string>::= 'XTIM:DDEM:MEAS' |
'XTIM:DDEM:REF' |
'XTIM:DDEM:ERR:MPH' |
'XTIM:DDEM:ERR:VECT' |
'XTIM:DDEM:SYMB' |
'XTIM:AM' |
'XTIM:FM' |
'XTIM:PM' |
'XTIM:AMSummary' |
'XTIM:FMSummary' |
'XTIM:PMSummary' |

Example: "CALC:FEED 'XTIM:DDEM:SYMB'"

Features: *RST value: 'XTIM:DDEM:MEAS'
SCPI: conforming

Mode: VA

The string parameters have the following meaning:

'XTIM:DDEM:MEAS'	Test signal (filtered, synchronized to symbol clock)
'XTIM:DDEM:REF'	Reference signal (internally generated from demodulated test signal)
'XTIM:DDEM:ERR:MPH'	Error signal (magnitude and phase error)
'XTIM:DDEM:ERR:VECT'	Vector error signal
'XTIM:DDEM:SYMB'	Symbol table (demodulated bits and table with modulation errors)
'XTIM:AM'	Demodulated AM signal (analog demodulation)
'XTIM:FM'	Demodulated FM signal (analog demodulation)
'XTIM:PM'	Demodulated PM signal (analog demodulation)
'XTIM:AMSummary'	AM-Summary Marker (analog demodulation)
'XTIM:FMSummary'	FM-Summary Marker (analog demodulation)
'XTIM:PMSummary'	PM-Summary Marker (analog demodulation)

3.6.4.4 CALCulate:FORMat Subsystem

The CALCulate:FORMat subsystem determines further processing and conversion of measured data in operating mode vector signal analysis.
This sub system is only valid in connection with option FSE-B7, Vector Signal Analysis.

COMMAND	PARAMETERS	UNIT	COMMENT
CALCulate<1|2> :FORMat	MAGNitude | PHASe | UPHase | RIMag | FREQuency | IEYE | QEYE | TEYE | FEYE | COMP | CONS		Vector Signal Analysis
:FSK :DEViation :REFerence	<numeric_value>	HZ	Vector Signal Analysis

CALCulate<1|2>:FORMat MAGNitude | PHASe | UPHase | RIMag | FREQuency | IEYE | QEYE | TEYE | FEYE | COMP | CONS

This command defines the display of the traces.

Example: "CALC:FORM CONS"

Features: *RST value: MAGNitude
SCPI: conforming

Mode: VA-D

The parameters have the following meaning:

MAGNitude	Display of the magnitude in the time domain
PHASe | UPHase	Display of the phase in the time domain with or without ("unwrapped") limitation to ±180°
RIMag	Display of the time characteristic of inphase and quadrature component
FREQuency	Display of the frequency response in the time domain
IEYE | QEYE	Eye diagram of the inphase or quadrature component
TEYE	Display of the trellis diagram
FEYE	Eye diagram of FSK modulation
COMP	Display of the polar vector diagram (complex)
CONS	Display of the polar vector diagaram (constellation)

CALCulate<1|2>:FSK:DEViation:REFerence <numeric_value>

This command defines the reference value of the frequency deviation for FSK modulation.

Example: "CALC:FSK:DEV:REF 20kHz"

Features: *RST value: -
SCPI: device-specific

Mode: VA-D

3.6.4.5 CALCulate:LIMit Subsystem

The CALCulate:LIMit subsystem comprises the limit lines and the corresponding limit checks. Limit lines can be defined as upper and lower limit lines. The individual values of the limit lines correspond to the values of the X-axis (CONTrol) which have to have the same number.

COMMAND	PARAMETERS	UNIT	COMMENT
CALCulate			
:LIMit<1 to 8>			
:TRACe	<numeric_value>		
:STATe	<Boolean>	--	
:UNIT	DBM | DBPW | WATT | DBUV | DBMV | VOLT | DBUA | AMPere | DB | DBUV_MHZ | DBMV_MHZ | DBUA_MHZ | DBUV_M | DBUA_M | DBUV_MMHZ | DBUA_MMHZ | DEG | RAD | S | HZ | PCT | UNITLESS		
:CONTrol			
[:DATA]	<numeric_value>,<numeric_value>..		
:DOMain	FREQuency | TIME	HZ | S | SYM	
:OFFSet	<numeric_value>		
:MODE	RELative | ABSolute	HZ | S | SYM	
:UNIT			
[:TIME]	S | SYM		Vector Signal Analysis
:SHIFt	<numeric_value>		
:SPACing	LINear | LOGarithmic	HZ | S | SYM	
:UPPer			
[:DATA]	<numeric_value>,<numeric_value>..		
:STATe	<Boolean>	DBM | DB | DEG | RAD | S | HZ | PCT	
:OFFSet	<numeric_value>	--	
:MARGin	<numeric_value>	DB | DEG | RAD | S | HZ | PCT	
:MODE	RELative | ABSolute	DB| DEG | RAD | S | HZ | PCT	
:SHIFt	<numeric_value>	--	
:SPACing	LINear | LOGarithmic	DB | DEG | RAD| S | HZ | PCT	
:LOWer			
[:DATA]	<numeric_value>,<numeric_value>..		
:STATe	<Boolean>	DBM | DB | DEG | RAD | S | HZ | PCT	
:OFFSet	<numeric_value>	--	
:MARGin	<numeric_value>	DB| DEG | RAD | S | HZ | PCT	
:MODE	RELative | ABSolute	DB| DEG | RAD | S | HZ | PCT	
:SHIFt	<numeric_value>	--	
:SPACing	LINear | LOGarithmic	DB | DEG | RAD | S | HZ | PCT	
:FAIL?			query only
:CLEar			
[:IMMediate]	--	--	no query
:COMMent		--	
:COPY	<string>		
:NAME	1 to 8 | < name>		
:DELete	<string>		

COMMAND	PARAMETERS	UNIT	COMMENT
CALCulate			
:LIMit<1 to 8>			
:BURSt	--		Option FSE-K11 or K10
:PTEMplate?			
:POWer?	--		
:SPECtrum	--		Option FSE-K11 or FSE-K10
:MODulation?	ARFCn | TXBand | RXBand | COMBined | DCSRx1800		
:FAILs?	ARFCn | TXBand | RXBand | COMBined | DCSRx1800		
:EXCeptions?	ARFCn | TXBand | RXBand | COMBined | DCSRx1800		
:SWITching?			Option FSE-K11 or FSE-K10
:FAILs?			
:SPURious?	TXBand | OTXBand | RXBand | IDLeband	DB	Option FSE-K11 or FSE-K10
:FAILs?	TXBand | OTXBand | RXBand | IDLeband		
:MARGin	<numeric_value>	DB; DB	
:ACPower			
[:STATe]	<Boolean>		
:ACHannel	<numeric_value>, <numeric_value>	DB; DB	
:STATe	<Boolean>		
:RESult?	--		query only
:ALTernate<1|2>	<numeric_value>, <numeric_value>		
:STATe	<Boolean>		
:RESult?	--		query only

CALCulate<1|2>:LIMit<1 to 8>:TRACe <numeric_value>

This command assigns a trace to a limit line.

Example: "CALC:LIM2:TRAC 2"

Features: *RST value: 1
SCPI: device-specific

Modes: A, VA, BTS, MS

CALCulate<1|2>:LIMit<1 to 8>:STATe ON | OFF

This command switches the limit check for the selected limit line on or off.

Example: "CALC:LIM:STAT ON"

Features: *RST value: OFF
SCPI: conforming

Modes: A, VA, BTS, MS

The result of the limit check can be queried with CALCulate:LIMit:FAIL?.

CALCulate<1|2>:LIMit<1...8>:UNIT DBM | DBPW | WATT | DBUV | DBMV | VOLT |DBUA | AMPere | DB | DBUV_MHZ | DBMV_MHZ | DBUA_MHZ | DBUV_M | DBUA_M | DBUV_MMHZ | DBUA_MMHZ |DEG | RAD | S | HZ | PCT | UNITLESS|

This command defines the unit of the selected limit line.

Example: "CALC:LIM:UNIT DBUV"

Features: *RST value: DBM
SCPI: device-specific

Modes: A, VA, BTS, MS

DBUV_MHZ and DBUA_MHZ denote the units DBUV/MHZ or DBUA/MHZ.
Upon selection of the unit DB the limit line is automatically switched to the relative mode. For units different from DB the limit line is automatically switched to the absolute mode.

The units DEG, RAD, S, HZ, PCT are available in the spectrum analysis mode only.

CALCulate<1|2>:LIMit<1 to 8>:CONTrol[:DATA] <numeric_value>,<numeric_value>..

This command defines the X-axis values (frequencies or times) of the upper or lower limit lines.

Example: "CALC:LIM:CONT 1MHz,30MHz,300MHz,1GHz"

Features: *RST value: - (LIMit:STATe is set to OFF)
SCPI: conforming

Modes: A, VA, BTS, MS

The number of values for the CONTrol axis and the corresponding UPPer- and/or LOWer limit lines have to be identical. Available units are HZ | S | SYM, SYM only for vector signal analyzer mode.

CALCulate<1|2>:LIMit<1 to 8>:CONTrol:DOMain FREQuency | TIME

This command defines the X-axis in the frequency or time domain.

Example: "CALC:LIM:CONT:DOM TIME"

Features: *RST value: FREQuency
SCPI: device-specific

Modes: A, VA, BTS, MS

CALCulate<1|2>:LIMit<1 to 8>:CONTrol:OFFSet <numeric_value>

This command defines an offset for the X-axis value of the selected relative limit line in the frequency or time domain.

Example: "CALC:LIM:CONT:OFFS 100us"

Features: *RST value: 0
SCPI: device-specific

Modes: A, VA

CALCulate<1|2>:LIMit<1 to 8>:CONTrol:MODE RELative | ABSolute

This command selects the relative or absolute scaling for the X-axis of the selected limit line.

Example: "CALC:LIM:CONT:MODE REL"

Features: *RST value: ABSolute
SCPI: device-specific

Modes: A, VA, BTS, MS

Upon selection of RELative, the unit is switched to DB.

CALCulate<1|2>:LIMit<1 to 8>:CONTrol:UNIT[:TIME] S | SYM

This command defines the unit of the x-axis scaling of limit lines.

Example: "CALC:LIM:CONT:UNIT SYM"

Features: *RST value: S
SCPI: device-specific

Mode: VA

CALCulate<1|2>:LIMit<1 to 8>:CONTrol:SHIFt <numeric_value>

This command shifts a limit line which has been specified for relative frequencies or times (X-axis).

Example: "CALC:LIM:CONT:SHIF 50kHz"

Features: *RST value: --
SCPI: device-specific

Modes: A, VA, BTS, MS

This command is an event which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:LIMit<1 to 8>:CONTrol:SPACing LINear | LOGarithmic

This command makes a selection between linear and logarithmic interpolation for determining the limit line from the frequency points.

Example: "CALC:LIM:CONT:SPAC LIN"

Features: *RST value: LIN
SCPI: device-specific

Modes: A, VA, BTS, MS

CALCulate<1|2>:LIMit<1 to 8>:UPPer[:DATA] <numeric_value>,<numeric_value>..

This command defines the values for the upper limit lines.

Example: "CALC:LIM:UPP -10,0,0,-10"

Features: *RST value: - (LIMit:STATe is set to OFF)
SCPI: conforming

Modes: A, VA, BTS, MS

The number of values for the CONTrol axis and the corresponding UPPer limit line have to be identical.

If the measured values exceed the UPPer limit line, the limit check signals errors.
The unit must be identical with the unit selected by CALC:LIM:UNIT.

The units DEG, RAD, S, HZ, PCT are available in the vector signal analysis mode only.

CALCulate<1|2>:LIMit<1 to 8>:UPPer:STATe ON | OFF

This command defines the selected limit line as upper limit line.

Example: "CALC:LIM:UPPer:STAT ON"

Features: *RST value: OFF
SCPI: conforming

Modes: A, VA, BTS, MS

The result of the limit check can be queried with CALCulate:LIMit<1 to 8>:FAIL?.

In analyzer and vector analyzer mode, the result of the limit check can be queried with CALCulate:LIMit<1 to 8>:FAIL?.

CALCulate<1|2>:LIMit<1 to 8>:UPPer:OFFSet <numeric_value>

This command defines an offset for the Y-axis of the selected relative upper limit line.

Example: "CALC:LIM:UPP:OFFS 3dB"

Features: *RST value: 0
SCPI: device-specific

Modes: A, VA

CALCulate<1|2>:LIMit<1 to 8>:UPPer:MARGin <numeric_value>

This command defines the margin of the selected upper limit line.

Example: "CALC:LIM:UPP:MARG 10dB"

Features: *RST value: 0
SCPI: device-specific

Modes: A, VA, BTS, MS

CALCulate<1|2>:LIMit<1 to 8>:UPPer:MODE RELative | ABSolute

This command selects the relative or absolute scaling for the Y-axis of the selected upper limit line.

Example: "CALC:LIM:UPP:MODE REL"

Features: *RST value: ABSolute
SCPI: device-specific

Modes: A, VA, BTS, MS

CALCulate<1|2>:LIMit<1 to 8>:UPPer:SHIFt <numeric_value>

This command shifts a limit line, which has relative values for the Y-axis (levels or linear units such as volt).

Example: "CALC:LIM:UPP:SHIF 20dB"

Features: *RST value: --
SCPI: device-specific

Modes: A, VA, BTS, MS

This command is an event which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:LIMit<1 to 8>:UPPer:SPACing LINear | LOGarithmic

This command makes a selection between linear and logarithmic interpolation for the upper limit line.

Example: "CALC:LIM:UPP:SPAC LIN"

Features: *RST value: LIN
SCPI: device-specific

Modes: A, VA, BTS, MS

CALCulate<1|2>:LIMit<1 to 8>:LOWer[:DATA] <numeric_value>,<numeric_value>..

This command defines the values for the selected lower limit line.

Example: "CALC:LIM:LOW -30,-40,-40,-30"

Features: *RST value: - (LIMit:STATe is set to OFF)
SCPI: conforming

Modes: A, VA, BTS, MS

The number of values for the CONTrol axis and the corresponding LOWer limit line have to be identical.If the measured values violate the LOWer limit line, the limit check signals errors. The unit must be identical with the unit selected by CALC:LIM:UNIT.

The units DEG, RAD, S, HZ, PCT are available in the vector signal analysis mode only.

CALCulate<1|2>:LIMit<1 to 8>:LOWer:STATe ON | OFF

This command defines the selected limit line as lower limit line.

Example: "CALC:LIM:LOWer:STAT ON"

Features: *RST value: OFF
SCPI: conforming

Modes: A, VA, BTS, MS

The result of the limit check can be queried with CALCulate:LIMit:FAIL?.

CALCulate<1|2>:LIMit<1 to 8>:LOWer:OFFSet <numeric_value>

This command defines an offset for the Y-axis of the selected relative lower limit line.

Example: "CALC:LIM:LOW:OFFS 3dB"

Features: *RST value: 0
SCPI: device-specific

Modes: A, VA

CALCulate<1|2>:LIMit<1 to 8>:LOWer:MARGin <numeric_value>

This command defines the margin of the selected lower limit line.

Example: "CALC:LIM:LOW:MARG 10dB"

Features: *RST value: 0
SCPI: device-specific

Modes: A, VA, BTS, MS

CALCulate<1|2>:LIMit<1 to 8>:LOWer:MODE RELative | ABSolute

This command selects the relative or absolute scaling for the Y-axis of the selected lower limit line.

Example: "CALC:LIM:LOW:MODE REL"

Features: *RST value: ABSolute
SCPI: device-specific

Modes: A, VA, BTS, MS

CALCulate<1|2>:LIMit<1 to 8>:LOWer:SHIFt <numeric_value>

This command shifts a limit line, which has relative values for the Y-axis (levels or linear units such as volt).

Example: "CALC:LIM:LOW:SHIF 20dB"

Features: *RST value: --
SCPI: device-specific

Modes: A, VA, BTS, MS

This command is an event which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:LIMit<1 to 8>:LOWer:SPACing LINear | LOGarithmic

This command makes a selection between linear and logarithmic interpolation for the lower limit line.

Example: "CALC:LIM:LOW:SPAC LIN"

Features: *RST value: LIN
SCPI: device-specific

Modes: A, VA, BTS, MS

CALCulate<1|2>:LIMit<1 to 8>:FAIL?

This command queries the result of the limit check.

Example: "CALC:LIM:FAIL?"

Features: *RST value: -
SCPI: conforming

Modes: A, VA, BTS, MS

The result of the limit check responds with 0 in case of PASS and with 1 in case of FAIL.

CALCulate<1|2>:LIMit<1 to 8>:CLEar[:IMMediate]

This command deletes the result of the current limit check.

Example: "CALC:LIM:CLE"

Features: *RST value: -
SCPI: conforming

Modes: A, VA, BTS, MS

This command is an event which is why it is not assigned an *RST value.

CALCulate<1|2>:LIMit<1 to 8>:COMMent <string>

This command defines a comment for the limit line selected.

Example: "CALC:LIM:COMM 'Upper limit for spectrum'"

Features: *RST value: blank comment
SCPI: device-specific

Modes: A, VA, BTS, MS

CALCulate<1|2>:LIMit<1 to 8>:COPY 1 to 8 | <name>

This command copies one limit line onto another one.

Parameter: 1 to 8 ::= number of the new limit line or, alternatively:
<name> ::= name of the new limit line given as a string

Example: "CALC:LIM1:COPY 2"
"CALC:LIM1:COPY 'GSM2'"

Features: *RST value: --
SCPI: device-specific

Modes: A, VA, BTS, MS

The name of the limit line may contain a maximum of 8 characters. This command is an "event" which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:LIMit<1 to 8>:NAME <name off limit line>

This command assigns a name to a limit line numbered 1 to 8. If it doesn't exist previously, a limit line with this name is created.

Example: "CALC:LIM1:NAME 'GSM1'"

Features: *RST value: 'REM1' to 'REM8' for lines 1 to 8
SCPI: device-specific

Modes: A, VA, BTS, MS

The name of the limit line may contain a maximum of 8 characters.

CALCulate<1|2>:LIMit<1 to 8>:DELete

This command deletes the limit line selected.

Examples: "CALC:LIM1:DEL"

Features: *RST value: --
SCPI: device-specific

Modes: A, VA, BTS, MS

This command is an "event" which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:LIMit<1 to 8>:BURSt:PTEMplate?

This command queries the result of the limit check for a power vs. time measurement.

Parameter: The result is displayed in character data form. Possible values are:
PASSED limit not exceeded
FAILED limit exceeded
RUNNING measurement not completed

Examples: "CALC:LIM:BURS:PTEM?"

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

This command is a query and therefore not assigned a *RST value.
If no measurement has been carried out yet, a query error is triggered off. The numeric suffixes <1|2> or <1 to 8> are not significant for this command.

CALCulate<1|2>:LIMit<1 to 8>:BURSt:POWer?

This command queries the total result of the carrier power measurement.

Parameter: The result is displayed in character data form. Possible values are:
PASSED limit not exceeded
FAILED limit exceeded
ABORTED measurement aborted
RUNNING measurement not completed

Examples: "CALC:LIM:BURS:POW?"
Result: PASSED

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

This command is a query and therefore not assigned a *RST value.
If the command is triggered off before the carrier power measurement was started for the first time, a query error results. The numeric suffixes <1|2> or <1 to 8> are not significant for this command.

CALCulate<1|2>:LIMit<1 to 8>:SPECtrum:MODulation? ARFCn | TXBand | RXBand | COMBined | DCSRx1800

This command queries the total result of the spectrum due to modulation measurement.

Parameter: The result is displayed in character data form. Possible values are:
PASSED limit not exceeded
FAILED limit exceeded
ABORTED measurement aborted
RUNNING measurement not completed

Examples: "CALC:LIM:SPEC:MOD? RXB"
Result: PASSED

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

ARFCn	ARFCN ± 1.8 MHz	TXBand	TX-band
RXBand	RX-band	COMBined	ARFCN ± 1.8 MHz / TX-band
DCSRx1800	RX-Band DCS 1800 (option FSE-K10 only)		

This command is a query and therefore not assigned a *RST value.
The numeric suffixes <1|2> or <1 to 8> are not significant for this command.

CALCulate<1|2>:LIMit<1 to 8>:SPECtrum:MODulation:FAILs? ARFCn | TXBand | RXBand | COMBined | DCSRx1800

This command queries the number of limit violations of the spectrum due to modulation measurement.

Examples: "CALC:LIM:SPEC:MOD:FAIL? RXB"

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

ARFCn	ARFCN ± 1.8 MHz
TXBand	TX-band
RXBand	RX-band
COMBined	ARFCN ± 1.8 MHz / TX-band
DCSRx1800	RX-Band DCS 1800 (option FSE-K10 only)

This command is a query and therefore not assigned a *RST value
The numeric suffixes <1|2> or <1 to 8> are not significant for this command.

CALCulate<1|2>:LIMit<1 to 8>:SPECtrum:MODulation:EXCeptions? ARFCn | TXBand | RXBand | COMBined | DCSRx1800

This command queries the number of limit violations of the spectrum due to modulation measurement which are marked as exceptions.

Examples: "CALC:LIM:SPEC:MOD:EXC? RXB"

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

ARFCn	ARFCN ± 1.8 MHz
TXBand	TX-band
RXBand	RX-band
COMBined	ARFCN ± 1.8 MHz / TX-band
DCSRx1800	RX-Band DCS 1800 (option FSE-K10 only

This command is a query and therefore not assigned a *RST value. The numeric suffixes <1|2> or <1 to 8> are not significant for this command.

CALCulate<1|2>:LIMit<1 to 8>:SPECtrum:SWITching?

This command queries the total result of the spectrum due to switching transients measurements.

Parameter: The result is displayed in character data form. Possible values are:

PASSED	limit not exceeded
FAILED	limit exceeded
ABORTED	measurement aborted
RUNNING	measurement not completed

Examples: "CALC:LIM:SPEC:SWIT?"
Result: PASSED

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

This command is a query and therefore not assigned a *RST value. The numeric suffixes <1|2> or <1 to 8> are not significant for this command.

CALCulate<1|2>:LIMit<1 to 8>:SPECtrum:SWITching:FAILs?

This command queries the number of limit violations of the spectrum due to switching transient measurement.

Examples: "CALC:LIM:SPEC:SWIT:FAIL?"

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

This command is a query and therefore not assigned a *RST value. The numeric suffixes <1|2> or <1 to 8> are not significant for this command.

CALCulate<1|2>:LIMit<1 to 8>:SPURious? TXBand | OTXBand | RXBand | IDLeband

This command queries the total result of the spurious emissions measurement.

Parameter: The result is displayed in character data form. Possible values are:

PASSED limit not exceeded
FAILED limit exceeded
ABORTED measurement aborted
RUNNING measurement not completed

Examples:
```
"CALC:LIM:SPUR? OTXB"
Result:PASSED
```

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

TXBand	TX-band
OTXBand	Not TX-band
RXBand	RX-band (option FSE-K11 only)
IDLeband	IDLeband (option FSE-K10 only)

This command is a query and therefore not assigned a *RST value. The numeric suffixes <1|2> or <1 to 8> are not significant for this command.

CALCulate<1|2>:LIMit<1 to 8>:SPURious:FAILs? TXBand | OTXBand | RXBand | IDLeband

This command queries the number of limit violations of the spurious emissions measurement.

Examples: "CALC:LIM:SPUR:FAIL? OTXB"

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

TXBand	TX-band
OTXBand	Not TX-band
RXBand	RX-band (option FSE-K11 only)
IDLeband	IDLeband (option FSE-K10 only)

This command is a query and therefore not assigned a *RST value. The numeric suffixes <1|2> or <1 to 8> are not significant for this command.

CALCulate<1|2>:LIMit<1 to 8>:MARGin 0 to 100DB

This command sets/changes the value of the margin (safe difference to the actual limit) for the limit check.

Examples: "CALC:LIM:MARG 6DB"

Features: *RST value: 3DB
SCPI: device-specific

Modes: BTS, MS

The numeric suffixes <1|2> or <1 to 8> are not significant for this command.

CALCulate<1|2>:LIMit<1 to 8>:ACPower[:STATe] ON | OFF

This command switches on and off the limit check for adjacent channel power measurements. The commands CALC:LIM:ACP:ACH:STAT or CALC:LIM:ACP:ALT:STAT must be used in addition to specify whether the limit check is to be performed for the upper/lower adjacent channel or for the alternate adjacent channels.

Examples: "CALC:LIM:ACP ON"

Features: *RST value: OFF
SCPI: device-specific

Modes: A, VA

The numeric suffixes <1|2> or <1 to 8> are not significant for this command.

CALCulate<1|2>:LIMit<1 to 8>:ACPower:ACHannel 0 to 100 dB, 0 to 100 dB

This command defines the limit for the upper/lower adjacent channel for adjacent channel power measurements.

Parameter: The first (second) numeric value is the limit for the upper (lower) adjacent channel.

Examples: "CALC:LIM:ACP:ACH 30DB, 30DB"

Features: *RST value: 0 dB
SCPI: device-specific

Modes: A, VA

The numeric suffixes <1|2> or <1 to 8> are not significant for this command.

CALCulate<1|2>:LIMit<1 to 8>:ACPower:ACHannel:STATe ON | OFF

This command activates the limit check for the adjacent channel when adjacent channel power measurement is performed. Before, the limit check must be activated using CALC:LIM:ACP ON.

Examples: "CALC:LIM:ACP:ACH:STAT ON"

Features: *RST value: OFF
SCPI: device-specific

Modes: A, VA

The numeric suffixes <1|2> or <1 to 8> are not significant for this command.

CALCulate<1|2>:LIMit<1 to 8>:ACPower:ACHannel:RESult?

This command queries the result of the limit check for the upper/lower adjacent channel when adjacent channel power measurement is performed.

Parameter: The result is returned in the form <result>, <result> where <result> = PASSED | FAILED, and where the first returned value denotes the lower, the second denotes the upper adjacent channel.

Examples: "CALC:LIM:ACP:ACH:RES?"

Features: *RST value: –
SCPI: device-specific

Modes: A, VA

This command is a query and therefore not assigned a *RST value. If the power measurement of the adjacent channel is switched off, the command triggers a query error.
The numeric suffixes <1|2> or <1 to 8> are not significant for this command.

CALCulate<1|2>:LIMit<1 to 8>:ACPower:ALTernate<1|2> 0 to 100DB, 0 to 100 dB.

This command defines the limit for the first/second alternate adjacent channel for adjacent channel power measurements.

Parameter: The first (second) numeric value is the limit for the lower (upper) alternate adjacent channel. The numeric suffix after ALTernate<1|2> denotes the first or the second alternate channel.

Examples: "CALC:LIM:ACP:ALT2 30DB 30DB"

Features: *RST value: 0DB
SCPI: device-specific

Modes: A, VA

The numeric suffixes <1|2> or <1 to 8> are not significant for this command.

CALCulate<1|2>:LIMit<1 to 8>:ACPower:ALTernate<1|2>:STATe ON | OFF

This command activates the limit check for the first/second alternate adjacent channel for adjacent channel power measurements. Before, the limit check must be activated using CALC:LIM:ACP ON.

Examples: "CALC:LIM:ACP:ALT2:STAT ON"

Features: *RST value: OFF
SCPI: device-specific

Modes: A, VA

The numeric suffixes <1|2> or <1 to 8> are not significant for this command.

CALCulate<1|2>:LIMit<1 to 8>:ACPower:ALTernate<1|2>:RESult?

Parameter: The result is returned in the form <result>, <result> where <result> = PASSED | FAILED and where the first (second) returned value denotes the lower (upper) alternate adjacent channel.

Examples: "CALC:LIM:ACP:ALT2:RES?"

Features: *RST value: –
SCPI: device-specific

Modes: A, VA

This command is a query and therefore not assigned a *RST value. If the power measurement of the adjacent channel is switched off, the command triggers a query error.
The numeric suffixes <1|2> or <1 to 8> are not significant for this command.

3.6.4.6 CALCulate:MARKer Subsystem

The CALCulate:MARKer subsystem checks the marker functions in the instrument.

COMMAND	PARAMETERS	UNIT	COMMENT
CALCulate<1|2>			
:MARKer<1 to 4>			
[:STATe]	<Boolean>	--	
:AOFF			no query
:TRACe	<numeric_value>	--	
:X	<numeric_value>	HZ | S | SYM	
:SLIMits			
[:STATe]	<Boolean>		
:COUNt	<Boolean>	--	
:RESolution	<numeric_value>	HZ	
:FREQuency?	--	--	query only
:COUPled			
[:STATe]	<Boolean>		
:LOEXclude	<Boolean>		
:Y?	--	--	query only
:MAXimum			
[:PEAK]	--	--	no query
:APEak	--	--	no query, Vector Signal Analysis
:NEXT	--	--	no query
:RIGHt	--	--	no query
:LEFT	--	--	no query
:MINimum			
[:PEAK]	--	--	no query
:NEXT	--	--	no query
:RIGHt	--	--	no query
:LEFT	--	--	no query
:STEP			
[:INCRement]	<numeric_value>	HZ | S | SYM	
:AUTO	<Boolean>	--	
:PEXCursion	<numeric_value>	DB	
:READout	MPHase | RIMaginary		Vector Signal Analysis
:FUNCtion			
:NDBDown	<numeric_value>	DB	
:STATe	<Boolean>		
:RESult?	--	--	query only
:FREQuency?	--	--	query only
:ZOOM	<numeric_value>	HZ	no query
:NOISe			
[:STATe]	<Boolean>		
:RESult?	--	--	query only
:DEModulation			
:SELect	AM|FM		
[:STATe]	<Boolean>		
:HOLDoff	<numeric_value>	S	
:SFACtor	<expr>		
:STATe	<Boolean>		
:RESult?	--	--	query only
:FREQuency?	--	--	query only

COMMAND	PARAMETERS	UNIT	COMMENT
CALCulate<1|2>			
:MARKer			
:FUNCtion			
:STRack	<Boolean>		
[:STATe]			
:ADEMod			Vector Signal Analysis
:AM			
[:RESult]?	PPEak | MPEak | MIDDle | RMS		query only
:FM			
[:RESult]?	PPEak | MPEak | MIDDle | RMS | RDEV		query only
:PM			
[:RESult]?	PPEak | MPEak | MIDDle | RMS		query only
:AFRequency			
[:RESult]?			query only
:FERRor			
[:RESult]?			query only
:SINad			
[:STATe]	<Boolean>		
:RESult?			query only
:CARRier			
[:RESult]?			query only
:DDEMod			Vector Signal Analysis
:RESult?	MERM | MEPK | MEPS | PERM | PEPK | PEPS |EVRM | EVPK | EVPS | IQOF | IQIM | ADR | FERR | DEV | FSRM | FSPK | FSPS | RHO |FEPK | DTTS		query only
:POWer			no query
:SELect	ACPower | CPOWer | OBANdwidth | OBWidth | CN | CN0		query only
:RESult?	ACPower | CPOWer | OBANdwidth | OBWidth | CN | CN0		
:PRESet	NADC | TETRA | PHS| PDC | CDPD | F8CDma | R8CDma | F19Cdma | R19Cdma | NONE		
:CFILter	<Boolean>		
[:STATe]	OFF		
:SUMMary			
:STATe	<Boolean>		
:MAXimum			Vector Signal Analysis
[:STATe]	<Boolean>		
:RESult?			query only
:AVERage			
:RESult?			query only
:PHOLd			
RESult?			query only
:PPEak			Vector Signal Analysis
[:STATe]	<Boolean>		
:RESult?			query only
:AVERage			
:RESult?			query only
:PHOLd			
RESult?			query only
:MPEak			Vector Signal Analysis
[:STATe]	<Boolean>		
:RESult?			query only
:AVERage			
:RESult?			query only
:PHOLd			
RESult?			query only

COMMAND	PARAMETERS	UNIT	COMMENT
CALCulate<1|2>			
:MARKer			
:FUNCtion			
:SUMMary			
:MIDDle			Vector Signal Analysis
[:STATe]	<Boolean>		
:RESult?			query only
:AVERage			
:RESult?			query only
:PHOLd			
RESult?			query only
:RMS			
[:STATe]	<Boolean>		
:RESult?			query only
:AVERage			
:RESult?			query only
:PHOLd			
RESult?			query only
:MEAN			
[:STATe]	<Boolean>		
:RESult?			query only
:AVERage	<Boolean>		
:RESult?			query only
:PHOLd	<Boolean>		
RESult?			query only
:AOFF			no query
:PHOLd			no query
:AVERage			no query
:CENTer			no query
:CSTep			no query
:STARt			no query
:STOP			no query
:MSTep			no query
:REFerence			no query

CALCulate<1|2>:MARKer<1 to 4>[:STATe] ON | OFF

This command switches on or off the currently selected marker. If no indication is made, marker 1 is selected automatically.

Example: "CALC:MARK3 ON"

Features: *RST value: OFF
SCPI: device-specific

Modes: A, VA, BTS, MS

CALCulate<1|2>:MARKer<1 to 4>:AOFF

This command switches off all active markers.

Example: "CALC:MARK:AOFF"

Features: *RST value: -
SCPI: device-specific

Modes: A, VA, BTS, MS

This command is an event which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:MARKer<1 to 4>:TRACe 1 to 4

This command assigns the selected marker (1 to 4) to the indicated test curve.

Example: "CALC:MARK3:TRAC 2"

Features: *RST value -
SCPI: device-specific

Modes: A, VA, BTS, MS

CALCulate<1|2>:MARKer<1 to 4>:X 0 ... MAX (frequency | sweep time | symbols)

This command positions the selected marker to the indicated frequency (span > 0) or time (span = 0).

Example: "CALC:MARK:X 10.7MHz"

Features: *RST value: -
SCPI: device-specific

Modes: A, VA, BTS, MS

The unit SYM is available only in the vector signal analysis mode.

CALCulate<1|2>:MARKer<1 to 4>:X:SLIMits[:STATe] ON | OFF

This command switches between a limited (ON) and unlimited (OFF) search range.

Example: "CALC:MARK:X:SLIM ON"

features: *RST value: OFF
SCPI: device-specific

Modes: A, VA

CALCulate<1|2>:MARKer<1 to 4>:COUNt ON | OFF

This command switches on or off the frequency counter at the marker position.

Example: "CALC:MARK:COUN ON"

Features: *RST value: OFF
SCPI: device-specific

Mode: A

CALCulate<1|2>:MARKer<1 to 4>:COUNt:RESolution 0.1 | 1 | 10 | 100 | 1000 | 10000 Hz

This command specifies the resolution of the frequency counter.

Example: "CALC:MARK:COUN:RES 1kHz"

Features: *RST value: 1kHz
SCPI: device-specific

Mode: A

The numeric suffix in MARKer<1 to 4> is not significant.

CALCulate<1|2>:MARKer<1 to 4>:COUNt7:FREQuency?

This command queries the result of the frequency counter.

Example: "CALC:MARK:COUN:FREQ?"

Features: *RST value: -
SCPI: device-specific

Modes: A, BTS, MS

This command is only a query and thus has no *RST value.

CALCulate<1|2>:MARKer<1 to 4>:COUPled[:STATe] ON | OFF

This command switches the coupling of markers on or off.

Example: "CALC:MARK:COUP ON"

Features: *RST value: OFF
SCPI: device-specific

Modes: A, BTS, MS

The numeric suffix in MARKer<1 to 4> is not significant.

CALCulate<1|2>:MARKer<1 to 4>:LOEXclude ON | OFF

This command switches the local oscillator suppression on or off.

Example: "CALC:MARK:LOEX ON"

Features: *RST value: OFF
SCPI: device-specific

Mode: A-F

The numeric suffixes 1|2 and 1 to 4 are not significant.

CALCulate<1|2>:MARKer<1 to 4>:Y?

This command queries the selected marker value.

Example: "CALC:MARK:Y?"

Features: *RST value: -
SCPI: device-specific

Modes: A, VA, BTS, MS

CALCulate<1|2>:MARKer<1 to 4>:MAXimum[:PEAK]

This command positions the marker to the current maximum value in the trace memory.

Example: "CALC:MARK:MAX"

Features: *RST value: -
SCPI: device-specific

Modes: A, VA, BTS, MS

This command is an event which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:MARKer<1 to 4>:MAXimum:APEak

This command positions the marker to the maximum absolute value of the trace.

Example: "CALC:MARK:MAX:APE"

Features: *RST value: -
SCPI: device-specific

Mode: VA

This command is an event which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:MARKer<1 to 4>:MAXimum:NEXT

This command positions the marker to the next lower maximum value in the trace memory.

Example: "CALC:MARK:MAX:NEXT"

Features: *RST value: -
SCPI: device-specific

Modes: A, BTS, MS

This command is an event which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:MARKer<1 to 4>:MAXimum:RIGHt

This command positions the marker to the next smaller maximum value to the right of the current value (i.e., in ascending X direction) in the trace memory.

Example: "CALC:MARK:MAX:RIGH"

Features: *RST value: -
SCPI: device-specific

Modes: A, BTS, MS

This command is an event which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:MARKer<1 to 4>:MAXimum:LEFT

This command positions the marker to the next smaller maximum value to the left of the current value (i.e., in descending X direction) in the trace memory.

Example: "CALC:MARK:MAX:LEFT"

Features: *RST value: -
SCPI: device-specific

Modes: A, BTS, MS

This command is an event which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:MARKer<1 to 4>:MINimum[:PEAK]

This command positions the marker to the current minimum value in the trace memory.

Example: "CALC:MARK:MIN"

Features: *RST value: -
SCPI: device-specific

Modes: A, VA, BTS, MS

This command is an event which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:MARKer<1 to 4>:MINimum:NEXT

This command positions the marker to the next higher minimum value in the trace memory.

Example: "CALC:MARK:MIN:NEXT"

Features: *RST value: -
SCPI: device-specific

Modes: A, BTS, MS

This command is an event which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:MARKer<1 to 4>:MINimum:RIGHt

This command positions the marker to the next higher minimum value to the right of the current value (ie in ascending X direction).

Example: "CALC:MARK:MIN:RIGH"

Features: *RST value: -
SCPI: device-specific

Modes: A, BTS, MS

This command is an event which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:MARKer<1 to 4>:MINimum:LEFT

This command positions the marker to the next higher minimum value to the left of the current value (ie in descending X direction).

Example: "CALC:MARK:MIN:LEFT"

Features: *RST value: -
SCPI: device-specific

Modes: A, BTS, MS

is command is an event which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:MARKer<1 to 4>:STEP[:INCRement] <numeric_value>

This command defines the marker step width.

Example: "CALC:MARK:STEP 10kHz" (frequency domain)
CALC:MARK:STEP 5ms" (time domain)

Features: *RST value: - (STEP is set to AUTO)
SCPI: device-specific

Mode: A

This command sets STEP:AUTO to OFF. The numeric suffix in MARKer<1 to 4> is not significant.

CALCulate<1|2>:MARKer<1 to 4>:STEP:AUTO ON | OFF

This command switches the automatic adaptation of the marker step width on or off.

Example: "CALC:MARK:STEP:AUTO OFF"

Features: *RST value: ON
SCPI: device-specific

Mode: A

With AUTO ON, the step width is 10% of the span. The numeric suffix in MARKer<1 to 4> is not significant.

CALCulate<1|2>:MARKer<1 to 4>:PEXCursion <numeric_value>

This command defines the peak excursion.

Example: "CALC:MARK:PEXC 10dB"

Features: *RST value: 6dB
SCPI: device-specific

Modes: A, VA, BTS, MS

The numeric suffix in MARKer<1 to 4> is not significant.

CALCulate<1|2>:MARKer<1 to 4>:READout MPHase | RIMaginary

This command determines the type of the marker display.

Example: "CALC:MARK:READ RIM"

Features: *RST value: -
SCPI: device-specific

Mode: VA-D

The numeric suffix in MARKer<1 to 4> is not significant.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:NDBDown <numeric_value>

This command defines the "N dB Down" value.

Example: "CALC:MARK:FUNC:NDBD 3dB"

Features: *RST value: 6dB
SCPI: device-specific

Mode: A

The temporary markers T1 and T2 are positioned by n dB below the active reference marker. The frequency spacing of these markers can be queried with CALCulate:MARKer:FUNCtion:NDBDown:RESult?.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:NDBDown:STATe ON | OFF

This command switches the "N dB Down" function on or off.

Example: "CALC:MARK:FUNC:NDBD:STAT ON"

Features: *RST value: OFF
SCPI: device-specific

Modes: A, BTS, MS

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:NDBDown:RESult?

This command queries the frequency spacing (bandwidth) of the "N dB Down" markers.

Example: "CALC:MARK:FUNC:NDBD:RES?"

Features: *RST value: -
SCPI: device-specific

Modes: A, BTS, MS

This command is only a query which is why it is not assigned an *RST value.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:NDBDown:FREQuency?

This command queries the frequencies of the "N dB Down" marker.

Example: "CALC:MARK:FUNC:NDBD:FREQ?"

Features: *RST value: -
SCPI: device-specific

Modes: A, BTS, MS

The two frequency values are separated by comma and indicated in ascending order. This command is only a query which is why it is not assigned an *RST value.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:ZOOM <numeric_value>

This command defines the range to be enlarged around the active marker.

Example: "CALC:MARK:FUNC:ZOOM 1kHz"

Features: *RST value: -
SCPI: device-specific

Mode: A-F

The subsequent frequency sweep is stopped at the marker position and the frequency of the signal is counted. This frequency becomes the new center frequency, the zoomed span is then set. This command is an event which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:NOISe[:STATe] ON | OFF

This command switches the noise measurement on or off.

Example: "CALC:MARK:FUNC:NOIS ON"

Features: *RST value: OFF
SCPI: device-specific

Mode: A

The noise power density is measured at the position of the markers. The result can be queried with CALCulate:MARKer:FUNCtion:NOISe:RESult?.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:NOISe:RESult?

This command queries the result of the noise measurement.

Example: "CALC:MARK:FUNC:NOIS:RES?"

Features: *RST value: -
SCPI: device-specific

Modes: A, BTS, MS

This command is an event which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:DEModulation:SELect AM | FM

This command selects the demodulation type.

Example: "CALC:MARK:FUNC:DEM:SEL FM"

Features: *RST value: AM
SCPI: device-specific

Mode: A

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:DEModulation[:STATe] ON | OFF

This command switches the demodulation on or off.

Example: "CALC:MARK:FUNC:DEM ON"

Features: *RST value: OFF
SCPI: device-specific

Mode: A

With demodulation switched on, the frequency sweep is stopped at the marker position and the signal is demodulated during the given stop time.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:DEModulation:HOLDoff 10ms to 1000s

This command defines the duration of the stop time for the demodulation.

Example: "CALC:MARK:FUNC:DEM:HOLD 3s"

Features: *RST value: - (DEModulation is set to OFF)
SCPI: device-specific

Mode: A

With demodulation switched on, the frequency sweep is stopped at the marker position and the signal is demodulated during the given stop time.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SFACtor (60dB/3dB) | (60dB/6dB)

This command defines the shape factor measurement 60dB/6dB or 60dB/3dB.

Example: "CALC:MARK:FUNC:SFAC (60dB/3dB)"

Features: *RST value: (60dB/6dB)
SCPI: device-specific

Modes: A, BTS, MS

The temporary markers T1 to T4 are positioned in pairs by 60dB and by 3dB or 6dB below the active reference marker. The frequency spacing ratio of these markers - the shape factor - can be queried with CALCulate:MARKer:FUNCtion:SFACtor:RESult?.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SFACtor:STATe ON | OFF

This command switches the shape factor measurement on or off.

Example: "CALC:MARK:FUNC:SFAC:STAT ON"

Features: *RST value: OFF
SCPI: device-specific

Modes: A, BTS, MS

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SFACtor:RESult?

This command queries the result of the shape factor measurement.

Example: "CALC:MARK:FUNC:SFAC:RES?"

Features: *RST value: -
SCPI: device-specific

Modes: A, BTS, MS

This command is an event which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SFACtor:FREQuency?

This command queries the frequencies of the shape factor measurement.

Example: "CALC:MARK:FUNC:SFAC:FREQ?"

Features: *RST value: -
SCPI: device-specific

Modes: A, BTS, MS

Four frequency values (at -60 dB, -6 or. -3 dB, -6 or -3 dB, -60dB) are indicated in ascending order. They are separated by a comma. This command is only a query which is why it is not assigned an *RST value.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:STRack[:STATe] ON | OFF

This command switches the signal-track function on or off.

Example: "CALC:MARK:FUNC:STR ON"

Features: *RST value: OFF
SCPI: device-specific

Mode: A-F

With SIGNAL TRACK function activated, the maximum signal is determined after each frequency sweep and the center frequency of this signal is set. With drifting signals the center frequency follows the signal.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:ADEMod:AM[:RESult]? PPEak| MPEak| MIDDle| RMS

This command queries the results of the AM modulation measurement of the analog demodulation.

Example: "CALC:MARK:FUNC:ADEM:AM? PPE"

Features: *RST value: -
SCPI: device-specific

Mode: VA-A

PPEak Result of the measurement with detector +PK
MPEak Result of the measurement with detector -PK
MIDDle Result of averaging ±PK/2
RMS Result of the measurement with detector RMS

In the modulation modes FM or PM query of the MIDDle-result is possible only.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:ADEMod:FM[:RESult]? PPEak | MPEak | MIDDle | RMS | RDEV

This command queries the results of the FM modulation measurement of the analog demodulation.

Example: "CALC:MARK:FUNC:ADEM:FM? PPE"

Features: *RST value: -
SCPI: device-specific

Mode: VA-A

PPEak Result of the measurement with detector +PK
MPEak Result of the measurement with detector -PK
MIDDle Result of averaging ±PK/2
RMS Result of the measurement with detector RMS

In the modulation modes FM or PM query of the MIDDle-result is possible only.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:ADEMod:PM[:RESult]? PPEak| MPEak| MIDDle| RMS

This command queries the results of the PM modulation measurement of the analog demodulation.

Example: "CALC:MARK:FUNC:ADEM:PM? PPE"

Features: *RST value: -
SCPI: device-specific

Mode: VA-A

PPEak Result of the measurement with detector +PK
MPEak Result of the measurement with detector -PK
MIDDle Result of averaging ±PK/2
RMS Result of the measurement with detector RMS

In the modulation modes FM or PM query of the MIDDle-result is possible only.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:ADEMod:AFRequency[:RESult]?

This command queries the audio frequency of the analog demodulation.

Example: "CALC:MARK:FUNC:ADEM:AFR? "

Features: *RST value: -
SCPI: device-specific

Mode: VA-A

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:ADEMod:FERRor[:RESult]?

This command queries the frequency error of the analog demodulation.

Example: "CALC:MARK:FUNC:ADEM:FERR? "

Features: *RST value: -
SCPI: device-specific

Mode: VA-A

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:ADEMod:CARRier[:RESult]?

This command queries the results of the carrier frequency measurement.

Example: "CALC:MARK:FUNC:ADEM:CARR?"

Features: *RST value: -
SCPI: device-specific

Mode: VA-A

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:ADEMod:SINad[:STATe] ON | OFF

This command switches the SINAD measurement on or off.

Example: "CALC:MARK:FUNC:ADEM:SIN ON"

Features: *RST value: OFF
SCPI: device-specific

Mode: VA-A

This command is valid only in the analog demodulation mode with Real Time ON.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:ADEMod:SINad:RESult?

This command queries the results of the SINAD measurement.

Example: "CALC:MARK:FUNC:ADEM:SIN:RES?"

Features: *RST value: -
SCPI: device-specific

Mode: VA-A

This command is only a query and thus has no *RST value assigned.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:DDEMod:RESult? MERM | MEPK | MEPS | PERM | PEPK | PEPS | EVRM | EVPK | EVPS | IQOF | IQIM | ADR | FERR | RHO

This command queries the error measurement results of digital demodulation.

Example: "CALC:MARK:FUNC:DDEM:RES? EVRM"

Features: *RST value: -
SCPI: device-specific

Mode: VA-D

MERM	magnitude error in %rms	FERR	frequency error in Hz
MEPK	maximum of magnitude error in %pk	FEPK	maximum of frequency error in Hz
MEPS	symbol number by which the maximum of the magnitude error occurred	ADR	amplitude drop in dB/symbol
PERM	phase error in deg	RHO	Rho-Factor
PEPK	maximum of phase error in deg	DEV	FSK deviation in Hz
PEPS	symbol number by which the maximum of the phase error occurred		
EVRM	vector error in %rms	FSPK	maximum of FSK deviation error in Hz
EVPK	maximum of vector error in %pk	FSRM	FSK deviation error in Hz
EVPS	symbol number by which the maximum of the vector error occurred	FSPS	symbol number by which the maximum of error occurred
IQOF	I/Q-offset error in %		
IQIM	I/Q Imbalance in %	DTTS	trigger delay of synchronization

CALCulate<1|2>:MARKer<1...4>:FUNCtion:POWer:SELect ACPower | CPOWer | OBANdwidth | OBWidth | CN | CN0

This command selects the power measurement and switches it on.

Example: "CALC:MARK:FUNC:POW:SEL ACP"

Features: *RST value: -
SCPI: device-specific

Mode: A-F

ACPower	adjacent channel power measurement
CPOWer	channel power measurement
OBANdwidth | OBWidth	occupied bandwidth power measurement
CN	signal / noise power measurement
CN0	signal-/ noise power measurement based on 1Hz bandwidth

This command is an event which is why it is not assigned an *RST value and query.

CALCulate<1|2>:MARKer<1...4>:FUNCtion:POWer:RESult? ACPower | CPOWer | OBANdwidth | OBWidth | CN | CN0

This command queries the results of the power measurement (see also `CALCulate:MARKer:FUNCtion:POWer:SELect`.)

Example: `"CALC:MARK:FUNC:POW:RES? OBW"`

Features: *RST value: -
SCPI: device-specific

Modes: A, VA, BTS, MS

ACPower — adjacent channel power measurement; Results are output separated by commas in the following order:
Power of main channel
Power of lower adjacent channel 1
Power of upper adjacent channel 1
Power of lower adjacent channel 2
Power of upper adjacent channel 2
...
The number of results depends on the number of adjacent channels selected. With logarithmic scaling (RANGE LOG), the power is output in dBm, with linear scaling (RANGE LIN dB or LIN %) in W. If SENSe:POWer:ACHannel:MODE REL is selected, adjacent channel power is output in dB.

CPOWer — channel power measurement
With logarithmic scaling (RANGE LOG), the channel power is output in dBm, with linear scaling (RANGE LIN dB or LIN %) in W.

OBANdwidth | OBWidth — occupied bandwidth power measurement
The return value is the occupied bandwidth in Hz

CN — signal / noise power measurement
The return value is always in dB..

CN0 — signal-/ noise power measurement based on 1Hz bandwidth
The return value is always in dB/Hz

This command is only a query which is why it is not assigned an *RST value.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:POWer[:STATe] OFF

This command switches the power measurement off.

Example: `"CALC:MARK:FUNC:POW OFF"`

Features: *RST value: -
SCPI: device-specific

Modes: A-F, VA-D

This command is an event which is why it is not assigned an *RST value.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:POWer:PRESet NADC | TETRA | PDC | PHS | CDPD | F8DCma | R8CDma | F19Cdma | R19Cdma | NONE

This command selects the settings for power measurement of one of the standards.

Example: "CALC:MARK:FUNC:POW:PRES NADC"

Features: *RST value: -
SCPI: device-specific

Mode: A-F

F8CDma CDMA 800 forward
R8CDma CDMA 800 reverse
F19Cdma CDMA 1900 forward
R19Cdma CDMA1900 reverse

The selection of a standard influences the parameters weighting filter, channel bandwidth and spacing, resolution and video bandwidth, as well as detector and sweep time.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:POWer:CFILter ON | OFF

This command switches the weighting filter for the selected standard on or off.

Example: "CALC:MARK:FUNC:POW:CFIL ON"

Features: *RST value: OFF
SCPI: device-specific

Mode: A-F

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:STATe ON | OFF

This command switches the messages selected by the summary marker (eg RMS and MEAN) on and off. One or several measurements can be selected with the commands listed in the following and then switched jointly on and off with SUMMary:STATe.

Example: "CALC:MARK:FUNC:SUMM:STAT ON"

Features: *RST value: OFF
SCPI: device-specific

Mode: A-Z, VA

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MAXimum[:STATe] ON | OFF

This command switches on or off the measurement of the maximum of the absolute value.

Example: "CALC:MARK:FUNC:SUMM:MAX ON"

Features: *RST value: OFF
SCPI: device-specific

Mode: VA

When the measurement is switched on, the summary marker is automatically activated (command SUMMary:STATe set to ON). When it is switched off, the summary marker remains switched on provided further measurements are selected. Otherwise the marker is switched off automatically.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MAXimum:RESult?

This command queries the results of the measurement of the maximum of the absolute value. Results of average calculation and peak hold are queried with commands `...:MAXimum:AVERage:RESult?` and `...:MAXimum:PHOLd:RESult?`.

Example: `"CALC:MARK:FUNC:SUMM:MAX:RES?"`

Features: *RST value: -
SCPI: device-specific

Mode: VA

This command is only a query and thus has no *RST value assigned.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MAXimum:AVERage:RESult?

This command is used to query the results of the measurement of the maximum of the absolute value if the average is calculated using the command `CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:AVERage`.

Example: `"CALC:MARK:FUNC:SUMM:MAX:AVER:RES?"`

Features: *RST value: -
SCPI: device-specific

Mode: VA

This command is only a query and thus has no *RST value assigned.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MAXimum:PHOLd:RESult?

This command is used to query the results of the measurement of the maximum of the absolute value when the peak hold function is switched on with command `CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:PHOLd`.

Example: `"CALC:MARK:FUNC:SUMM:MAX:PHOL:RES?"`

Features: *RST value: -
SCPI: device-specific

Mode: VA

This command is only a query and thus has no *RST value assigned.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:PPEak[:STATe] ON | OFF

This command switches on or off the measurement of the positive peak value if the calculation and.

Example: `"CALC:MARK:FUNC:SUMM:PPE ON"`

Features: *RST value: OFF
SCPI: device-specific

Mode: VA

When the measurement is switched on, the summary marker is automatically activated (command `SUMMary:STATe` set to `ON`). When it is switched off, the summary marker remains switched on provided further measurements are selected. Otherwise the marker is switched off automatically.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:PPEak:RESult?

This command is used to query the result of the measurement of the positive peak value . Results of average calculation and peak hold are queried with commands `...:PPEak:AVERage:RESult?` and `...:PPEak:PHOLd:RESult?`

Example: `"CALC:MARK:FUNC:SUMM:PPE:AVER:RES?"`

Features: *RST value: -
SCPI: device-specific

Mode: VA

This command is only a query and thus has no *RST value assigned.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:PPEak:AVERage:RESult?

This command is used to query the result of the measurement of the positive peak value if the average is calculated using the command `CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:AVERage`.

Example: `"CALC:MARK:FUNC:SUMM:PPE:AVER:RES?"`

Features: *RST value: -
SCPI: device-specific

Mode: VA

This command is only a query and thus has no *RST value assigned.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:PPEak:PHOLd:RESult?

This command is used to query the result of the measurement of the positive peak value if the peak hold function is switched on with command `CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:PHOLd`.

Example: `"CALC:MARK:FUNC:SUMM:PPE:PHOL:RES?"`

Features: *RST value: -
SCPI: device-specific

Mode: VA

This command is only a query and thus has no *RST value assigned.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MPEak[:STATe] ON | OFF

This command switches on or off the measurement of the negative peak value.

Example: `"CALC:MARK:FUNC:SUMM:MPE ON"`

Features: *RST value: OFF
SCPI: device-specific

Mode: VA

When the measurement is switched on, the summary marker is automatically activated (command `SUMMary:STATe` set to `ON`). When it is switched off, the summary marker remains switched on provided further measurements are selected. Otherwise the marker is switched off automatically.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MPEak:RESult?

This command queries the result of the measurement of the negative peak value. Results of average calculation and peak hold are queried with commands `...:MPEak:AVERage:RESult?` and `...:MPEak:PHOLd:RESult?`.

Example: "CALC:MARK:FUNC:SUMM:MPE:RES?"

Features: *RST- value: -
SCPI: device-specific

Mode: VA

This command is only a query and thus has no *RST value assigned.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MPEak:AVERage:RESult?

This command queries the result of the measurement of the negative peak value if the average is calculated using the command `CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:AVERage`.

Example: "CALC:MARK:FUNC:SUMM:MPE:AVER:RES?"

Features: *RST- value: -
SCPI: device-specific

Mode: VA

This command is only a query and thus has no *RST value assigned.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MPEak:PHOLd:RESult?

This command queries the result of the measurement of the negative peak value if the peak hold function is switched on with command `CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:PHOLd`.

Example: "CALC:MARK:FUNC:SUMM:MPE:RES?"

Features: *RST- value: -
SCPI: device-specific

Mode: VA

This command is only a query and thus has no *RST value assigned.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MIDDle[:STATe] ON | OFF

This command switches on or off the measurement of the arithmetical mean between positive and negative peak value.

Example: "CALC:MARK:FUNC:SUMM:MIDD ON"

Features: *RST value: OFF
SCPI: device-specific

Mode: VA

When the measurement is switched on, the summary marker is automatically activated (command `SUMMary:STATe` set to `ON`). When it is switched off, the summary marker remains switched on provided further measurements are selected. Otherwise the marker is switched off automatically.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MIDDle:RESult?

This command queries the result of the measurement of the arithmetical mean between positive and negative peak value. Results of average calculation and peak hold are queried with commands `...:MIDDle:AVERage:RESult?` and `...:MIDDle:PHOLd:RESult?`.

Example: `"CALC:MARK:FUNC:SUMM:MIDD:RES? "`

Features: *RST- value: -
SCPI: device-specific

Mode: VA

This command is only a query and thus has no *RST value assigned

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MIDDle:AVERage:RESult?

This command queries the result of the measurement of the arithmetical mean between positive and negative peak value if the average is calculated using the command `CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:AVERage`.

Example: `"CALC:MARK:FUNC:SUMM:MIDD:AVER:RES? "`

Features: *RST- value: -
SCPI: device-specific

Mode: VA

This command is only a query and thus has no *RST value assigned

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MIDDle:PHOLd:RESult?

This command queries the result of the measurement of the arithmetical mean between positive and negative peak value if the peak hold function is switched on using the command `CALCulate<1|2>:MARKer<1 to4>:FUNCtion:SUMMary:PHOLd`.

Example: `"CALC:MARK:FUNC:SUMM:MIDD:PHOL:RES? "`

Features: *RST- value: -
SCPI: device-specific

Mode: VA

This command is only a query and thus has no *RST value assigned

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:RMS[:STATe] ON | OFF

This command switches on or off the measurement of the effective (rms) value of the total trace.

Example: `"CALC:MARK:FUNC:SUM:RMS ON"`

Features: *RST value: OFF
SCPI: device-specific

Modes: A-Z, VA

When the measurement is switched on, the summary marker is automatically activated (command `SUMMary:STATe` set to `ON`). When it is switched off, the summary marker remains switched on provided further measurements are selected. Otherwise the marker is switched off automatically.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:RMS:RESult?

This command queries the result of the measurement of the mean value of the total trace. Results of average calculation and peak hold are queried with commands `...:RMS:AVERage:RESult?` and `...:RMS:PHOLd:RESult?`..

Example: "CALC:MARK:FUNC:SUMM:RMS:RES?"

Features: *RST- value: -
SCPI: device-specific

Modes: A-Z, VA

This command is only a query and thus has no *RST value assigned.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:RMS:AVERage:RESult?

This command queries the result of the measurement of the mean value of the total trace if the average is calculated using the command `CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:AVERage`.

Example: "CALC:MARK:FUNC:SUMM:RMS:AVER:RES?"

Features: *RST- value: -
SCPI: device-specific

Modes: A-Z, VA

This command is only a query and thus has no *RST value assigned.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:RMS:PHOLd:RESult?

This command queries the result of the measurement of the mean value of the total trace if the peak hold function is switched on using the command `CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:PHOLd`.

Example: "CALC:MARK:FUNC:SUMM:RMS:PHOL:RES?"

Features: *RST- value: -
SCPI: device-specific

Modes: A-Z, VA

This command is only a query and thus has no *RST value assigned.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MEAN[:STATe] ON | OFF

This command switches on or off the measurement of the mean value of the total trace.

Example: "CALC:MARK:FUNC:SUMM:MEAN ON"

Features: *RST value: OFF
SCPI: device-specific

Modes: A-Z, VA

When the measurement is switched on, the summary marker is automatically activated (command `SUMMary:STATe` set to `ON`). When it is switched off, the summary marker remains switched on provided further measurements are selected. Otherwise the marker is switched off automatically.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MEAN:RESult?

This command queries the result of the measurement of the mean value of the total trace. Results of average calculation and peak hold are queried with commands `...:MEAN:AVERage:RESult?` and `...:MEAN:PHOLd:RESult?`..

Example: `"CALC:MARK:FUNC:SUMM:MEAN:RES?"`

Features: *RST- value: -
SCPI: device-specific

Modes: A-Z, VA

This command is only a query and thus has no *RST value assigned.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MEAN:AVERage:RESult?

This command queries the result of the measurement of the mean value of the total trace if the average is calculated using the command `CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:AVERage`.

Example: `"CALC:MARK:FUNC:SUMM:MEAN:AVER:RES?"`

Features: *RST- value: -
SCPI: device-specific

Modes: A-Z, VA

This command is only a query and thus has no *RST value assigned.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MEAN:PHOLd:RESult?

This command queries the result of the measurement of the mean value of the total trace if the peak hold function is switched on using the command `CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:PHOLd`.

Example: `"CALC:MARK:FUNC:SUMM:MEAN:PHOL:RES?"`

Features: *RST- value: -
SCPI: device-specific

Modes: A-Z, VA

This command is only a query and thus has no *RST value assigned.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:PHOLd ON | OFF

This command switches on or off the peak-hold function.

Example: `"CALC:MARK:FUNC:SUMM:PHOL ON"`

Features: *RST value: OFF
SCPI: device-specific

Modes: A-Z, VA

The peak-hold function is reset by switching off and on, again.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:AVERage ON | OFF

This command switches the calculation of the average value on or off.

Example: `"CALC:MARK:FUNC:SUMM:AVER ON"`

Features: *RST value: OFF
SCPI: device-specific

Modes: A-Z, VA

The calculation of the average is reset by switching off and on, again.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:AOFF

This command switches off all measuring functions.

Example: "CALC:MARK:FUNC:SUMM:AOFF"

Features: *RST value: _
SCPI: device-specific

Modes: A-Z, VA

This command is an "event" and therefore has no *RST value assigned and no query.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:CENTer

This command sets the center frequency to that of the current marker.

Example: "CALC:MARK:FUNC:CENT"

Features: *RST value: -
SCPI: device-specific

Mode: A-F

This command is an "event" and therefore has no *RST value assigned and no query.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:CSTep

This command sets the step width of the center frequency to the x-value of the current marker.

Example: "CALC:MARK:FUNC:CST"

Features: *RST value: -
SCPI: device-specific

Mode: A-F

This command is an "event" and therefore has no *RST value assigned and no query.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:STARt

This command sets the start frequency to the frequency of the current marker.

Example: "CALC:MARK:FUNC:STAR"

Features: *RST value: -
SCPI: device-specific

Mode: A-F

This command is an "event" which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:STOP

This command sets the stop frequency to the frequency of the current marker.

Example: "CALC:MARK:FUNC:STOP"

Features: *RST value: -
SCPI: device-specific

Mode: A-F

This command is an "event" which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:MSTep

This command sets the marker step width to the x-value of the current marker.

Example: "CALC:MARK:FUNC:MST"

Features: *RST value: -
SCPI: device-specific

Modes: A, VA

This command is an "event" which is why it is not assigned an *RST value and has no query.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:REFerence

This command sets the reference level to that of the current marker.

Example: "CALC:MARK:FUNC:REF"

Features: *RST value: -
SCPI: device-specific

Modes: A, VA

This command is an "event" and therefore has no *RST value assigned and no query.

3.6.4.7 CALCulate:MATH Subsystem

The CALCulate:MATH - subsystem allows to process data from the SENSe-subsystem in numeric expressions.

COMMAND	PARAMETERS	UNIT	COMMENT
CALCulate<1|2>			
:MATH<1 to 4>			
[:EXPRession]			
[:DEFine]	<expr>	--	
:STATe	<Boolean>	--	

CALCulate<1|2>:MATH<1 to 4>[:EXPression][:DEFine] <expr>

This command defines the mathematical expression for relating traces and reference line. Command `CALCulate:MATH:STATe` switches the mathematical relation of traces on or off .

Parameter: <expr>::= 'OP1 - OP2 [+ RLINE]'
OP1 ::= TRACE1 | TRACE2 | TRACE3 | TRACE4
OP2 ::= TRACE1 | TRACE2 | TRACE3 | TRACE4 | RLINE

Examples:
```
"CALC:MATH1 (TRACE1 - TRACE3 + RLINE)"
"CALC:MATH4 (TRACE4 - RLINE)"
```

Features: *RST value: -
SCPI: conforming

Modes: A, VA

The operand [+ RLINE] may be used only if OP2 is different from RLINE. The numeric suffix in CALCULATE<1|2> is not significant. The numeric suffix in MATH<1 to 4> denotes the trace where the result of the mathematical operation is stored. The number must be identical to the number of the operand OP1.

CALCulate<1|2>:MATH<1 to 4>:STATe ON | OFF

This command switches the mathematical relation of traces on or off.

Example:
```
"CALC:MATH1:STAT ON"
```

Features: *RST value: OFF
SCPI: conforming

Modes: A, VA

The numeric suffix in CALCULATE<1|2> is not significant. The numeric suffix in MATH<1 to 4> denotes the trace which the command refers to.

3.6.4.8 CALCulate:UNIT Subsystem

The CALCulate:Unit subsystem defines the units for vector signal analyzer mode and power measurements.

COMMAND	PARAMETERS	UNIT	COMMENT
CALCulate<1|2>			
:X			Vector Signal Analysis
:UNIT			
:TIME	S | SYM		
:UNIT			Vector Signal Analysis
:ANGLe	DEG | RAD		
:POWer	DBM | V | W | DB | PCT | UNITLESS | DBPW | WATT | DBUV | DBMV | VOLT | DBUA | AMPere DBUV_MHZ | DBMV_MHZ | DBUA_MHZ | DBUV_M | DBUA_M | DBUV_MMHZ | DBUA_MMHZ		

CALCulate<1|2>:X:UNIT:TIME S | SYM

This command selects seconds or symbols as an x-axis unit.

Example: "CALC:X:UNIT:TIME S"

Features: *RST value: S
SCPI: device-specific

Mode: VA-D

CALCulate<1|2>: UNIT:ANGLe DEG | RAD

This command selects the unit for angular measurement.

Example: "CALC:UNIT:ANGL DEG"

Features: *RST- value: RAD
SCPI: device-specific

Mode: VA-D

CALCulate<1|2>: UNIT:POWer DBM | V | W | DB | PCT | UNITLESS | DBPW | WATT | DBUV | DBMV | VOLT | DBUA | AMPere| DBUV_MHZ | DBMV_MHZ | DBUA_MHZ | DBUV_M | DBUA_M |DBUV_MMHZ | DBUA_MMHZ

This command selects the unit for power.

Example: "CALC:UNIT:POW DBM"

Features: *RST value: _
SCPI: device-specific

Modes: A, VA

In the vector analyzer mode, the units DEG, RAD, S, HZ, PCT are available.

DBUV_MHZ and DBUA_MHZ denote the units DBUV/MHZ or DBUA/MHZ.

3.6.5 CALibration Subsystem

The commands of the CALibration subsystem perform instrument calibrations.

COMMAND	PARAMETERS	UNIT	COMMENT
CALibration			
[:ALL]?	--	--	query only
:BANDwidth			
[:RESolution]?	--	--	query only
:BWIDth			
[:RESolution]?	--	--	query only
:IQ?	--	--	query only / Vector Signal Analysis
:LDETector?	--	--	query only
:LOSuppression?	--	--	query only
:PPEak?	--	--	query only FSEM/FSEK only
:SHORt?	--	--	query only
:STATe	<Boolean>	--	

CALibration[:ALL]?

This command performs a complete calibration of the instrument. A "0" is returned if the calibration was successful.

Example: `"CAL?"`

Features: *RST value: -
SCPI: conforming

Modes: A, VA, BTS, MS

CALibration:BANDwidth | BWIDth[:RESolution]?

This command performs a calibration of the filter bandwidths. A "0" is returned if the calibration was successful.

Example: `"CAL:BAND?"`

Features: *RST value: -
SCPI: device-specific

Modes: A, VA, BTS, MS

CALibration:IQ?

This command performs a calibration of the vector signal analyzer. A "0" is returned if the calibration was successful.

Example: `"CAL:IQ?"`

features: *RST value: -
SCPI: device-specific

Modes: VA, BTS, MS

CALibration:LDETector?

This command performs a calibration of the log module's characteristic and of the detectors. A "0" is returned if the calibration was successful.

Example: "CAL:LDET?"

Features: *RST value: -
SCPI: device-specific

Modes: A, VA, BTS, MS

CALibration:LOSuppression?

This command performs a calibration of the local oscillator suppression. . A "0" is returned if the calibration was successful.

Example: "CAL:LOS?"

Features: *RST value: -
SCPI: device-specific

Modes: A, VA, BTS, MS

Modes: E, A, VA

This command is only valid by model '30 instruments or by instruments which have been retrofitted.

CALibration:PPEak?

This command performs a calibration of the tracking YIG filter (preselector peaking). A "0" is returned if the calibration was successful.

Example: "CAL:PPE?"

Features: *RST value: -
SCPI: device-specific

Modes: A

This command is only valid by the models FSEM and FSEK.

CALibration:SHORt?

This command performs a short calibration. A "0" is returned if the calibration was successful.

Example: "CAL:SHOR?"

Features: *RST value: -
SCPI: device-specific

Modes: A, VA, BTS, MS

CALibration:STATe ON | OFF

This command determines whether (ON) or not (OFF) the current calibration data are taken into consideration.

Example: "CAL:STAT OFF"

Features: *RST value: -
SCPI: conforming

Modes: A, VA, BTS, MS

3.6.6 CONFigure Subsystem

The CONFigure subsystem contains commands for configuring complex measurement tasks, like those provided by the option GSM BTS Analyzer (FSE-K11). The CONFigure subsystem is closely linked to the functions of the FETCH and READ subsystems, where the measurement cycles are started and/or the results of the measurements are queried.

3.6.6.1 CONFigure:BTS Subsystem

This subsystem provides the commands for configuring the GSM BTS Analyzer mode (Option FSE-K11) for analyzing the behavior of base stations corresponding to the standards P-GSM, E-GSM, DCS1800 or PCS1900.

COMMAND	PARAMETERS	UNIT	COMMENT
CONFigure			
:BTS			Option FSE-K11
:ARFCn	<numeric_value>	--	
:AUTO	ONCE		
:POWer			
:CLASs	<numeric_value> | M1 | M2 | M3	--	
:STATic	<numeric_value>	--	
:DYNamic	<numeric_value>	--	
:EXPected	<numeric_value>	DBM	
:CHANnel			
:SLOT	<numeric_value>	--	
:AUTO	ONCE		
:TSC	<numeric_value>	--	
:AUTO	<Boolean>		
:SFH	<Boolean>		
:NETWork			
[:TYPE]	PGSM | EGSM | DCS | PCS		
:PHASe	1|2		
:COSiting	<Boolean>		
:TXSupp	<Boolean>		
:PRESet	--		

CONFigure:BTS:ARFCn <numeric_value>

This command selects the number of the transmission channel of the base station.

Parameter: <numeric_value>::= 1 to 124(P-GSM phase I/II)
0 to 124, 975 to 1023(E-GSM)
512 to 885(DCS1800 phase I/II)
512 to 810(PCS1900)

Example: "CONF:BTS:ARFC 67"

Features: *RST value: 1 (P-GSM phase I/II)
0 (E-GSM)
512 (DCS1800 phase I/II)
512 (PCS1900)
SCPI: device-specific

Mode: BTS

CONFigure:BTS:ARFCn:AUTO ONCE

This command is used to search for the channel number of the transmission channel of the base station automatically. This requires only one channel to be active.

Example: "CONF:BTS:ARFC:AUTO ONCE"

Features: *RST value: --
SCPI: device-specific

Mode: BTS

This command is an event and thus has no query and no *RST value assigned.

CONFigure:BTS:POWer:CLASs <numeric_value> | M1 | M2 | M3

This command defines the power class of the base station.

Parameter: <numeric_value> ::= 1 to 8 (P-GSM phase I/II, E-GSM, DCS1800 phase I/II)
::= 1 to 4 (PCS1900)
M1, M2, M3 ::= Power Classes for Micro BTS

Example: "CONF:BTS:POW:CLAS 4"

Features: *RST value: 4 (P-GSM phase I/II, E-GSM)
1 (DCS1800, PCS1900)
SCPI: device-specific

Mode: BTS

CONFigure:BTS:POWer:STATic 0 to 6

This command defines the static power control level of the base station.

Example: "CONF:BTS:POW:STAT 3"

Features: *RST value: 0
SCPI: device-specific

Mode: BTS

CONFigure:BTS:POWer:DYNamic 0 to 15

This command defines the dynamic power control level of the base station.

Example: "CONF:BTS:POW:DYN 5"

Features: *RST value: 0
SCPI: device-specific

Mode: BTS

CONFigure:BTS:POWer:EXPected <numeric_value>

This command enters directly the rated output level of the base station specified by the manufacturer.

Example: "CONF:BTS:POW:EXP 43DBM"

Features: *RST value: 46 dBm (P-GSM phase I/II, E-GSM)
43 dBm (DCS1800, PCS1900)
SCPI: device-specific

Mode: BTS

CONFigure:BTS:CHANnel:SLOT 0 to 7

This command selects the slot number within a transmission frame of the base station.

Example: "CONF:BTS:CHAN:SLOT 3"

Features: *RST value: 0
SCPI: device-specific

Mode: BTS

On changing the slot number, the number of the midamble (TSC) is automatically adapted to the slot.

CONFigure:BTS:CHANnel:SLOT:AUTO ONCE

This command automatically searches for the slot number within a transmission frame of the base station. This requires only one slot to be active.

Example: "CONF:BTS:CHAN:SLOT:AUTO ONCE"

Features: *RST value: --
SCPI: device-specific

Mode: BTS

This command is an event and thus has no query and no *RST value assigned.

CONFigure:BTS:CHANnel:SFH ON | OFF

This command defines whether the base station uses slow frequency hopping or not.

Example: "CONF:BTS:CHAN:SFH ON"

Features: *RST value: OFF
SCPI: device-specific

Mode: BTS

This command is available only when spurious or transient spectrum measurement is selected. The settings for spurious measurement are independent from those selected for transient spectrum.

CONFigure:BTS:CHANnel:TSC:AUTO ON | OFF

This command couples the midamble (training sequence TSC_0 to 7) to the slot, i.e. if the slot number is changed the training sequence in the ON state is automatically adapted. In the OFF state, the training sequence set is conserved even if the slot number is changed.

Example: "CONF:BTS:CHAN:TSC:AUTO ON"

Features: *RST value: ON
SCPI: device-specific

Mode: BTS

CONFigure:BTS:CHANnel:TSC 0 to 7

This command selects the midamble (training sequence TSC_0 to 7) of the active slot.

Example: "CONF:BTS:CHAN:TSC 3"

Features: *RST value: 0
SCPI: device-specific

Mode: BTS

CONFigure:BTS:NETWork[:TYPE] PGSM | EGSM | DCS | PCS

This command selects the standard type according to which the base station will work.

Example: "CONF:BTS:NETW DCS"

Features: *RST value: GSM
SCPI: device-specific

Mode: BTS

CONFigure:BTS:NETWork:PHASe 1|2

This command selects the phase of the standard according to which the base station will work.

Example: "CONF:BTS:NETW:PHAS 2"

Features: *RST value: 1
SCPI: device-specific

Mode: BTS

CONFigure:BTS:COSiting ON | OFF

This command selects whether the base station has the "cositing" feature.

Example: "CONF:BTS:COSiting ON"

Features: *RST value: OFF
SCPI: device-specific

Mode: BTS

This command is available only if spurious emission measurement is selected.

CONFigure:BTS:TXSupp ON | OFF

This command defines that an additional carrier suppression of min. 20dB is taken into account for the measurement. If there is already suppression, a more sensitive setting of the instrument is selected.

Example: "CONF:BTS:TXSupp ON"

Features: *RST value: OFF
SCPI: device-specific

Mode: BTS

For measurements in the RX-band the value is automatically set to ON.

CONFigure:BTS:PRESet

This command resets the parameters for the standard selected to their default values (DEFAULT SETTINGS).

Example: "CONF:BTS:PRES"

Features: *RST value: --
SCPI: device-specific

Mode: BTS

This command is an event and has thus no query and no *RST value assigned.

3.6.6.2 CONFigure:BURSt Subsystem

This subsystem provides the commands for configuring the measurements in the GSM BTS Analyzer mode (option FSE-K11) or GSM MS Analyzer mode (option FSE-K10) which are performed on individual bursts. (carrier power, phase/frequency error, power vs. time).

COMMAND	PARAMETERS	UNIT	COMMENT
CONFigure			
:BURSt			
:PFERror			Option FSE-K11&FSE-B7 or FSE-K10&FSE-B7
[:IMMediate]	--	--	
:COUNt	<numeric_value>	--	
:POWer			
[:IMMediate]	--	--	Option FSE-K11 or FSE-K10
:COUNt	<numeric_value>	--	
:CONDition	NORMal | EXTReme		
:PTEMplate			
[:IMMediate]	--	--	Option FSE-K11 or FSE-K10
:COUNt	<numeric_value>	--	
:SELect	FULL | TOP | RISing | FALLing		

CONFigure:BURSt:PFERror[:IMMediate]

This command selects measurement of the phase and frequency error of the base station or mobile.

Example: "CONF:BURST:PFER"

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

This command is an event and thus has no query and no *RST value assigned. It is available only in conjunction with option GSM BTS Analyzer FSE-K11 and Vector Signal Analysis FSE-B7 or in conjunction with option GSM MS Analyzer, FSE-K10, and Vector Signal Analysis, FSE-B7.

CONFigure:BURSt:PFERror:COUNt 1 to 1000

This command sets the number of bursts used for the determination of average and maximum value.

Example: "CONF:BURST:PFER:COUN 100"

Features: *RST value: 500 (GSM/DCS1800 Phase I)
200 otherwise
SCPI: device-specific

Modes: BTS, MS

CONFigure:BURSt:POWer[:IMMediate]

This command selects measurement of the average carrier power of the base station or mobile.

Example: "CONF:BURST:POW"

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

This command is an event and thus has no query and no *RST value assigned.

CONFigure:BURSt:POWer:COUNt 1 to 1000

This command sets the number of bursts used for the determination of measured values.

Example: "CONF:BURST:POW:COUN 100"

Features: *RST value: 500 (GSM/DCS1800 phase I)
200 otherwise
SCPI: device-specific

Modes: BTS, MS

CONFigure:BURSt:POWer:CONDition NORMal | EXTReme

This command defines the conditions for power measurement.

Example: "CONF:BURST:POW:COND EXTR"

Features: *RST value: NORMal
SCPI: device-specific

Modes: BTS, MS

CONFigure:BURSt:PTEMplate[:IMMediate]

This command selects measurement of power of the base station or mobile vs. time.

Example: "CONF:BURST:PTEM"

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

This command is an event and thus has no query and no *RST value assigned.

CONFigure:BURSt:PTEMPlate:COUNt 1 to 1000

This command defines the number of bursts used for determining the measured value.

Example: "CONF:BURS:PTEM:COUN 100"

Features: *RST value: 500 (GSM/DCS1800 phase I)
200 otherwise
SCPI: device-specific

Modes: BTS, MS

CONFigure:BURSt:PTEMplate:SELect FULL | TOP | RISing | FALLing

This command defined the burst section to be measured.

Example: "CONF:BURS:PTEM:SEL TOP"

Features: *RST value: FULL
SCPI: device-specific

Modes: BTS, MS

3.6.6.3 CONFigure:MS Subsystem

This subsystem provides the commands for configuring the GSM MS Analyzer mode (Option FSE-K10) for analyzing the behavior of mobiles corresponding to the standards P-GSM, E-GSM, DCS1800 or PCS1900.

COMMAND	PARAMETERS	UNIT	COMMENT
CONFigure			
:MS			Option FSE-K10
:ARFCn	<numeric_value>	--	
:AUTO	ONCE		
:POWer			
:CLASs	<numeric_value>	--	
:LEVel	<numeric_value>	--	
:EXPected	<numeric_value>	DBM	
:CHANnel			
:TSC	<numeric_value>	--	
:NETWork			
[:TYPE]	PGSM | EGSM | DCS | PCS		
:PHASe	1|2		
:TXSupp	<Boolean>		
:PRESet	--		

CONFigure:MS:ARFCn <numeric_value>

This command selects the number of the transmission channel of the mobile.

Parameter: <numeric_value>::= 1 to 124(P-GSM phase I/II)
0 to 124, 975 to 1023(E-GSM)
512 to 885(DCS1800 phase I/II)
512 to 810(PCS1900)

Example: "CONF:MS:ARFC 67"

Features: *RST value: 1 (P-GSM phase I/II)
0 (E-GSM)
512 (DCS1800 phase I/II)
512 (PCS1900)
SCPI: device-specific

Mode: MS

CONFigure:MS:ARFCn:AUTO ONCE

This command selects automatically the transmission channel of the mobile.

Example: "CONF:MS:ARFC:AUTO ONCE"

Features: *RST value: -
SCPI: device-specific

Mode: MS

CONFigure:MS:POWer:CLASs <numeric_value>

This command defines the power class of the mobile.

Parameter: <numeric_value> ::= 1 to 5 (P-GSM phase I)
2 to 5 (P-GSM phase II)
2 to 5 (E-GSM)
1 to 2 (DCS1800 phase I)
1 to 3 (DCS1800 phase II)
1 to 3 (PCS1900)

Example: "CONF:MS:POW:CLAS 4"

Features: *RST value: 2 (P-GSM phase I/II, E-GSM)
1 (DCS1800, PCS1900)
SCPI: device-specific

Mode: MS

CONFigure:MS:POWer:LEVel 0 to 6

This command defines the power control level of the mobile.

Example: "CONF:MS:POW:LEV 3"

Features: *RST value: 0
SCPI: device-specific

Mode: MS

CONFigure:MS:POWer:EXPected <numeric_value>

This command enters directly the rated output level of the mobile.

Example: "CONF:MS:POW:EXP 43DBM"

Features: *RST value: 46 dBm (P-GSM phase I/II, E-GSM)
43 dBm (DCS1800, PCS1900)
SCPI: device-specific

Mode: MS

CONFigure:MS:CHANnel:TSC 0 to 7 | AB

This command selects the midamble used by the mobile.

Parameter: 0 to 7 (training sequence for the Normal Burst)
AB (training sequence for the Access Burst)

Example: "CONF:MS:CHAN:TSC 3"

Features: *RST value: 0
SCPI: device-specific

Mode: MS

CONFigure:MS:NETWork[:TYPE] PGSM | EGSM | DCS | PCS

This command selects the standard type according to which the mobile will work.

Example: "CONF:MS:NETW DCS"

Features: *RST value: GSM
SCPI: device-specific

Mode: MS

CONFigure:MS:NETWork:PHASe 1 | 2

This command selects the phase of the standard according to which the mobile will work.

Example: "CONF:MS:NETW:PHAS 2"

Features: *RST value: 1
SCPI: device-specific

Mode: MS

CONFigure:MS:TXSupp ON | OFF

This command defines that an additional carrier suppression of min. 20dB is taken into account for the measurement. If there is already suppression, a more sensitive setting of the instrument is selected.

Example: "CONF:MS:TXSupp ON"

Features: *RST value: OFF
SCPI: device-specific

Mode: MS

For measurements in the RX-band the value is automatically set to ON.

CONFigure:MS:PRESet

This command resets the parameters for the standard selected to their default values (DEFAULT SETTINGS).

Example: "CONF:MS:PRES"

Features: *RST value: --
SCPI: device-specific

Mode: MS

This command is an event and has thus no query and no *RST value assigned

3.6.6.4 CONFigure:SPECtrum Subsystem

This subsystem provides the commands for configuring the measurements in the GSM BTS Analyzer mode (FSE-K11) or in the GSM MS Analyzer mode (FSE-K10) used to determine the power of the spectral contributions due to modulation and switching (modulation spectrum, transient spectrum).

COMMAND	PARAMETERS	UNIT	COMMENT
CONFigure			
:SPECtrum			Option FSE-K11 or FSE-K10
:MODulation			
[:IMMediate]	--	--	
:COUNt	<numeric_value>	--	
:RANGe	ARFCn | TXBand | RXBand | COMBined | DCSRx1800		
:SWITching			
[:IMMediate]	--	--	
:COUNt	<numeric_value>	--	

CONFigure:SPECtrum:MODulation[:IMMediate]

This command selects measurement of the spectrum due to modulation.

Example: "CONF:SPEC:MOD"

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

This command is an event and has thus no query and no *RST value assigned.

CONFigure:SPECtrum:MODulation:COUNt 1 to 1000

This command sets the number of bursts used for determining the average and maximum values.

Example: "CONF:SPEC:MOD:COUN 100"

Features: *RST value: 500 (GSM/DCS1800 phase I)
200 otherwise
SCPI: device-specific

Modes: BTS, MS

CONFigure:SPECtrum:MODulation:RANGe ARFCn | TXBand | RXBand | COMBined | DCSRx1800

This command selects the frequency range for the measurement.

Example: "CONF:SPEC:MOD:RANG TXB"

Features: *RST value: ARFCn
SCPI: device-specific

Modes: BTS, MS

ARFCn	ARFCN ± 1.8 MHz
TXBand	TX-Band
RXBand	RX-Band
COMBined	ARFCN ± 1.8 MHz / TX-Band
DCSRx1800	RX band DCS 1800 (option FSE-K10 only)

CONFigure:SPECtrum:SWITching[:IMMediate]

This command selects measurement of the spectrum due to switching transients.

Example: "CONF:SPEC:SWIT "

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

This command is an event and has thus no query and no *RST value assigned.

CONFigure:SPECtrum:SWITching:COUNt 1 to 1000

This command defines the number of bursts used for determining the average and maximum values.

Example: "CONF:SPEC:SWIT:COUN 100"

Features: *RST value: 500 (GSM/DCS1800 phase I)
200 otherwise
SCPI: device-specific

Modes: BTS, MS

3.6.6.5 CONFigure:SPURious Subsystem

This subsystem provides commands for configuring the measurements in the GSM BTS (FSE-K11) or GSM MS (FSE-K10) Analyzer mode used for measuring the power of spurious emissions.

COMMAND	PARAMETERS	UNIT	COMMENT
CONFigure			
:SPURious			Option FSE-K11 or FSE-K10
[:IMMediate]	--	--	
:COUNt	<numeric_value>	--	
:RXBand	<numeric_value>	--	
:RANGe	TXBand | OTXBand | RXBand | IDLeband	--	

CONFigure:SPURious[:IMMediate]

This command selects measurement of spurious emissions.

Example: "CONF:SPUR"

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

This command is an event and has thus no query and no *RST value assigned.

CONFigure:SPURious:COUNt 1 to 1000

This command sets the number of bursts used for determining the average and maximum values.

Example: "CONF:SPUR:COUN 100"

Features: *RST value: 500 (GSM/DCS1800 phase I)
200 otherwise
SCPI: device-specific

Modes: BTS, MS

The number of bursts in measurements of the RX band is set by command CONFigure:SPURious :RANGe:RXBand (FSE K11 only).

CONFigure:SPURious:COUNt:RXBand 1 to 1000

This command ses the number of bursts used for determining the average and maximum values in measurements of the RX band.

Example: "CONF:SPUR:COUN:RXB 100"

Features: *RST value: 1
SCPI: device-specific

Modes: BTS, MS

CONFigure:SPURious:RANGe TXBand | OTXBand | RXBand

This command selects the frequency range used for the measurement.

Example: "CONF:SPUR:RANG OTX"

Features: *RST value: TXB
SCPI: device-specific

Modes: BTS, MS

TXBand	TX-Band
OTXBand	Not TX-Band
RXBand	RX-Band (option FSE-K11 only)
IDLeband	Idle band (option FSE-K10 only)

3.6.7 DIAGnostic Subsystem

The DIAGnostic subsystem contains the commands which support instrument diagnostics for maintenance, service and repair. In accordance with the SCPI standard, all of these commands are device-specific.

COMMAND	PARAMETERS	UNIT	COMMENT
DIAGnostic			
:SERVice			
:INPut			
[:SELect]	CALibration | RF	--	
:FUNCtion	<numeric_value>,>numeric_value>	--	no query
:NSOurce	<Boolean>	--	

DIAGnostic:SERVice:INPut[:SELect] CALibration | RF

This command toggles between the RF input on the front panel and the internal 120-MHz reference signal.

Example: `"DIAG:SERV:INP CAL"`

Features: *RST value: RF
SCPI: device-specific

Modes: A, VA

DIAGnostic:SERVice:FUNCtion <numeric_value>,<numeric_value>...

This command activates a service function.

Example: `"DIAG:SERV:FUNC 2,0,2,12,1"`

Features: *RST value: -
SCPI: device-specific

Modes: A, VA

The service function is selected via five parameters: functional group number, board number, function number, parameter 1 and parameter 2.

See service manual 1065.6016.24.

DIAGnostic:SERVice:NSOurce ON | OFF

This command switches the 28-V supply at the rear connector of the noise source on and off.

Example: `"DIAG:SERV:NSO ON"`

Features: *RST value: OFF
SCPI: device-specific

Modes: A, VA

3.6.8 DISPlay Subsystem

The DISPLay subsystem controls the selection and presentation of textual and graphic information as well as of trace data on the display.
The displays in the split-screen mode are assigned to WINDow 1 (screen A) or 2 (screen B) .

COMMAND	PARAMETERS	UNIT	COMMENT
DISPlay			
:FORMat	SINGle | SPLit		
:PROgram			
[:MODE]	<Boolean>		option FSE-B15
:ANNotation			
:FREQuency	<Boolean>		
:LOGO	<Boolean>		
:CMAP<1 to 13>			
:DEFault			
:HSL	0 to 1,0 to 1,0 to 1		
:PDEFined	BLACk | BLUE | BROWn | GREen | CYAN | RED | MAGenta | YELLow | WHITe | DGRAy | LGRAy | LBLUe | LGREen | LCYan | LRED | LMAGenta		
[:WINDow<1|2>]			
:TEXT			
[:DATA]	<string>		
:STATe	<Boolean>		
:TIME	<Boolean>		
:MINFo	<Boolean>		
:TRACe<1 to 4>			
:X			
[:SCALe]			Vector Signal Analysis
:RVALue	<numeric_value>		
:ZOOM	<Boolean>		
[:FREQuency]			
:STARt	<numeric_value>	HZ	
:STOP	<numeric_value>	HZ	
:CENTer	<numeric_value>	HZ	
:SPACing	LINear | LOGarithmic	--	
:Y			
[:SCALe]	<numeric_value>	DB	
:MODE	ABSolute | RELative		
:RLEVel	<numeric_value>	DBM	
:OFFSet	<numeric_value>	DB	
:RVALue	<numeric_value>	DBM|DB|HZ| DEG|RAD	Vector Signal Analysis
:AUTO	<Boolean>		Analyzer mode only
:RPOSition	<numeric_value>	PCT	Vector Signal Analysis
:PDIVision	<numeric_value>	DBM|DB|HZ| DEG|RAD	Vector Signal Analysis
:SPACing	LINear|LOGarithmic|PERCent	--	
:MODE	WRITe | VIEW | AVERage | MAXHold | MINHold	--	
:CWRite	<Boolean>	--	Vector Signal Analysis
:ANALog	<Boolean>	--	
:HCONtinuous	<Boolean>	--	
[:STATe]	<Boolean>	--	
:SYMBol	DOTS | BARS | OFF		Vector Signal Analysis
:EYE			
COUNt	<numeric_value>	SYM	Vector Signal Analysis

DISPlay:FORMat SINGle | SPLit

This command switches the test result display between FULL SCREEN and SPLIT SCREEN.

Example: "DISP:FORM SPL"

Features: *RST value: SINGle
SCPI: device-specific

Modes: A, VA

DISPlay:PROGram[:MODE] ON | OFF

This command switches the display between the measuring instrument and the computer function.

Example: "DISP:PROG ON"

Features: *RST value: OFF
SCPI: device-specific

Modes: A, VA, BTS, MS

This command is only valid in conjunction with Option Computer Function (FSE-B15).

DISPlay:ANNotation:FREQuency ON | OFF

This command switches the x-axis annotation on or off.

Example: "DISP:ANN:FREQ OFF"

Features: *RST value: ON
SCPI: conforming

Modes: A, VA, BTS, MS

DISPlay:LOGO ON | OFF

This command switches the factory logo on the screen on or off.

Example: "DISP:LOGO OFF"

Features: *RST value: ON
SCPI: device-specific

Modes: A, VA, BTS, MS

DISPlay:CMAP<1 to 13>:DEFault

This command resets the screen colors of the instrument to their default settings.

Example: "DISP:CMAP:DEF"

Features: *RST value: --
SCPI: conforming

Modes: A, VA, BTS, MS

This command is an event and has thus no query and no *RST value assigned. The numeric suffix in CMAP<1 to 13> is not significant.

DISPlay:CMAP<1 to 13>:HSL <hue>,<sat>,<lum>

This command defines the color table of the instrument.

Parameter: hue = TINT
sat = SATURATION
lum = BRIGHTNESS

The value range is 0 to 1 for all parameters.

Example: `"DISP:CMAP2:HSL 0.3,0.8,1.0"`

Features: *RST value: --
SCPI: conforming

Modes: A, VA, BTS, MS

To each numeric suffix of CMAP is assigned one or several picture elements which can be modified by varying the corresponding color setting. The following assignment applies:

CMAP1	Trace 1	CMAP8	Soft key State Data Entry
CMAP2	Trace 2	CMAP9	Soft key State OFF
CMAP3	Trace 3	CMAP10	Soft key Shade
CMAP4	Trace 4	CMAP11	Text
CMAP5	Marker	CMAP12	Title
CMAP6	Grid	CMAP13	Background
CMAP7	Soft key State On		

The values set are not changed by *RST.

DISPlay:CMAP<1 to 13>:PDEFined BLACk | BLUE | BROWn | GREen | CYAN | RED | MAGenta | YELLow |WHITe | DGRAy | LGRAy | LBLUe | LGREen | LCYan |LRED | LMAGenta

This command defines the color table of the instrument using predefined color values. To each numeric suffix of CMAP is assigned one or several picture elements which can be modified by varying the corresponding color setting. The same assignment as for `DISPlay:CMAP<1 to 13>:HSL` applies.

Example: `"DISP:CMAP2:PDEF GRE"`

Features: *RST value: --
SCPI: conforming

Modes: A, VA, BTS, MS

The values set are not changed by *RST.

DISPlay[:WINDow<1|2>]:MINFo ON | OFF

This command switches the marker info list on the screen on or off.

Example: `"DISP:MINF ON"`

Features: *RST value: OFF
SCPI: device-specific

Modes: A, VA, BTS, MS

DISPlay[:WINDow<1|2>]:TEXT[:DATA] <string>

This command defines a comment (max. 50 characters) which can be displayed on the screen.

Example: "DISP:TEXT "signal/noise power measurement"

Features: *RST value: "" (empty)
SCPI: conforming

Modes: A, VA, BTS, MS

The numeric suffix in WINDow<1|2> is not significant.

DISPlay[:WINDow<1|2>]:TEXT:STATe ON | OFF

This command switches on or off the screen display of the comment.

Example: "DISP:TEXT:STAT ON"

Features: *RST value: OFF
SCPI: conforming

Modes: A, VA, BTS, MS

The numeric suffix in WINDow<1|2> is not significant.

DISPlay[:WINDow<1|2>]:TIME ON | OFF

This command switches on or off the screen display of date and time.

Example: "DISP:TIME ON"

Features: *RST value: OFF
SCPI: device-specific

Modes: A, VA, BTS, MS

The numeric suffix in WINDow<1|2> is not significant.

DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:X[:SCALe]:RVALue <numeric_value>

This command defines the reference value for the X-axis of the measuring diagram.

Example: "DISP:TRAC:X:RVAL 20SYM"

Features: *RST value: -
SCPI: device-specific

Mode: VA-D

DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:X[:SCALe]:ZOOM ON | OFF

This command displays the zoomed current frequency range in the opposite window of the split screen representation.

Example: "DISP:TRAC:X:ZOOM ON"

Features: *RST value: OFF
SCPI: device-specific

Mode: A-F

The numeric suffix in TRACe<1 to 4> is not significant.

DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:X[:SCALe]:ZOOM[:FREQuency]:STARt <numeric_value>

This command defines the start frequency of the zoomed display range. The value must lie between start and stop frequency of the original range.

Example: "DISP:TRAC:X:ZOOM:STAR 100MHZ"

Features: *RST value: -- (depending on the current frequency setting)
SCPI: device-specific

Mode: A-F

The numeric suffix in TRACe<1 to 4> is not significant.

DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:X[:SCALe]:ZOOM[:FREQuency]:STOP <numeric_value>

This command defines the stop frequency of the zoomed display range. The value must lie between start and stop frequency of the original range.

Example: "DISP:TRAC:X:ZOOM:STOP 200MHZ"

Features: *RST value: -- (depending on the current frequency setting)
SCPI: device-specific

Mode: A-F

The numeric suffix in TRACe<1 to 4> is not significant.

DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:X[:SCALe]:ZOOM[:FREQuency]:CENTer <numeric_value>

This command shifts the zoomed frequency range to the specified center frequency.

Example: "DISP:TRAC:X:ZOOM:CENT 1GHZ"

Features: *RST value: -- (depending on the current frequency setting)
SCPI: device-specific

Mode: A-F

The numeric suffix in TRACe<1 to 4> is not significant.

DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:X:SPACing LINear | LOGarithmic

This command toggles between linear and logarithmic display.

Example: "DISP:TRAC:X:SPAC LIN"

Features: *RST value: LOGarithmic
SCPI: conforming

Mode: A

The numeric suffix in TRACe<1 to 4> is not significant.

DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:Y[:SCALe] 10dB to 200dB

This command defines the display range of the Y-axis (level axis) with logarithmic scaling (`DISP:TRAC:Y:SPAC LOG`).

Example: `"DISP:TRAC:Y 110dB"`

Features: *RST value: 100dB
SCPI: device-specific

Mode: A

For linear scaling, (`DISP:TRAC:Y:SPAC LIN | PERC`) the display range is fixed and cannot be set. The numeric suffix in TRACe<1 to 4> is not significant.

DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:Y[:SCALe]:MODE ABSolute | RELative

This command defines the scale of the y-axis (absolute or relative).

Example: `"DISP:TRAC:Y:MODE REL"`

Features: *RST value: ABS
SCPI: device-specific

Mode: A

As long as `SYSTem:DISPlay` is set to `OFF`, this command does not directly influence the screen. The numeric suffix in TRACe<1 to 4> is not significant.

DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:Y[:SCALe]:RLEVel -200dBm to 200dBm

This command defines the reference level.

Example: `"DISP:TRAC:Y:RLEV -60dBm"`

Features: *RST value: -20dBm
SCPI: conforming

Modes: A, VA

The numeric suffix in TRACe<1 to 4> is not significant.

DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:Y[:SCALe]:RLEVel:OFFSet -200dB to 200dB

This command defines the offset of the reference level.

Example: `"DISP:TRAC:Y:RLEV:OFFS -10dB"`

Features: *RST value: 0dB
SCPI: conforming

Modes: A, VA

The numeric suffix in TRACe<1 to 4> is not significant.

DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:Y[:SCALe]:RVALue <numeric_value>

This command defines the reference value for the y-axis of the measurement diagram.
This defines the upper limit of the display range, the corresponding parameters of the manual control vary according to the measurement mode.

In the spectrum analysis mode the setting corresponds to the parameter MAX LEVEL.

In the vector signal analysis mode the setting corresponds to the parameter REFERENCE VALUE Y AXIS.

IF option tracking generator is fitted and the normalization in the analyzer mode is activated, the value corresponds to the parameter REFERENCE VALUE.

Example:
```
"DISP:TRAC:Y:RVAL -20dBm"      (spectrum analysis)
"DISP:TRAC:Y:RVAL +1.20"       (vector signal analysis)
"DISP:TRAC:Y:RVAL 0"           (tracking generator)
```

Features:
*RST value: - coupled to reference level
0 (vector signal analysis)
0 dB (tracking generator with active normalization)
SCPI: device specific

Modes: A, VA

The numeric suffix in TRACe<1 to 4> is not significant.

DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:Y[:SCALe]:RVALue:AUTO ON | OFF

This command defines whether the reference value for the y-axis of the measured diagram is coupled to the reference level (default) or can be set independently.

Example:
```
"DISP:TRAC:Y:RVAL:AUTO ON"
```

Features:
*RST value: ON
SCPI: device-specific

Mode: A

This command is available in the analyzer mode only. The numeric suffix in TRACe<1 to 4> is not significant.

DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:Y[:SCALe]:RPOSition 0 to 100PCT

This command defines the position of the reference value. The numeric suffix in TRACe<1 to 4> is not significant.

Example:
```
"DISP:TRAC:Y:RPOS 50PCT"
```

Features:
*RST value: 100PCT (tracking generator)
50PCT (vector analyzer)
SCPI: conforming

Modes: A, VA

This command is only valid in conjunction with option Tracking Generator or in vector analyzer mode.

DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:Y[:SCALe]:PDIVision <numeric_value>

This command defines the scaling of the Y-axis in the current unit.

Example: `"DISP:TRAC:Y:PDIV +1.20"`

Features: *RST value: -
SCPI: conforming

Mode: VA

The numeric suffix in TRACe<1 to 4> is not significant.

DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:Y:SPACing LINear | LOGarithmic | PERCent

This command toggles between linear and logarithmic display.

Example: `"DISP:TRAC:Y:SPAC LIN"`

Features: *RST value: LOGarithmic
SCPI: conforming

Mode: A

The linear display can be LIN/% (PERCent) or LIN/dB (LINear). The numeric suffix in TRACe<1 to 4> is not significant.

DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:MODE WRITe | VIEW | AVERage | MAXHold | MINHold

This command defines the type of display and the evaluation of the traces.

Example: `"DISP:TRAC3:MODE MAXH"`

Features: *RST value: WRITe for TRACe1, STATe OFF for TRACe2 to 4
SCPI: device-specific

Modes: A, VA, BTS, MS

DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:MODE:CWRite ON | OFF

This command selects continuous display of the measured values (continuous write).

Example: `"DISP:TRAC3:MODE:CWR ON"`

Features: *RST value: OFF
SCPI: device-specific

Mode: VA

DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:MODE:ANALog ON | OFF

This command selects continuous display of the measured values in the analyzer mode (analog trace).

Example: `"DISP:TRAC3:MODE:ANAL ON"`

Features: *RST value: OFF
SCPI: device-specific

Mode: A

DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:MODE:HCONtinuous ON | OFF

This command defines whether the traces in the min hold/max hold mode are reset after some definite parameter changes.

Example: "DISP:TRAC3:MODE:HCON ON"

Features: *RST value: OFF
SCPI: device-specific

Mode: A

OFF The traces are reset after some definite parameter changes.

ON This mechanism is switched off.

In general, parameter changes require a restart of the measurement before results are evaluated (e.g. with markers). For those changes that are known to require a new measurement (e.g. modification of the span), the trace is automatically reset so that erroneous evaluations of previous results are avoided. This mechanism can be switched off for those exceptional cases where the described behavior is unwelcome.

DISPlay[:WINDow<1|2>]:TRACe<1 to 4>[:STATe] ON | OFF

This command switches the display of the corresponding trace on or off.

Example: "DISP:TRAC3 ON"

Features: *RST value: ON for TRACe1, OFF for TRACe2 to 4
SCPI: conforming

Modes: A, VA, BTS, MS

DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:SYMBol DOTS | BARS | OFF

This command determines the display of the points of decision on the trace.

Example: "DISP:TRAC:SYMB BARS"

Features: *RST value: OFF
SCPI: device-specific

Mode: VA-D

DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:EYE:COUNt 1 to Result Length

This command determines the display range of the eye diagram in symbols.

Example: "DISP:TRAC:EYE:COUNt 5"

Features: *RST value: 2
SCPI: device-specific

Mode: VA-D

3.6.9 FETCh Subsystem

The FETCh subsystem contains commands for reading out results of complex measurement tasks like those provided by options GSM BTS Analyzer, FSE-K11, or GSM MS Analyzer, FSE-K10. The FETCh-subsystem is closely linked to the functions of the CONFigure and READ-subsystems, where the measurement sequences are configured, the measurements are started and their results are queried.

3.6.9.1 FETCh:BURSt Subsystem

This subsystem provides the commands for reading out results of measurements in the GSM BTS (option FSE-K11) or GSM MS (option FSE-K10) Analyzer mode, which are performed on individual bursts (Carrier Power, Phase/Frequency Error) without starting the measurement by themselves.

COMMAND	PARAMETERS	UNIT	COMMENT
FETCh			Option FSE-K11 or FSE-K10
:BURSt			
:PERRor			
:RMS			
:AVERage?	--		
:MAXimum?	--		
:PEAK			
:AVERage?	--		
:MAXimum?	--		
:FERRor			
:AVERage?	--		
:MAXimum?	--		
:POWer	--		
[:IMMediate]?	--		
:ALL?	--		

FETCh:BURSt:PERRor:RMS:AVERage?

This command reads out the average of the RMS-measurement of the phase error taken over the selected number of bursts.

Example: "FETC:BURS:PERR:RMS:AVER?"

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

This command is a query and has therefore no *RST value assigned.
It is available only when measurement of the phase/frequency error is selected (see CONFigure:BURSt:PFERror).

FETCh:BURSt:PERRor:RMS:MAXimum?

This command reads out the maximum of the RMS-measurement of the phase error for the selected number of bursts.

Example: "FETC:BURS:PERR:RMS:MAX?"

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

If no measurement has been performed yet, a query error results.
This command is a query only and therefore has no *RST value assigned. It is available only when measurement of the phase/frequency error is selected (see CONFigure:BURSt:PFERror).

FETCh:BURSt:PERRor:PEAK:AVERage?

This command reads out the average of the peak measurement of the phase error taken over the selected number of bursts.

Example: "FETC:BURS:PERR:PEAK:AVER?"

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

If no measurement has been performed yet, a query error results.
This command is a query only and therefore has no *RST value assigned. It is available only if measurement of the phase/frequency error is selected (see CONFigure:BURSt:PFERror).

FETCh:BURSt:PERRor:PEAK:MAXimum?

This command reads out the maximum of the peak measurement of the phase error for the selected number of bursts.

Example: "FETCh:BURS:PERR:PEAK:MAX?"

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

If no measurement has been performed yet, a query error results.
This command is a query only and therefore has no *RST value assigned. It is available only when measurement of the phase/frequency error is selected (see CONFigure:BURSt:PFERror).

FETCh:BURSt:FERRor:AVERage?

This command reads out the average of the measurement of the frequency error taken over the selected number of bursts.

Example: "FETCh:BURS:FERR:AVER?"

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

If no measurement has been performed yet, a query error results.
This command is a query only and therefore has no *RST value assigned. It is available only if measurement of the phase/frequency error is selected (see CONFigure:BURSt:PFERror).

FETCh:BURSt:FERRor:MAXimum?

This command reads out the maximum frequency error measured over the selected number of bursts.

Example: "FETCh:BURS:FERR:MAX?"

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

If no measurement has been performed yet, a query error results.
This command is a query only and therefore has no *RST value assigned. It is available only if measurement of the phase/frequency error is selected (see CONFigure:BURSt:PFERror).

FETCh:BURSt:POWer[:IMMediate]?

This command reads out the result of the last step performed during the measurement of the output power of the base station or mobile.

Parameter: The result is output as an ASCII string in the following format:

<Static Power Ctrl>,<Dyn Power Ctrl>,<Rat-Level>,<Act-Level>, <Delta>,<Status>

with

<Static Power Ctrl>:	current static power control level
<Dyn Power Ctrl>:	current dynamic power control level
<Rat-Level>:	Rated value for the current power control level acc. to standard dBm
<Act-Level>:	measured power in dBm
<Delta>:	Difference between the measured power and the power at the previous static/dynamic power control level.
<Status>:	Result of limit check in character data form: PASSED no limits exceeded FAILED limit exceeded

Example: "FETC:BURS:POW?"
Result: 0,0,43,44.1,0,PASSED

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

If no measurement has been performed yet, a query error results.
This command is a query only and therefore has no *RST value assigned. It is available only if measurement of the phase/frequency error is selected (see CONFigure:BURSt:PFERror).

FETCh:BURSt:POWer:ALL?

This command reads out the results of all individual steps during the measurement of the output power of the base station or mobile.

Parameter: The result is output as an ASCII string in the following format:

<Static Power Ctrl>,<Dyn Power Ctrl>,<Rat-Level>,<Act-Level>, <Delta>,<Status>

with

<Static Power Ctrl>:	current static power control level
<Dyn Power Ctrl>:	current dynamic power control level
<Rat-Level>:	Rated value for the current power control level acc. to standard dBm
<Act-Level>:	measured power in dBm
<Delta>:	Difference between the measured power and the power at the previous static/dynamic power control level.
<Status>:	Result of limit check in character data form: PASSED no limits exceeded FAILED limit exceeded

Example: "FETC:BURS:POW:ALL?"
Result:
0,0,43,44.1,0,PASSED,1,0,41,42.5,1.6,PASSED,1,1,35,32.5,5.6,FAILED

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

If no measurement has been performed yet, a query error results.
This command is a query only and therefore has no *RST value assigned. It is available only if measurement of the phase/frequency error is selected (see CONFigure:BURSt:PFERror).

3.6.9.2 FETCh:SPECtrum Subsystem

This subsystem provides the commands for reading out results of measurements in the GSM BTS (FSE-K11) or GSM MS (FSE-K10) Analyzer mode, used to measure the power of the spectral contributions due to modulation and switching (modulation spectrum, transient spectrum) without first restarting a new measurement.

COMMAND	PARAMETERS	UNIT	COMMENT
FETCh			Option FSE-K11 or FSE-K10
:SPECtrum			
:MODulation			
[:ALL]?	ARFCn | TXBand | RXBand | COMBined | DCSRx1800		
:SWITching			
[:ALL]?	--		

FETCh:SPECtrum:MODulation[:ALL]? ARFCn | TXBand | RXBand | COMBined | DCSRx1800

This command reads out the result of the measurement of the modulation spectrum of the base station or mobile.

Parameter: The result is output as a list of partial result strings separated by ',' in the following (ASCII) format:

<Index>,<Freq1>,<Freq2>,<Level>,<Limit>, <Abs/Rel>,<Status> [,
<Index>,<Freq1>,<Freq2>,<Level>,<Limit>, <Abs/Rel>,<Status>]...

where the parts between '[...]' denote a partial result string that can be repeated n times.

<Index>: 0, if the partial result string characterizes a measurement range

current number <>0,
if the partial result string characterizes a single limit excess.

<Freq1>: Start frequency of the measurement range or frequency where the limit line is exceeded

<Freq2>: Start frequency of the measurement range or frequency exceeding the measurement range. The value of <Freq2> is equal to the value of <Freq1>, if either the measurement is performed in the time domain or if the partial result string contains a limit excess.

<Level>: Measured maximum level of the partial range or measured level at the test point.

<Limit>: Limit in the partial range or at the test point

<Abs/Rel>: ABS <Level> and <Limit> are in absolute units (dBm)
REL <Level> and <Limit> are in absolute units (dBm)

<Status>: Result of the limit check in character data form:
PASSED no limit exceeded
FAILED limit exceeded
MARGIN margin exceeded
EXC limit excess marked as an exception

The frequencies <Freq1> and <Freq2> are always absolute i. e. not referred to the carrier frequency.

Example: "FETC:SPEC:MOD? TXB"
Result: 0,890E6,915E6,-87.4,-108.0,ABS,FAILED,
1,893.2E6,893.2E6,-83.2,-108.0,ABS,FAILED,
2,895.7E6,895.7E6,-87.4,-108.0,ABS,FAILED

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

ARFCn	ARFCN ± 1.8 MHz
TXBand	TX-Band
RXBand	RX-Band
COMBined	ARFCN ± 1.8 MHz / TX-Band (option FSE-K11 only)
DCSRx1800	RX band DCS 1800 (option FSE-K10 only)

If no measurement has been performed yet, a query error results.
This command is a query only and therefore has no *RST value assigned. It is available only if measurement of the modulation spectrum is selected (see CONFigure:SPECtrum:MODulation).

FETCh:SPECtrum:SWITching[:ALL]?

This command reads out the result of the measurement of the transient spectrum of the base station or mobile.

Parameter: The result is output as a list of partial result strings separated by ',' as for the command FETCh:SPECtrum:MODulation[:ALL]?.

Example: "FETC:SPEC:SWIT?"
Result: 0,833.4E6,833.4E6,37.4,-36.0,ABS,MARGIN,
1,834.0E6,834.0E6,-35.2,-36.0,ABS,FAILED,
2,834.6E6,834.6E6,-74.3,-75.0,REL,FAILED
0,835.0E6,835.0E6,-65,0,-60.0,REL,PASSED

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

If no measurement has been performed yet, a query error results.
This command is a query only and therefore has no *RST value assigned. It is available only if measurement of the transient spectrum is selected (see CONFigure:SPECtrum:MODulation).

3.6.10 FORMat Subsystem

The FORMat subsystem specifies the data format of the data transmitted from and to the instrument.

COMMAND	PARAMETERS	UNIT	COMMENT
FORMat [:DATA]	ASCii|REAL|UINT[,<numeric_value>]	-	

FORMat[:DATA] ASCii | REAL | UINT [, 32]

This command specifies the data format of the data transmitted from and to the instrument.

Example:
```
"FORM REAL,32"
"FORM ASC"
```

Features: *RST value: ASCii
SCPI: conforming

Modes: A, VA, BTS, MS

The data format is either ASCii or one of the formats REAL or UINT (Unsigned Integer). ASCii data are transmitted in plain text, separated by commas. REAL data are transmitted as 32-bit IEEE 754 floating-point numbers in the "definite length block". The format UINT is only used in operating mode Vector Signal Analysis, for the symbol table.

Format setting for the binary transmission of trace data (see also `TRACE:DATA?`):

Analyzer mode: REAL, 32

Vector analyzer: UINT, 8 with digital demodulation, symbol table
REAL, 32otherwise

Note: *Incorrect format setting will result in numerical conversion, which may lead to incorrect results.*

The FORMat command is valid for the transmission of trace data. The data format of trace data received by the instrument is automatically recognized, regardless of the format which is programmed.

3.6.11 HCOPy Subsystem

The HCOPy subsystem controls the output of display information for documentation purposes on output devices or files.

COMMAND	PARAMETERS	UNIT	COMMENT
HCOPy			
:ABORt	--		no query
:DESTination<1|2>	'SYST:COMM:GPIB'| 'SYST:COMM:SER1'| 'SYST:COMM:SER2'| 'SYST:COMM:CENT'| 'MMEM'		no query
:DEVice			
:COLor	<Boolean>		
:LANGuage<1|2>	HPGL | PCL4 | PCL5 | POSTscript | ESCP | WMF| PCX | HP7470 | EPSON24 | EPSON24C | PCL4_C | PCL4_C3 | LASERJ | DESKJ | DESKJ_C | DESKJ_C3 | HPGL_LS | HP7470LS		
:PRESet<1|2>	<Boolean>		
:RESolution<1|2>	<numeric_value>		
[:IMMediate<1|2>]	--		no query
:ITEM			
:ALL			no query
:FFEed<1|2>			
:STATe	<Boolean>		
:LABEL			
:TEXT	<string>		
:PFEed<1|2>			
:STATe	<Boolean>		
:WINDow<1|2>			
:TABle			
:STATe	<Boolean>		
:TEXT	<string>		
:TRACe			
:STATe	<Boolean>		
:CAINcrement	<Boolean>		
:PAGE			
:DIMensions			no query
:QUADrant<1 to 4>			no query
:FULL			
:ORIentation<1|2>	LANDscape|PORTrait		

HCOPy:ABORt

This command aborts a running hardcopy output.

Example: `"HCOP:ABOR"`

Features: *RST value: -
SCPI: conforming

Modes: A, VA, BTS, MS

This command is an event which is why it is not assigned an *RST value and no query.

HCOPy:DESTination<1|2> <string>

This command selects the interface and the configuration (1 or 2) for the hardcopy device.

Parameter: <string>::= 'SYST:COMM:GPIB' |
'SYST:COMM:SER1' |
'SYST:COMM:SER2' |
'SYST:COMM:CENT' |
'MMEM' |

Example: `"HCOP:DEST2 'MMEM'"`

Features: *RST value: -
SCPI: conforming

Modes: A, VA, BTS, MS

This command is an event which is why it is not assigned an *RST value and no query. `HCOPy:DESTination 'MMEM'` creates a file for the hardcopy output. Command `MMEM:NAME <file_name>` defines the file name.

HCOPy:DEVice:COLor ON|OFF

This command selects between color and monochrome hardcopy of the screen.

Example: `"HCOP:DEV:COL ON"`

Features: *RST value: OFF
SCPI: conforming

Modes: A, VA, BTS, MS

HCOPy:DEVice:LANGuage<1|2> HPGL | PCL4 | PCL5 | POSTscript | ESCP | WMF| PCX | HP7470 | EPSON24| EPSON24C | PCL4_C | PCL4_C3 | LASERJ | DESKJ | DESKJ_C | DESKJ_C3 | HPGL_LS | HP7470LS

This command determines the data format of the printout.

Example: `"HCOP:DEV:LANG WMF"`

Features: *RST value: -
SCPI: conforming

Modes: A, VA, BTS, MS

HPGL	data format for printout on a plotter in HPGL,
HP7470	special format for printout on a plotter hp7470 (reduced HPGL format)
HPGL_LS and HP7470LS	special HPGL/HP7470-format allowing output of the traces with variable Line_styles
PCL4.and PCL5	generic data formats for laser and ink-jet printers, with
PCL4:	Black/white
PCL4_C:	Color (3 color cartridges + black cartridge)
PCL4_C3:	Color (3 color cartridges only)
PCL5:	Black/white with 300DPI resolution, new language version.
LASERJ	Data format for HP-laserjet starting with series III
DESKJ...	Data formats for printers of HP-deskjet series, with
	DESKJ: Black/white
	DESKJ_C: Color (3 color cartridges + black cartridge, e. g. Deskjet 560)
	DESKJ_C3: Color (3 color cartridges only, e. g. Deskjet 500)

POSTscript a printer language,

ESCP data format for a 24-pin printer.

EPSON24 data format for Epson-compatible 24-needle printers, black/white, e. g. Epson LQ-series, R&S PDN

EPSON24C data format for Epson-compatible 24-needle color printers, e. g. Epson Stylus Color, R&S PDN Color

WMF (WINDOWS Metafile Format) and PCX (pixel graphics)
data formats for output files which can at a later time be directly integrated in corresponding programs for documentation purposes.

HCOPy:DEVice:PRESet<1|2> ON|OFF

This command resets the hardcopy unit (1 or 2) prior to generating the hardcopy.

Example: `"HCOP:DEV:PRES2 ON"`

Features: *RST value: OFF
SCPI: device-specific

Modes: A, VA, BTS, MS

HCOPy:DEVice:RESolution<1|2> 150 | 300

This command controls the resolution of the printout in PCL4 and HP-deskjet format (hardcopy unit 1 or 2).

Example: `"HCOP:DEV:RES 300"`

Features: *RST value: 150
SCPI: conforming

Modes: A, VA, BTS, MS

The resolution for an output in PCL4 format is between 150 dpi or 300 dpi.

HCOPy[:IMMediate<1|2>]

This command starts a hardcopy output.

Example: `"HCOP"`

Features: *RST value: -
SCPI: conforming

Modes: A, VA, BTS, MS

`HCOP[1]` starts the hardcopy output to device 1 (default), `HCOP2` starts the output to device 2. This command is an event which is why it is not assigned an *RST value and has no query.

HCOPy:DEVice:ITEM:ALL

This command selects the complete screen to be output.

Example: `"HCOP:DEV:ITEM:ALL"`

Features: *RST value: OFF
SCPI: conforming

Modes: A, VA, BTS, MS

The hardcopy output is always provided with comments, title, time and date. As an alternative to the whole screen, only traces (commands `'HCOPy:DEVice:WINDow:TRACe: STATe ON'`) or tables (command `'HCOPy:DEVice:WINDow:TABLe:STATe ON'`) can be output.

HCOPy:DEVice:ITEM:FFEed<1|2>:STATe ON|OFF

The command adds a form feed command to the hardcopy output of the screen.

Example: `"HCOP:DEV:ITEM:FFE2:STAT ON"`

Features: *RST value: OFF
SCPI: conforming

Modes: A, VA, BTS, MS

HCOPy:DEVice:ITEM:LABel:TEXT <string>

This command defines the title of the screen with a maximum of 60 characters.

Example: `"HCOP:DEV:ITEM:LAB:TEXT 'My Title'"`

Features: *RST value: OFF
SCPI: conforming

Modes: A, VA, BTS, MS

HCOPy:DEVice:ITEM:PFEed<1|2>:STATe ON|OFF

This command adds a paper feed command to the hardcopy output of the screen (ON).

Example: `"HCOP:DEV:ITEM:PFE2:STAT ON"`

Features: *RST value: OFF
SCPI: device-specific

Modes: A, VA, BTS, MS

HCOPy:DEVice:ITEM:WINDow<1|2>:TABle:STATe ON | OFF

This command selects the output of the currently displayed tables (ON).

Example: `"HCOP:DEV:ITEM:WIND:TABL:STAT ON"`

Features: *RST value: OFF
SCPI: device-specific

Modes: A, VA, BTS, MS

The command `HCOPy:DEVice:ITEM:WINDow<1|2>:TABle:STATe OFF` same as command `HCOPy:DEVice:ITEM:ALL` enables the output of the whole screen.

HCOPy:DEVice:ITEM:WINDow<1|2>:TEXT <string>

This command defines the comment text for printout to trace 1 or 2 with a maximum of 100 characters.

Example: `"HCOP:DEV:ITEM:WIND2:TEXT 'comment'"`

Features: *RST value: -
SCPI: device-specific

Modes: A, VA, BTS, MS

HCOPy:DEVice:ITEM:WINDow<1|2>:TRACe:STATe ON | OFF

This command selects the output of the currently displayed trace (ON).

Example: `"HCOP:DEV:ITEM:WIND:TRACe:STAT ON"`

Features: *RST value: OFF
SCPI: device-specific

Modes: A, VA, BTS, MS

The command `HCOPy:DEVice:ITEM:WINDow<1|2>:TRACe:STATe OFF` same as command `HCOPy:DEVice:ITEM:ALL` enables the output of the whole screen.

HCOPy:DEVice:ITEM:WINDow<1|2>:TRACe:CAINcrement ON | OFF

The command automatically changes the colour of the currently displayed trace after printout (ON).

Example: `"HCOP:DEV:ITEM:WIND:TRACe:CAIN ON"`

Features: *RST value: OFF
SCPI: device-specific

Modes: A, VA, BTS, MS

The automatic change of colour of the trace allows outputting to a plotter of several traces of the same diagram. For a better distinction, the colour of the trace is changed ("Color Auto Increment").

HCOPy:PAGE:DIMensions:QUADrant<1 to 4>

The command defines the quadrant which is allocated to the screen output.

Example: `"HCOP:PAGE:DIM:QUAD1"`

Features: *RST value: -
SCPI: conforming

Modes: A, VA, BTS, MS

The quadrants are defined as QUAD1 at the top right, QUAD2 at the top left, QUAD3 at the bottom left and QUAD4 at the bottom right. This command is an event which is why it is not assigned an *RST value and has no query.

HCOPy:PAGE:DIMensions:FULL

This command defines that the full screen is to be printed out.

Example: `"HCOP:PAGE:DIM:FULL"`

Features: *RST value: -
SCPI: device-specific

Modes: A, VA, BTS, MS

This command is an event which is why it is not assigned and *RST value and has no query.

HCOPy:PAGE:ORIentation<1|2> LANDscape | PORTrait

The command selects the format of the output (portrait and landscape) (hardcopy unit 1 or 2).

Example: `"HCOP:PAGE:ORI LAND"`

Features: *RST value: -
SCPI: conforming

Modes: A, VA, BTS, MS

3.6.12 INITiate Subsystem

The INITiate subsystem checks the initialization of the trigger subsystem.
In the split-screen representation, a distinction is made between INITiate1 (screen A) and INITiate2 (screen B)

COMMAND	PARAMETERS	UNIT	COMMENT
INITiate<1|2>			
:CONTinuous	<boolean>	--	
:CONMeas	--	--	no query
[:IMMediate]	--	--	no query
:DISPlay	<boolean>	--	

INITiate<1|2>:CONTinuous ON | OFF

This command determines if the trigger system is continuously initiated ("Free Run").

Example: `"INIT:CONT OFF"`

Features: *RST value: ON
SCPI: conforming

Modes: A, VA, BTS, MS

Setting "`INITiate:CONTinuous ON`" corresponds to function SWEEP CONTinuous, ie the sweep of the analyzer is cyclically repeated. The setting "`INITiate:CONTinuous OFF`" corresponds to function SWEEP SINGLE.

INITiate<1|2>:CONMeas

This command continues the sweep from the current sweep position.

Example: `"INIT:CONM"`

Features: *RST value: -
SCPI: device-specific

Modes: A, VA, BTS, MS

This command is an event and therefore has no *RST value and no query.
Sweeps are stopped, for example, in the case of transducer sets between the different transducer factors.

INITiate<1|2>[:IMMediate]

The command initiates a new sweep or starts a single sweep.

Example: `"INIT"`

Features: *RST value: -
SCPI: conforming

Modes: A, VA, BTS, MS

This command is an event which is why it is not assigned an *RST value and has no query.

INITiate<1|2>:DISPlay ON | OFF

This command switches the display on or off during a single sweep.

Example: `"INIT:DISP OFF"`

Features: *RST value: ON
SCPI: device-specific

Modes: A, VA, BTS, MS

3.6.13 INPut Subsystem

The INPut subsystem checks the input features of the instrument. In the split-screen representation, a distinction is made between INPut1 (screen A) and INPut2 (screen B).

COMMAND	PARAMETERS	UNIT	COMMENT
INPut<1|2>			
:ATTenuation	<numeric_value>	DB	
:AUTO	<Boolean>	--	
:MODE	NORMal | LNOise|LDIStortion	--	
:UPORt<1|2>			
[:VALue]?	--	--	query only
:STATe	<Boolean>	--	
:IMPedance	50 | 75	OHM	
:CORRection	RAM | RAZ		
:MIXer	<numeric_value>	DBM	

INPut<1|2>:ATTenuation 0 to 70 dB

This command programs the input attenuator.

Example: `"INP:ATT 40dB"`

Features: *RST value: - (AUTO is set to ON)
SCPI: conforming

Modes: A, VA

The attenuation of the input calibration line can be programmed in steps of 10 dB. If the attenuation is programmed directly, the coupling to the reference level is switched off.

INPut<1|2>:ATTenuation:AUTO ON | OFF

This command automatically couples the input attenuation to the reference level.

Example: `"INP:ATT:AUTO ON"`

Features: *RST value: ON
SCPI: conforming

Modes: A, VA

INPut<1|2>:ATTenuation:AUTO:MODE NORMal | LNOise | LDIStortion

This command optimizes the coupling of the input attenuation to the reference level to high sensitivity or to high intermodulation immunity.

Example: `"INP:ATT:AUTO:MODE LDIS"`

Features: *RST value: ON
SCPI: device-specific

Modes: A, VA

For `LNOise`, the input attenuator value is set 10 dB lower than for `INPut:ATTenuation:AUTO:MODE NORMal`, for `LDIStortion` it is set 10 dB higher.

INPut<1|2>:UPORt<1|2>[:VALue]?

This command queries the control lines of the user ports.

Example: `"INP:UPOR2?"`

Features: *RST value: -
SCPI: device-specific

Modes: A, VA, BTS, MS

This command is a query command which is why it is not assigned an *RST value.

INPut<1|2>:UPORt<1|2>:STATe ON | OFF

This command toggles the control lines of the user ports between INPut and OUTPut.

Example: `"INP:UPOR2:STAT ON"`

Features: *RST value: ON
SCPI: device-specific

Modes: A, VA, BTS, MS

With ON, the user port is switched to INPut, with OFF to OUTPut.

INPut<1|2>:IMPedance 50 | 75

This command sets the nominal input impedance of the instrument.

Example: `"INP:IMP 75"`

Features: *RST value: 50
SCPI: conforming

Modes: A, VA, BTS, MS

Switching the input impedance to 75 Ω includes the matching elements RAM or RAZ selected by the command `INPut:IMPedance:CORRection`.

INPut<1|2>:IMPedance:CORRection RAM | RAZ

This command selects the matching element for 75 Ω input impedance.

Example: `"INP:IMP:CORR RAM"`

Features: *RST value: - (INPut:IMPedance = 50 Ω)
SCPI: device-specific

Modes: A, VA, BTS, MS

INPut<1|2>:MIXer -10 to -100 dBm

This command defines the nominal mixer level of the instrument.

Example: `"INP:MIX -30"`

Features: *RST value: -
SCPI: device-specific

Modes: A, VA

3.6.14 INSTrument Subsystem

The INSTrument subsystem selects the operating mode of the unit either via text parameters or fixed numbers. In the split-screen representation, a distinction is made between INSTrument1 (screen A) and INSTrument2 (screen B).

COMMAND	PARAMETERS	UNIT	COMMENT
INSTrument<1|2>			
[:SELect]	SANalyzer | DDEMod | ADEMod | BSGM | MGSM		Vector Signal Analysis FSE-K11 or FSE-K10,
:NSELect	<numeric_value>		
:COUPle	NONE | MODE | X | Y | CONTrol | XY | XCONtrol | YCONtrol | ALL		

INSTrument<1|2>[:SELect] SANalyzer | DDEMod | ADEMod | BGSM | MSGM

This command switches between the operating modes by means of text parameters.

Parameter: SANalyzer: spectrum analysis
DDEMod: vector signal analysis, digital demodulation
ADEMod: vector signal analysis, analog demodulation
BGSM: GSM BTS analysis
MGSM: GSM MS analysis r

Example: `"INST DDEM"`

Features: *RST value: SANalyzer
SCPI: conforming

Modes: A, VA, BTS, MS

Switchover to DDEMod or ADEMod is only possible in conjunction with option FSE-B7, Vector Signal Analysis.
Switchover to BGSM is only possible in conjunction with option FSE-K11, GSM BTS Analyzer
Switchover to MGSM is only possible in conjunction with option FSE-K10, GSM MS Analyzer

INSTrument<1|2>:NSELect 1 to 5

This command switches between the two modes by means of numbers.

Example: `"INST:NSEL 2"`

Features: *RST value: 1
SCPI: conforming

Modes: A, VA, BTS, MS
1: spectrum analysis
2: vector signal analysis, digital demodulation
3: vector signal analysis, analog demodulation
4: GSM BTS analysis
5: GSM MS analysis

Switchover to 2 or 3 is only possible in conjunction with option FSE-B7, Vector Signal Analysis.
Switchover to 4 is only possible in conjunction with option FSE-K11, GSM BTS Analyzer
Switchover to 5 is only possible in conjunction with option FSE-K10, GSM MS Analyzer

INSTrument:COUPle NONE | MODE | X | Y | CONTrol | XY | XCONtrol | YCONtrol | ALL

This command defines the coupling between the two measurement windows screen A and B.

Example: `"INST:COUP NONE"`

Features: *RST value: ALL
SCPI: device specific

Modes: A, VA

NONE	no coupling.
MODE	the operating mode of the two screens is coupled.
X or Y	the scaling of the x- or y axis of the two screens is coupled.
CONTrol	the trigger and gate parameter ,and the sweep parameters SINGle/ CONTinous and COUNt of the two screens are coupled.
XY	the scaling of the x- and y-axis of the two screens are coupled.
XCONTrol bzw. YCONTrol	the trigger and gate parameter, and the sweep parameters SINGle CONTinous/ COUNt of the two screens are coupled.
ALL	the scaling of the x- or y axis the trigger and gate parameter and the sweep parameters SINGle/ CONTinous/ COUNt of the two screens are coupled.

3.6.15 MMEMory Subsystem

The MMEMory (mass memory) subsystem provides commands which allow for access to the storage media of the instrument and for storing and loading various instrument settings.
The NAME command stores the HCOPy outputs in a file.

The various drives can be addressed via the mass storage unit specifier <msus> using the conventional DOS syntax. The internal hard disk is addressed by "C:", the floppy-disk drive installed by "A:".
The file names <file_name> are indicated as string parameters with the commands being enclosed in quotation marks. They correspond to the DOS conventions.

DOS file names consist of max. 8 ASCII characters and an extension of up to three characters separated from the file name by a colon "." Both, the colon and the extension are optional. The colon is not part of the file name. DOS file names do not differ between uppercase and lowercase notation. All letters and digits are permitted as well as the special characters "_", "^", "$", "~", "!", "#", "%", "&", "-", "{", "}", "(", ")", "@" and "‘". Reserved file names are CLOCK$, CON, AUX, COM1 to COM4, LPT1 to LPT3, NUL and PRN.

The two characters "*" and "?" have the function of so-called "wildcards", i.e., they are variables for selection of several files. The question mark "?" replaces exactly one character which may be any, the asterisk means any of the remaining characters in the file name. "*.*" thus means all files in a directory.

COMMAND	PARAMETERS	UNIT	COMMENT
MMEMory			
:CATalog	<string>		
:CDIRectory	<directory_name>	--	
:COPY	<file_name>,<file_name>	--	no query
:DATA	<file name>[,<block>]	--	
:DELete	<file_name>	--	no query
:INITialize	<msus>	--	no query
:LOAD			
:STATe	1,<file_name>	--	no query
:AUTO	1,<file_name>	--	no query
:MDIRectory	<directory_name>	--	no query
:MOVE	<file_name>,<file_name>	--	no query
:MSIS	<msus>	--	
:NAME	<file_name>	--	
:RDIRectory	<directory_name>	--	no query
:STORe			
:STATe	1,<file_name>	--	no query
:CLEar			
:STATe	1,<file_name>	--	no query
:ALL			no query

COMMAND	PARAMETERS	UNIT	COMMENT
:SELect			
[:ITEM]			
:GSETup	<Boolean>		
:HWSettings	<Boolean>		
:TRACE<1 to 4>	<Boolean>		
:LINes			
[:ACTive]	<Boolean>		
:ALL	<Boolean>		
:CSETup	<Boolean>		
:HCOPy	<Boolean>		
:MACRos	<Boolean>		
:SCData	<Boolean>		Option Tracking Generator
:TRANsducer			
[:ACTive]	<Boolean>		
:ALL	<Boolean>		
:CVL			
[:ACTive]	<Boolean>		
:ALL	<Boolean>		
:ALL	--		no query
:NONE	--		no query
:DEFault	--		no query
:COMMent	<string>		

MMEMory:CATalog? <string>

This command is for read-out of the current directory. A mask, eg "*.bat", can be defined so that only files with "bat" as extension are selected.

Parameter: <string>::= DOS file name

Example: "MMEM:CAT 'rem?.lin'"

Characteristics: *RST value: -
SCPI: conformal

Modes: A, VA, BTS, MS

MMEMory:CDIRectory <directory_name>

This command changes the current directory.

Parameter: <directory_name>::= DOS path name

Example: "MMEM:CDIR 'C:\USER\DATA'"

Features: *RST value: -
SCPI: conforming

Modes: A, VA, BTS, MS

In addition to the path name, the indication of the directory may contain the drive name. The path name complies with the DOS conventions.

MMEMory:COPY <file_source>,<file_destination>

This command copies the files indicated.

Parameter: <file_source>,<file_destination> ::= <file_name>
<file_name> ::= DOS file name

Example: "MMEM:COPY 'C:\USER\DATA\SETUP.CFG','A:'"

Features: *RST value: -
SCPI conforming

Modes: A, VA, BTS, MS

The indication of the file name may include the path and the drive. The file names and path information must be in accordance with the DOS conventions. This command is an event which is why it is not assigned an *RST value and has no query.

MMEMory:DATA <file_name>[,<block data>]

This command writes block data to the specified file.

Syntax: MMEMory:DATA <file_name>,<block data>
MMEMory:DATA? <file_name>

Example: "MMEM:DATA? 'TEST01.HCP'"
"MMEM:DATA 'TEST01.HCP', #217This is the file"

Features: *RST value: -
SCPI: conforming

Modes: A, VA, BTS, MS

Each <block> starts with the character '#', followed by the value stating the length of the length information. This is followed by one or several characters for the length information; then come the data themselves. The end character must be set to EOI to ensure correct data transmission.

MMEMory:DELete <file_name>

This command deletes the files indicated.

Parameter: <file_name> ::= DOS file name

Example: "MMEM:DEL 'TEST01.HCP'"

Features: *RST value: -
SCPI: conforming

Modes: A, VA, BTS, MS

The indication of the file name contains the path and, optionally, the drive. Indication of the path corresponds to the DOS conventions. The file name includes indication of the path and may also include the drive. The path name corresponds to the DOS conventions. This command is an event which is why it is not assigned an *RST value and has no query.

MMEMory:INITialize 'A:'

This command formats the disk in drive A.

Example: "MMEM:INIT 'A:'"

Features: *RST value: -
SCPI: conforming

Modes: A, VA, BTS, MS

Formatting deletes all data stored on the floppy disk. This command is an event which is why it is not assigned an *RST value and has no query.

MMEMory:LOAD:STATe 1,<file_name>

This command loads instrument settings from files.

Parameter: <file_name> ::= DOS file name without extension

Example: "MMEM:LOAD:STAT 1,'A:TEST'"

Features: *RST value: -
SCPI: conforming

Modes: A, VA, BTS, MS

The contents of the file is loaded and set as new instrument state. The file name includes indication of the path and may also include the drive. The path name corresponds to the DOS conventions. This command is an event which is why it is not assigned an *RST value and has no query.

MMEMory:LOAD:AUTO 1,<file_name>

This command defines which device setting is automatically loaded after the instrument is switched on.

Parameter: <file_name> ::= DOS file name without extension;
FACTORY denotes the data set previously in the instrument

Example: "MMEM:LOAD:AUTO 1,'C:\USER\DATA\TEST'"

Features: *RST value: -
SCPI: device-specific

Modes: A, VA, BTS, MS

The contents of the file are read after switching on the instrument and used to define the new device state. The file name includes indication of the path and may also include the drive. The path name corresponds to the DOS conventions. This command is an event which is why it is not assigned an *RST value and has no query.

MMEMory:MDIRectory <directory_name>

This command creates a new directory.

Parameter: <directory_name>::= DOS path name

Example: "MMEM:MDIR 'C:\USER\DATA'"

Features: *RST value: -
SCPI: device-specific

Modes: A, VA, BTS, MS

The file name includes indication of the path and may also include the drive. The path name corresponds to the DOS conventions. This command is an event which is why it is not assigned an *RST value and has no query.

MMEMory:MOVE <file_source>,<file_destination>

This command renames existing files.

Parameter: <file_source>,<file_destination> ::= <file_name>
<file_name> ::= DOS file name

Example: "MMEM:MOVE 'TEST01.CFG','SETUP.CFG'"

Features: *RST value: -
SCPI: conforming

Modes: A, VA, BTS, MS

The file name includes indication of the path and may also include the drive. The path name corresponds to the DOS conventions. This command is an event which is why it is not assigned an *RST value and has no query.

MMEMory:MSIS 'A:' | 'C:'

This command changes to the drive indicated.

Example: "MMEM:MSIS 'A:'"

Features: *RST value: "C:'
SCPI: conforming

Modes: A, VA, BTS, MS

The drive may be the internal hard disk C: or the floppy-disk drive A:. The drive is indicated according to the DOS conventions.

MMEMory:NAME <file_name>

This command specifies a file which is printed or plotted to.

Parameter: <file_name> ::= DOS filename

Example: "MMEM:NAME 'PLOT1.HPG'"

Features: *RST value: -
SCPI: conforming

Modes: A, VA, BTS, MS

The file name includes indication of the path and may also include the drive. The file name and path information correspond to the DOS conventions. The output to the printer is routed into a file using the command "HCOP:DEST 'MMEM'".

MMEMory:RDIRectory <directory_name>

This command deletes the directory indicated.

Parameter: <directory_name>::= DOS path name

Example: "MMEM:RDIR 'C:\TEST'"

Features: *RST value: -
SCPI: device-specific

Modes: A, VA, BTS, MS

The directory name includes indication of the path and may also include the drive. The path name corresponds to the DOS conventions. This command is an event which is why it is not assigned an *RST value and has no query.

MMEMory:STORe:STATe 1,<file_name>

This command stores the current instrument setting in a file.

Parameter: <file_name> ::= DOS file name without extension

Example: "MMEM:STOR:STAT 1,'TEST'"

Features: *RST value: -
SCPI: conforming

Modes: A, VA, BTS, MS

The current instrument state is stored as a file. The file name includes indication of the path and may also include the drive. The path name corresponds to the DOS conventions. This command is an event which is why it is not assigned an *RST value and has no query.

MMEMory:CLEar:STATe 1,<file_name>

This command deletes the instrument setting denoted by <file_name>.

Parameter: <file_name> ::= DOS file name without extension

Example: "MMEM:CLE:STAT 1,'TEST'"

Features: *RST value: -
SCPI: device-specific

Modes: A, VA, BTS, MS

The device data set specified is deleted. The file name includes indication of the path and may also include the drive. The path name corresponds to the DOS conventions. This command is an event which is why it is not assigned an *RST value and has no query.

MMEMory:CLEar:ALL

This command deletes all instrument settings in the current directory.

Example: "MMEM:CLE:ALL"

Features: *RST value: -
SCPI: device-specific

Modes: A, VA, BTS, MS

This command is an "event" which is why it is not assigned an *RST value and has no query.

MMEMory:SELect[:ITEM]:GSETup ON | OFF

This command includes the data of the general setup in the list of data subsets of a device setting to be stored/loaded.

Example: "MMEM:SEL:GSET ON"

Features: *RST value: OFF
SCPI: device-specific

Modes: A, VA, BTS, MS

MMEMory:SELect[:ITEM]:HWSettings ON | OFF

This command includes the hardware settings in the list of data subsets of a device setting to be stored/loaded.

Example: "MMEM:SEL:HWS ON"

Features: *RST value: ON
SCPI: device-specific

Modes: A, VA, BTS, MS

Level and frequency lines are stored with this command as well.

MMEMory:SELect[:ITEM]:TRACe<1 to 4> ON | OFF

This command includes the data of the selected trace in the list of data subsets of a device setting to be stored/loaded.

Example: "MMEM:SEL:TRACE3 ON"

Features: *RST value: OFF for all Traces
SCPI: device-specific

Modes: A, VA, BTS, MS

MMEMory:SELect[:ITEM]:LINes[:ACTive] ON | OFF

This command includes the active limit lines in the list of data subsets of a device setting to be stored/loaded.

Example: "MMEM:SEL:LIN ON"

Features: *RST value: ON
SCPI: device-specific

Modes: A, VA, BTS, MS

Upon MMEM:LOAD the limit lines which are not currently active but contained in the data set are restored as well.

MMEMory:SELect[:ITEM]:LINes:ALL ON | OFF

This command includes all limit lines in the list of data subsets of a device setting to be stored/loaded.

Example: "MMEM:SEL:LIN:ALL ON"

Features: *RST value: ON
SCPI: device-specific

Modes: A, VA, BTS, MS

This command includes selection of the active limit lines.

MMEMory:SELect[:ITEM]:CSETup ON | OFF

This command includes the current color setting in the list of partial datasets of a device setting to be stored/loaded.

Example: "MMEM:SEL:CSET ON"

Features: *RST value: ON
SCPI: device-specific

Modes: A, VA, BTS, MS

MMEMory:SELect[:ITEM]:HCOPy ON | OFF

This command includes the hardcopy settings in the list of data subsets of a device setting to be stored/loaded.

Example: "MMEM:SEL:HCOPy ON"

Features: *RST value: ON
SCPI: device-specific

Modes: A, VA, BTS, MS

MMEMory:SELect[:ITEM]:MACRos ON | OFF

This command includes the keyboard macros in the list of data subsets of a device setting to be stored/loaded.

Example: "MMEM:SEL:MACRos ON"

Features: *RST value: OFF
SCPI: device-specific

Modes: A, VA, BTS, MS

MMEMory:SELect[:ITEM]:SCData ON | OFF

This command includes the tracking generator calibration data in the list of data subsets of a device setting to be stored/loaded.

Example: "MMEM:SEL:SCData ON"

Features: *RST value: OFF
SCPI: device-specific

Modes: A, VA

This command only available in conjunction with the option Tracking Generator.

MMEMory:SELect[:ITEM]:TRANsducer[:ACTive] ON | OFF

This command includes the active transducer factors and set in the list of data subsets of a device setting to be stored/loaded.

Example: "MMEM:SEL:TRAN ON"

Features: *RST value: ON
SCPI: device-specific

Modes: A, VA, BTS, MS

Upon MMEM:LOAD the transducer factors and sets which are not currently active but contained in the data set are restored as well.

MMEMory:SELect[:ITEM]:TRANsducer:ALL ON | OFF

This command includes all transducer factors and sets in the list of data subsets of a device setting to be stored/loaded.

Example: "MMEM:SEL:TRAN:ALL ON"

Features: *RST value: ON
SCPI: device-specific

Modes: A, VA, BTS, MS

This command is an event and therefore has no *RST value assigned.

MMEMory:SELect[:ITEM]:CVL[:ACTive] ON | OFF

This command includes the active conversion loss table into the list of data subrecords to be stored / loaded for a device setup.

Example: "MMEM:SEL:CVL ON"

Features: *RST value: OFF
SCPI: device-specific

Modes: A, VA, BTS, MS

With MMEM:LOAD, inactive conversion loss tables too are restored if they are included in the data record.

MMEMory:SELect[:ITEM]:CVL:ALL ON | OFF

This command includes all conversion loss tables into the list of data subrecords to be stored / loaded for a device setup.

Example: "MMEM:SEL:CVL:ALL ON"

Features: *RST value: OFF
SCPI: device-specific

Modes: A, VA, BTS, MS

MMEMory:SELect[:ITEM]:ALL

This command includes all data subsets in the list of data subsets of a device setting to be stored/loaded.

Example: "MMEM:SEL:ALL"

Features: *RST value: --
SCPI: device-specific

Modes: A, VA, BTS, MS

This command is an event and therefore has no *RST value assigned.

MMEMory:SELect[:ITEM]:NONE

This command deletes all data subsets in the list of data subsets of a device setting to be stored/loaded.

Example: "MMEM:SEL:NONE"

Features: *RST value: --
SCPI: device-specific

Modes: A, VA, BTS, MS

This command is an event and therefore has no *RST value assigned.

MMEMory:SELect[:ITEM]:DEFault

This command sets the default list of the data subsets of a device setting to be stored/loaded.

Example: "MMEM:SEL:DEFault"

Features: *RST value: --
SCPI: device-specific

Modes: A, VA, BTS, MS

This command is an event and therefore has no *RST value assigned.

MMEMory:COMMent <string>

This command defines a comment for a device setting to be stored.

Example: "MMEM:COMM 'Setup for GSM measurement'"

Features: *RST value: blank comment
SCPI: device-specific

Modes: A, VA, BTS, MS

3.6.16 OUTPut Subsystem

The OUTPut subsystem checks the output features of the instrument.
In conjunction with option tracking generator, in the split screen mode, a distinction is made between OUTPut1 (screen A) and OUTPut2 (screen B).

COMMAND	PARAMETERS	UNIT	COMMENT
OUTPut<1|2>			
[:STATe]	<boolean>	--	Option Tracking Generator
:UPORt<1|2>			
[:VALue]	<binary>	--	
:STATe	<boolean>	--	
:AF			
:SENSitivity	<numeric_value	PCT | HZ | KHZ | DEG | RAD	Vector Signal Analysis

OUTPut<1|2>[:STATe] ON | OFF

This command switches the tracking generator on or off.

Example: `"OUTP ON"`

Features: *RST value: -
SCPI: conforming

Modes: A, VA

This command is only valid in conjunction with one of the options tracking generator.

OUTPut:UPORt<1|2>[:VALue #B00000000 to #B11111111

This command sets the control lines of the user ports.

Example: `"OUTP:UPOR2 #B10100101"`

Features: *RST value: -
SCPI: device-specific

Modes: A, VA, BTS, MS

User port 1 or 2 is written with the given binary pattern. If the user port is programmed to INPut instead of OUTPut, the output value is temporarily stored.

OUTPut:UPORt<1|2>:STATe ON | OFF

This command switches the control line of the user ports between INPut and OUTPut.

Example: `"OUTP:UPOR:STAT ON"`

Features: *RST value: OFF
SCPI: device-specific

Modes: A, VA, BTS, MS

With ON, the user port is switched to OUTPut, with OFF to INPut.

OUTPut:AF:SENSitivity <numeric_value>

This command changes the sensitivity of the AF-output.

Parameter: <numeric_value> ::= 0.1 PCT to 100 PCTfor AM
0.1 KHZ to 100 KHZfor FM
0.0 1RAD to 10 RADfor PM

Example: `"OUTP:AF:SENS 20PCT"`

Features: *RST value: 100 % for AM
100 kHz for FM
10 rad for PM
SCPI: device-specific

Mode: VA-A

3.6.17 READ Subsystem

The READ-subsystem contains commands for starting complex measurement tasks such as those provided by options GSM BTS Analyzer (FSE-K11) or GSM MS Analyzer (FSE-K10), and for querying the results subsequently. The READ-subsystem is closely linked to the functions of the CONFigure- and FETCh-subsystems, where the measurement sequences are configured or the results are queried without restarting a new measurement.

3.6.17.1 READ:BURSt Subsystem

This subsystem provides the commands for starting measurements in the GSM BTS Analyzer mode (option FSE-K11), which are performed on individual bursts (carrier power, phase/frequency error), and for reading out the results subsequently.

COMMAND	PARAMETERS	UNIT	COMMENT
READ			
:BURSt			Option FSE-K11 or FSE-K10
:PERRor			
:RMS			
:AVERage?	--		query only
:MAXimum?	--		query only
:PEAK			
:AVERage?	--		query only
:MAXimum?	--		query only
:FERRor			
:AVERage?	--		query only
:MAXimum?	--		query only
:POWer?	--		
:STATic?	--		query only; FSE-K11 only
:DYNamic?	--		query only; FSE-K11 only
:LEVel?	--		query only; FSE-K10 only

READ:BURSt:PERRor:RMS:AVERage?

This command starts the measurement of the phase and frequency error of the base station or mobile and reads out the average of the RMS-measurement of the phase error taken over the selected number of bursts.

Example: "READ:BURS:PERR:RMS:AVER?"

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

When the measurement is started the instrument automatically assumes the SINGLE mode.

An ongoing measurement can be aborted via the command ABORt. Further results of the phase/frequency error measurement can be then queried without restart of the measurement via the FETCh:BURSt-subsystem.

This command is a query only and therefore has no *RST value assigned. It is available only if measurement of the phase/frequency error is selected (see CONFigure:BURSt:PFERror).

READ:BURSt:PERRor:RMS:MAXimum?

This command starts the measurement of the phase and frequency error of the base station or mobile and reads out the maximum of the RMS-measurement of the phase error for the selected number of bursts.

Example: "READ:BURS:PERR:RMS:MAX?"

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

When the measurement is started the instrument automatically assumes the SINGLE mode.

An ongoing measurement can be aborted via the command ABORt. Further results of the phase/frequency error measurement can be then queried without restart of the measurement via the FETCh:BURSt-subsystem.

This command is a query only and therefore has no *RST value assigned. It is available only if measurement of the phase/frequency error is selected (see CONFigure:BURSt:PFERror).

READ:BURSt:PERRor:PEAK:AVERage?

This command starts the measurement of the phase and frequency error of the base station or mobile and reads out the maximum of the peak measurement of the phase error taken over the selected number of bursts.

Example: "READ:BURS:PERR:PEAK:AVER?"

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

When the measurement is started the instrument automatically assumes the SINGLE mode.

An ongoing measurement can be aborted via the command ABORt. Further results of the phase/frequency error measurement can be then queried without restart of the measurement via the FETCh:BURSt-subsystem.

This command is a query only and therefore has no *RST value assigned. It is available only if measurement of the phase/frequency error is selected (see CONFigure:BURSt:PFERror).

READ:BURSt:PERRor:PEAK:MAXimum?

This command starts the measurement of the phase and frequency error of the base station or mobile and reads out the maximum of the peak measurement of the phase error for the selected number of bursts.

Example: "READ:BURS:PERR:PEAK:MAX?"

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

When the measurement is started the instrument automatically assumes the SINGLE mode.

An ongoing measurement can be aborted via the command ABORt. Further results of the phase/frequency error measurement can be then queried without restart of the measurement via the FETCh:BURSt-subsystem.

This command is a query only and therefore has no *RST value assigned. It is available only if measurement of the phase/frequency error is selected (see CONFigure:BURSt:PFERror).

READ:BURSt:FERRor:AVERage?

This command starts the measurement of the phase and frequency error of the base station or mobile and reads out the average of the frequency error taken over the selected number of bursts.

Example: "READ:BURS:FERR:AVER?"

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

When the measurement is started the instrument automatically assumes the SINGLE mode.

An ongoing measurement can be aborted via the command ABORt. Further results of the phase/frequency error measurement can be then queried without restart of the measurement via the FETCh:BURSt-subsystem.

This command is a query only and therefore has no *RST value assigned. It is available only if measurement of the phase/frequency error is selected (see CONFigure:BURSt:PFERror).

READ:BURSt:FERRor:MAXimum?

This command starts the measurement of the phase and frequency error of the base station or mobile and reads out the maximum of the frequency error for the selected number of bursts.

Example: "READ:BURS:FERR:MAX?"

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

When the measurement is started the instrument automatically assumes the SINGLE mode.

An ongoing measurement can be aborted via the command ABORt. Further results of the phase/frequency error measurement can be then queried without restart of the measurement via the FETCh:BURSt-subsystem.

This command is a query only and therefore has no *RST value assigned. It is available only if measurement of the phase/frequency error is selected (see CONFigure:BURSt:PFERror).

READ:BURSt:POWer?

This command starts the measurement of the maximum output power of the base station or mobile and reads out the result.

Measurement of the maximum output power marks the beginning of a measurement cycle where subsequently the limits of the static and dynamic power control levels are checked step by step (`READ:BURSt:STATic?` or `READ:BURSt:DYNamic?`).

Parameter: The result is read out as an ASCII string in the following format:

<Static Power Ctrl>,<Dyn Power Ctrl>,<Rat-Level>,<Act-Level>, <Delta>,<Status>

<Static Power Ctrl>: 0
<Dyn Power Ctrl>: 0
<Rat-Level>: rated value for the current power control level acc. to standard in dBm
<Act-Level>: measured power in dBm
<Delta>: 0
<Status>: result of limit check in character data form:
PASSED no limits exceeded
FAILED limit exceeded

Example: "`READ:BURS:POW?`"
Result: `0,0,43,44.1,0,PASSED`

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

When the measurement is started any ongoing measurement cycle is aborted.

An ongoing measurement can be aborted with the command `ABORT`. This command is a query only and has therefore no *RST value assigned. It is available only when measurement of the maximum carrier power is selected (see `CONFigure:BURSt:POWer`).

READ:BURSt:POWer:STATic?

This command increases the static power control level for the measurement by one step, measures the output power of the base station and reads out the result.

If the command `READ:BURSt:POWer:STATic?` is repeated after the maximum static power control level is reached, the measurement sequence is terminated and the result of the maximum static power control level is read out again. In this case the value 'FINISHED' indicating the status is read out. Before the status value 'FINISHED' is read out, the value 'RUNNING' is output if the total result of the limit check is queried via `CALCulate<1|2>:LIMit<1 to 8>:BURSt:POWer?`.

Parameter: The result is read out as an ASCII string in the following format:

<Static Power Ctrl>,<Dyn Power Ctrl>,<Rat-Level>,<Act-Level>, <Delta>,<Status>

<Static Power Ctrl>: current static power control level
<Dyn Power Ctrl>: current dynamic power control level
<Rat-Level>: rated value for the current power control level acc. to standard in dBm
<Act-Level>: measured power in dBm
<Delta>: difference between the measured power and the power at the previous static power control level.
<Status>: result of the limit check in character data form:
PASSED no limit exceeded
FAILED limit exceeded
FINISHED measurement sequence terminated

Example: "READ:BURS:POW:STAT?"
Result: 1,0,41,42.5,1.6,PASSED

Features: *RST value: --
SCPI: device-specific

Mode: BTS

The command `ABORt` terminates an ongoing measurement and resets the static and dynamic power control level to 0.

This command is only a query and therefore has no *RST value assigned. It is available only if measurement of the maximum carrier power is selected. (see `CONFigure:BURSt:POWer`).

READ:BURSt:POWer:DYNamic?

This command increases the dynamic power control level for the measurement by one step, measures the output power of the base station and reads out the result.

Once the maximum dynamic power control level is reached the command is accepted only after the static power control level is increased by one step.

Note that the command is no longer accepted after the measurement sequence is terminated which implies that the static power control level was read out again with `READ:BURSt:POWer:STATic?` after the maximum value was reached and marked with the 'FINISHED' status.

Parameter: The result is read out as an ASCII string in the following format:

<Static Power Ctrl>,<Dyn Power Ctrl>,<Rat-Level>,<Act-Level>, <Delta>,<Status>

<Static Power Ctrl>: current static power control level
<Dyn Power Ctrl>: current dynamic power control level
<Rat-Level>: rated value for the current power control level acc. to standard in dBm
<Act-Level>: measured power in dBm
<Delta>: difference between the measured power and the power at the previous dynamic power control level.
<Status>: result of the limit check in character data form:
PASSED no limit exceeded
FAILED limit exceeded

Example: "`READ:BURS:POW:DYN?`"
Result: `1,3,35,32.5,5.6,FAILED`

Features: *RST value: --
SCPI: device-specific

Mode: BTS

The command `ABORt` terminates an ongoing measurement and resets the static and dynamic power control level to 0.

This command is only a query and therefore has no *RST value assigned. It is available only if measurement of the maximum carrier power is selected. (see `CONFigure:BURSt:POWer`).

READ:BURSt:POWer:LEVel?

This command increases the power control level for the measurement by one step, measures the output power of the mobile and reads out the result.

Note that the command is no longer accepted after the measurement sequence is terminated which implies that the power control level was read out again with `READ:BURSt:POWer:LEVel?` after the maximum value was reached and marked with the 'FINISHED' status.

Parameter: The result is read out as an ASCII string in the following format:

<0>, <Power Ctrl Level>,<Rat-Level>,<Act-Level>, <Delta>,<Status>

<0>: always 0 (this field is only significant for option FSE-K11)
<Power Ctrl Level>: current power control level
<Rat-Level>: rated value for the current power control level acc. to standard in dBm
<Act-Level>: measured power in dBm
<Delta>: difference between the measured power and the power at the previous power control level.
<Status>: result of the limit check in character data form:
PASSED no limit exceeded
FAILED limit exceeded

Example: `"READ:BURS:POW:LEV?"`
Result: `0,3,35,32.5,5.6,FAILED`

Features: *RST value: --
SCPI: device-specific

Mode: MS

The command `ABORt` terminates an ongoing measurement and resets the power control level to 0.

This command is only a query and therefore has no *RST value assigned. It is available only if measurement of the maximum carrier power is selected. (see `CONFigure:BURSt:POWer`).

3.6.17.2 READ:SPECtrum Subsystem

This subsystem provides the commands for starting measurements in the GSM BTS (option FSE-K11) and GSM MS (option FSE-K10) Analyzer mode, which are used to measure the power of the spectral components due to modulation and switching (modulation spectrum, transient spectrum), and for reading out the results subsequently.

COMMAND	PARAMETERS	UNIT	COMMENT
READ			
:SPECtrum			Option FSE-K11 or FSE-K10
:MODulation			
[:ALL]?	--		
:SWITching			
[:ALL]?	--		

READ:SPECtrum:MODulation[:ALL]?

This command starts the measurement of the modulation spectrum of the base station or mobile and reads out the result. The measurement is performed in the currently set frequency range.

Parameter: The result is read out as a list of partial ASCII result strings separated by ',' in the following format:

<Index>,<Freq1>,<Freq2>,<Level>,<Limit>, <Abs/Rel>,<Status> [,
<Index>,<Freq1>,<Freq2>,<Level>,<Limit>, <Abs/Rel>,<Status>]...

where the part set in '[...]' characterizes a partial result string which can be repeated n times.

<Index>: 0, if the partial result string characterizes a measurement range.
current number <>0, if the partial result string characterizes a single limit excess.

<Freq1>: Start frequency of the measurement range or frequency where the limit is exceeded.

<Freq2>: Stop frequency of the measurement range or frequency where the measured range is exceeded. The value of <Freq2> is equal to the value of <Freq1>, if either the measurement is performed in the time domain or the partial result string contains a limit excess.

<Level>: Measured maximum level of the partial range or measured level at the test point.

<Limit>: Limit in the partial range or at the test point.

<Abs/Rel>: ABS <Level> and <Limit> are in absolute units (dBm)
REL <Level> and <Limit> are in relative units (dBm)

<Status>: Result of the limit check in character data form:
PASSED no limit exceeded
FAILED limit exceeded
MARGIN margin exceeded
EXC limited excess characterized as an exception

The frequencies <Freq1> and <Freq2> are always absolute and not referred to the carrier frequency.

Example: "READ:SPEC:MOD?"
Result: 0,890E6,915E6,-87.4,-108.0,ABS,FAILED,
1,893.2E6,893.2E6,-83.2,-108.0,ABS,FAILED,
2,895.7E6,895.7E6,-87.4,-108.0,ABS,FAILED

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

The command ABORt aborts an ongoing measurement.

This command is only a query and therefore has no *RST value assigned. It is available only if measurement of the modulation spectrum is selected. (see CONFigure:SPECtrum:MODulation).

READ:SPECtrum:SWITching[:ALL]?

This command starts the measurement of the transient spectrum of the base station or mobile and reads out the result.

Parameter: The result is read out as a list of partial ASCII result strings separated by ',' in the format used for READ:SPECtrum:MODulation[:ALL]?.

Example: "READ:SPEC:SWIT?"
Result: 0,833.4E6,833.4E6,37.4,-36.0,ABS,MARGIN,
1,834.0E6,834.0E6,-35.2,-36.0,ABS,FAILED,
2,834.6E6,834.6E6,-74.3,-75.0,REL,FAILED
0,835.0E6,835.0E6,-65,0,-60.0,REL,PASSED

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

The command ABORt aborts an ongoing measurement.

This command is only a query and therefore has no *RST value assigned. It is available only if measurement of the transient spectrum is selected. (see CONFigure:SPECtrum:SWITCHing).

3.6.17.3 READ:SPURious Subsystem

This subsystem provides the commands for starting measurements in the GSM BTS (option FSE-K11) and GSM MS (option FSE-K10) Analyzer mode, which are used to measure the power of spurious emissions, and for reading out the results subsequently.

COMMAND	PARAMETERS	UNIT	COMMENT
READ :SPURIOUS [:ALL]? :STEP?			Option FSE-K11 or FSE-K10

READ:SPURious[:ALL]?

This command starts the measurement of the spurious emissions of the base station or mobile and reads out the result. The measurement is performed in the currently set frequency range.

Parameter: The result is read out as a list of partial ASCII result strings separated by ',' in the following format:

<Index>,<Freq1>,<Freq2>,<Level>,<Limit>, <Abs/Rel>,<Status> [,
<Index>,<Freq1>,<Freq2>,<Level>,<Limit>, <Abs/Rel>,<Status>]...

where the part set in '[...]' characterizes a partial result string which can be repeated n times.

<Index>: 0, if the partial result string characterizes a measurement range.
current number <>0, if the partial result string characterizes a single limit excess.

<Freq1>: Start frequency of the measurement range or frequency where the limit is exceeded.

<Freq2>: Stop frequency of the measurement range or frequency where the measured range is exceeded. The value of <Freq2> is equal to the value of <Freq1>, if either the measurement is performed in the time domain or the partial result string contains a limit excess.

<Level>: Measured maximum level of the partial range or measured level at the test point.

<Limit>: Limit in the partial range or at the test point.

<Abs/Rel>: ABS <Level> and <Limit> are in absolute units (dBm)
REL <Level> and <Limit> are in absolute units (dBm)

<Status>: Result of the limit check in character data form:
PASSED no limit exceeded
FAILED limit exceeded
MARGIN margin exceeded

Example: "READ:SPUR?"
Result: 0,890E6,915E6,-87.4,-108.0,ABS,FAILED,
1,893.2E6,893.2E6,-83.2,-108.0,ABS,FAILED,
2,895.7E6,895.7E6,-87.4,-108.0,ABS,FAILED

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

The command ABORt aborts an ongoing measurement.

This command is only a query and therefore has no *RST value assigned. It is available only if measurement of the spurious emissions is selected. (see CONFigure:SPURious).

READ:SPURious:STEP?

This command starts the next single step for measuring the spurious emissions in the STEP mode and reads out the results. The measurement is performed in the currently set frequency range.

If the command READ:SPURious:STEP? is sent again after the last single step is reached, the measurement sequence is terminated, the result of the last single step is output again and characterized by the value 'FINISHED' indicating its status. Until the status value 'FINISHED' is returned, the value 'RUNNING' is output when the total result of the limit check is queried with the command CALCulate<1|2>:LIMit<1 to 8>:SPURious?.

Afterwards, sending the command again causes a restart of the measurement.

Parameter: The measured result is read out as a list of partial result strings separated by ',' and in the same format as for the command READ:SPURious[:ALL]?.
The additional status value 'FINISHED' marks the end of a measurement sequence.

Example: "READ:SPUR:STEP?"
Result: First query: 0,890E6,915E6,-87.4,-108.0,ABS,FAILED
...
Second-last query:1,893.2E6,893.2E6,-83.2,-108.0,ABS,FAILED
Last query: 1,893.2E6,893.2E6,-83.2,-108.0,ABS,FINISHED

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

The command ABORt aborts an ongoing measurement. If the command READ:SPURious:STEP? is sent again, the instrument restarts with the first single step.

This command is only a query and therefore has no *RST value assigned. It is available only if measurement of the spurious emissions is selected. (see CONFigure:SPURious).

3.6.18 SENSe Subsystem

The SENSe subsystem is itself divided up into several subsystems. The commands of these subsystems directly control device-specific settings, they do not refer to the signal characteristics of the measurement signal.
The SENSe subsystem controls the essential parameters of the analyzer and vector analyzer. In accordance with the SCPI standard, it is for this reason optional, which means that it is not necessary to include the SENSe node in command sequences.

3.6.18.1 SENSe:ADEMod Subsystem

This subsystem controls the parameters for analog demodulation.
It is active only in conjunction with option Vector Signal Analysis, FSE-B7.

COMMAND	PARAMETERS	UNIT	COMMENT
[SENSe<1|2>]			
:ADEMod			option Vector Signal Analysis
:AF			
:COUPling	AC | DC		
:SQUelch			
[:STATe]	<Boolean>		
:LEVel	<numeric_value>	DBM	
:SBANd	NORMal | INVerse		
:RTIMe	<Boolean>		

[SENSe:]ADEMod:AF:COUPling AC | DC

This command selects coupling of the AF-branch.

Example: `"ADEM:AF:COUP DC"`

Features: *RST value: AC
SCPI: device-specific

Mode: VA-A

[SENSe:]ADEMod:SQUelch[:STATe] ON | OFF

This command switches the squelch for the audio branch on or off.

Example: `"ADEM:SQU ON"`

Features: *RST value: OFF
SCPI: device-specific

Mode: VA-A

[SENSe:]ADEMod:SQUelch:LEVel 30 to -150 dBm

This command defines the switching threshold for the squelch referred to the measured signal.

Example: `"ADEM:SQU -10DBM"`

Features: *RST value: -40dBm
SCPI: device-specific

Mode: VA-A

[SENSe:]ADEMod:SBANd NORMal | INVerse

This command selects the side band for the demodulation.

Example: `"ADEM:SBAN INV"`

Features: *RST value: NORMal
SCPI: device-specific

Mode: VA-A

[SENSe:]ADEMod:RTIMe ON | OFF

This command selects whether the demodulation performed in real time or in blocks.

Example: `"ADEM:RTIM ON"`

Features: *RST value: ON
SCPI: device-specific

Mode: VA-A

3.6.18.2 [SENSe:]AVERage Subsystem

The [SENSe:]AVERage subsystem calculates the average of the data acquired. A new test result is obtained from various successive measurements. The amount of test points and the axis reference of the new result correspond to those of the original measurements.

COMMAND	PARAMETERS	UNIT	COMMENT
[SENSe]			
:AVERage			
:COUNt	<numeric_value>	--	
:AUTO	<Boolean>	--	
[:STATe]	<Boolean>	--	
:TYPE	MAXimum | SCALar	--	

[SENSe:]AVERage:COUNt 0 to 32767

The command specifies the number of measurements which are combined.

Example: "AVER:COUN 16"

Features: *RST value: 0
SCPI: conforming

Modes: A. VA-D

[SENSe:]AVERage:COUNt:AUTO ON | OFF

AUTO ON selects a suitable number of :COUNt for the respective type of measurement.

Example: "AVER:COUN:AUTO ON"

Features: *RST value: OFF
SCPI: conforming

Modes: A. VA-D

[SENSe:]AVERage[:STATe] ON | OFF

The command switches on or off the average function.

Example: "AVER OFF"

Features: *RST value: OFF
SCPI: conforming

Modes: A, VA, BTS, MS

[SENSe:]AVERage:TYPE MAXimum | SCALar

The command selects the type of average function.

Example: "AVER:TYPE SCAL"

Features: *RST value: SCALar
SCPI: conforming

Modes: A, VA, BTS, MS

The following average functions have been defined:

MAXimum: $AVG(n) = MAX(X_1 \text{ to } X_n)$

SCALar: $$AVG(n) = \frac{1}{n} \times \sum_{i=1}^{n} xi$$

3.6.18.3 SENSe:BANDwidth Subsystem

This subsystem controls the setting of the instrument's filter bandwidths. Both groups of commands (BANDwidth and BWIDth) perform the same functions.

COMMAND	PARAMETERS	UNIT	COMMENT
[SENSe]			
:BANDwidth			
[:RESolution]	<numeric_value>	HZ	
:AUTO	<Boolean>	--	
:MODE	ANALog|DIGital	--	
:FFT	<Boolean>	--	option FFT Filter
:RATio	<numeric_value>	--	
:VIDeo	<numeric_value>	HZ	
:AUTO	<Boolean>	--	
:RATio	<numeric_value> | SINe | PULSe | NOISe	--	
:DEMod	<numeric_value>	HZ	option Vector Signal Analysis
:PLL	AUTO | HIGH | MEDium | LOW		
:BWIDth			
[:RESolution]	<numeric_value>	HZ	
:AUTO	<Boolean>	--	
:MODE	ANALog|DIGital	--	
:FFT	<Boolean>	--	option FFT Filter
:RATio	<numeric_value>	--	
:VIDeo	<numeric_value>	HZ	
:AUTO	<Boolean>	--	
:RATio	<numeric_value> | SINe | PULSe | NOISe	--	
:DEMod	<numeric_value>	HZ	option Vector Signal Analysis
:PLL	AUTO | HIGH | MEDium | LOW		

[SENSe:]BANDwidth|BWIDth[:RESolution] <numeric_value>

This command defines the analyzer's resolution bandwidth.

Example: `"BAND 1MHz"`

Features: *RST value: - (AUTO is set to ON)
SCPI: conforming

Modes: A, VA, BTS, MS

The values for the resolution bandwidth are rounded in 1 | 2 | 3 | 5 steps. Bandwidths >1kHz are always analog bandwidths, bandwidths <1kHz are always realized digitally. For the bandwidth 1kHz, it is possible to select either analog or digital filters.

In the GSM BTS/MS ANALYZER mode with option FSE-K11/K10, the command is available for POWER vs. TIME measurement. In this case, the parameters DEFault (bandwidth setting according to GSM standard), 300KHZ and 1MHZ are permitted.

[SENSe:]BANDwidth|BWIDth[:RESolution]:AUTO ON | OFF

This command either automatically couples the resolution bandwidth of the instrument to the span or cancels the coupling.

Example: `"BAND:AUTO OFF"`

Features: *RST value: ON
SCPI: conforming

Modes: A, VA

The automatic coupling matches the resolution bandwidth to the currently set span according to the relationship between span and resolution bandwidth.

[SENSe:]BANDwidth|BWIDth[:RESolution]:MODE ANALog | DIGital

This command toggles between analog and digital resolution filters for the 1-kHz bandwidth.

Example: `"BAND:MODE DIG"`

Features: *RST value: ANALog
SCPI: device-specific

Mode: A

Depending on the bandwidth, the resolution filters are automatically toggled between digital filters (<1kHz) and analog filters (>1kHz). The 1-kHz bandwidth is present in the instrument as a digital filter and as an analog filter and can be toggled using this command. If the analog filter is selected for the bandwidth 1kHz, the FFT-filtering for bandwidths ≤ 1kHz is switched off.

[SENSe:]BANDwidth|BWIDth[:RESolution]:MODE:FFT ON | OFF

This command toggles the digital filters used for bandwidths ≤ 1 kHz between ordinary mode and FFT-filter mode.

Example: `"BAND:MODE:FFT ON"`

Features: *RST value: OFF
SCPI: device-specific

Mode: A

The filter bandwidth of 1 kHz is switched to digital filtering for both ON and OFF. This command is only available in conjunction with option FFT Filter.

[SENSe:]BANDwidth|BWIDth[:RESolution]:RATio 0.0001 to 1

This command defines the ratio resolution bandwidth (Hz) / span (Hz).).

Example: `"BAND:RAT 0.1"`

Features: *RST value: -- (AUTO is set to ON)
SCPI: conforming

Modes: A. VA, E

The ratio to be entered is reciprocal to the ratio Span/RBW used in manual control.

[SENSe:]BANDwidth|BWIDth:VIDeo 1Hz to 10MHz

This command defines the instrument's video bandwidth.

Example: "BAND:VID 10kHz"

Features: *RST value: - (AUTO is set to ON)
SCPI: conforming

Mode: A

The values for the video bandwidth are rounded in 1 | 2 | 3 | 5 steps.

[SENSe:]BANDwidth|BWIDth:VIDeo:AUTO ON | OFF

This command either automatically couples the instrument's video bandwidth to the resolution bandwidth or cancels the coupling.

Example: "BAND:VID:AUTO OFF"

Features: *RST value: ON
SCPI: conforming

Mode: A

[SENSe:]BANDwidth|BWIDth:VIDeo:RATIO 0.001to 1000 | SINe | PULSe | NOISe

This command defines the ratio video bandwidth (Hz) / resolution bandwidth (Hz).

Parameter: The parameters SINe, PULSe and NOISe may be used as synonyms for the following values:
SINe: 1
PULSe: 10
NOISe: 0.1

Example: "BAND:VID:RAT 10"

Features: *RST value: - (AUTO is set to ON)
SCPI: conforming

Modes: A. VA

The ratio to be entered is reciprocal to the ratio RBW/VBW used in manual control.

[SENSe:]BANDwidth|BWIDth:DEMod 5kHz to 200kHz (Real Time on) | 5kHz to 5MHz (Real Time off)

This command defines the demodulation bandwidth of the instrument for analog demodulation.

Example: "BAND:DEM 100KHZ"

Features: *RST value: 10KHZ
SCPI: device-specific

Mode: VA-A

The values for the demodulation bandwidth are rounded in steps of 1 | 2 | 3 | 5.

[SENSe:]BANDwidth|BWIDth:PLL AUTO | HIGH | MEDium | LOW

This command defines the bandwidth of the main PLL of the instrument synthesizer.

Example: "BAND:PLL HIGH"

Features: *RST value: AUTO
SCPI: device-specific

Mode: A

3.6.18.4 SENSe:CORRection-Subsystem

The SENSe:CORRection-subsystem controls the correction of measured results by means of frequency-dependent correction factors (e. g. for antenna or cable attenuation).
It also controls calibration and normalization during operation with the option Tracking Generator .

COMMAND	PARAMETERS	UNIT	COMMENT
[SENSe]			
:CORRection			option Tracking Generator
:METHod	TRANsmission | REFLexion		
:COLLect			
[:ACQuire]	THRough | OPEN		no query
[:STATe]	<Boolean>		
:RECall			no query
:TRANsducer			
:SELect	<name>		
:UNIT	<string>		
:SCALing	LINear | LOGarithmic		
:DATA	<freq> , <level> ..	HZ , --	
[:STATe]	<Boolean>		
:DELete	--	--	no query
:TSET			
:SELect	<name>		
:UNIT	<string>		
:BREak	<Boolean>		
:RANGe<1 to 10>	<freq> , <freq>, <name> ..	HZ, HZ, --	
[:STATe]	<Boolean>		
:DELete	--	--	no query
:LOSS			option FSE-K11 or FSE-K10
:INPut			
[:MAGNitude]	<numeric_value>	DB	
:RXGain			option FSE-K11
:INPut			
[:MAGNitude]	<numeric_value>	DB	
:CVL			option external mixer output
:SELect	<file_name>		
:MIXer	<string>		
:SNUMber	<string>		
:BAND	A|Q|U|V|E|W|F|D|G|Y|J		
:TYPE	ODD | EVEN | EODD		
:PORTs	2 | 3		
:BIAS	<numeric_value>	A	
:COMMent	<string>		
:DATA	<freq> , <level> ..	HZ , DB	
:CLEar	--	--	no query

[SENSe:]CORRection[:STATe] ON | OFF

This command activates/deactivates normalization of the measurement results.

Example: "CORR ON "

Features: *RST value: OFF
SCPI: conforming

Mode: A

This command is only valid in conjunction with option Tracking Generator.

[SENSe:]CORRection:METHod TRANsmission | REFLexion

This command selects the kind of measurement with active tracking generator (transmission/reflexion).

Example: `"CORR:METH TRAN "`

Features: *RST value: TRANsmission
SCPI: device specific

Mode: A

This command is only valid in conjunction with option Tracking Generator.

[SENSe:]CORRection:COLLect[:ACQuire] THRough | OPEN

This command selects the kind of measurement for the reference values of the normalization (response calibration).

Example: `"CORR:COLL THR"`

Features: *RST value:
SCPI: conforming

Mode: A

THRough "TRANsmission" mode: calibration with direct connection between tracking generator and device input.

"REFLexion" mode: calibration with short circuit at the input

OPEN only valid in "REFLexion" mode:calibration with open input

This command is an event which is why it is not assigned an *RST value an a query. It is only valid in conjunction with option Tracking Generator.

[SENSe:]CORRection:RECall

This command restores the instrument setting that was valid for the measurement of the reference data. It is only valid in conjunction with option Tracking Generator, FSE-B8 to B12.

Example: `"CORR:REC"`

Features: *RST value: -
SCPI: conforming

Mode: A

This command is an event which is why it is not assigned an *RST value and a query. It is only valid in conjunction with option Tracking Generator.

[SENSe:]CORRection:TRANsducer:SELect <name>

This command selects the transducer factor designated by <name>. If <name> does not exist yet, a new transducer factor is created.

Parameter: <name>::= Name of the transducer factor in string data form with a maximum of 8 characters.

Example: `"CORR:TRAN:SEL 'FACTOR1'"`

Features: *RST value: -
SCPI: device-specific

Mode: A

This command must be sent prior to the subsequent commands for modifying/activating transducer factors.

[SENSe:]CORRection:TRANsducer:UNIT <string>

This command defines the unit of the transducer factor selected.

Parameter: <string>::= 'DB' | 'DBM' | 'DBMV' | 'DBUV' | 'DBUV/M' | 'DBUA' 'DBUA/M' | 'DBPW' | 'DBPT'

Example: `"CORR:TRAN:UNIT 'DBUV'"`

Features: *RST value: 'DB'
SCPI: device-specific

Mode: A

Prior to this command, the command `SENS:CORR:TRAN:SEL` must be sent.

[SENSe:]CORRection:TRANsducer:SCALing LINear | LOGarithmic

This command defines whether the frequency scaling of the transducer factor is linear or logarithmic.

Example: `"CORR:TRAN:SCAL LOG"`

Features: *RST value: LINear
SCPI: device-specific

Mode: A

Prior to this command, the command `SENS:CORR:TRAN:SEL` must be sent.

[SENSe:]CORRection:TRANsducer:DATA <freq>,<level>..

This command defines the test points for the selected transducer factor. The values are entered as a series of frequency/level pairs. The frequencies must be in ascending order.

Example: `"CORR:TRAN:TRANsducer:DATA 1MHZ,-30,2MHZ,-40"`

Features: *RST value: -
SCPI: device-specific

Mode: A

Prior to this command, the command `SENS:CORR:TRAN:SEL` must be sent. The level values are sent as dimensionless numbers; the unit is specified by means of the command `SENS:CORR:TRAN:UNIT`.

[SENSe:]CORRection:TRANsducer[:STATe] ON | OFF

This command switches the selected transducer factor on or off.

Example: `"CORR:TRAN ON"`

Features: *RST value: OFF
SCPI: device-specific

Mode: A

Prior to this command, the command `SENS:CORR:TRAN:SEL` must be sent.

[SENSe:]CORRection:TRANsducer:DELete

This command deletes the selected transducer factor.

Example: "CORR:TRAN:DEL"

Features: *RST value: -
SCPI: device-specific

Mode: A

This command is an event and therefore has no *RST value.
Prior to this command, the command SENS:CORR:TRAN:SEL must be sent.

[SENSe:]CORRection:TSET:SELect <name>

This command selected the transducer set designated by <name>. If <name> does not exist yet, a new set is created.

Parameter: <name>::= name of the transducer set in string data form with a maximum of 8 characters.

Example: "CORR:TSET:SEL 'SET1'"

Features: *RST value: -
SCPI: device-specific

Mode: A

This command must be sent prior to the subsequent commands for changing/activating the transducer sets.

[SENSe:]CORRection:TSET:UNIT <string>

This command defines the unit of the selected transducer sets. When assigning transducer factors to the set, only factors which are compatible to the selected unit, i. e. factors with the same unit or the unit dB, are allowed.

Parameter: <string>::= 'DB' | 'DBM' | 'DBUV' | 'DBUV/M' | 'DBUA' 'DBUA/M" | DBPW' | 'DBPT'

Example: "CORR:TSET:UNIT 'DBUV'"

Features: *RST value: 'DB'
SCPI: device-specific

Mode: A

Prior to this command, the command SENS:CORR:TSET:SEL must be sent.

[SENSe:]CORRection:TSET:BREak ON | OFF

This command defines if the sweep is to be stopped on changeover from range to another.

Example: "CORR:TSET:BRE ON"

Features: *RST value: OFF
SCPI: device-specific

Mode: A

Prior to the above command, the command SENS:CORR:TSET:SEL must be sent.

[SENSe:]CORRection:TSET:RANGe<1 to 10> <freq>,<freq>,<name>..

This command defines a partial range of the selected transducer set. The partial range is determined by its start and stop frequencies plus a list of names of the assigned transducer factors. The ranges 1 to 10 must be sent in ascending order.

Parameter: <freq>,<freq>::= start frequency, stop frequency of the range
<name>...::= list of names for the assigned transducer factors. The individual names must be characterized by single quotation marks (') and separated by commas.

Example: `"CORR:TRAN:TSET:RANG 1MHZ,2MHZ,'FACTOR1,'FACTOR2'"`

Features: *RST value: -
SCPI: device-specific

Mode: A

Prior to this command, the command `SENS:CORR:TSET:SEL` must be sent.

[SENSe:]CORRection:TSET[:STATe] ON | OFF

This command switches the selected transducer set on or off.

Example: `"CORR:TSET ON"`

Features: *RST value: OFF
SCPI: device-specific

Mode: A

Prior to this command, the command `SENS:CORR:TSET:SEL` must be sent.

[SENSe:]CORRection:TSET:DELete

This command deletes the selected transducer set.

Example: `"CORR:TSET:DEL"`

Features: *RST value: -
SCPI: device-specific

Mode: A

This command is an event and thus has no *RST value assigned.
Prior to this command, the command `SENS:CORR:TSET:SEL` must be sent.

[SENSe:]CORRection:LOSS:INPut[:MAGNitude] <numeric_value>

This command announces to the instrument a possibly needed external attenuation of the input signal, so that it is taken into account later when the level is set.

Parameter: <numeric_value>::= value of external attenuation in dB.

Example: `"CORR:LOSS:INP 30DB "`

Features: *RST value: 20dB
SCPI: device-specific

Modes: BTS, MS

The external attenuation must be selected such that the input power of the analyzer does not exceed 27 dBm.

[SENSe:]CORRection:RXGain:INPut[:MAGNitude] <numeric_value>

This command announces to the instrument a possibly needed preamplification in the RX-band (RX BAND GAIN), so that it is taken into account later when the measured values are read out.

Parameter: <numeric_value>::= value of the amplification in dB.

Example: "CORR:RXG:INP 30DB "

Features: *RST value: 0 dB
SCPI: device-specific

Modes: BTS, MS

The command is available only for spurious emission or modulation spectrum measurement (K11 only).

[SENSe:]CORRection:CVL:SELect <file_name>

This command selects the Conversion Loss Table designated with <file_name>. If <file_name> is not available, a new Conversion Loss Table will be created.

Parameter: <file_name>::= Name of Conversion Loss Table as string data with a maximum of 8 characters

Example: "CORR:CVL:SEL 'LOSS_TAB'"

Features: *RST value: -
SCPI: device-specific

Mode: A

This command must be sent prior to the subsequent commands used to change/activate the Conversion Loss files.

[SENSe:]CORRection:CVL:MIXer <string>

This command defines the type designation of the mixer in the Conversion Loss Table.

Parameter: <string>::= Type designation of mixer with a maximum of 16 characters

Example: "CORR:CVL:MIX 'FSE_Z60'"

Features: *RST value: -
SCPI: device-specific

Mode: A

Command SENS:CORR:CVL:SEL must be sent prior to this command.

[SENSe:]CORRection:CVL:SNUMber <string>

This command defines the serial number of the mixer in the Conversion Loss Table.

Parameter: <string>::= Serial number of mixer with a maximum of 16 characters

Example: "CORR:CVL:SNUM '123.4567'"

Features: *RST value: -
SCPI: device-specific

Mode: A

Command SENS:CORR:CVL:SEL must be sent prior to this command.

[SENSe:]CORRection:CVL:BAND A|Q|U|V|E|W|F|D|G|Y|J

This command defines the waveguide band in the Conversion Loss Table.

Example: `"CORR:CVL:BAND E"`

Features: *RST value: -
SCPI: device-specific

Mode: A

Command `SENS:CORR:CVL:SEL` must be sent prior to this command.

[SENSe:]CORRection:CVL:TYPE ODD | EVEN | EODD

This command defines the type of harmonic in the Conversion Loss Table.

Example: `"CORR:CVL:TYPE EODD"`

Features: *RST value: -
SCPI: device-specific

Mode: A

Command `SENS:CORR:CVL:SEL` must be sent prior to this command.

[SENSe:]CORRection:CVL:PORTs 2 | 3

This command defines the type of mixer in the Conversion Loss Table.

Example: `"CORR:CVL:PORT 3"`

Features: *RST value: -
SCPI: device-specific

Mode: A

Command `SENS:CORR:CVL:SEL` must be sent prior to this command.

[SENSe:]CORRection:CVL:BIAS <numeric_value>

This command defines the bias current in the Conversion Loss Table.

Example: `"CORR:CVL:BIAS 7mA"`

Features: *RST value: -
SCPI: device-specific

Mode: A

Command `SENS:CORR:CVL:SEL` must be sent prior to this command.

[SENSe:]CORRection:CVL:COMMent <string>

This command defines the comment in the Conversion Loss Table.

Parameter: <string>::= Comment of mixer with a maximum of 60 characters

Example: `"CORR:CVL:COMMENT 'MIXER FOR BAND U'"`

Features: *RST value: -
SCPI: device-specific

Mode: A

Command `SENS:CORR:CVL:SEL` must be sent prior to this command.

[SENSe:]CORRection:CVL:DATA <freq>,<level>..

This command defines the reference values of the selected Conversion Loss Tabels. The values are entered as a result of frequency/level pairs. The frequencies have to be sent in ascending order.

Example: `"CORR:CVL:DATA 1MHZ,-30DB,2MHZ,-40DB"`

Features: *RST value: -
SCPI: device-specific

Mode: A

Command `SENS:CORR:CVL:SEL` must be sent prior to this command.

[SENSe:]CORRection:CVL:CLEar

This command deletes the selected Conversion Loss Table.

Example: `"CORR:CVL:CLE"`

Features: *RST value: -
SCPI: device-specific

Mode: A

This command is an event which is why it is not assigned an *RST value.
Command `SENS:CORR:CVL:SEL` must be sent prior to this command.

3.6.18.5 SENSe:DETector Subsystem

The SENSe:DETector subsystem controls the recording of measurement values via the type of detector selected for each trace.

COMMAND	PARAMETERS	UNIT	COMMENT
[SENSe]			
:DETector<1to4>			
[:FUNCtion]	APEak | NEGative| POSitive | SAMPle| RMS | AVERage | QPEak		
:AUTO	<Boolean>	--	

[SENSe:]DETector<1 to 4>[:FUNCtion] APEak | NEGative | POSitive | SAMPle | RMS | AVERage

This command switches the detector for recording of the measured value.

Example: "DET POS"

Features: *RST value: APEak
SCPI: conforming

Mode: A

The value "APEak" (AutoPeak) displays both the positive peak value and the negative peak value when noise is present. The positive peak value is displayed when one signal is present. The trace is selected by means of the numeric suffix after DETector.

[SENSe:]DETector<1 to 4>[:FUNCtion]:AUTO ON | OFF

This command either couples the detector to the current trace setting or turns coupling off.

Example: "DET:AUTO OFF"

Features: *RST value: ON
SCPI: conforming

Mode: A

The trace is defined by the numeric suffix at DETector.

3.6.18.6 SENSe:DDEMod Subsystem

This subsystem controls the parameters for digital demodulation.
It is only active in conjunction with operating mode Vector Signal Analysis (option FSE-B7).

COMMAND	PARAMETERS	UNIT	COMMENT
[SENSe]			
:DDEMod			Vector Signal Analysis
:FORMat	QPSK | PSK | MSK | QAM | FSK		
:SBANd	NORMal | INVerse		
:QPSK			
:FORMat	NORMal | DIFFerential | OFFSet | DPI4		
:PSK			
:NSTate	2 | 8		
:FORMat	NORMal | DIFFerential		
:MSK			
:FORMat	TYPE1 | TYPE2 | NORMal | DIFFerential		
:QAM			
:NSTate	16		
:FSK			
:NSTate	2 | 4		
:SRATe	<numeric_value>	HZ	
:TIMe	<numeric_value>	SYM	
:PRATe	1 | 2 | 4 | 8 | 16		
:FILTer			
:MEASurement	OFF | RCOSine | RRCosine | GAUSsian		
:REFerence	RCOSine | RRCosine | GAUSsian		
:ALPHa	<numeric_value>		
:NORMalize	<Boolean>		
:PRESet	GSM | TETRa | DCS1800 | PCS1900 | PHS | PDCup | PDCDown | APCO25CQPSK | APCO25C4FM | CDPD | DECT | CT2 | ERMes | MODacom | PWT | TFTS | F16 | F322 | F324 | F64 | FQCDma | RQCDma | FNADc | RNADc		
:SEARch			
:PULSe			
:STATe	<Boolean>		
:SYNC			
:OFFSet	<numeric_value>	SYM	
:PATTern	<string>		
:STATe	<Boolean>		
:TIME	<numeric value>	SYM	
:TCAPture			Vector Signal Analysis
:LENGth	<numeric_value>		

[SENSe:]DDEMod:FORMat QPSK | PSK | MSK | QAM | FSK

This command selects the digital demodulation type.

Example: "DDEM:FORM QPSK"

Features: *RST value: MSK
SCPI: device-specific

Mode: VA-D

[SENSe:]DDEMod:SBANd NORMal | INVerse

This command selects the sideband for the demodulation.

Example: "DDEM:SBAN INV"

Features: *RST value: NORMal
SCPI: device-specific

Mode: VA-D

[SENSe:]DDEMod:QPSK:FORMat NORMal | DIFFerential | OFFSet | DPI4

This command determines the specific demodulation type for QPSK.

Example: "DDEM:QPSK:FORM DPI4"

Features: *RST value: -
SCPI: device-specific

Mode: VA-D

[SENSe:]DDEMod:PSK:NSTate 2 | 8

This command determines the specific demodulation type for PSK.

Example: "DDEM:PSK:NST 2"

Features: *RST value: -
SCPI: device-specific

Mode: VA-D

Value 2 (i.e. PSK2) corresponds to BPSK demodulation, value 8 the 8PSK demodulation.

[SENSe:]DDEMod:PSK:FORMat NORMal | DIFFerential

This command determines the specific demodulation type for PSK.

Example: "DDEM:PSK:FORM DIFF"

Features: *RST value: -
SCPI: device-specific

Mode: VA-D

[SENSe:]DDEMod:MSK:FORMat TYPE1 | TYPE2 | NORMal | DIFFerential

This command determines the specific demodulation type for MSK.

Example: `"DDEM:MSK:FORM TYPE2"`

Features: *RST value: TYPE2 | DIFFerential
SCPI: device-specific

Mode: VA-D

`TYPE1 | NORMal` corresponds to MSK demodulation, `TYPE2 | DIFFerential` corresponds to DMSK demodulation.

[SENSe:]DDEMod:QAM:NSTate 16

This command determines the specific demodulation type for QAM.

Example: `"DDEM:QAM:NST 16"`

Features: *RST value: 16
SCPI: device-specific.

Mode: VA-D

[SENSe:]DDEMod:FSK:NSTate 2 | 4

This command determines the specific demodulation type for FSK.

Example: `"DDEM:FSK:NST 2"`

Features: *RST- value: -
SCPI: device-specific

Mode: VA-D

The parameter 2 corresponds to the demodulation type 2FSK, the parameter 4 to the demodulation type 4FSK.

[SENSe:]DDEMod:SRATe 160 Hz ...1.6 MHz

This command defines the symbol rate.

Example: `"DDEM:SRAT 18kHz"`

Features: *RST value: 270.833333kHz
SCPI: device-specific

Mode: VA-D

[SENSe:]DDEMod:TIME 1 to Frame Length

The command determines the number of displayed symbols (result length).

Example: `"DDEM:TIME 80"`

Features: *RST value: 147
SCPI: device-specific

Mode: VA-D

[SENSe:]DDEMod:PRATe 1 | 2 | 4 | 8 | 16

This command determines the number of points per symbol.

Example: `"DDEM:PRAT 8"`

Features: *RST value: 4
SCPI: device-specific

Mode: VA-D

[SENSe:]DDEMod:FILTer:MEASurement OFF | RCOSine | RRCosine | GAUSsian

This command selects the input filter for the test signal.

Example: `"DDEM:FILT:MEAS RCOS"`

Features: *RST value: OFF
SCPI: device-specific

Mode: VA-D

[SENSe:]DDEMod:FILTer:REFerence RCOSine | RRCosine | GAUSsian

This command selects the input filter for the reference signal.

Example: `"DDEM:FILT:REF RCOS"`

Features: *RST value: GAUSsian
SCPI: device-specific

Mode: VA-D

[SENSe:]DDEMod:FILTer:ALPHa 0.2 to 1

This command determines the filter characteristic (ALPHA/BT). Step width is 0.05.

Example: `"DDEM:FILT:ALPH 0.5"`

Features: *RST value: 0.3
SCPI: device-specific

Mode: VA-D

[SENSe:]DDEMod:NORMalize ON | OFF

This command switches normalizing of the unit circle on or off using IQ offset.

Example: `"DDEM:NORM OFF"`

Features: *RST value: ON
SCPI: device-specific

Mode: VA-D

[SENSe:]DDEMod:SEARch:PULSe:STATe ON | OFF

This command switches the signal burst search on or off.

Example: "DDEM:SEAR:PULS:STAT OFF"

Features: *RST value: ON
SCPI: device-specific

Mode: VA-D

[SENSe:]DDEMod:SEARch:SYNC:OFFSet <numeric_value>

This command defines the offset of the display with reference to the synchronization sequence.

Example: "DDEM:SEAR:SYNC:OFFS 10SYM"

Features: *RST value: 0 SYM
SCPI: device-specific

Mode: VA-D

[SENSe:]DDEMod:SEARch:SYNC:PATTern <string>

This command defines the synchronization sequence.

Example: "DDEM:SEAR:SYNC:PATT "1101001"

Features: *RST value: ""
SCPI: device-specific

Mode: VA-D

[SENSe:]DDEMod:SEARch:SYNC:STATe ON | OFF

This command switches the search for a synchronization sequence on or off.

Example: "DDEM:SEARch:SYNC:STAT ON"

Features: *RST value: OFF
SCPI: device-specific

Mode: VA-D

[SENSe:]DDEMod:SEARch:TIME 100 to 1600

This command determines the number of symbols required for demodulation (frame length). The values > 800 are only permissible if the number of points per symbol is <16, the values > 1600 only if the number of points per symbol is <8. Step width is 100.

Example: "DDEM:SEAR:TIME 800"

Features: *RST value: 400
SCPI: device-specific

Mode: VA-D

[SENSe:]DDEMod:PRESet GSM | TETRa | DCS1800 | PCS1900 |PHS | PDCup | PDCDown | APCO25CQPSK | APCO25C4FM | CDPD | DECT | CT2 | ERMes | MODacom | PWT | TFTS | F16 | F322 | F324 | F64 |FQCDma | RQCDma | FNADc | RNADc

This command selects an automatic setting of all modulation parameters according to a standard transmission method.

Example: `"DDEM:PRES TETR"`

Features: *RST value: GSM
SCPI: device-specific

Mode: VA-D

APCO25CQPSK	APCO25 Continous Phase QPSK
APCO25C4FM	APCO25 Continous Phase 4FM
F16	FLEX 1600 - 2FSK
F322	FLEX 3200 - 2FSK
F324	FLEX 3200 - 4FSK
F64	FLEX 6400 - 4FSK
FNADc	Forward NADC
RNADc	Reverse NADC
FQCDma	Forward CDMA according to IS95 standard
RQCDma	Reverse CDMA according to IS95 standard

[SENSe:]TCAPture:LENGth 1024 | 2048 | 4096 | 8192 | 16384

This command determines the number of sampling points that are written into the memory for each measurement (memory size).

Example: `"TCAP:LENG 1024"`

Features: *RST value: 16384
SCPI: device-specific

Mode: VA-D

3.6.18.7 SENSe:FILTer Subsystem

The SENSe:FILTer subsystem selects the filters in the video signal path.
This subsystem is active only in the Vector Signal Analysis mode (option FSE-B7).

COMMAND	PARAMETERS	UNIT	COMMENT
[SENSe]			
:FILTer			Vector Signal Analyzer
:HPASs			
[:STATe]	<Boolean>	--	
:FREQuency	<numeric_value>	HZ	
:LPASs			Vector Signal Analyzer
[:STATe]	<Boolean>	--	
:FREQuency	<numeric_value>	HZ | PCT	
:CCITt			
[:STATe]	<Boolean>	--	
:CMESsage			
[:STATe]	<Boolean>	--	
:DEMPhasis			
[:STATe]	<Boolean>		
:TCONstant	<numeric_value>	S	
:LINK	DISPlay | AUDio		

[SENSe:]FILTer:HPASs[:STATe] ON | OFF

This command activates the high-pass filter in the AF-branch for analog demodulation.

Example: `"FILT:HPAS ON"`

Features: *RST value: OFF
SCPI: conforming

Mode: VA-A

[SENSe:]FILTer:HPASs:FREQuency 30 Hz | 300 Hz

In the Vector Signal Analysis mode with analog demodulation, this command defines the frequency limit of the high-pass filter in the AF-branch. For REAL TIME ON absolute frequencies are entered, for REAL TIME OFF, the frequencies are entered relative to the demodulation bandwidth.

Example: `"FILT:HPAS:FREQ 300HZ"`

Features: *RST value: - (STATe = OFF)
SCPI: conforming

Mode: VA-A

[SENSe:]FILTer:LPASs[:STATe] ON | OFF

This command activates the low-pass filter in the AF-branch with analog demodulation.

Example: `"FILT:LPAS ON"`

Features: *RST value: OFF
SCPI: conforming

Mode: VA-A

On switching to ON, a bandwidth of 3 kHz for REAL TIME ON and a bandwidth of 5 PCT for REAL TIME OFF is set automatically.

[SENSe:]FILTer:LPASs:FREQuency <numeric_value>

This command defines the frequency limit of the low-pass filter in the NF-branch for analog demodulation.

Parameter: <numeric_value> ::= 3 kHz | 15 kHz for REAL TIME ON
5 PCT | 10 PCT | 25 PCT for REAL TIME OFF

Example: "FILT:LPAS:FREQ 3KHZ" for REAL TIME ON
"FILT:LPAS:FREQ 25PCT" for REAL TIME OFF

Features: *RST value: - (STATe = OFF)
SCPI: conforming

Mode: VA-A

[SENSe:]FILTer:CCITt[:STATe] ON | OFF

This command activates the weighting filter according to CCITT-recommendation in the AF-branch for analog demodulation.

Example: "FILT:CCIT ON"

Features: *RST value: OFF
SCPI: conforming

Mode: VA-A

[SENSe:]FILTer:CMESsage[:STATe] ON | OFF

This command activates the C-message weighting filter according to CCITT-recommendation in the AF-branch for analog demodulation.

Example: "FILT:CMES ON"

Features: *RST value: OFF
SCPI: conforming

Mode: VA-A

This command is valid only with REAL TIME OFF.

[SENSe:]FILTer:DEMPhasis[:STATe] ON | OFF

This command activates the selected de-emphasis for analog demodulation.

Example: "FILT:DEMP ON"

Features: *RST value: OFF
SCPI: conforming

Mode: VA-A

[SENSe:]FILTer:DEMPhasis:TCONstant 50US | 75US | 750US

This command sets the time constant of the de-emphasis for analog demodulation.

Example: "FILT:DEMP:TCON 75US"

Features: *RST value: 50us
SCPI: conforming

Mode: VA-A

[SENSe:]FILTer:DEMPhasis:LINK DISPlay | AUDio

For analog demodulation, this command selects whether the de-emphasis set is to be active in the audio branch only or in addition for the display of measured values.

Example: `"FILT:DEMP:LINK DISP"`

Features: *RST value: AUDio
SCPI: device-specific

Mode: VA-A

AUDio	De-emphasis effective in the audio branch only
DISPlay	De-emphasis effective in the audio branch and in the display of measured values

3.6.18.8 SENSe:FREQuency Subsystem

The SENSe:FREQuency subsystem defines the frequency axis of the active display. The frequency axis can either be defined via the start/stop frequency or via the center frequency and span.

COMMAND	PARAMETERS	UNIT	COMMENT
[SENSe]			
:FREQuency			
:CENTer	<numeric_value>	HZ	
:LINK	STARt | STOP | SPAN	--	
:STEP	<numeric_value>	HZ	
:LINK	SPAN | RBW | OFF	--	
:FACTor	<numeric_value>	PCT	
:SPAN	<numeric value>	HZ	
:FULL	--	--	
:LINK	CENTer | STARt | STOP	--	
:STARt	<numeric_value>	HZ	
:LINK	CENTer | STOP | SPAN	--	
:STOP	<numeric_value>	HZ	
:LINK	CENTer | STARt |SPAN	--	
:MODE	CW | FIXed | SWEep	--	
:OFFSet	<numeric_value>	HZ	
:CW:	<numeric_value>	HZ	
:STEP	<numeric_value>	HZ	
:FIXed	<numeric_value>	HZ	
:STEP	<numeric_value>	HZ	

[SENSe:]FREQuency:CENTer 0 GHz to f_{max}

This command defines the center frequency of the analyzer.

Example: `"FREQ:CENT 100MHz"`

Features: *RST value: f_{max} / 2
SCPI: conforming

Modes: A, VA

The automatic coupling of the parameters is set to SPAN FIXED.

[SENSe:]FREQuency:CENTer:LINK STARt | STOP | SPAN

This command defines the coupling of the center frequency to the start, stop frequency or the frequency span.

Example: `"FREQ:CENT:LINK STAR"`

Features: *RST value: SPAN
SCPI: device-specific

Mode: A

[SENSe:]FREQuency:CENTer:STEP 0 to f_{max}

This command defines the step width of the center frequency.

Example: `"FREQ:CENT:STEP 120MHz"`

Features: *RST value: - (AUTO 0.1 × SPAN is switched on)
SCPI: conforming

Modes: A, VA, BTS, MS

[SENSe:]FREQuency:CENTer:STEP:LINK SPAN | RBW | OFF

This command couples the step width of the center frequency to span (span >0) or to the resolution bandwidth (span = 0) or cancels the couplings.

Example: `"FREQ:CENT:STEP:LINK SPAN"`

Features: *RST value: SPAN
SCPI: device-specific

Modes: A, BTS, MS

[SENSe:]FREQuency:CENTer:STEP:LINK:FACTor 1 to 100 PCT

This command couples the step width of the center frequency with a factor to the span (span >0) or to the resolution bandwidth (span = 0).

Example: `"FREQ:CENT:STEP:LINK:FACT 20PCT"`

Features: *RST value: - (AUTO 0.1 × SPAN is switched on)
SCPI: device-specific

Modes: A, BTS, MS

[SENSe:]FREQuency:SPAN 0 GHz to f_{max}

This command defines the frequency span of the analyzer.

Example: `"FREQ:SPAN 10MHz"`

Features: *RST value: f_{max}
SCPI: conforming

Mode: A

The automatic coupling of the parameters is set to CENTER FIXED.

[SENSe:]FREQuency:SPAN:FULL

This command sets the maximum frequency span of the analyzer.

Example: `"FREQ:SPAN:FULL"`

Features: *RST value: -
SCPI: conforming

Mode: A

This command is an event which is why it is not assigned an *RST value and has no query.

[SENSe:]FREQuency:SPAN:LINK CENTer | START | STOP

This command defines the coupling for frequency-span changes.

Example: `"FREQ:SPAN:LINK STOP"`

Features: *RST value: CENTer
SCPI: conforming

Mode: A

[SENSe:]FREQuency:STARt 0 GHz to f_{max}

This command defines the start frequency of the analyzer.

Example: `"FREQ:STAR 20MHz"`

Features: *RST value: 0
SCPI: conforming

Mode: A

The automatic coupling of the parameters is set to STOP FIXED.

[SENSe:]FREQuency:STARt:LINK CENTer | STOP | SPAN

This command defines the coupling for start-frequency changes.

Example: `"FREQ:STAR:LINK SPAN"`

Features: *RST value: STOP
SCPI: device-specific

Mode: A

[SENSe:]FREQuency:STOP 0 GHz to f_{max}

This command defines the stop frequency of the scan in receiver mode or the stop frequency of the analyzer.

Example: `"FREQ:STOP 2000MHz"`

Features: *RST value: f_{max}
SCPI: conforming

Mode: A

The automatic coupling of the parameters is set to STARt FIXED.

[SENSe:]FREQuency:STOP:LINK CENTer | STARt | SPAN

This command defines the coupling for stop-frequency changes.

Example: `"FREQ:STOP:LINK SPAN"`

Features: *RST value: STARt
SCPI: device-specific

Mode: A

[SENSe:]FREQuency:MODE CW | FIXed | SWEep

This command switches between frequency (SWEep) and time (CW | FIXed) domain in the analyzer mode.

Example: `"FREQ:MODE SWE"`

Features: *RST value: CW
SCPI: conforming

Mode: A

For CW and FIXed, the frequency setting is via command `FREQuency:CENTer`. In the SWEep mode, the setting is via commands `FREQuency:STARt`, `STOP`, `CENTer` and `SPAN`.

[SENSe:]FREQuency:OFFSet <numeric_value>

This command defines the frequency offset of the instrument.

Example: `"FREQ:OFFS 1GHZ"`

Features: *RST value: 0 Hz
SCPI: conforming

Modes: A, VA

3.6.18.9 SENSe:MIXer - Subsystem

The SENSe:MIXer subsystem controls the settings of the external mixer. It is only active in Analyzer mode (`INSTrument SANalyzer`).

COMMAND	PARAMETERS	UNIT	COMMENT
[SENSe]			
:MIXer			
[:STATe]	<Boolean>	--	
:BLOCk	<Boolean>		
:PORTs	2 | 3		
:SIGNal	OFF | ON | AUTO		
:THReshold	<numeric_value>		
:HARMonic	<numeric_value>	--	Only query in band lock on
:TYPE	ODD | EVEN | EODD		Not in band lock off
:BAND	A|Q|U|V|E|W|F|D|G|Y|J		Not in band lock off
:LOSS			
[:LOW]	<numeric_value>	DB	
:HIGH	<numeric_value>	DB	Not in band lock off
:TABLe	<file_name>		
:BIAS	<numeric_value>	A	
:LIMit			
[:MAX]	<numeric_value>	A	Not in band lock on
:MIN	<numeric_value>	A	Not in band lock on

[SENSe:]MIXer[:STATe] ON | OFF

This command activates or shuts off the external mixer.

Example: `"MIX ON"`

Features: *RST value: OFF
SCPI: device-specific

Mode: A

This command is available only in conjunction with option FSE-B21, External Mixer Output.

[SENSe:]MIXer:BLOCk ON | OFF

This command activates the BAND LOCK ON or BAND LOCK OFF mode.

Example: `"MIX:BLOC ON"`

Features: *RST value: OFF
SCPI: device-specific

Mode: A

This command is available only if the external mixer (option FSE-B21) is switched on.

[SENSe:]MIXer:PORTs 2 | 3

This command activates the 2- or 3-port mixer. In the BAND LOCK ON mode, the command refers to the active band selected with `SENSe:MIXer:HARMonic:BAND`.

Example: `"MIX:PORT 3"`

Features: *RST value: 2
SCPI: device-specific

Mode: A

This command is available only if the external mixer (option FSE-B21) is switched on.

[SENSe:]MIXer:SIGNal ON | OFF | AUTO

This command activates the Signal ID or Auto ID mode.

Example: `"MIX:SIGN ON"`

Features: *RST value: OFF
SCPI: device-specific

Mode: A

This command is available only if the external mixer (option FSE-B21) is switched on.

[SENSe:]MIXer:THReshold 0.1 to 100 dB

This command sets the level threshold for auto ID.

Example: `"MIX:THR 20"`

Features: *RST value: 10
SCPI: device-specific

Mode: A

The command is available only if the external mixer (option FSE-B21) is switched on.

[SENSe:]MIXer:HARMonic <numeric_value>

With BAND LOCK OFF, this command sets the nth harmonic. The command may be a query with BAND LOCK ON.

Parameter: <numeric_value> := 2..X; X: depending on the LO

Example: `"MIX:HARM 5"`

Features: *RST value: 2
SCPI: conforming

Mode: A

[SENSe:]MIXer:HARMonic:TYPE ODD | EVEN | EODD

With BAND LOCK ON, this command sets the type of harmonic.

Example: `"MIX:HARM:TYPE EODD"`

Features: *RST value: EVEN
SCPI: device-specific

Mode: A

[SENSe:]MIXer:HARMonic:BAND A|Q|U|V|E|W|F|D|G|Y|J

With BAND LOCK ON, this command sets the active band.

Example: `"MIX:HARM:BAND E"`

Features: *RST value: U
SCPI: device-specific

Mode: A

[SENSe:]MIXer:LOSS[:LOW] <numeric_value>

This command sets the conversion loss of the mixer.

Example: `"MIX:LOSS -12DB"`

Features: *RST value: 0 dB
SCPI: conforming

Mode: A

[SENSe:]MIXer:LOSS:HIGH <numeric_value>

With BAND LOCK ON, this command sets the conversion loss of the mixer for higher harmonics in bands with two harmonics (band A: even harmonics, band Q: odd harmonics).

Example: `"MIX:LOSS:HIGH -14DB"`

Features: *RST value: 0 dB
SCPI: device-specific

Mode: A

[SENSe:]MIXer:LOSS:TABLe <file_name>

This command sets a conversion loss table.

Parameter: <file_name> := DOS file name

Example: `"MIX:LOSS:table mix_1"`

Features: *RST value: no table set
SCPI: device-specific

Mode: A

[SENSe:]MIXer:BIAS <numeric_value>

This command sets the bias current.

Example: `"MIX:BIAS 7mA"`

Features: *RST value: 0 A
SCPI: conforming

Mode: A

[SENSe:]MIXer:BIAS:LIMit[:MAX] <numeric_value>

This command sets the maximum limit of the bias current.

Example: "MIX:BIAS:LIM 7mA"

Features: *RST value: +10mA
SCPI: conforming

Mode: A

[SENSe:]MIXer:BIAS:LIMit:MIN <numeric_value>

This command sets the minimum limit of the bias current.

Example: "MIX:BIAS:LIM:MIN -8mA"

Features: *RST value: -10 mA
SCPI: conforming

Mode: A

3.6.18.10 SENSe:MSUMmary Subsystem

This subsystem controls the modulation summary setting for analog demodulation.
It is active only in conjunction with option Vector Analysis, FSE-B7.

COMMAND	PARAMETERS	UNIT	COMMENT
[SENSe<1|2>]			
:MSUMmary			Vector Signal Analysis
:AHOLd			
[:STATe]	<Boolean>		
:MODE	ABSolute | RELative		
:REFerence	<numeric_value>	PCT | HZ | DEG | RAD	
:AUTO	ONCE		no query
:MTIMe	<numeric_value>	S	

[SENSe:]MSUMmary:AHOLd[:STATe] ON | OFF

This command switches on the average/peak hold mode.

Example: "MSUM:AHOL ON"

Features: *RST value: OFF
SCPI: device-specific

Mode: VA-A

[SENSe:]MSUMmary:MODE ABSolute | RELative

This command selects the absolute or relative indication of the summary marker values.

Example: "MSUM:MODE REL"

Features: *RST value: ABSolute
SCPI: device-specific

Mode: VA-A

[SENSe:]MSUMmary:REFerence <numeric_value>

This command selects the reference modulation.

Parameter: <numeric_value> := 0.001PCT to 1000PCTfor AM
0.1HZ to 10MHZfor FM
0.0001RAD to 1000RADfor PM

Example: "MSUM:REF 50PCT"

Features: *RST value: 100PCTfor AM
100KHZfor FM
10RAD for PM
SCPI: device-specific

Mode: VA-A

[SENSe:]MSUMmary:REFerence:AUTO ONCE

This command sets the current absolute measured values of the main modulation signal as reference values for the relative indication.

Example: `"MSUM:REF:AUTO ONCE"`

Features: *RST value: --
SCPI: device-specific

Mode: VA-A

This command is an event and has therefore no query and no *RST value assigned.

[SENSe:]MSUMmary:MTIMe 0.1 s | 1 s

This command selects the measurement time for the summary markers.

Example: `"MSUM:MTIM 100US"`

Features: *RST value: 0.1S
SCPI: device-specific

Mode: VA-A

3.6.18.11 SENSe:POWer Subsystem

This subsystem controls the setting of the instrument's power measurements.

COMMAND	PARAMETER	UNIT	COMMENT
[SENSe<1|2>]			
:POWer			
:ACHannel			
:SPACing			
[:UPPer]	<numeric_value>	HZ	
:ACHannel	<numeric_value>	HZ	
:ALTernate<1|2>	<numeric_value>	HZ	
:ACPairs	1 | 2 | 3		
:BANDwidth			
[:CHANnel]	<numeric_value>	HZ	
:ACHannel	<numeric_value>	HZ	
:ALTernate<1|2>	<numeric_value>	HZ	
:BWIDth			
[:CHANnel]	<numeric_value>	HZ	
:ACHannel	<numeric_value>	HZ	
:ALTernate<1|2>	<numeric_value>	HZ	
:MODE	ABSolute | RELative		
:REFerence			
:AUTO	ONCE		no query
:PRESet	ACPower | CPOWer | OBANdwidth | OBWidth | CN | CN0		
:BANDwidth	<numeric_value>	PCT	
:BWIDth	<numeric_value>	PCT	

[SENSe:]POWer:ACHannel:SPACing[:UPPer] 0 Hz to 1000 MHz

This command defines the channel spacing of adjacent channel to carrier.

Example: `"POW:ACH:SPAC 28kHz"`

Features: *RST value: 24 kHz
SCPI: conforming

Mode: A-F

[SENSe:]POWer:ACHannel:SPACing:ACHannel 0 Hz to 1000 MHz

This command defines the channel spacing of adjacent channel to carrier. This command has the same effect as `POW:ACH:SPAC`.

Example: `"POW:ACH:SPAC:ACH 338kHz"`

Features: *RST value: 24 kHz
SCPI: device-specific

Mode: A-F

[SENSe:]POWer:ACHannel:SPACing:ALTernate<1|2> 0 Hz ... 1000 MHz

This command defines the spacing of the first (ALTernate1) or the second alternate adjacent channel (ALTernate2) relative to the carrier signal.

Example: `"POW:ACH:SPAC:ALT1 99kHz"`

Features: *RST value: 24 kHz
SCPI: device-specific

Mode: A-F

[SENSe:]POWer:ACHannel:ACPairs 1.| 2 | 3

This command sets the number of adjacent channels (upper and lower channel in pairs).

Example: `"POW:ACH:ACP 3"`

Features: *RST value: 1
SCPI: device-specific

Mode: A-F

[SENSe:]POWer:ACHannel:BANDwidth|BWIDth[:CHANnel] 0 Hz to 1000 MHz

This command sets the channel bandwidth of the radio communication system.

Example: `"POW:ACH:BWID 30kHz"`

Features: *RST value: 24 kHz
SCPI: device-specific

Mode: A-F

If the channel bandwidth of the adjacent channel is changed the bandwiths of all alternate adjacent channels are automatically set to the same value.

[SENSe:]POWer:ACHannel:BANDwidth|BWIDth:ACHannel 0 Hz to 1000 MHz

This command defines the channel bandwidth of the adjacent channel of the radio transmission system.

Example: `"POW:ACH:BWID:ACH 30kHz"`

Features: *RST value: 24 kHz
SCPI: device-specific

Mode: A-F

If the channel bandwidth of the adjacent channel is changed the bandwiths of all alternate adjacent channels are automatically set to the same value.

[SENSe:]POWer:ACHannel:BANDwidth|BWIDth:ALTernate<1|2> 0 Hz to 1000 MHz

This command defines the channel bandwidth of the first/second alternate adjacent channel of the radio transmission system.

Example: `"POW:ACH:BWID:ALT2 30kHz"`

Features: *RST value: 24 kHz
SCPI: device-specific

Mode: A-F

If the channel bandwidth of the alternate adjacent channel no. 1is changed the bandwith of the alternate adjacent channel no. 2 is automatically set to the same value.

[SENSe:]POWer:ACHannel:MODE ABSolute | RELative

This command toggles between absolute and relative measurement.

Example: `"POW:ACH:MODE REL"`

Features: *RST value: ABSolute
SCPI: device-specific

Mode: A-F

For the relative measurement the reference value is set to the currently measured channel power by command `POW:ACH:REF:AUTO ONCE`.

[SENSe:]POWer:ACHannel:REFerence:AUTO ONCE

This command sets the reference value to the currently measured channel power.

Example: `"POW:ACH:REF:AUTO ONCE"`

Features: *RST value: -
SCPI: device-specific

Mode: A-F

This command is an event which is why it is not assigned an *RST value and has no query.

[SENSe:]POWer:ACHannel:PRESet ACPower | CPOWer | OBANdwidth|OBWidth | CN | CN0

This command selects the type of power measurement.

Example: `"POW:ACH:REF:PRES ACP"`

Features: *RST value: -
SCPI: device-specific

Mode: A-F

[SENSe:]POWer:BANDwidth|BWIDth 0 to 100PCT

This command defines the percentage of the power with respect to the total power.

Example: `"POW:BWID 95PCT"`

Features: *RST value: 99PCT
SCPI: device-specific

Mode: A-F

This value defines the occupied bandwidth (measurement `POW:ACH:PRES OBW`).

3.6.18.12 SENSe:ROSCillator Subsystem

This subsystem controls the reference oscillator.

COMMAND	PARAMETERS	UNIT	COMMENT
[SENSe]			
:ROSCillator			
:SOURce	INTernal | EXTernal	--	
:EXTernal			
:FREQuency	<numeric_value>	HZ	
[:INTernal]			
:TUNe	<numeric_value>		
:SAVe			no query

[SENSe:]ROSCillator:SOURce INTernal | EXTernal

This command controls selection of the reference oscillator.

Example: `"ROSC:SOUR EXT"`

Features: *RST value: –
SCPI: conforming

Modes: A, VA, BTS, MS

If the external reference oscillator is selected, the reference signal must be connected to the rear panel of the instrument. *RST has no influence on this setting.

[SENSe:]ROSCillator:EXTernal:FREQuency 1MHz to 16MHz

This command defines the frequency of the external reference oscillator.

Example: `"ROSC:EXT:FREQ 5MHz"`

Features: *RST value: 10MHz
SCPI: conforming

Modes: A, VA, BTS, MS

The value of the external reference frequency (1MHz to 16MHz) is rounded in steps of 1MHz.

[SENSe:]ROSCillator[:INTernal]:TUNe 0 to 4095

This command defines the value for the tuning of the internal reference oscillator.

Example: `"ROSC:TUN 128"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

The reference oscillator should be tuned only if an error has been detected in the frequency accuracy check. After PRESET or switching on the instrument, the saved value of the reference frequency is restored.

[SENSe:]ROSCillator[:INTernal]:TUNe:SAVe

This command saves the new value for the tuning of the internal reference oscillator. The factory-set value in the EEPROM is overwritten.

Example: `"ROSC:TUN:SAV"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

3.6.18.13 SENSe:SWEep Subsystem

This subsystem controls the sweep parameters.

COMMAND	PARAMETERS	UNIT	COMMENT
[SENSe]			
:SWEep			
:TIME	<numeric_value>	S	
:AUTO	<Boolean>	--	
:COUNt	<numeric_value>	--	
:EGATe	<Boolean>	--	
:LEVel	<numeric_value>	V	
:TYPE	LEVel | EDGE	--	
:POLarity	POSitive|NEGative	--	
:HOLDoff	<numeric_value>	S	
:LENGth	<numeric_value>	S	
:SOURce	EXTernal | RFPower	--	
:GAP	<Boolean>	--	
:PRETrigger	<numeric_value>	S	
:TRGTogap	<numeric_value>	S	
:LENGth	<numeric_value>	S	

[SENSe:]SWEep:TIME <numeric_value>

This command defines the duration of the sweep.
The allowed value range depends on the selected domain and, for frequency domain, on the set resolution bandwith (see Chapter 2, Soft key SWEEP TIME MANUAL).

Example: `"SWE:TIME 10s"`

Features: *RST value - (AUTO is set to ON)
SCPI: conforming

Modes: A, VA-A

If `SWEep:TIME` is directly programmed, automatic coupling is switched off.

[SENSe:]SWEep:TIME:AUTO ON | OFF

This command switches the automatic coupling of the sweep time for the frequency span or bandwidth settings.

Example: `"SWE:TIME:AUTO ON"`

Features: *RST value: ON
SCPI: conforming

Mode: A

If `SWEep:TIME` is directly programmed, automatic coupling is switched off.

[SENSe:]SWEep:COUNt 0 to 32767

This command defines the number of sweeps started with single sweep.

Example: `"SWE:COUNT 64"`

Features: *RST value: 0
SCPI: conforming

Modes: A, VA-D

This parameter defines the number of sweeps or the number of averaging procedures. In the average mode, the value 0 defines a running averaging of measurement data over 10 sweeps.

[SENSe:]SWEep:EGATe ON | OFF

This command controls the sweep with the external gate signal.

Example: `"SWE:EGAT ON"`

Features: *RST value: OFF
SCPI: device-specific

Mode: A

[SENSe:]SWEep:EGATe:LEVel -5V to +5V

This command determines the threshold for the external gate signal.

Example: `"SWE:EGAT:LEV 3V"`

Features: *RST value: 2V
SCPI: device-specific

Mode: A

If `SWEep:TIME` is directly programmed, automatic coupling is switched off.

[SENSe:]SWEep:EGATe:TYPE LEVel | EDGE

This command sets the type of triggering (level or edge) by the external gate signal.

Example: `"SWE:EGAT:TYPE EDGE"`

Features: *RST value: EDGE
SCPI: device-specific

Mode: A

Parameter `EGATe:LENGth` is not used for level triggering.

[SENSe:]SWEep:EGATe:POLarity POSitive | NEGative

This command determines the polarity of the external gate signal.

Example: `"SWE:EGAT:POL POS"`

Features: *RST value: POSitive
SCPI: device-specific

Mode: A

[SENSe:]SWEep:EGATe:HOLDoff 0 to 100s

This command defines the delay time between the external gate signal and the continuation of the sweep.

Example: `"SWE:EGAT:HOLD 100us"`

Features: *RST value: 0s
SCPI: device-specific

Mode: A

The values for the delay time can be set in steps 1, 2, 3 and 5.

[SENSe:]SWEep:EGATe:LENGth 0 to 100s

In case of edge triggering, this command determines the time interval in which the instrument sweeps.

Example: `"SWE:EGAT:LENG 10ms"`

Features: *RST value: 0s
SCPI: device-specific

Modes: A

The values for the delay time can be set in steps 1, 2, 3 and 5.

[SENSe:]SWEep:EGATe:SOURce EXTernal | RFPower

This command toggles between external gate signal and RF power signal.

Example: `"SWE:EGAT:SOUR RFP"`

Features: *RST value: EXTernal
SCPI: device-specific

Mode: A

[SENSe:]SWEep:GAP ON | OFF

This command controls the operating mode GAP SWEEP.

Example: `"SWE:GAP ON"`

Features: *RST value: OFF
SCPI: device-specific

Mode: A-Z

Operating mode GAP SWEEP for measurements in the time domain controls the display of measured values. Measured values can be blanked for a defined time range (GAP).

[SENSe:]SWEep:GAP:PRETrigger 0 to 100s

This command defines the evaluation time for measured values before the pretrigger time (resolution: 50 ns).

Example: `"SWE:GAP:PRET 100us"`

Features: *RST value: 0s
SCPI: device-specific

Mode: A

[SENSe:]SWEep:GAP:TRGTogap 0 to 100s

This command defines the time between the pretrigger time and the beginning of the gap (trigger-to-gap time) (resolution: 50 ns).

Example: `"SWE:GAP:TRGT 50us"`

Features: *RST value: 0s
SCPI: device-specific

Mode: A

[SENSe:]SWEep:GAP:LENGth 0 to 100s

This command defines the gap length.

Example: "SWE:GAP:LENG 400us"

Features: *RST value: 0s
SCPI: device-specific

Mode: A

The gap length can be programmed from 0 to 100s in steps of 1, 2, 3 and 5.

[SENSe:]SWEep:SPACing LINear | LOGarithmic

This command toggles between linear and logarithmic sweep.

Example: "SWE:SPAC LOG"

Features: *RST value: LIN
SCPI: conforming

Modes: A

The frequency axis is set to linear or logarithmic scaling accordingly.

3.6.18.14 SENSe:TV Subsystem

This subsystem controls the optional TV-demodulator (only in conjunction with option TV-Demodulator, FSE-B3).

COMMAND	PARAMETERS	UNIT	COMMENT
[SENSe]			
:TV			Option TV-Demodulator
[:STATe]	<Boolean>	--	
:PSOFfset	<numeric_value>	HZ	

[SENSe:]TV[:STATe] ON | OFF

This command switches the optional TV-demodulator on or off.

Example: `"TV ON"`

Features: *RST value: OFF
SCPI: device-specific

Mode: A-Z

This command is available only in conjunction with option TV-Demodulator, FSE-B3.

[SENSe:]TV:PSOFfset 0 to 6.5 MHz

This command defines the frequency offset between video and audio carrier of the measured signal.

Example: `"TV:PSOF 1 MHz"`

Features: *RST value: 5 MHz
SCPI: device-specific

Mode: A-Z

This command is available only in conjunction with option TV-Demodulator, FSE-B3.

3.6.19 SOURce Subsystem

The SOURce subsystem controls the output signals of the analyzer when the option Tracking Generator is installed (FSE-B8 to FSE-B11). In the split screen mode, a distinction is made between SOURce1 (screen A) and SOURce2 (screen B).

COMMAND	PARAMETERS	UNIT	COMMENT
SOURce<1|2>			Option Mitlaufgenerator
:AM			
:STATe	<Boolean>		
:DM			
:STATe	<Boolean>		
:FM			
:STATe	<Boolean>		
:FREQuency			
:OFFSet	<numeric_value>	HZ	
:POWer			
:ALC			
:SOURce	INTernal | EXTernal		
[:LEVel]			
[:IMMediate]			
[:AMPLitude]	<numeric_value>	DBM	
:OFFSet	<numeric_value>	DB	

SOURce<1|2>:AM:STATe ON | OFF

This command switches on or off the external amplitude modulation of the tracking generator.

Example: `"SOUR:AM:STAT ON "`

Features: *RST-value: OFF
SCPI: conforming

Modes: A, VA

External ALC and external I/Q-modulation is switched off, if active. This command is only valid in conjunction with option Tracking Generator.

SOURce<1|2>:DM:STATe ON | OFF

This command switches on or off the external delta modulation of the tracking generator.

Example: `"SOUR:DM:STAT ON "`

Features: *RST- value: OFF
SCPI: conforming

Modes: A, VA

External AM, external ALC, external FM and external frequency offset are switched off, if active. This command is only valid in conjunction with option Tracking Generator.

SOURce<1|2>:FM:STATe ON | OFF

This command switches on or off the external frequency modulation of the tracking generator.

Example: "SOUR:FM:STAT ON "

Features: *RST-value: OFF
SCPI: conforming

Modes: A, VA

External AM, external I/Q-modulation and frequency offset are switched off, if active. This command is only valid in conjunction with option Tracking Generator.

SOURce<1|2>:FREQuency:OFFSet -200MHz to 200MHz

This command defines a frequency offset of the tracking generators to the current instrument frequency.

Example: "SOUR:FREQ:OFFS "

Features: *RST-value: 0 Hz
SCPI: conforming

Modes: A, VA

External delta modulation is switched off, if active. This command is only valid in conjunction with option Tracking Generator.

SOURce<1|2>:POWer:ALC:SOURce INTernal | EXTernal

This command switches on or off the external level control (ALC).

Example: "SOUR:POW:ALC:SOUR INT "

Features: *RST- value: INT
SCPI: conforming

Modes: A, VA

External AM and external delta modulation are switched off, if active. This command is only valid in conjunction with option Tracking Generator.

SOURce<1|2>:POWer[:LEVel][:IMMediate][:AMPLitude] -20dBm to 0dBm / Option FSE-B12: -90dBm to 0dBm

This command defines the level of the tracking generator.

Example: "SOUR:POW -20dBm"

Features: *RST- value:
SCPI: conforming

Modes: A, VA

This command is only valid in conjunction with option Tracking Generator.

SOURce<1|2>:POWer[:LEVel][:IMMediate]:OFFSet -200dB to +200dB

This command defines a level offset for the tracking generator.

Example: `"SOUR:POW:OFFS -10dB"`

Features: *RST- value: 0dB
SCPI: conforming

Modes: A, VA

This command is only valid in conjunction with option Tracking Generator.

3.6.20 STATus Subsystem

The STATus subsystem contains the commands for the status reporting system (see Section 3.8, Status Reporting System"). *RST does not influence the status registers.

COMMAND	PARAMETERS	UNIT	COMMENT
STATus			
:OPERation			
[:EVENt]?	--	--	
:CONDition?	--	--	
:ENABle	0 to 65535	--	
:PTRansition	0 to 65535	--	
:NTRansition	0 to 65535	--	
:PRESet	--	--	
:QUEStionable			
[:EVENt]?	--	--	
:CONDition?	--	--	
:ENABle	0 to 65535	--	
:PTRansition	0 to 65535	--	
:NTRansition	0 to 65535	--	
:POWer			
[:EVENt]?	--	--	
:CONDition?	--	--	
:ENABle	0 to 65535	--	
:PTRansition	0 to 65535	--	
:NTRansition	0 to 65535	--	
:LIMit			
[:EVENt]?	--	--	
:CONDition?	--	--	
:ENABle	0 to 65535	--	
:PTRansition	0 to 65535	--	
:NTRansition	0 to 65535	--	
:LMARgin			
[:EVENt]?	--	--	
:CONDition?	--	--	
:ENABle	0 to 65535	--	
:PTRansition	0 to 65535	--	
:NTRansition	0 to 65535	--	
:SYNC			
[:EVENt]?	--	--	
:CONDition?	--	--	
:ENABle	0 to 65535	--	
:PTRansition	0 to 65535	--	
:NTRansition	0 to 65535	--	
:ACPLimit			
[:EVENt]?	--	--	
:CONDition?	--	--	
:ENABle	0 to 65535	--	
:PTRansition	0 to 65535	--	
:NTRansition	0 to 65535	--	

COMMAND	PARAMETERS	UNIT	COMMENT
STATus			
:QUEStionable	--	--	
:FREQuency	--	--	
[:EVENt]?	0 to 65535	--	
:CONDition?	0 to 65535	--	
:ENABle	0 to 65535	--	
:PTRansition	--	--	
:NTRansition	--	--	
:TRANsducer			
[:EVENt]?	--	--	
:CONDition?	--	--	
:ENABle	0 to 65535	--	
:PTRansition	0 to 65535	--	
:NTRansition	0 to 65535	--	
:QUEue?	--	--	
[:NEXT]?	--	--	

STATus:OPERation[:EVENt]?

This command queries the contents of the EVENt section of the STATus:OPERation register.

Example: `"STAT:OPER?"`

Features: *RST value: –
SCPI: conforming

Modes: A, VA, BTS, MS

The contents of the EVENt section is deleted with readout.

STATus:OPERation:CONDition?

This command queries the CONDition section of the STATus:OPERation register.

Example: `"STAT:OPER:COND?"`

Features: *RST value: –
SCPI: conforming

Modes: A, VA, BTS, MS

Readout does not delete the contents of the CONDition section. The value returned reflects the current hardware status.

STATus:OPERation:ENABle 0 to 65535

This command sets the bits of the ENABle section of the STATus:QUEStionable register.

Example: `"STAT:OPER:ENAB 65535"`

Features: *RST value: –
SCPI: conforming

Modes: A, VA, BTS, MS

The ENABle register selectively enables the individual events of the associated EVENt section for the sum bit in the status byte.

STATus:OPERation:PTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:OPERation register from 0 to 1 for the transitions of the CONDition bit.

Example: `"STAT:OPER:PTR 65535"`

Features: *RST value: –
SCPI: conforming

Modes: A, VA, BTS, MS

STATus:OPERation:NTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:OPERation register from 1 to 0 for the transitions of the CONDition bit.

Example: `"STAT:OPER:NTR 65535"`

Features: *RST value: –
SCPI: conforming

Modes: A, VA, BTS, MS

STATus:PRESet

This command resets the edge detectors and ENABle parts of all registers to a defined value. All PTRansition parts are set to FFFFh, i.e., all transitions from 0 to 1 are detected. All NTRansition parts are set to 0, i.e., a transition from 1 to 0 in a CONDition bit is not detected. The ENABle part of the STATus:OPERation and STATus:QUEStionable registers are set to 0, i.e., all events in these registers are not passed on.

Example: `"STAT:PRES"`

Features: *RST value: –
SCPI: conforming

Modes: A, VA, BTS, MS

STATus:QUEStionable[:EVENt]?

This command queries the contents of the EVENt section of the STATus:QUEStionable register.

Example: `"STAT:QUES?"`

Features: *RST value: –
SCPI: conforming

Modes: A, VA, BTS, MS

Readout deletes the contents of the EVENt section.

STATus:QUEStionable:CONDition?

This command queries the CONDition section of the STATus:QUEStionable register.

Example: `"STAT:QUES:COND?"`

Features: *RST value: –
SCPI: conforming

Modes: A, VA, BTS, MS

Readout does not delete the contents of the CONDition section.

STATus:QUEStionable:ENABle 0 to 65535

This command sets the bits of the ENABle section of the STATus-QUEStionable register.

Example: `"STAT:QUES:ENAB 65535"`

Features: *RST value: –
SCPI: conforming

Modes: A, VA, BTS, MS

The ENABle register selectively enables the individual events of the associated EVENt section for the sum bit in the status byte.

STATus:QUEStionable:PTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:OPERation register from 0 to 1 for the transitions of the CONDition bit.

Example: `"STAT:QUES:PTR 65535"`

Features: *RST value: –
SCPI: conforming

Modes: A, VA, BTS, MS

STATus:QUEStionable:NTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:OPERation register from 1 to 0 for the transitions of the CONDition bit.

Example: `"STAT:QUES:NTR 65535"`

Features: *RST value: –
SCPI: conforming

Modes: A, VA, BTS, MS

STATus:QUEStionable:POWer[:EVENt]?

This command queries the contents of the EVENt section of the STATus:QUEStionable:POWer register.

Example: `"STAT:QUES?"`

Features: *RST value: –
SCPI: conforming

Modes: A, VA, BTS, MS

Readout deletes the contents of the EVENt section.

STATus:QUEStionable:POWer:CONDition?

This command queries the content of the CONDition section of the STATus:QUEStionable:POWer register.

Example: `"STAT:QUES:COND?"`

Features: *RST value: –
SCPI: conforming

Modes: A, VA, BTS, MS

Readout does not delete the contents of the CONDition section.

STATus:QUEStionable:POWer:ENABle 0 to 65535

This command sets the bits of the ENABle section of the STATus:QUEStionable:POWer register.

Example: `"STAT:QUES:ENAB 65535"`

Features: *RST value: –
SCPI: conforming

Modes: A, VA, BTS, MS

The ENABle register selectively enables the individual events of the associated EVENt section for the sum bit in the status byte.

STATus:QUEStionable:POWer:PTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:QUEStionable:POWer register from 0 to 1 for the transitions of the CONDition bit.

Example: `"STAT:QUES:PTR 65535"`

Features: *RST-value: –
SCPI: conforming

Modes: A, VA, BTS, MS

STATus:QUEStionable:POWer:NTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:QUEStionable:POWer register from 1 to 0 for the transitions of the CONDition bit.

Example: `"STAT:QUES:NTR 65535"`

Features: *RST value: –
SCPI: conforming

Modes: A, VA, BTS, MS

STATus:QUEStionable:LIMit[:EVENt]?

This command queries the contents of the EVENt section of the STATus:QUEStionable:LIMit register.

Example: `"STAT:QUES?"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

Readout deletes the contents of the EVENt section.

STATus:QUEStionable:LIMit:CONDition?

This command queries the contents of the CONDition section of the STATus:QUEStionable:LIMit register.

Example: `"STAT:QUES:COND?"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

Readout does not delete the contents of the CONDition section.

STATus:QUEStionable:LIMit:ENABle 0 to 65535

This command sets the bits of the ENABle section of the STATus:QUEStionable register.

Example: `"STAT:QUES:ENAB 65535"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

The ENABle register selectively enables the individual events of the associated EVENt section for the sum bit in the status byte.

STATus:QUEStionable:LIMit:PTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:QUEStionable:LIMit register from 0 to 1 for the transitions of the CONDition bit.

Example: `"STAT:QUES:PTR 65535"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

STATus:QUEStionable:LIMit:NTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:QUEStionable:LIMit register from 1 to 0 for the transitions of the CONDition bit.

Example: `"STAT:QUES:NTR 65535"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

STATus:QUEStionable:LMARgin[:EVENt]?

This command queries the contents of the EVENt section of the STATus:QUEStionable:LMARgin register.

Example: `"STAT:QUES?"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

Readout deletes the contents of the EVENt section.

STATus:QUEStionable:LMARgin:CONDition?

This command queries the contents of the CONDition section of the STATus:QUEStionable:LMARgin register.

Example: `"STAT:QUES:COND?"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

Readout does not delete the contents of the CONDition section.

STATus:QUEStionable:LMARgin:ENABle 0 to 65535

This command sets the bits of the ENABle section of the STATus:QUEStionable:LMARgin register.

Example: `"STAT:QUES:ENAB 65535"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

The ENABle register selectively enables the individual events of the associated EVENt section for the sum bit in the status byte.

STATus:QUEStionable:LMARgin:PTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:QUEStionable: LMARgin register from 0 to 1 for the transitions of the CONDition bit.

Example: `"STAT:QUES:PTR 65535"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

STATus:QUEStionable:LMARgin:NTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:QUEStionable: LMARgin register from 1 to 0 for the transitions of the CONDition bit.

Example: `"STAT:QUES:NTR 65535"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

STATus:QUEStionable:SYNC[:EVENt]?

This command queries the contents of the EVENt section of the STATus:QUEStionable:SYNC register.

Example: `"STAT:QUES?"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

Readout deletes the contents of the EVENt section.

STATus:QUEStionable:SYNC:CONDition?

This command queries the contents of the CONDition section of the STATus:QUEStionable:SYNC register.

Example: `"STAT:QUES:COND?"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

Readout does not delete the contents of the CONDition section.

STATus:QUEStionable:SYNC:ENABle 0 to 65535

This command sets the bits of the ENABle section of the STATus:QUEStionable: SYNC register.

Example: `"STAT:QUES:ENAB 65535"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

The ENABle register selectively enables the individual events of the associated EVENt section for the sum bit in the status byte.

STATus:QUEStionable:SYNC:PTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:QUEStionable: SYNC register from 0 to 1 for the transitions of the CONDition bit.

Example: `"STAT:QUES:PTR 65535"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

STATus:QUEStionable:SYNC:NTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:QUEStionable: SYNC register from 1 to 0 for the transitions of the CONDition bit.

Example: `"STAT:QUES:NTR 65535"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

STATus:QUEStionable:ACPLimit[:EVENt]?

This command queries the contents of the EVENt section of the STATus:QUEStionable:ACPLimit register.

Example: `"STAT:QUES:ACPL?"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

Readout deletes the contents of the EVENt section.

STATus:QUEStionable:ACPLimit:CONDition?

This command queries the contents of the CONDition section of the STATus:QUEStionable:ACPLimit register.

Example: `"STAT:QUES:ACPL:COND?"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

Readout does not delete the contents of the CONDition section.

STATus:QUEStionable:ACPLimit:ENABle 0 to 65535

This command sets the bits of the ENABle section of the STATus:QUEStionable:ACPLimit register.

Example: `"STAT:QUES:ACPL:ENAB 65535"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

The ENABle register selectively enables the individual events of the associated EVENt section for the sum bit in the status byte.

STATus:QUEStionable:ACPLimit:PTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:QUEStionable: ACPLimit register from 0 to 1 for the transitions of the CONDition bit.

Example: `"STAT:QUES:ACPL:PTR 65535"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

STATus:QUEStionable:ACPLimit:NTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:QUEStionable: ACPLimit register from 1 to 0 for the transitions of the CONDition bit.

Example: `"STAT:QUES:ACPL:NTR 65535"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

STATus:QUEStionable:FREQuency[:EVENt]?

This command queries the contents of the EVENt section of the STATus:QUEStionableFREQuency register.

Example: `"STAT:QUES:FREQ?"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

Readout deletes the contents of the EVENt section.

STATus:QUEStionable:FREQuency:CONDition?

This command queries the contents of the CONDition section of the STATus:QUEStionable:FREQuency register.

Example: `"STAT:QUES:FREQ:COND?"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

Readout does not delete the contents of the CONDition section.

STATus:QUEStionable:FREQuency:ENABle 0 to 65535

This command sets the bits of the ENABle section of the STATus:QUEStionable:FREQuency register.

Example: `"STAT:QUES:FREQ:ENAB 65535"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

The ENABle register selectively enables the individual events of the associated EVENt section for the sum bit in the status byte.

STATus:QUEStionable:FREQuency:PTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:QUEStionable:FREQuency register from 0 to 1 for the transitions of the CONDition bit.

Example: `"STAT:QUES:FREQ:PTR 65535"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

STATus:QUEStionable:FREQuency:NTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:QUEStionable:FREQuency register from 1 to 0 for the transitions of the CONDition bit.

Example: `"STAT:QUES:FREQ:NTR 65535"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

STATus:QUEStionable:TRANsducer[:EVENt]?

This command queries the contents of the EVENt section of the STATus:QUEStionable:TRANsducer register.

Example: `"STAT:QUES:TRAN?"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

Readout deletes the contents of the EVENt section.

STATus:QUEStionable:TRANsducer:CONDition?

This command queries the contents of the CONDition section of the STATus:QUEStionable:FREQuency register.

Example: `"STAT:QUES:TRAN:COND?"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

Readout does not delete the contents of the CONDition section.

STATus:QUEStionable:TRANsducer:ENABle 0 to 65535

This command sets the bits of the ENABle section of the STATus:QUEStionable:TRANsducer register.

Example: `"STAT:QUES:TRAN:ENAB 65535"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

The ENABle register selectively enables the individual events of the associated EVENt section for the sum bit in the status byte.

STATus:QUEStionable:TRANsducer:PTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:QUEStionable:TRANsducer register from 0 to 1 for the transitions of the CONDition bit.

Example: `"STAT:QUES:TRAN:PTR 65535"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

STATus:QUEStionable:TRANsducer:NTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:QUEStionable:TRANsducer register from 1 to 0 for the transitions of the CONDition bit.

Example: `"STAT:QUES:TRAN:NTR 65535"`

Features: *RST value: –
SCPI: device-specific

Modes: A, VA, BTS, MS

STATus:QUEue[:NEXT]?

This command queries the earliest entry to the error queue, thus deleting it.

Example: `"STAT:QUE?"`

Features: *RST value: –
SCPI: conforming

Modes: A, VA, BTS, MS

Positive error numbers indicate device-specific errors, negative error numbers are error messages defined by SCPI (cf. Appendix B). If the error queue is empty, the error number 0, "no error", is returned. This command is identical with the command `SYSTem:ERRor`.

3.6.21 SYSTem Subsystem

This subsystem comprises a series of commands for general functions.

COMMAND	PARAMETERS	UNIT	COMMENT
SYSTem			
:COMMunicate			
:GPIB			
[:SELF]			
:ADDRess	0 to 30	--	
:RTERminator	LFEoi | EOI		
:RDEVice<1|2>			
:ADDRess	0 to 30	--	
:SERial<1|2>			
:CONTrol			
:DTR	IBFull | OFF		
:RTS	IBFull | OFF		
[:RECeive]		--	
:BAUD	<numeric_value>	--	
:BITS	7 | 8		
:PARity			
[:TYPE]	EVEN | ODD | NONE	--	
:SBITs	1 | 2		
:PACE	XON | NONE	--	
:DATE	<num>, <num>, <num>	--	
:DISPlay			
:UPDate	ON | OFF		
:ERRor?	--		query only
:PASSword		--	
[:CENable]	<string>		no query
:PRESet	--		no query
:SET	<block>	--	
:SPEaker		--	
:VOLume	<numeric_value>	--	
:TIME	0 to 23, 0 to 59, 0 to 59		
:VERSion?	--		query only

SYSTem:COMMunicate:GPIB[:SELF]:ADDRess 0 to 30

This command changes the IEC/IEEE-bus address of the unit.

Example: `"SYST:COMM:GPIB:ADDR 18"`

Features: *RST value: - (no influence on this parameter)
SCPI: conforming

Modes: A, VA, BTS, MS

SYSTem:COMMunicate:GPIB[:SELF]:RTERminator LFEOI | EOI

This command changes the delimiter.

Example: `"SYST:COMM:GPIB:RTER EOI"`

Features: *RST value: LFEOI
SCPI: device-specific

Modes: A, VA, BTS, MS

The instrument contains a DMA-channel for communication via IEC-bus. This ensures maximum speed for the transfer of commands and data. The parser for command decoding integrated in the instrument is, however, only activated by the delimiter when the command is completely transferred. In order to make this possible for the transfer of binary data, too (e. g. trace data which are retransferred into the instrument), the delimiter recognition must be switched to the EOI signal prior to the transfer. Output of binary data from the instrument does not require such a switching.

SYSTem:COMMunicate:GPIB:RDEVice<1|2>:ADDRess 0 to 30

This command changes the IEC/IEEE-bus address of the unit which is selected as hardcopy device 1 or 2, provided that the IEC/IEEE-bus interface of this unit is set as an interface.

Example: `"SYST:COMM:GPIB:RDEV2:ADDR 5"`

Features: *RST value: 4
SCPI: conforming

Modes: A, VA, BTS, MS

SYSTem:COMMunicate:SERial<1|2>:CONTrol:DTR IBFull | OFF
SYSTem:COMMunicate:SERial<1|2>:CONTrol:RTS IBFull | OFF

These commands switch the hardware handshake procedure for the given serial interface off (OFF) or on (IBFull).

Examples:
```
"SYST:COMM:SER:CONT:DTR OFF"
"SYST:COMM:SER2:CONT:RTS IBF"
```

Features: *RST value: OFF
SCPI: conforming

Modes: A, VA, BTS, MS

The two commands have the same meaning. SERial1 and SERial 2 correspond to device COM1and COM2, respectively.

SYSTem:COMMunicate:SERial<1|2>[:RECeive]:BAUD 75 | 150 | 300 | 600 | 1200 | 2400 | 9600

This command sets the transmission speed for the given serial interface.

Example: `"SYST:COMM:SER:BAUD 2400"`

Features: *RST value: 9600
SCPI: conforming

Modes: A, VA, BTS, MS

SERial1 and SERial 2 correspond to device interface COM1 and COM2, respectively. Permissible values are 75 Baud, 150 Baud, 300 Baud, 600 Baud, 1200 Baud, 2400 Baud, 4800 Baud, 9600 Baud.

SYSTem:COMMunicate:SERial<1|2>[:RECeive]:BITS 7 | 8

This command defines the number of data bits per data word for the given serial interface.

Example: `"SYST:COMM:SER2:BITS 7"`

Features: *RST value: 8
SCPI: conforming

Modes: A, VA, BTS, MS

SERial1 and SERial 2 correspond to device interface COM1 and COM2, respectively.

SYSTem:COMMunicate:SERial<1|2>[:RECeive]:PARity[:TYPE] EVEN | ODD | NONE

This command defines the parity check for the given serial interface.

Example: `"SYST:COMM:SER:PAR EVEN"`

Features: *RST value: NONE
SCPI: conforming

Modes: A, VA, BTS, MS

SERial1 and SERial 2 correspond to device interface COM1 and COM2, respectively. Permissible values are:

EVEN even parity
ODD odd parity
NONE no parity check.

SYSTem:COMMunicate:SERial<1|2>[:RECeive]:SBITs 1|2

This command defines the number of stopbits per data word for the given serial interface.

Example: `"SYST:COMM:SER:SBITs 2"`

Features: *RST value: 1
SCPI: conforming

Modes: A, VA, BTS, MS

SERial1 and SERial 2 correspond to device interface COM1 and COM2, respectively.

SYSTem:COMMunicate:SERial<1|2>[:RECeive]:PACE XON | NONE

This command switches on or off the software handshake for the given serial interface.

Example: `"SYST:COMM:SER:PACE XON"`

features: *RST value: NONE
SCPI: conforming

Modes: A, VA, BTS, MS

SERial1 and SERial 2 correspond to device interface COM1 and COM2, respectively.

SYSTem:DATE 1980 to 2099, 1 to 12, 1 to 31

This command is used to enter the date for the internal calendar.

Example: `" SYST:DATE 1994,12,1"`

Features: *RST value: –
SCPI: conforming

Modes: A, VA, BTS, MS

The sequence of entry is year, month, day.

SYSTem:DISPlay:UPDate ON | OFF

This command switches on or off the update of all display elements.

Example: `" SYST:DISP ON`

Features: *RST value: OFF
SCPI: device specific

SYSTem:ERRor?

This command queries the earliest entry to the error queue, thus deleting it. .

Example: `"SYST:ERR?"`

Features: *RST value: –
SCPI: conforming

Modes: A, VA, BTS, MS

Positive error numbers indicate device-specific errors, negative error numbers are error messages defined by SCPI (cf. Appendix B). If the error queue is empty, the error number 0, "no error", is returned. This command is identical with the command `STATus:QUEue:NEXT?`. This command is a query which is why it is not assigned an *RST value.

SYSTem:PASSword[:CENable] <string>

This command enables access to the service functions by means of the password.

Example: `"SYST:PASS 'XXXX'"`

Features: *RST value: –
SCPI: conforming

Modes: A, VA, BTS, MS

This command is an event which is why it is not assigned an *RST value and has no query.

SYSTem:SET <block>

The query `SYSTem:SET?` causes the data of the current instrument setting to be transmitted to the controller in binary form (SAVE function). The data can be read back into the instrument (RECALL function) by means of command `SYSTem:SET` <block>. If the data records are stored on the instrument harddisk with SAVE/RECALL (`MMEMory:STORe` bzw. `MMEMory:LOAD`), it is possible to store the data in an external computer by means of `SYSTem:SET`.

Example: `"SYST:SET "`

Features: *RST value: –
SCPI: conforming

Modes: A, VA, BTS, MS

The receive terminator has to be set to EOI to ensure reliable transfer of data (setting `SYST:COMM:GPIB:RTER EOI`).

SYSTem:PRESet

This command triggers an instrument reset.

Example: `"SYST:PRES"`

Features: *RST value: –
SCPI: conforming

Modes: A, VA, BTS, MS

The effect of this command corresponds to that of the *PRESET* key with manual control or to the *RST command.

SYSTem:SPEaker:VOLume 0 to 1

This command sets the volume of the built-in loudspeaker for demodulated signals.

Example: `"SYST:SPE:VOL 0.5"`

Features: *RST value: 0
SCPI: device-specific

Modes: A

The value 0 is the lowest volume, the value 1 is the highest volume.

SYSTem:TIME 0 to 23, 0 to 59, 0 to 59

This command sets the internal clock.

Example: `"SYST:TIME 12,30,30"`

Features: *RST value: –
SCPI: conforming

Modes: A, VA, BTS, MS

The sequence of entry is hour, minute, second.

SYSTem:VERSion?

This command queries the number of the SCPI version, which is relevant for the instrument.

Example: `"SYST:VERS?"`

Features: *RST value: –
SCPI: conforming

Modes: A, VA, BTS, MS

This command is a query which is why it is not assigned an *RST value.

3.6.22 TRACe Subsystem

The TRACe subsystem controls access to the instrument's internal trace memory.

COMMAND	PARAMETERS	UNIT	COMMENT
TRACe			
[:DATA]	TRACE1 | TRACE2 | TRACE3 | TRACE4, <block>|<numeric_value>...	-	
:COPY	TRACE1|TRACE2|TRACE3|TRACE4, TRACE1|TRACE2|TRACE3|TRACE4		
:FEED			
:CONTrol<1...4>	ALWays | NEVer		

TRACe[:DATA] TRACE1| TRACE2| TRACE3| TRACE4, <block> | <numeric_value>

This command transfers trace data from the controller to the instrument, the query reads trace data out of the instrument.

Example: `"TRAC TRACE1,"+A$  (A$: data list in the current format)`
`"TRAC? TRACE1"`

Features: *RST value: -
SCPI: conforming

Modes: A, VA, BTS, MS

The trace data are transferred in the current format (corresponding to the command FORMat ASCii|REAL). The device-internal trace memory is addressed using the trace names 'TRACE1' to 'TRACE4'.
The parameter of the query is the trace name TRACE1 to TRACE4, it indicates which trace memory will be read out.
The transfer of trace data from the controller to the instrument takes place by indicating the trace name and then the data to be transferred. In ASCII format, these data are values separated by commas. If the transfer takes place using the format real (REAL 32), the data are transferred in block format.

Saving and recalling trace data to/from the device-internal hard disk or to/from a floppy is controlled via the commands "`MMEMory:STORe:TRACe`" and "`MMEMory:LOAD:TRACe`" respectively.

The transfer format for the trace data depends on the instrument setting

Analyzer mode (span >0 and zero span):

500 results are output in the unit selected for display.

Note: *With AUTO PEAK detector, only positive peak values can be read out.*
Trace data can be read into instrument with logarithmic display only in dBm, with linear display only in volts.

FORMAT REAL,32 is to be used as format for binary transmission.

Vector analyzer mode, digital demodulation

The number of data transferred (except for the symbol table) is determined by the following formula

number of results = result length * points per symbol

Max. 6400 results can be transferred (for example result length 1600, points per symbol 4).

In all cartesian diagrams (MAGNITUDE CAP BUFFER, MAGNITUDE, PHASE, FREQUENCY, REAL/IMAG, EYE[I], EYE[Q], ERROR VECT MAGNITUDE) test data are transferred in the unit selected for display.

FORMAT REAL,32 is to be used for binary transmission.

Note: *In the case of the eye pattern, results are simply superimposed in the display, ie the EYE representation is the same as the REAL/IMAG representation.*

In the polar diagrams (POLAR CONSTELL, POLAR VECTOR) the real and the imaginary component are transferred as a pair for each result.

FORMAT REAL,32 is to be used for binary transmission.

With the SYMB TABLES / ERRORS setting, the displayed symbols can be read out as traces. Trace assignment is as follows:

Full screen	Trace 1
Split screen, screen A:	Trace 1
Split screen, screen B:	Trace 2

One byte (8 bits) is read out for each symbol.

FORMAT UINT,8 is to be used for binary transmission.

Vector analyzer mode, analog demodulation

The number of results transferred depends on the SWEEP TIME and DEMOD BW settings. Max. 5000 and min. 10 points are available. The unit for the results depends on the selected demodulation:

AM	unit %
FM	unit Hz
PM	unit rad or deg

FORMAT REAL,32 is to be used for binary data transmission.

TRACe:COPY TRACe:COPY TRACE1| TRACE2| TRACE3| TRACE4 ,
TRACE1| TRACE2| TRACE3| TRACE4

This command copies data from one trace to another. The second operand designates the source, the first operand the destination of the data to be copied.

Example: `"TRAC:COPY TRACE1,TRACE2"`

Features: *RST value:
SCPI: conforming

Modes: A, VA, BTS, MS

This command is an event and therefore has no query and no *RST value assigned.

3.6.23 TRIGger Subsystem

The TRIGger subsystem is used to synchronize instrument actions with events. This makes it possible to control and synchronize the start of a sweep. An external trigger signal can be fed to the connector at the rear panel of the instrument. In split screen mode, a distinction is made between TRIGger1 (screen A) and TRIGger2 (screen B).

COMMAND	PARAMETERS	UNIT	COMMENT
TRIGger<1|2>			
[:SEQuence]			
:SOURce	IMMediate | LINE | EXTernal |VIDeo | RFPower | TV | AF	--	TV only with option TV Demodulator
:LEVel			
[:EXTernal]	<numeric_value>	V|MV|UV	
:VIDeo	<numeric_value>	PCT	
:HOLDoff	<numeric_value>	S	
:SLOPe	POSitive|NEGative	--	
:VIDeo			
:FORMat			
:LPFRame	525 | 625		Option TV Demodulator
:FIELd			
:SELect	ALL | ODD | EVEN		Option TV Demodulator
:LINE			
:NUMBer	<numeric_value>		Option TV Demodulator
:SSIGnal			
:POLarity	NEGative | POSitive		Option TV Demodulator
:SYNChronize			
:ADJust			
:FRAMe	<numeric_value>	s	Option FSE-K11
:AUTO	ONCE		Option FSE-K11 & FSE-B7
			Option FSE-K11 or FSE-K10
:SLOT	<numeric_value>	s	Option FSE-K11 or FSE-K10 & FSE-B7
:AUTO	ONCE		
:SOURCe	FRAMe | TSC		Option FSE-K11or FSE-K10 & FSE-B7

TRIGger<1|2>[:SEQuence]:SOURce IMMediate | LINE | EXTernal | VIDeo | RFPower | TV | AF

This command selects the trigger source for the start of a sweep.

Example: `"TRIG:SOUR EXT"`

Features: *RST value: IMMediate
SCPI: conforming

Modes: A, VA, BTS, MS

The value IMMediate corresponds to the "FREE RUN" setting.
Selecting the parameter TV is possible only when the option TV-demodulator is fitted, the parameter AF only in the vector signal analysis mode with analog demodulation.

TRIGger<1|2>[:SEQuence]:LEVel[:EXTernal] –5.0 to +5.0V

This command sets the level of the external trigger source.

Example: `"TRIG:LEV 2V"`

Features: *RST value: –5.0V
SCPI: conforming

Modes: A, VA, BTS, MS

TRIGger<1|2>[:SEQuence]:LEVel:VIDeo 0 to 100PCT

This command sets the level of the video trigger source.

Example: `"TRIG:LEV:VID 50PCT"`

Features: *RST value: 50 PCT
SCPI: device-specific

Modes: A, VA, BTS, MS

TRIGger<1|2>[:SEQuence]:HOLDoff -100 to 100s

This command defines the length of the trigger delay.

Example: `"TRIG:HOLD 500us"`

Features: *RST value: 0s
SCPI: conforming

Modes: A-Z, VA

A negative delay time (pretrigger) can be set in the time domain (SPAN < 0 Hz) only. The maximum permissible range and the maximum effective resolution of the pretrigger are limited by the set sweep time (max range= - 499/500 x sweep time; max. resolution = sweep time/500). Pretriggering is not possible when the rms or the average detector is activated.

TRIGger<1|2>[:SEQuence]:SLOPe POSitive | NEGative

This command selects the slope of the trigger signal.

Example: `"TRIG:SLOP NEG"`

Features: *RST value: POSitive
SCPI: conforming

Modes: A, VA, BTS, MS

The selected trigger slope applies to all trigger signal sources.

TRIGger<1|2>[:SEQuence]:VIDeo:FORMat:LPFRame 525 | 625

This command defines the number of lines per frame to be used (525 or 625 lines)

Example: `"TRIG:VID:FORM:LPFR 525"`

Features: *RST value:
SCPI: conforming

Mode: A-Z

This command is only valid if option FSE-B3, TV Demodulator, is fitted.

TRIGger<1|2>[:SEQuence]:VIDeo:LINE:NUMBer <numeric value>

This command selects the horizontal synchronizing signal for triggering.

Example: `"TRIG:VID:LINE:NUMB 17"`

Features: *RST value:
SCPI: conforming

Mode: A-Z

The instrument is triggered at the specified line. This command is only valid if option FSE-B3, TV Demodulator is fitted.

TRIGger<1|2>[:SEQuence]:VIDeo:FIELd:SELect ALL | ODD | EVEN

This command selects the vertical synchronizing signal for triggering.

Example: `"TRIG:VID:FIEL:SEL ALL"`

Features: *RST value:
SCPI: conforming

Mode: A-Z

With the parameter ALL, the instrument is triggered when the field is changed, irrespective of the half fields. With ODD, triggering by the first half field, with even, triggering by the second half field is selected. This command is valid only if option FSE-B3, TV Demodulator, is fitted.

TRIGger<1|2>[:SEQuence]:VIDeo:SSIGnal:POLarity NEGative | POSitive

This command defines the polarity of the video synchronizing signal.

Example: `"TRIG:VID:SSIG:POL NEG "`

Features: *RST value:
SCPI: conforming

Mode: A-Z

This command is valid only if option FSE-B3, TV Demodulator, is fitted.

TRIGger[:SEQuence]:SYNChronize:ADJust:FRAMe 0 to 100s

This command defines the correction value for the time offset between the frame trigger and the midamble of the slot selected. The value set is corrected by means of the calculated offsets of the other slots and used as a base value for the correction of all slots.
This correction value is necessary in order to conserve the exact time relation between the trigger event and the midamble of the slot in question in cases where there is no midamble triggering.

Example: `"TRIG:SYNC:ADJ:FRAM 30us"`

Features: *RST value: -- (depending on the slot selected)
SCPI: device-specific

Modes: BTS

TRIGger[:SEQuence]:SYNChronize:ADJust:FRAMe:AUTO ONCE

This command determines once the correction value for the time offset between the frame trigger and the midamble of the slot selected. The value set is corrected by means of the calculated offsets of the other slots and used as a base value for the correction of all slots.
This correction value is necessary in order to conserve the exact time relation between the trigger event and the midamble of the slot in question in cases where there is no midamble triggering.

Example: `"TRIG:SYNC:ADJ:FRAMe:AUTO ONCE"`

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

This command is available only in conjunction with option GSM BTS Analyzer, FSE-K11, and with option Vector Signal Analysis, FSE-B7.

TRIGger[:SEQuence]:SYNChronize:ADJust:SLOT 0 to 100s

This command defines the correction value for the time offset between the frame trigger and the midamble of the slot selected, without influencing the correction values of the other slots.
This correction value is necessary in order to conserve the exact time relation between the trigger event and the midamble of the slot in question in cases where there is no midamble triggering. The value set is corrected by means of the calculated offsets of the other slots and used as a base value for the correction of all slots.

Example: `"TRIG:SYNC:ADJ:SLOT 30us"`

Features: *RST value: -- (depending on slot selected)
SCPI: device-specific

Modes: BTS, MS

TRIGger[:SEQuence]:SYNChronize:ADJust:SLOT:AUTO ONCE

This command defines the correction value for the time offset between the frame trigger and the midamble of the slot selected. The value set is corrected by means of the calculated offsets of the other slots and used as a base value for the correction of all slots.
This correction value is necessary in order to conserve the exact time relation between the trigger event and the midamble of the slot in question in cases where there is no midamble triggering.

Example: `"TRIG:SYNC:ADJ:SLOT:AUTO ONCE"`

Features: *RST value: --
SCPI: device-specific

Modes: BTS, MS

This command is available only in conjunction with option GSM BTS Analyzer, FSE-K11, or GSM MS Analyzer, FSE-K10, and with option Vector Signal Analysis, FSE-B7.

TRIGger[:SEQuence]:SYNChronize:SOURce FRAME | TSC

This command defines the trigger reference point for measurements in the time domain (carrier power, power vs. time). The frame trigger of the base station or mobile may be selected as well as the relation to the midamble (TSC) of the slot to be measured.

Example: `"TRIG:SYNC:SOURce TSC"`

Features: *RST value: FRAME
SCPI: device-specific

Modes: BTS, MS

This command is available only in conjunction with option GSM BTS Analyzer, FSE-K11, or GSM MS Analyzer, FSE-K10. The parameter TSC requires in addition the option Vector Signal Analysis, FSE-B7.

3.6.24 UNIT Subsystem

The UNIT subsystem is used to switch the basic unit of setting parameters. In split screen mode, a distinction is made between UNIT1 (screen A) and UNIT2 (screen B).

COMMAND	PARAMETERS	UNIT	COMMENT
UNIT<1|2>			
:POWer	DBM | DBPW | WATT | DBUV | DBMV | VOLT | DBUA | AMPere V | W | DB | PCT | UNITLESS | DBUV_MHZ | DBMV_MHZ | DBUA_MHZ | DBUV_M | DBUA_M | DBUV_MMHZ | DBUA_MMHZ		
:PROBe			

UNIT<1|2>:POWer DBM | DBPW | WATT | DBUV | DBMV | VOLT | DBUA | AMPere | V | W | DB | PCT | UNITLESS | DBUV_MHZ |DBMV_MHZ | DBUA_MHZ | DBUV_M | DBUA_M | DBUV_MMHZ | DBUA_MMHZ

This command selects the default unit for input and output.

Example: `"UNIT:POW DBUV"`

Features: *RST value: DBM
SCPI: conforming

Mode: A

UNIT<1|2>:PROBe ON | OFF

This command determines whether the coding of a probe which is connected to the front panel is taken into consideration (ON) or not (OFF).

Example: `"UNIT:PROB OFF"`

Features: *RST value: ON
SCPI: device-specific

Mode: A

This page is intentionally left blank.

3.7 Instrument Model and Command Processing

The instrument model shown in Fig. 3.7-1 has been made viewed from the standpoint of the servicing of IEC-bus commands. The individual components work independently of each other and simultaneously. They communicate by means of so-called "messages".



Fig. 3.7-1 Instrument model in the case of remote control by means of the IEC bus

3.7.1 Input Unit

The input unit receives commands character by character from the IEC bus and collects them in the input buffer. The input buffer has a size of 256 characters. The input unit sends a message to the command recognition as soon as the input buffer is full or as soon as it receives a delimiter, <PROGRAM MESSAGE TERMINATOR>, as defined in IEEE 488.2, or the interface message DCL.
If the input buffer is full, the IEC-bus traffic is stopped and the data received up to then are processed. Subsequently the IEC-bus traffic is continued. If, however, the buffer is not yet full when receiving the delimiter, the input unit can already receive the next command during command recognition and execution. The receipt of a DCL clears the input buffer and immediately initiates a message to the command recognition.

3.7.2 Command Recognition

The command recognition analyses the data received from the input unit. It proceeds in the order in which it receives the data. Only a DCL is serviced with priority, a GET (Group Execute Trigger), e.g., is only executed after the commands received before as well. Each recognized command is immediately transferred to the data set but without being executed there at once.
Syntactical errors in the command are recognized here and supplied to the status reporting system. The rest of a command line after a syntax error is analysed further if possible and serviced.
If the command recognition recognizes a delimiter or a DCL, it requests the data set to set the commands in the instrument hardware as well now. Subsequently it is immediately prepared to process commands again. This means for the command servicing that further commands can already be serviced while the hardware is still being set ("overlapping execution").

3.7.3 Data Set and Instrument Hardware

Here the expression "instrument hardware" denotes the part of the instrument fulfilling the actual instrument function - signal generation, measurement etc. The controller is not included.

The data set is a detailed reproduction of the instrument hardware in the software.

IEC-bus setting commands lead to an alteration in the data set. The data set management enters the new values (e.g. frequency) into the data set, however, only passes them on to the hardware when requested by the command recognition. As this is always only effected at the end of a command line, the order of the setting commands in the command line is not relevant.

The data are only checked for their compatibility among each other and with the instrument hardware immediately before they are transmitted to the instrument hardware. If the detection is made that an execution is not possible, an "execution error" is signalled to the status reporting system. All alterations of the data set are cancelled, the instrument hardware is not reset. Due to the delayed checking and hardware setting, however, it is permissible to set impermissible instrument states within one command line for a short period of time without this leading to an error message. At the end of the command line, however, a permissible instrument state must have been reached again.

Before passing on the data to the hardware, the settling bit in the STATus:OPERation register is set (cf. Section 3.8.3.4). The hardware executes the settings and resets the bit again as soon as the new state has settled. This fact can be used to synchronize command servicing.

IEC-bus queries induce the data set management to send the desired data to the output unit.

3.7.4 Status Reporting System

The status reporting system collects information on the instrument state and makes it available to the output unit on request. The exact structure and function are described in Section 3.8

3.7.5 Output Unit

The output unit collects the information requested by the controller, which it receives from the data set management. It processes it according to the SCPI rules and makes it available in the output buffer. The output buffer has a size of 4096 characters. If the information requested is longer, it is made available "in portions" without this being recognized by the controller.
If the instrument is addressed as a talker without the output buffer containing data or awaiting data from the data set management, the output unit sends error message "Query UNTERMINATED" to the status reporting system. No data are sent on the IEC bus, the controller waits until it has reached its time limit. This behaviour is specified by SCPI.

3.7.6 Command Sequence and Command Synchronization

What has been said above makes clear that all commands can potentially be carried out overlapping. Equally, setting commands within one command line are not absolutely serviced in the order in which they have been received.

In order to make sure that commands are actually carried out in a certain order, each command must be sent in a separate command line, that is to say, with a separate IBWRT()-call.
In order to prevent an overlapping execution of commands, one of commands *OPC, *OPC? or *WAI must be used. All three commands cause a certain action only to be carried out after the hardware has been set and has settled. By a suitable programming, the contoller can be forced to wait for the respective action to occur (cf. Table 3.7-1).

Table 3.7-1 Synchronisation using *OPC, *OPC? and *WAI

Commnd	Action after the hardware has settled	Programming the controller
*OPC	Setting the opteration-complete bit in the ESR	- Setting bit 0 in the ESE - Setting bit 5 in the SRE - Waiting for service request (SRQ)
*OPC?	Writing a "1" into the output buffer	Addressing the instrument as a talker
*WAI	Continuing the IEC-bus handshake	Sending the next command

An example as to command synchronization can be found in annex D "Program Examples".

This page is intentionally left blank.

3.8 Status Reporting System

The status reporting system (cf. Fig. 3.8-2) stores all information on the present operating state of the instrument, e.g. that the instrument presently carries out an AUTORANGE and on errors which have occurred. This information is stored in the status registers and in the error queue. The status registers and the error queue can be queried via IEC bus.

The information is of a hierarchical structure. The register status byte (STB) defined in IEEE 488.2 and its associated mask register service request enable (SRE) form the uppermost level. The STB receives its information from the standard event status register (ESR) which is also defined in IEEE 488.2 with the associated mask register standard event status enable (ESE) and registers STATus:OPERation and STATus:QUEStionable which are defined by SCPI and contain detailed information on the instrument.

The IST flag ("Individual STatus") and the parallel poll enable register (PPE) allocated to it are also part of the status reporting system. The IST flag, like the SRQ, combines the entire instrument status in a single bit. The PPE fulfills an analog function for the IST flag as the SRE for the service request.

The output buffer contains the messages the instrument returns to the controller. It is not part of the status reporting system but determines the value of the MAV bit in the STB and thus is represented in Fig. 3.8-2.

3.8.1 Structure of an SCPI Status Register

Each SCPI register consists of 5 parts which each have a width of 16 bits and have different functions (cf. Fig. 3.8-1). The individual bits are independent of each other, i.e. each hardware status is assigned a bit number which is valid for all five parts. For example, bit 3 of the STATus:OPERation register is assigned to the hardware status "wait for trigger" in all five parts. Bit 15 (the most significant bit) is set to zero for all parts. Thus the contents of the register parts can be processed by the controller as positive integer.


15 14 13 12 CONDition part 3 2 1 0
15 14 13 12 PTRansition part 3 2 1 0
15 14 13 12 NTRansition part 3 2 1 0
15 14 13 12 EVENt part 3 2 1 0
& & & & & & & & & & & & & & &
15 14 13 12 ENABle part 3 2 1 0
to higher-order register
⊕ Sum bit
& = logical AND
⊕ = logical OR of all bits

Fig. 3.8-1 The status-register model

CONDition part

The CONDition part is directly written into by the hardware or the sum bit of the next lower register. Its contents reflects the current instrument status. This register part can only be read, but not written into or cleared. Its contents is not affected by reading.

PTRansition part

The Positive-TRansition part acts as an edge detector. When a bit of the CONDition part is changed from 0 to 1, the associated PTR bit decides whether the EVENt bit is set to 1.
PTR bit =1: the EVENt bit is set.
PTR bit =0: the EVENt bit is not set.
This part can be written into and read at will. Its contents is not affected by reading.

NTRansition part

The Negative-TRansition part also acts as an edge detector. When a bit of the CONDition part is changed from 1 to 0, the associated NTR bit decides whether the EVENt bit is set to 1.
NTR-Bit = 1: the EVENt bit is set.
NTR-Bit = 0: the EVENt bit is not set.
This part can be written into and read at will. Its contents is not affected by reading.

With these two edge register parts the user can define which state transition of the condition part (none, 0 to 1, 1 to 0 or both) is stored in the EVENt part.

EVENt part

The EVENt part indicates whether an event has occurred since the last reading, it is the "memory" of the condition part. It only indicates events passed on by the edge filters. It is permanently updated by the instrument. This part can only be read by the user. During reading, its contents is set to zero. In linguistic usage this part is often equated with the entire register.

ENABle part

The ENABle part determines whether the associated EVENt bit contributes to the sum bit (cf. below). Each bit of the EVENt part is ANDed with the associated ENABle bit (symbol '&'). The results of all logical operations of this part are passed on to the sum bit via an OR function (symbol '+').
ENABle-Bit = 0: the associated EVENt bit does not contribute to the sum bit
ENABle-Bit = 1: if the associated EVENT bit is "1", the sum bit is set to "1" as well.
This part can be written into and read by the user at will. Its contents is not affected by reading.

Sum bit

As indicated above, the sum bit is obtained from the EVENt and ENABle part for each register. The result is then entered into a bit of the CONDition part of the higher-order register.
The instrument automatically generates the sum bit for each register. Thus an event, e.g. a PLL that has not locked, can lead to a service request throughout all levels of the hierarchy.

Note: *The service request enable register SRE defined in IEEE 488.2 can be taken as ENABle part of the STB if the STB is structured according to SCPI. By analogy, the ESE can be taken as the ENABle part of the ESR.*

3.8.2 Overview of the Status Registers



Fig. 3.8-2 Overview of the status registers

3.8.3 Description of the Status Registers

3.8.3.1 Status Byte (STB) and Service Request Enable Register (SRE)

The STB is already defined in IEEE 488.2. It provides a rough overview of the instrument status by collecting the pieces of information of the lower registers. It can thus be compared with the CONDition part of an SCPI register and assumes the highest level within the SCPI hierarchy. A special feature is that bit 6 acts as the sum bit of the remaining bits of the status byte.
The STATUS BYTE is read out using the command "*STB?" or a serial poll.

The STB implies the SRE. It corresponds to the ENABle part of the SCPI registers as to its function. Each bit of the STB is assigned a bit in the SRE. Bit 6 of the SRE is ignored. If a bit is set in the SRE and the associated bit in the STB changes from 0 to 1, a Service Request (SRQ) is generated on the IEC bus, which triggers an interrupt in the controller if this is appropriately configured and can be further processed there.
The SRE can be set using command "*SRE" and read using "*SRE?".

Table 3.8-1 Meaning of the bits in the status byte

Bit No.	Meaning
2	**Error Queue not empty** The bit is set when an entry is made in the error queue. If this bit is enabled by the SRE, each entry of the error queue generates a Service Request. Thus an error can be recognized and specified in greater detail by polling the error queue. The poll provides an informative error message. This procedure is to be recommended since it considerably reduces the problems involved with IEC-bus control.
3	**QUEStionable status sum bit** The bit is set if an EVENt bit is set in the QUEStionable-Status register and the associated ENABle bit is set to 1. A set bit indicates a questionable instrument status, which can be specified in greater detail by polling the QUEStionable-Status register.
4	**MAV bit** (message available) The bit is set if a message is available in the output buffer which can be read. This bit can be used to enable data to be automatically read from the instrument to the controller (cf. annex D, program examples).
5	**ESB bit** Sum bit of the event status register. It is set if one of the bits in the event status register is set and enabled in the event status enable register. Setting of this bit implies an error or an event which can be specified in greater detail by polling the event status register.
6	**MSS bit** (master status smmary bit) The bit is set if the instrument triggers a service request. This is the case if one of the other bits of this registers is set together with its mask bit in the service request enable register SRE.
7	**OPERation status register sum bit** The bit is set if an EVENt bit is set in the OPERation-Status register and the associated ENABle bit is set to 1. A set bit indicates that the instrument is just performing an action. The type of action can be determined by polling the OPERation-status register.

3.8.3.2 IST Flag and Parallel Poll Enable Register (PPE)

By analogy with the SRQ, the IST flag combines the entire status information in a single bit. It can be queried by means of a parallel poll (cf. Section 3.8.4.3) or using command "*IST?".

The parallel poll enable register (PPE) determines which bits of the STB contribute to the IST flag. The bits of the STB are ANDed with the corresponding bits of the PPE, with bit 6 being used as well in contrast to the SRE. The Ist flag results from the ORing of all results. The PPE can be set using commands "*PRE" and read using command "*PRE?".

3.8.3.3 Event-Status Register (ESR) and Event-Status-Enable Register (ESE)

The ESR is already defined in IEEE 488.2. It can be compared with the EVENt part of an SCPI register. The event status register can be read out using command "*ESR?".
The ESE is the associated ENABle part. It can be set using command "*ESE" and read using command "*ESE?".

Table -3.8-2 Meaning of the bits in the event status register

Bit No.	Meaning
0	**Operation Complete** This bit is set on receipt of the command *OPC exactly when all previous commands have been executed.
1	**Request Control** This bit is set if the instrument requests the controller function. This is the case when hardcopy is outputted to a printer or a plotter via the IEC-bus.
2	**Query Error** This bit is set if either the controller wants to read data from the instrument without having send a query, or if it does not fetch requested data and sends new instructions to the instrument instead. The cause is often a query which is faulty and hence cannot be executed.
3	**Device-dependent Error** This bit is set if a device-dependent error occurs. An error message with a number between -300 and -399 or a positive error number, which denotes the error in greater detail, is entered into the error queue (cf. annex B, Error Messages).
4	**Execution Error** This bit is set if a received command is syntactically correct, however, cannot be performed for other reasons. An error message with a number between -200 and -300, which denotes the error in greater detail, is entered into the error queue (cf. annex B, Error Messages).
5	**Command Error** This bit is set if a command which is undefined or syntactically incorrect is received. An error message with a number between -100 and -200, which denotes the error in greater detail, is entered into the rror queue (cf. annex B, -Error Messages).
6	**User Request** This bit is set on pressing the *LOCAL* key.
7	**Power On** (supply voltage on) This bit is set on switching on the instrument.

3.8.3.4 STATus:OPERation Register

In the CONDition part, this register contains information on which actions the instrument is being executing or, in the EVENt part, information on which actions the instrument has executed since the last reading. It can be read using commands `"STATus:OPERation:CONDition?"` or `"STATus:OPERation[:EVENt]?"`.

Table 3.8-3 Meaning of the bits in the STATus.OPERation register

Bit No.	Meaning
0	**CALibrating** This bit is set as long as the instrument is performing a calibration.
1	**SETTling** This bit is set as long as the new status is settling after a setting command. It is only set if the settling time is longer than the command processing time.
2	**RANGing** This bit is set as long as the instrument is changing a range (e.g. Autorange).
3	**SWEeping** This bit is set while the instrument is performing a sweep.
4	**MEASuring** This bit is set while the instrument is performing a measurement.
5	**WAIT for TRIGGER** This bit is set as long as the instrument is waiting for a trigger event.
6	**WAIT for ARM** This bit is set as long as the instrument is waiting for an arming event.
7	**CORRecting** This bit is set while the instrument is performing a correction.
8	**HardCOPy in progress** This bit is set while the instrument is printing a hardcopy.
9-12	Device dependent
13	**INSTrument Summary Bit** This bit is set when one or more logical instruments is reporting a status message.
14	**PROGram running** This bit is set while the instrument is performing a program.
15	This bit is always 0

The FSE supports bits 0 and 8.

3.8.3.5 STATus:QUEStionable Register

This register comprises information about indefinite states which may occur if the unit is operated without meeting the specifications. It can be queried by commands `STATus:QUEStionable:CONDition?` and `STATus:QUEStionable[:EVENt]?`.

Table 3.8-4 Meaning of bits in STATus:QUEStionable register

Bit No.	Meaning
0	**VOLTage** This bit is set if a questionable voltage occurs.
1	**CURRent** This bit is set if a questionable current occurs.
2	**TIME** This bit is set if a questionable time occurs.
3	**POWer** This bit is set if a questionable power occurs (cf. also section "STATus:QUEStionable:POWerRegister")
4	**TEMPerature** This bit is set if a questionable temperature occurs.
5	**FREQuency** The bit is set if a frequency is questionable (cf. section "STATus:QUEStionable:FREQuency Register")
6	**PHASe** The bit is set if a phase value is questionable.
7	**MODulation** The bit is set if a modulation is performed questionably.
8	**CALibration** The bit is set if a measurement is performed uncalibrated (≙ label "UNCAL")
9	**LIMit** (unit-dependent) This bit is set if a limit value is violated (see also section STATus:QUEStionable:LIMit Register)
10	**LMARgin** (unit-dependent) This bit is set if a margin is violated (see also section STATus:QUEStionable:LMARgin Register)
11	**SYNC** (unit-dependent) This bit is set if, during measurements with Option B7 (Signal Vector Analysis), the synchronization with midamble or a successful search for bursts cannot be performed (see also STATus:QUEStionable:SYNC Register)
12	**ACPLimit** (unit-dependent) This bit is set if a limit for the adjacent channel power measurement is violated (see also section STATus:QUEStionable:ACPLimit Register)
13	**TRANsducer break** This bit is set when the limit of the transducer set subrange is attained.
14	**COMMand Warning** This bit is set if the instrument ignores parameters when executing a command.
15	This bit is always 0.

The FSE supports bits 3, 5, 7, 8, 9, 10, 11, 12 and 13, bits 7 (MODulation) and 11 (SYNC) only with option FSE-B7, Vector Signal Analysis'.

3.8.3.6 STATus QUEStionable:ACPLimit Register

This register comprises information about the observance of limits during adjacent power measurements. It can be queried with commands 'STATus:QUEStionable:ACPLimit :CONDition?' and 'STATus:QUEStionable:ACPLimit[:EVENt]?'

Table 3.8-5 Meaning of bits in STATus:QUEStionable:ACPLimit register

Bit No.	Meaning
0	**ADJ UPPer FAIL(Screen A)** This bit is set if the limit is exceeded in the upper adjacent channel.
1	**ADJ LOWer FAIL (Screen A)** This bit is set if the limit is exceeded in the lower adjacent channel.
2	**ALT1 UPPer FAIL (Screen A)** This bit is set if the limit is exceeded in the upper 1st alternate channel.
3	**ALT1 LOWer FAIL (Screen A)** This bit is set if the limit is exceeded in the lower 1st alternate channel.
4	**ALT2 UPPer FAIL (Screen A)** This bit is set if the limit is exceeded in the upper 2nd alternate channel.
5	**ALT2 LOWer FAIL (Screen A)** This bit is set if the limit is exceeded in the lower 2nd alternate channel.
6	not used
7	**C0 (REF) FAIL (Screen A)** This bit is set if the limit is exceeded in the reference channel.
8	**ADJ UPPer FAIL (Screen B)** This bit is set if the limit is exceeded in the upper adjacent channel.
9	**ADJ LOWer FAIL (Screen B)** This bit is set if the limit is exceeded in the lower adjacent channel.
10	**ALT1 UPPer FAIL (Screen B)** This bit is set if the limit is exceeded in the upper 1st alternate channel.
11	**ALT1 LOWer FAIL (Screen B)** This bit is set if the limit is exceeded in the lower 1st alternate channel.
12	**ALT2 UPPer FAIL (Screen B)** This bit is set if the limit is exceeded in the upper 2nd alternate channel.
13	**ALT2 LOWer FAIL (Screen A)** This bit is set if the limit is exceeded in the lower 2nd alternate channel.
14	not used
15	**C0 (REF) FAIL (Screen B)** This bit is set if the limit is exceeded in the reference channel.

3.8.3.7 STATus QUEStionable:FREQuency Register

This register comprises information about the reference and local oscillator.
It can be queried with commands `STATus:QUEStionable:FREQuency:CONDition?` and "`STATus:QUEStionable:FREQuency[:EVENt]?`.

Table 3.8-6 Meaning of bits in STATus:QUEStionable:FREQuency register

Bit No.	Meaning
0	**OVEN COLD** This bit is set if the reference oscillator has not yet attained its operating temperature. 'OCXO' will then be displayed.
1	**LO UNLocked** (Screen A) This bit is set if the local oscillator no longer locks. 'LO unl' will then be displayed.
2	**LO LEVel** (Screen A) This bit is set if the level of the local oscillator is smaller than the nominal value. 'LO LVL' will then be displayed.
3	not used
4	not used
5	not used
6	not used
7	not used
8	not used
9	**LO UNLocked** (Screen B) This bit is set if the local oscillator no longer locks.' LO unl' will then be displayed.
10	**LO LEVel** (Screen B) This bit is set if the level of the local oscillator is smaller than the nominal value. 'LO LVL' will then be displayed.
11	not used
12	not used
13	not used
14	not used
15	This bit is always 0.

3.8.3.8 STATus QUEStionable:LIMit Register

This register comprises information about the observance of limit lines. It can be queried with commands `STATus:QUEStionable:LIMit:CONDition?` and `STATus:QUEStionable:LIMit[:EVENt]?`.

Table3.8-7 Meaning of bits in STATus:QUEStionable:LIMit register

Bit No.	Meaning
0	**LIMit 1 FAIL** This bit is set if limit line 1 is violated.
1	**LIMit 2 FAIL** This bit is set if limit line 2 is violated.
2	**LIMit 3 FAIL** This bit is set if limit line 3 is violated.
3	**LIMit 4 FAIL** This bit is set if limit line 4 is violated.
4	**LIMit 5 FAIL** This bit is set if limit line 5 is violated.
5	**LIMit 6 FAIL** This bit is set if limit line 6 is violated.
6	**LIMit 7 FAIL** This bit is set if limit line 7 is violated.
7	**LIMit 8 FAIL** This bit is set if limit line 8 is violated.
8	not used
9	not used
10	not used
11	not used
12	not used
13	not used
14	not used
15	This bit is always 0.

3.8.3.9 STATus QUEStionable:LMARgin Register

This register comprises information about the observance of limit margins. It can be queried with commands `STATus:QUEStionable:LMARgin:CONDition?` and `"STATus:QUEStionable:LMARgin[:EVENt]?`.

Table3.8-8 Meaning of bits in STATus:QUEStionable:LMARgin register

Bit No.	Meaning
0	**LMARgin 1 FAIL** This bit is set if limit margin 1 is violated.
1	**LMARgin 2 FAIL** This bit is set if limit margin 2 is violated.
2	**LMARgin 3 FAIL** This bit is set if limit margin 3 is violated.
3	**LMARgin 4 FAIL** This bit is set if limit margin 4 is violated.
4	**LMARgin 5 FAIL** This bit is set if limit margin 5 is violated.
5	**LMARgin 6 FAIL** This bit is set if limit margin 1 is violated.
6	**LMARgin 7 FAIL** This bit is set if limit margin 7 is violated.
7	**LMARgin 8 FAIL** This bit is set if limit margin 8 is violated.
8	not used
9	not used
10	not used
11	not used
12	not used
13	not used
14	not used
15	This bit is always 0.

3.8.3.10 STATus QUEStionable:POWer Register

This register comprises all information about possible overloads of the unit.
It can be queried with commands `STATus:QUEStionable :POWer:CONDition?` and "`STATus :QUEStionable:POWer [:EVENt]?`.

Table3.8-9 Meaning of bits in STATus:QUEStionable:POWer register

Bit No.	Meaning
0	**OVERload** (Screen A) This bit is set if the RF input is overloaded. 'OVLD' will then be displayed.
1	**UNDerload** (Screen A) - Option FSE-B7 This bit is set if, during measurements in vector analyzer mode without capture buffer used, the lower level limit in the IF path is violated.
2	**IF_OVerload** (Screen A) This bit is set if the IF path is overloaded. 'IFOVLD' will then be displayed.
3	not used
4	not used
5	not used
6	not used
7	not used
8	**OVERload** (Screen B) This bit is set if the RF input is overloaded. 'OVLD' will then be displayed.
9	**UNDerload** (Screen B) - Option FSE-B7 This bit is set if, during measurements without capture buffer used, the lower level limit in the IF path is violated.
10	**IF_OVerload** (Screen B) This bit is set if the IF path is overloaded. 'IFOVLD' will then be displayed.
11	not used
12	not used
13	not used
14	not used
15	This bit is always 0.

3.8.3.11 STATus QUEStionable:SYNC Register

This register comprises information about sync and burst events.
It can be queried with commands `STATus:QUEStionable:SYNC:CONDition?` and `"STATus:QUEStionable:SYNC[:EVENt]?`.

Table 3.8-10 Meaning of bits in STATus:QUEStionable:SYNC register

Bit No.	Meaning
0	**SYNC not found** This bit is set if the sync sequence of midamble was not found.
1	**BURSt not found** This bit is set if a burst was not found.
2	not used
3	not used
4	not used
5	not used
6	not used
7	not used
8	not used
9	not used
10	not used
11	not used
12	not used
13	not used
14	not used
15	This bit is always 0.

3.8.3.12 STATus QUEStionable:TRANsducer Register

This register indicates that a transducer hold point is attained (bit 15) and what range is to be swept next (bit 0 to 10). The sweep can be continued with command `INITiate:CONMeasure`.
It can be queried with commands `STATus:QUEStionable:TRANsducer:CONDition?` and "`STATus:QUEStionable:TRANsducer[:EVENt]?`.

Table 3.8-11 Meaning of bits in STATus:QUEStionable:TRANsducer register

Bit No.	Meaning
0	**Range 1** This bit is set when subrange 1 is attained.
1	**Range 2** This bit is set when subrange 2 is attained.
2	**Range 3** This bit is set when subrange 3 is attained.
3	**Range 4** This bit is set when subrange 4 is attained.
4	**Range 5** This bit is set when subrange 1 is attained.
5	**Range 6** This bit is set when subrange 6 is attained.
6	**Range 7** This bit is set when subrange 7 is attained.
7	**Range 8** This bit is set when subrange 8 is attained.
8	**Range 9** This bit is set when subrange 9 is attained.
9	**Range 10** This bit is set when subrange 10 is attained.
10	**not used**
11	**not used**
12	**not used**
13	**not used**
14	**Subrange limit** This bit is set when the transducer is at the point of changeover from one range to another.
15	This bit is always 0.

3.8.4 Application of the Status Reporting Systems

In order to be able to effectively use the status reporting system, the information contained there must be transmitted to the controller and further processed there. There are several methods which are represented in the following. Detailed program examples are to be found in annex D, Program Examples.

3.8.4.1 Service Request, Making Use of the Hierarchy Structure

Under certain circumstances, the instrument can send a service request (SRQ) to the controller. Usually this service request initiates an interrupt at the controller, to which the control program can react with corresponding actions. As evident from Fig. 3.8-1 (Section 3.8.2), an SRQ is always initiated if one or several of bits 2, 3, 4, 5 or 7 of the status byte are set and enabled in the SRE. Each of these bits combines the information of a further register, the error queue or the output buffer. The corresponding setting of the ENABle parts of the status registers can achieve that arbitrary bits in an arbitrary status register initiate an SRQ. In order to make use of the possibilities of the service request, all bits should be set to "1" in enable registers SRE and ESE.

Examples (cf. Fig. 3.8-1 and annex D, Program Examples, as well):

Use of command "*OPC" to generate an SRQ at the end of a sweep.

- Set bit 0 in the ESE (Operation Complete)
- Set bit 5 in the SRE (ESB)?

  After its settings have been completed, the instrument generates an SRQ.

The SRQ is the only possibility for the instrument to become active on its own. Each controller program should set the instrument such that a service request is initiated in the case of malfunction. The program should react appropriately to the service request. A detailed example for a service request routine is to be found in annex D, Program Examples.

3.8.4.2 Serial Poll

In a serial poll, just as with command "*STB", the status byte of an instrument is queried. However, the query is realized via interface messages and is thus clearly faster. The serial-poll method has already been defined in IEEE 488.1 and used to be the only standard possibility for different instruments to poll the status byte. The method also works with instruments which do not adhere to SCPI or IEEE 488.2.

The quick-BASIC command for executing a serial poll is "IBRSP()". Serial poll is mainly used to obtain a fast overview of the state of several instruments connected to the IEC bus.

3.8.4.3 Parallel Poll

In a parallel poll, up to eight instruments are simultaneously requested by the controller by means of a single command to transmit 1 bit of information each on the data lines, i.e., to set the data line allocated to each instrument to logically "0" or "1". By analogy to the SRE register which determines under which conditions an SRQ is generated, there is a parallel poll enable register (PPE) which is ANDed with the STB bit by bit as well considering bit 6. The results are ORed, the result is then sent (possibly inverted) as a response in the parallel poll of the controller. The result can also be queried without parallel poll by means of command "*IST".

The instrument first has to be set for the parallel poll using quick-BASIC command "IBPPC()". This command allocates a data line to the instrument and determines whether the response is to be inverted. The parallel poll itself is executed using "IBRPP()".

The parallel-poll method is mainly used in order to quickly find out after an SRQ which instrument has sent the service request if there are many instruments connected to the IEC bus. To this effect, SRE and PPE must be set to the same value. A detailed example as to the parallel poll is to be found in annex D, Program Examples.

3.8.4.4 Query by Means of Commands

Each part of every status register can be read by means of queries. The individual commands are indicated in the detailed description of the registers in Section 3.8.3. What is returned is always a number which represents the bit pattern of the register queried. Evaluating this number is effected by the controller program.

Queries are usually used after an SRQ in order to obtain more detailed information on the cause of the SRQ.

3.8.4.5 Error-Queue Query

Each error state in the instrument leads to an entry in the error queue. The entries of the error queue are detailed plain-text error messages which can be looked at in the ERROR menu via manual control or queried via the IEC bus using command "SYSTem:ERRor?". Each call of "SYSTem:ERRor?" provides an entry from the error queue. If no error messages are stored there any more, the instrument responds with 0, "No error".

The error queue should be queried after every SRQ in the controller program as the entries describe the cause of an error more precisely than the status registers. Especially in the test phase of a controller program the error queue should be queried regularly since faulty commands from the controller to the instrument are recorded there as well.

3.8.5 Resetting Values of the Status Reporting System

Table 3.8-12 comprises the different commands and events causing the status reporting system to be reset. None of the commands, except for *RST and SYSTem:PRESet influences the functional instrument settings. In particular, DCL does not change the instrument settings.

Table 3.8-12 Resettting instrument functions

Event / Effect	Switching on supply voltage: Power-On-Status-Clear 0	Switching on supply voltage: Power-On-Status-Clear 1	DCL,SDC (Device Clear, Selected Device Clear)	*RST or SYSTem:PRESet	STATus:PRESet	*CLS
Clear STB,ESR	—	yes	—	—	—	yes
Clear SRE,ESE	—	yes	—	—	—	—
Clear PPE	—	yes	—	—	—	—
Clear EVENTt parts of the registers	—	yes	—	—	—	yes
Clear Enable parts of all OPERation and QUEStionable registers, Fill Enable parts of all other registers with "1".	—	yes	—	—	yes	—
Fill PTRansition parts with "1", Clear NTRansition parts	—	yes	—	—	yes	—
Clear error queue	yes	yes	—	—	—	yes
Clear output buffer	yes	yes	yes	1)	1)	1)
Clear command processing and input buffer	yes	yes	yes	—	—	—

1) Every command being the first in a command line, i.e., immediately following a <PROGRAM MESSAGE TERMINATOR> clears the output buffer.

This page is intentionally left blank.

3.9 Table of Softkeys with IEC/IEEE-Bus Command Assignment

3.9.1 Basic Instrument - Signal Analysis Mode

3.9.1.1 FREQUENCY Key Group

```
[SENSe:]FREQuency:STARt <num_value>
```

```
[SENSe:]FREQuency:STARt:LINK CENTer
```

```
[SENSe:]FREQuency:STARt:LINK SPAN
```

```
[SENSe:]FREQuency:STARt:LINK STOP
```

```
[SENSe:]SWEep:SPACing LIN | LOG
```

```
[SENSe:]FREQuency:STOP <num_value>
```

```
[SENSe:]FREQuency:STOP:LINK STARt
```

```
[SENSe:]FREQuency:STOP:LINK CENTer
```

```
[SENSe:]FREQuency:STOP:LINK SPAN
```




```
[SENSe:]SWEep:SPACing LIN | LOG
```

```
[SENSe:]FREQuency:CENTer <num_value>
```

```
[SENSe:]FREQuency:CENTer:LINK STARt
```

```
[SENSe:]FREQuency:CENTer:LINK SPAN
```




```
[SENSe:]FREQuency:CENTer:LINK STOP
```




```
[SENSe:]FREQuency:OFFSet <num_value>
```




```
[SENSe:]SWEep:SPACing LIN | LOG
```

STEP

AUTO 0.1 * SPAN	[SENSe:]FREQuency:CENTer:STEP:LINK SPAN; [SENSe:]FREQuency:CENTer:STEP:LINK:FACTor 10PCT
or	
AUTO 0.1 * RBW	[SENSe:]FREQuency:CENTer:STEP:LINK RBW; [SENSe:]FREQuency:CENTer:STEP:LINK:FACTor 10PCT
AUTO 0.5 * SPAN	[SENSe:]FREQuency:CENTer:STEP:LINK SPAN; [SENSe:]FREQuency:CENTer:STEP:LINK:FACTor 50PCT
or	
AUTO 0.5 * RBW	[SENSe:]FREQuency:CENTer:STEP:LINK RBW; [SENSe:]FREQuency:CENTer:STEP:LINK:FACTor 50PCT
AUTO X * SPAN	[SENSe:]FREQuency:CENTer:STEP:LINK SPAN; [SENSe:]FREQuency:CENTer:STEP:LINK:FACTor <num_value>
or	
AUTO X * RBW	[SENSe:]FREQuency:CENTer:STEP:LINK RBW; [SENSe:]FREQuency:CENTer:STEP:LINK:FACTor <num_value>
STEPSIZE MANUAL	[SENSe:]FREQuency:CENTer:STEP <num_value>
STEPSIZE = CENTER	no corresponding IEC/IEEE-bus command

SPAN

SPAN MANUAL	[SENSe:]FREQuency:SPAN <num_value>
START FIXED	[SENSe:]FREQuency:SPAN:LINK START
CENTER FIXED	[SENSe:]FREQuency:SPAN:LINK CENTer
STOP FIXED	[SENSe:]FREQuency:SPAN:LINK STOP
ZERO SPAN	[SENSe:]FREQuency:SPAN 0HZ
FULL SPAN	[SENSe:]FREQuency:SPAN:FULL
LAST SPAN	no corresponding IEC/IEEE-bus command
ZOOM	DISPlay[:WINDow<1|2>]:TRACe<1...4>:X[:SCALe]:ZOOM ON| OFF
MOVE ZOOM WINDOW	DISPlay[:WINDow<1|2>]:TRACe<1...4>:X[:SCALe]:ZOOM[:FREQuency]:CENTer <num_value>
MOVE ZOOM START	DISPlay[:WINDow<1|2>]:TRACe<1...4>:X[:SCALe]:ZOOM[:FREQuency]:STARt <num_value>
MOVE ZOOM STOP	DISPlay[:WINDow<1|2>]:TRACe<1...4>:X[:SCALe]:ZOOM[:FREQuency]:STOP <num_value>
ZOOM OFF	DISPlay[:WINDow<1|2>]:TRACe<1...4>:X[:SCALe]:ZOOM OFF
FREQ AXIS LIN LOG	[SENSe:]SWEep:SPACing LIN | LOG

3.9.1.2 LEVEL Key Group

REF	
REF LEVEL	DISPlay[:WINDow<1|2>]:TRACe<1...4>:Y[:SCALe]:RLEVel <num_value>
REF LEVEL OFFSET	DISPlay[:WINDow<1|2>]:TRACe<1...4>:Y[:SCALe]:RLEVel:OFFSet <num_value>
GRID ABS/REL	DISPlay[:WINDow<1|2>]:TRACe<1...4>:Y[:SCALe]:MODE ABSolute|RELative
UNIT	--
dBm	CALCulate<1|2>:UNIT:POWer DBM
dBmV	CALCulate<1|2>:UNIT:POWer DBMV
dBµV	CALCulate<1|2>:UNIT:POWer DBUV
dBµA	CALCulate<1|2>:UNIT:POWer DBUA
dBpW	CALCulate<1|2>:UNIT:POWer DBPW
dB*/MHz	CALCulate<1|2>:UNIT:POWer DBUV_MHZ CALCulate<1|2>:UNIT:POWer DBUA_MHZ CALCulate<1|2>:UNIT:POWer DBMV_MHZ
VOLT	CALCulate<1|2>:UNIT:POWer VOLT
AMPERE	CALCulate<1|2>:UNIT:POWer AMPere
WATT	CALCulate<1|2>:UNIT:POWer WATT
PROBE CODE ON / OFF	UNIT:PROBe ON|OFF
RF ATTEN MANUAL	INPut:ATTenuation <num_value>
ATTEN AUTO NORMAL	INPut:ATTenuation:AUTO:MODE NORMal; INPut:ATTenuation:AUTO ON
ATTEN AUTO LOW NOISE	INPut:ATTenuation:AUTO:MODE LNOise; INPut:ATTenuation:AUTO ON
ATTEN AUTO LOW DIST	INPut:ATTenuation:AUTO:MODE LDIStortion; INPut:ATTenuation:AUTO ON
MIXER LEVEL	INPut:MIXer <num_value>
MAX LEVEL AUTO	DISPlay[:WINDow<1|2>]:TRACe<1...4>:Y[:SCALe]:RVALue:AUTO ON
MAX LEVEL MANUAL	DISPlay[:WINDow<1|2>]:TRACe<1...4>:Y[:SCALe]:RVALue:AUTO OFF; DISPlay[:WINDow<1|2>]:TRACe<1...4>:Y[:SCALe]:RVALue <num_value>

RANGE	
LINEAR/%	DISPlay[:WINDow<1|2>]:TRACe<1...4>:Y:SPACing PERCent
LINEAR/dB	DISPlay[:WINDow<1|2>]:TRACe<1...4>:Y:SPACing LINear
LOG MANUAL	DISPlay[:WINDow<1|2>]:TRACe<1...4>:Y:SPACing LOGarithmic; DISPlay[:WINDow<1|2>]:TRACe<1...4>:Y[:SCALe] <num_value>

3.9.1.3 INPUT Key

INPUT	
RF ATTEN MANUAL	INPut:ATTenuation <num_value>
ATTEN AUTO NORMAL	INPut:ATTenuation:AUTO:MODE NORMal; INPut:ATTenuation:AUTO ON
ATTEN AUTO LOW NOISE	INPut:ATTenuation:AUTO:MODE LNOise; INPut:ATTenuation:AUTO ON
ATTEN AUTO LOW DIST	INPut:ATTenuation:AUTO:MODE LDIStortion; INPut:ATTenuation:AUTO ON
MIXER LEVEL	INPut:MIXer <num_value>
INPUT SELECT	--
RF INPUT 50 OHM	INPut:IMPedance 50
RF INPUT 75 OHM/RAM	INPut:IMPedance:CORRection RAM
RF INPUT 75OHM/RAZ	INPut:IMPedance:CORRection RAZ

3.9.1.4 MARKER Key Group

NORMAL	
MARKER 1..4	CALCulate<1|2>:MARKer<1...4>[:STATe] ON | OFF; CALCulate<1|2>:MARKer<1...4>:X <num_value>; CALCulate<1|2>:MARKer<1...4>:Y?
SIGNAL COUNT	CALCulate<1|2>:MARKer<1...4>:COUNt ON | OFF; CALCulate<1|2>:MARKer<1...4>:COUNt:FREQuency?
MARKER DEMOD	--

MKR DEMOD ON/OFF	CALCulate<1|2>:MARKer<1...4>:FUNCtion:DEModulation[:STATe] ON | OFF
AM	CALCulate<1|2>:MARKer<1...4>:FUNCtion:DEModulation:SELect AM
FM	CALCulate<1|2>:MARKer<1...4>:FUNCtion:DEModulation:SELect FM
MKR STOP TIME	CALCulate<1|2>:MARKer<1..4>:FUNCtion:DEModulation:HOLDoff <num_value>
VOLUME	SYSTem:SPEaker:VOLume <num_value>
MARKER ZOOM	CALCulate<1|2>:MARKer<1...4>:FUNCtion:ZOOM <num_value>
MARKER INFO	DISPlay:WINDow<1|2>:MINFo ON | OFF (indication)
ALL MARKER OFF	CALCulate<1|2>:MARKer<1...4>:AOFF
POWER MEAS SETTINGS	--
SET NO OF ADJ CHAN'S	[SENSe:]POWer:ACHannel:ACPairs
ACP STANDARD	CALCulate<1|2>:MARKer<1...4>:FUNCtion:POWer:PRESet NADC | TETRA | PDC | PHS | CDPD | F8DCma | R8CDma | F19DCma | F8DCma | R8CDma | F19DCma | NONE
CH FILTER ON/OFF	CALCulate<1|2>:MARKer<1...4>:FUNCtion:POWer:CFILter ON | OFF
CHANNEL BANDWIDTH	[SENSe:]POWer:ACHannel:BANDwidth|BWIDth[:CHANnel] <num_value> [SENSe:]POWer:ACHannel:BANDwidth|BWIDth:ACHannel <num_value> [SENSe:]POWer:ACHannel:BANDwidth|BWIDth:ALTernate<1|2> <num_value>
CHANNEL SPACING	[SENSe:]POWer:ACHannel:SPACing[:UPPer] <num_value> [SENSe:]POWer:ACHannel:SPACing:ACHannel <num_value> [SENSe:]POWer:ACHannel:SPACing:ALTernate<1|2> <num_value>
EDIT ACP LIMITS	CALCulate<1|2>:LIMit<1...8>:ACPower:ACHannel <num_value>,<num_value> CALCulate<1|2>:LIMit<1...8>:ACPower:ACHannel:STATe ON | OFF CALCulate<1|2>:LIMit<1...8>:ACPower:ALTernate<1|2> <num_value>, <num_value> CALCulate<1|2>:LIMit<1...8>:ACPower:ALTernate<1|2>:STATe ON | OFF
LIMIT CHECK	CALCulate<1|2>:LIMit:ACPower[:STATe] ON | OFF CALCulate<1|2>:LIMit<1...8>:ACPower:ACHannel:RESult? CALCulate<1|2>:LIMit<1...8>:ACPower:ALTernate<1|2>:RESult?
% POWER BANDWIDTH	[SENSe:]POWer: BANDwidth|BWIDth <num_value>
CHANNEL POWER	CALCulate<1|2>:MARKer<1...4>:FUNCtion:POWer:SELect CPOWer; CALCulate<1|2>:MARKer<1...4>:FUNCtion:POWer:RESult? CPOWer; CALCulate<1|2>:MARKer<1...4>:FUNCtion:POWer[:STATe] OFF
CP/ACP ABS/REL	[SENSe:]POWer:ACHannel:MODE ABSolute|RELative
SET CP REFERENCE	[SENSe:]POWer:ACHannel:REFerence:AUTO ONCE
C/N	CALCulate<1|2>:MARKer<1...4>:FUNCtion:POWer:SELect CN; CALCulate<1|2>:MARKer<1...4>:FUNCtion:POWer:RESult? CN; CALCulate<1|2>:MARKer<1...4>:FUNCtion:POWer[:STATe] OFF

C/No	CALCulate<1|2>:MARKer<1...4>:FUNCtion:POWer:SELect CN0; CALCulate<1|2>:MARKer<1...4>:FUNCtion:POWer:RESult? CN0; CALCulate<1|2>:MARKer<1...4>:FUNCtion:POWer[:STATe] OFF
ADJACENT CHAN POWER	CALCulate<1|2>:MARKer<1...4>:FUNCtion:POWer:SELect ACPower; CALCulate<1|2>:MARKer<1...4>:FUNCtion:POWer:RESult? ACPower; CALCulate<1|2>:MARKer<1...4>:FUNCtion:POWer[:STATe] OFF
ADJUST CP SETTINGS	[SENSe:]POWer:ACHannel:PRESet ACPower|CPOWer|OBANdwidth|OBWidth|CN|CN0
OCCUPIED PWR BANDW	CALCulate<1|2>:MARKer<1...4>:FUNCtion:POWer:SELect OBANdwidth | OBWidth CALCulate<1|2>:MARKer<1...4>:FUNCtion:POWer:RESult? OBANdwidth| OBWidth CALCulate<1|2>:MARKer<1...4>:FUNCtion:POWer[:STATe] OFF
COUNTER RESOL	CALCulate<1|2>:MARKer<1...4>:COUNt:RESolution <num_value>
SIGNAL TRACK	CALCulate<1|2>:MARKer<1...4>:FUNCtion:STRack[:STATe] ON | OFF
NOISE	CALCulate<1|2>:MARKer<1...4>:FUNCtion:NOISe[:STATe] ON | OFF; CALCulate<1|2>:MARKer<1...4>:FUNCtion:NOISe:RESult?
STEP	
STEPSIZE AUTO	CALCulate<1|2>:MARKer<1...4>:STEP:AUTO ON | OFF
STEPSIZE MANUAL	CALCulate<1|2>:MARKer<1...4>:STEP[:INCRement] <num_value>
MKR TO STEPSIZE	CALCulate<1|2>:MARKer<1...4>:FUNCtion:MSTep
DELTA TO STEPSIZE	--

DELTA

DELTA 1...4
```
CALCulate<1|2>:DELTamarker<1...4>[:STATe]  ON | OFF
CALCulate<1|2>:DELTamarker<1...4>:X <num_value>
CALCulate<1|2>:DELTamarker<1...4>:X:RELative?
CALCulate<1|2>:DELTamarker<1...4>:Y?
```

PHASE NOISE
```
CALCulate<1|2>:DELTamarker<1...4>:FUNCtion:PNOise[:STATe]  ON | OFF
CALCulate<1|2>:DELTamarker<1...4>:FUNCtion:PNOise:RESult?
```

REFERENCE POINT
```
--
```

REF POINT LEVEL
```
CALCulate<1|2>:DELTamarker<1..4>:FUNCtion:FIXed:RPOint:Y <num_value>
```

REF POINT LVL OFFSET
```
CALCulate<1|2>:DELTamarker<1..4>:FUNCtion:FIXed:RPOint:Y:OFFSet
                                                          <num_value>
```

REF POINT FREQUENCY
```
CALCulate<1|2>:DELTamarker<1..4>:FUNCtion:FIXed:RPOint:X  <num_value>
```

REF POINT TIME
```
CALCulate<1|2>:DELTamarker<1..4>:FUNCtion:FIXed:RPOint:X  <num_value>
```

REFERENCE FIXED
```
CALCulate<1|2>:DELTamarker<1...4>:FUNCtion:FIXed[:STATe]  ON | OFF
```

DELTA MKR ABS REL
```
CALCulate<1|2>:DELTamarker<1...4>:MODE  ABSolute | RELative
```

ALL DELTA OFF
```
CALCulate<1|2>:DELTamarker<1...4>:AOFF
```

STEP

STEPSIZE AUTO
```
CALCulate<1|2>:DELTamarker<1...4>:STEP:AUTO ON | OFF
```

MANUAL STEPSIZE
```
CALCulate<1|2>:DELTamarker<1...4>:STEP[:INCRement] <num_value>
```

DELTA TO STEPSIZE
```
--
```

SEARCH

PEAK
```
CALCulate<1|2>:MARKer<1...4>:MAXimum[:PEAK]
CALCulate<1|2>:DELTamarker<1...4>:MAXimum[:PEAK]
```

NEXT PEAK
```
CALCulate<1|2>:MARKer<1...4>:MAXimum:NEXT
CALCulate<1|2>:DELTamarker<1...4>:MAXimum:NEXT
```

NEXT PEAK RIGHT
```
CALCulate<1|2>:MARKer<1...4>:MAXimum:RIGHt
CALCulate<1|2>:DELTamarker<1...4>:MAXimum:RIGHt
```

NEXT PEAK LEFT
```
CALCulate<1|2>:MARKer<1...4>:MAXimum:LEFT
CALCulate<1|2>:DELTamarker<1...4>:MAXimum:LEFT
```

SUM MKR ON/OFF
```
CALCulate<1|2>:MARKer<1...4>:FUNCtion:SUMMary:STATe ON | OFF
```

SUMMARY MARKER

RMS
```
CALCulate<1|2>:MARKer<1...4>:FUNCtion:SUMMary:RMS[:STATe] ON | OFF
CALCulate<1|2>:MARKer<1...4>:FUNCtion:SUMMary:RMS:RESult?
CALCulate<1|2>:MARKer<1...4>:FUNCtion:SUMMary:RMS:AVERage:RESult?
CALCulate<1|2>:MARKer<1...4>:FUNCtion:SUMMary:RMS:PHOLd:RESult?
```

MEAN
```
CALCulate<1|2>:MARKer<1...4>:FUNCtion:SUMMary:MEAN[:STATe]  ON | OFF
CALCulate<1|2>:MARKer<1...4>:FUNCtion:SUMMary:MEAN:RESult?
CALCulate<1|2>:MARKer<1...4>:FUNCtion:SUMMary:MEAN:AVERage:RESult?
CALCulate<1|2>:MARKer<1...4>:FUNCtion:SUMMary:MEAN:PHOLd:RESult?
```

PEAK HOLD ON/OFF
```
CALCulate<1|2>:MARKer<1...4>:FUNCtion:SUMMary:PHOLd ON | OFF
```

AVERAGE ON/OFF
```
CALCulate<1|2>:MARKer<1...4>:FUNCtion:SUMMary:AVERage ON | OFF
```

SWEEP COUNT
```
[SENSe:]SWEep:COUNt <num_value>
```

ALL SUM MKR OFF
```
CALCulate<1|2>:MARKer<1...4>:FUNCtion:SUMMary:AOFF
```

SEARCH LIM ON/OFF
```
CALCulate<1|2>:MARKer<1...4>:X:SLIMits[STATe] ON | OFF
```

SELECT MARKER

no corresponding IEC/IEEE-bus command

ACTIVE MKR/DELTA

no corresponding IEC/IEEE-bus command

MIN
```
CALCulate<1|2>:MARKer<1...4>:MINimum[:PEAK]
CALCulate<1|2>:DELTamarker<1...4>:MINimum[:PEAK]
```

NEXT MIN
```
CALCulate<1|2>:MARKer<1...4>:MINimum:NEXT
CALCulate<1|2>:DELTamarker<1...4>:MINimum:NEXT
```

NEXT MIN LEFT
```
CALCulate<1|2>:MARKer<1...4>:MINimum:LEFT
CALCulate<1|2>:DELTamarker<1...4>:MINimum:LEFT
```

NEXT MIN RIGHT
```
CALCulate<1|2>:MARKer<1...4>:MINimum:RIGHt
CALCulate<1|2>:DELTamarker<1...4>:MINimum:RIGHt
```

EXCLUDE LO ON/OFF
```
CALCulate<1|2>:MARKer<1...4>:LOEXclude ON | OFF
```

PEAK EXCURSION
```
CALCulate<1|2>:MARKer<1...4>:PEXCursion <num_value>
```

N dB DOWN
```
CALCulate<1|2>:MARKer<1...4>:FUNCtion:NDBDown <num_value>
CALCulate<1|2>:MARKer<1...4>:FUNCtion:NDBDown:STATe ON | OFF
CALCulate<1|2>:MARKer<1...4>:FUNCtion:NDBDown:RESult?
CALCulate<1|2>:MARKer<1...4>:FUNCtion:NDBDown:FREQuency?
```

SHAPE FACT 60/3 dB
```
CALCulate<1|2>:MARKer<1...4>:FUNCtion:SFACtor (60dB/3dB)
CALCulate<1|2>:MARKer<1...4>:FUNCtion:SFACtor:STATe ON | OFF
CALCulate<1|2>:MARKer<1...4>:FUNCtion:SFACtor:RESult?
CALCulate<1|2>:MARKer<1...4>:FUNCtion:SFACtor:FREQuency?
```

SHAPE FACT 60/6 dB
```
CALCulate<1|2>:MARKer<1...4>:FUNCtion:SFACtor (60dB/6dB)
CALCulate<1|2>:MARKer<1...4>:FUNCtion:SFACtor:STATe ON | OFF
CALCulate<1|2>:MARKer<1...4>:FUNCtion:SFACtor:RESult?
CALCulate<1|2>:MARKer<1...4>:FUNCtion:SFACtor:FREQuency?
```

MKR->

PEAK
CALCulate<1|2>:MARKer<1...4>:MAXimum[:PEAK]
CALCulate<1|2>:DELTamarker<1...4>:MAXimum[:PEAK]

MKR-> CENTER
CALCulate<1|2>:MARKer<1...4>:FUNCtion:CENTer

MKR-> REF LEVEL
CALCulate<1|2>:MARKer<1...4>:FUNCtion:REFerence

MKR-> CF STEPSIZE
CALCulate<1|2>:MARKer<1...4>:FUNCtion:CSTep

MKR-> START
CALCulate<1|2>:MARKer<1...4>:FUNCtion:STARt

MKR-> STOP
CALCulate<1|2>:MARKer<1...4>:FUNCtion:STOP

MKR-> TRACE
CALCulate<1|2>:MARKer<1...4>:TRACe <num_value>
CALCulate<1|2>:DELTamarker<1...4>:TRACe <num_value>

3.9.1.5 LINES Key Group

D LINES

DISPLAY LINE 1/2
CALCulate:DLINe<1|2>:STATe ON | OFF;
CALCulate:DLINe<1|2> <num_value>

THRESHOLD LINE
CALCulate:THReshold ON | OFF;
CALCulate:THReshold <num_value>

REFERENCE LINE
CALCulate:RLINe:STATe ON | OFF;
CALCulate:RLINe <num_value>

FREQUENCY LINE 1/2
CALCulate:FLINe<1|2>:STATe ON | OFF;
CALCulate:FLINe<1|2> <num_value>

or

TIME LINE 1/2
CALCulate:TLINe<1|2>:STATe ON | OFF;
CALCulate:TLINe<1|2> <num_value>

LIMITS

SELECT LIMIT LINE
CALCulate<1|2>:LIMit<1...8>:NAME <string>;
CALCulate<1|2>:LIMit<1...8>:STATe ON | OFF

NEW LIMIT LINE
see EDIT LIMIT LINE

NAME
CALCulate<1|2>:LIMit<1...8>:NAME <string>

VALUES
no corresponding IEC/IEEE-bus command

INSERT VALUE
no corresponding IEC/IEEE-bus command

DELETE VALUE

no corresponding IEC/IEEE-bus command

SHIFT X LIMIT LINE

```
CALCulate<1|2>:LIMit<1...8>:CONTrol:SHIFt <num_value>
```

SHIFT Y LIMIT LINE

```
CALCulate<1|2>:LIMit<1...8>:UPPer:SHIFt <num_value>
CALCulate<1|2>:LIMit<1...8>:LOWer:SHIFt <num_value>
```

SAVE LIMIT LINE

automatically executed during IEC/IEEE-bus operation

EDIT LIMIT LINE

```
CALCulate<1|2>:LIMit<1...8>:UNIT DBM| DBPW| WATT| DBUV| VOLT|DBUA|
        AMPere| DB| DBUV_MHZ| DBUA_MHZ| DEG| RAD| S| HZ| PCT| UNITLESS
CALCulate<1|2>:LIMit<1...8>:CONTrol[:DATA] <num_value>, <num_value>..
CALCulate<1|2>:LIMit<1...8>:CONTrol:DOMain   FREQuency|TIME
CALCulate<1|2>:LIMit<1...8>:CONTrol:OFFset <num_value>
CALCulate<1|2>:LIMit<1...8>:CONTrol:SPACing LINear | LOGarithmic
CALCulate<1|2>:LIMit<1...8>:CONTrol:MODE   RELative | ABSolute
CALCulate<1|2>:LIMit<1...8>:CONTrol:UNIT[:TIME] S | SYM
CALCulate<1|2>:LIMit<1...8>:UPPer[:DATA] <num_value>, <num_value>..
CALCulate<1|2>:LIMit<1...8>:UPPer:STATe   ON | OFF
CALCulate<1|2>:LIMit<1...8>:UPPer:OFFset <num_value>
CALCulate<1|2>:LIMit<1...8>:UPPer:MARGin <num_value>
CALCulate<1|2>:LIMit<1...8>:UPPer:MODE   RELative | ABSolute
CALCulate<1|2>:LIMit<1...8>:LOWer[:DATA] <num_value>,<num_value>..
CALCulate<1|2>:LIMit<1...8>:LOWer:STATe ON | OFF
CALCulate<1|2>:LIMit<1...8>:LOWer:OFFset <num_value>
CALCulate<1|2>:LIMit<1...8>:LOWer:MARGin <num_value>
CALCulate<1|2>:LIMit<1...8>:LOWer:MODE   RELative | ABSolute
```

COPY LIMIT LINE

```
CALCulate<1|2>:LIMit<1...8>:COPY 1...8 | <name>
```

DELETE LIMIT LINE

```
CALCulate<1|2>:LIMit<1...8>:DELete
```

X OFFSET

```
CALCulate<1|2>:LIMit<1...8>:CONTrol:OFFset <num_value>
```

Y OFFSET

```
CALCulate<1|2>:LIMit<1...8>:UPPer:OFFset <num_value>
CALCulate<1|2>:LIMit<1...8>:LOWer:OFFset <num_value>
```

3.9.1.6 TRACE Key Group

TRACE 1

CLEAR/ WRITE

```
DISPlay[:WINDow<1|2>]:TRACe<1...4>:MODE WRITe
```

VIEW

```
DISPlay[:WINDow<1|2>]:TRACe<1...4>:MODE VIEW
```

BLANK

```
DISPlay[:WINDow<1|2>]:TRACe<1...4>[:STATe] OFF
```

AVERAGE

```
DISPlay[:WINDow<1|2>]:TRACe<1...4>:MODE  AVERage
```

MAX HOLD

```
DISPlay[:WINDow<1|2>]:TRACe<1...4>:MODE MAXHold
```

MIN HOLD

```
DISPlay[:WINDow<1|2>]:TRACe<1...4>:MODE MINHold
```

HOLD CONT ON/OFF	DISPlay[:WINDow<1|2>]:TRACe<1...4>:MODE:HCONtinuous ON|OFF
SWEEP COUNT	[SENSe:]SWEep:COUNt <num_value>
DETECTOR	--
AUTO SELECT	[SENSe:]DETector[:FUNCtion]:AUTO ON | OFF
DETECTOR AUTOPEAK	[SENSe:]DETector[:FUNCtion] APEak
DETECTOR MAX PEAK	[SENSe:]DETector[:FUNCtion] POSitive
DETECTOR MIN PEAK	[SENSe:]DETector[:FUNCtion] NEGative
DETECTOR SAMPLE	[SENSe:]DETector[:FUNCtion] SAMPle
DETECTOR RMS	[SENSe:]DETector[:FUNCtion] RMS
DETECTOR AVERAGE	[SENSe:]DETector[:FUNCtion] AVERage
COPY..	TRACe:COPY TRACE1| TRACE2| TRACE3| TRACE4 , TRACE1| TRACE2| TRACE3| TRACE4
ANALOG TR ON/OFF	DISPlay[:WINDow<1|2>]:TRACe<1...4>:MODE:ANALog ON|OFF
TRACE MATH	--
T1-T2/T3/T4 +REF ->T1	CALCulate<1|2>:MATH<1...4>:STATe ON CALCulate<1|2>:MATH<1...4>[:EXPRession][:DEFine] <expr>
T1-REF ->T1	CALCulate<1|2>:MATH<1...4>:STATe ON CALCulate<1|2>:MATH<1...4>[:EXPRession][:DEFine] <expr>
ADJUST TO TRACE	no corresponding IEC/IEEE-bus command
TRACE MATH OFF	CALCulate<1|2>:MATH<1...4>:STATe OFF

3.9.1.7 SWEEP Key Group

COUPLING	
RES BW MANUAL	[SENSe:]BANDwidth|BWIDth[:RESolution] <num_value>
RES BW AUTO	[SENSe:]BANDwidth|BWIDth[:RESolution]:AUTO ON | OFF
VIDEO BW MANUAL	[SENSe:]BANDwidth|BWIDth:VIDeo <num_value>
VIDEO BW AUTO	[SENSe:]BANDwidth|BWIDth:VIDeo:AUTO ON | OFF
SWEEP TIME MANUAL	[SENSe:]SWEep:TIME <num_value>
SWEEP TIME AUTO	[SENSe:]SWEep:TIME:AUTO ON | OFF
COUPLING DEFAULT	[SENSe:]BANDwidth|BWIDth[:RESolution]:AUTO ON; [SENSe:]BANDwidth|BWIDth:VIDeo:AUTO ON; [SENSe:]SWEep:TIME:AUTO ON
COUPLING RATIO	--
RBW / VBW SINE [1]	[SENSe:]BANDwidth|BWIDth:VIDeo:RATio SINe
RBW / VBW PULSE [.1]	[SENSe:]BANDwidth|BWIDth:VIDeo:RATio PULSe
RBW / VBW NOISE [10]	[SENSe:]BANDwidth|BWIDth:VIDeo:RATio NOISe
RBW / VBW MANUAL	[SENSe:]BANDwidth|BWIDth:VIDeo:RATio <num_value>
SPAN / RBW AUTO [50]	[SENSe:]BANDwidth|BWIDth[:RESolution]:RATio 0.02
SPAN / RBW MANUAL	[SENSe:]BANDwidth|BWIDth[:RESolution]:RATio <num_value>
RBW 1kHz ANA/DIG	[SENSe:]BANDwidth|BWIDth[:RESolution]:MODE ANALog | DIGital
RBW <=1kHz FFT/NORM	[SENSe:]BANDwidth|BWIDth[:RESolution]:MODE:FFT ON | OFF
MAIN PLL BANDWIDTH	[SENSe:]BANDwidth|BWIDth:PLL AUTO|HIGH|MEDium|LOW

TRIGGER	
FREE RUN	TRIGger[:SEQuence]:SOURce IMMediate
VIDEO	TRIGger[:SEQuence]:SOURce VIDeo TRIGger[:SEQuence]:LEVel:VIDeo <num_value>
LINE	TRIGger[:SEQuence]:SOURce LINE
EXTERN	TRIGger[:SEQuence]:SOURce EXTernal TRIGger[:SEQuence]:LEVel[:EXTernal] -5.0...+5.0V
RF POWER	TRIGger[:SEQuence]:SOURce RFPower
TRIGGER DELAY	TRIGger[:SEQuence]:HOLDoff <num_value>
SLOPE POS/NEG	TRIGger[:SEQuence]:SLOPe POSitive|NEGative
SWEEP	
CONTINUOUS SWEEP	INITiate:CONTinuous ON
SINGLE SWEEP	INITiate:CONTinuous OFF
SWEEP TIME AUTO	[SENSe:]SWEep:TIME:AUTO ON | OFF
SWEEP TIME MANUAL	[SENSe:]SWEep:TIME <num_value>
SWEEP COUNT	[SENSe:]SWEep:COUNt <num_value>
GAP SWEEP ON/OFF	[SENSe:]SWEep:GAP ON | OFF
GAP SWEEP SETTINGS	--
TRIGGER LEVEL	TRIGger[:SEQuence]:LEVel:VIDeo <num_value>
PRE TRIGGER	[SENSe:]SWEep:GAP:PRETrigger <num_value>
TRG TO GAP TIME	[SENSe:]SWEep:GAP:TRGTogap <num_value>
GAP LENGTH	[SENSe:]SWEep:GAP:LENGth <num_value>
GATE ON / OFF	[SENSe:]SWEep:EGATe ON | OFF
GATE SETTINGS	--

GATE LEVEL	[SENSe:]SWEep:EGATe:LEVel <num_value>
GATE MODE LEVEL/EDGE	[SENSe:]SWEep:EGATe:TYPE LEVel | EDGE
GATE POL POS/NEG	[SENSe:]SWEep:EGATe:POLarity POSitive | NEGative
GATE DELAY	[SENSe:]SWEep:EGATe:HOLDoff <num_value>
GATE LENGTH	[SENSe:]SWEep:EGATe:LENGth <num_value>
GATE EXTERN	[SENSe:]SWEep:EGATe:SOURce EXTernal
GATE RF POWER	[SENSe:]SWEep:EGATe:SOURce RFPower
GATE ADJUST	
GATE LEVEL	[SENSe:]SWEep:EGATe:LEVel <num_value>
GATE MODE LEVEL/EDGE	[SENSe:]SWEep:EGATe:TYPE LEVel | EDGE
GATE POL POS/NEG	[SENSe:]SWEep:EGATe:POLarity POSitive | NEGative
GATE DELAY	[SENSe:]SWEep:EGATe:HOLDoff <num_value>
GATE LENGTH	[SENSe:]SWEep:EGATe:LENGth <num_value>
SWEEP TIME MANUAL	[SENSe:]SWEep:TIME <num_value>
RES BW MANUAL	[SENSe:]BANDwidth|BWIDth[:RESolution] <num_value>
VIDEO MANUAL	[SENSe:]BANDwidth|BWIDth:VIDeo <num_value>
VIDEO AUTO	[SENSe:]BANDwidth|BWIDth:VIDeo:AUTO ON | OFF
SGL SWEEP DISP OFF	INITiate:DISPlay ON | OFF

3.9.2 Basic Instrument - General Device Settings

3.9.2.1 DATA VARIATION Key Group

HOLD	
UNLOCK	no corresponding IEC/IEEE-bus command
LOCK DATA	no corresponding IEC/IEEE-bus command
LOCK ALL	no corresponding IEC/IEEE-bus command
STEP	if needed, the step width is entered in the subsystem of the corresponding parameter.
STEPSIZE AUTO	--
STEPSIZE MANUAL	--

3.9.2.2 SYSTEM Key Group

DISPLAY	
FULL SCREEN	`DISPlay:FORmat SINGle`
SPLIT SCREEN	`DISPlay:FORmat SPLit`
ACTIVE SCREEN A	The screen is selected via the numeric suffix of the individual commands.
SCREEN COUPLING	--
MODE COUPLED	`INSTrument:COUPle MODE`
HORIZONTAL SCALING	`INSTrument:COUPle X`
VERTICAL SCALING	`INSTrument:COUPle Y`
COUPLING CONTROL	`INSTrument:COUPle CONTrol`
SCREENS UNCOUPLED	`INSTrument:COUPle NONE | ALL`

CONFIG DISPLAY	--
SELECT OBJECT	--
BRIGHTNESS	DISPlay:CMAP:HSL <hue>,<sat>,<lum>
TINT	DISPlay:CMAP<1...13>:HSL <hue>,<sat>,<lum>
SATURATION	DISPlay:CMAP<1...13>:HSL <hue>,<sat>,<lum>
DEFAULT COLORS	DISPlay:CMAP<1...13>:DEFault
PREDEFINED COLORS	DISPlay:CMAP<1...13>:PDEFined BLACk | BLUE | BROWn | GREen | CYAN | RED | MAGenta | YELLow | WHITe | DGRAy | LGRAy | LBLUe | LGREen | LCYan | LRED | LMAGenta
LOGO ON/OFF	DISPlay:LOGO ON|OFF
FREQUENCY ON/OFF	DISPlay:ANNotation:FREQuency ON|OFF
DATA ENTRY FIELD	--
DATAENTRY X	no corresponding IEC/IEEE-bus command
DATAENTRY Y	no corresponding IEC/IEEE-bus command
DEFAULT POSITION	no corresponding IEC/IEEE-bus command
DATAENTRY OPAQUE	no corresponding IEC/IEEE-bus command
TIME ON OFF	DISPlay[:WINDow<1|2>]:TIME ON | OFF
DISPLAY COMMENT	DISPlay[:WINDow<1|2>]:TEXT[:DATA] <string> DISPlay[:WINDow<1|2>]:TEXT:STATe ON | OFF
CAL	
CAL SHORT	CALibration:SHORt?
CAL TOTAL	CALibration[:ALL]?
CAL RES BW	CALibration:BANDwidth|BWIDth[:RESolution]?
CAL LOG	CALibration:LDETector?
CAL LO SUPP	CALibration:LOSuppression?

CAL I/Q	CALibration:IQ?
CAL CORR ON/OFF	CALibration:STATe ON | OFF
CAL RESULTS	no corresponding IEC/IEEE-bus command
PRESEL PEAK	CALibration:PPEak?
INFO	
FIRMWARE VERSION	*IDN?
HARDWARE+ OPTIONS	*OPT?
SELFTEST	*TST?
EXECUTE TEST	*TST?
SYSTEM MESSAGES	SYSTem:ERRor?
CLEAR MESSAGE	SYSTem:ERRor?
CLEAR ALL MESSAGES	--
UPDATE MESSAGES	--
OPTIONS	*OPT?

3.9.2.3 CONFIGURATION Key Group

MODE	The submenus are described under the associated operating mode.
ANALYZER	INSTrument[:SELect] SANalyzer
TRACKING GENERATOR	OUTPut:[:STATe] ON | OFF
VECTOR ANALYZER	INSTrument[:SELect] ADEMod | DDEMod
TV DEMOD	[SENSe:]TV[:STATe] ON | OFF

GSM MS ANALYZER — INSTrument[:SELect] MGSM

GSM BTS ANALYZER — INSTrument[:SELect] BGSM

SETUP

TRANSDUCER — --

TRANSDUCER FACTOR — [SENSe:]CORRection:TRANsducer:SELect <name>
[SENSe:]CORRection:TRANsducer[:STATe] ON | OFF

TRANSDUCER SET — [SENSe:]CORRection:TSET:SELect <name>
[SENSe:]CORRection:TSET[:STATe] ON | OFF

EDIT TRD FACTOR — [SENSe:]CORRection:TRANsducer:SCALing LINear|LOGarithmic

TRD FACTOR NAME — [SENSe:]CORRection:TRANsducer:SELect <name>

TRD FACTOR UNIT — [SENSe:]CORRection:TRANsducer:UNIT <string>

TRD FACTOR VALUES — [SENSe:]CORRection:TRANsducer:DATA <freq>,<level>..

INSERT LINE — no corresponding IEC/IEEE-bus command

DELETE LINE — no corresponding IEC/IEEE-bus command

SAVE TRD FACTOR — automatically executed during IEC/IEEE-bus operation

EDIT TRD SET — [SENSe:]CORRection:TSET:BREak ON | OFF

TRANSD SET NAME — [SENSe:]CORRection:TSET:SELect <name>

TRANSD SET UNIT — [SENSe:]CORRection:TSET:UNIT <string>

TRANSD SET RANGES	[SENSe:]CORRection:TSET:RANGe<1...10> <freq>,<freql>,<name>..
INSERT LINE	no corresponding IEC/IEEE-bus command
DELETE LINE	no corresponding IEC/IEEE-bus command
SAVE TRD SET	automatically executed during IEC/IEEE-bus operation
NEW FACT/SET	see *EDIT TRD FACTOR* or *EDIT TRD SET*
DELETE FACTOR/SET	[SENSe:]CORRection:TRANsducer:DELete [SENSe:]CORRection:TSET:DELete
OPTIONS	no corresponding IEC/IEEE-bus command
REFERENCE INT/EXT	[SENSe:]ROSCillator:SOURce INTernal|EXTernal
EXT REF FREQUENCY	[SENSe:]ROSCillator:EXTernal:FREQuency <num_value>
SERVICE	--
INPUT RF	DIAGnostic:SERVice:INPut[:SELect] RF
INPUT CAL	DIAGnostic:SERVice:INPut[:SELect] CALibration
NOISE SOURCE	DIAGnostic:SERVice:NSOurce ON | OFF
REFERENCE ADJUST	--
REFERENCE	[SENSe:]ROSCillator:[INTernal:]TUNe <num_value>
REFERENCE PROG	[SENSe:]ROSCillator:[INTernal:]TUNe:SAVe
SERVICE FUNCTION	DIAGnostic:SERVice:FUNCtion <num_value>,<num_value>...
ENTER PASSWORD	SYSTem:PASSword[:CENable] <string>
GENERAL SETUP	--
GPIB ADDRESS	SYSTem:COMMunicate:GPIB[:SELF]:ADDRess 0...30
USER PORT A/B	INPut:UPORt<1|2>[:VALue]? INPut:UPORt<1|2>:STATe ON | OFF OUTPut:UPORt<1|2>:STATe ON | OFF OUTPut:UPORt<1|2>[:VALue] <Binary>

COM PORT 1/2	SYSTem:COMMunicate:SERial<1|2>:CONTrol:DTR IBFull | OFF SYSTem:COMMunicate:SERial<1|2>:CONTrol:RTS IBFull | OFF SYSTem:COMMunicate:SERial<1|2>[:RECeive:]BAUD <num_value> SYSTem:COMMunicate:SERial<1|2>[:RECeive]:BITS 7 | 8 SYSTem:COMMunicate:SERial<1|2>:RECeive:PARity[:TYPE] EVEN | ODD | NONE SYSTem:COMMunicate:SERial<1|2>[:RECeive]:SBITs 1|2 SYSTem:COMMunicate:SERial<1|2>[:RECeive]:PACE XON | NONE
TIME	SYSTem:TIME 0...23, 0...59, 0...59
DATE	SYSTem:DATE <num>,<num>,<num>
MOUSE	no corresponding IEC/IEEE-bus command
EXTERNAL KEYBOARD	no corresponding IEC/IEEE-bus command
KEY CLICK ON/OFF	no corresponding IEC/IEEE-bus command

3.9.2.4 STATUS Key Group

LOCAL	Device message "Go to LOCAL (GTL)"

3.9.2.5 HARDCOPY Key Group

START	HCOPy[:IMMediate<1|2>]
SETTINGS	
COPY SCREEN	HCOPy:ITEM:ALL
COPY TRACE	HCOPy:ITEM:WINDow<1|2>:TRACe:STATe ON | OFF
COPY TABLE	HCOPy:ITEM:WINDow<1|2>:TABle:STATe ON | OFF
SELECT QUADRANT	--
UPPER LEFT	HCOPy:PAGE:DIMensions:QUADrant 1
LOWER LEFT	HCOPy:PAGE:DIMensions:QUADrant 2
UPPER RIGHT	HCOPy:PAGE:DIMensions:QUADrant 3
LOWER RIGHT	HCOPy:PAGE:DIMensions:QUADrant 4
FULL PAGE	HCOPy:PAGE:DIMensions:FULL
ENTER TEXT	--
COMMENT SCREEN A/B	HCOPy:ITEM:WINDow<1|2>:TEXT <string>
TITLE	HCOPy:ITEM:LABel:TEXT <string>
HARDCOPY DEVICE	HCOPy:DEVice:LANGuage HPGL | PCL4 | PCL5 | POSTscript | ESCP | WMF|PCX | HP7470 | EPSON24| EPSON24C | PCL4_C | PCL4_C3 | PCL4_H | PCL4_CH | PCL4_C3H | LASERJ | DESKJ | DESKJ_C | DESKJ_C3 | DESKJ_H | DESKJ_CH | DESKJC3H | HPGL_LS | HP7470LS
SETTINGS DEVICE 1/2	HCOPy:DESTination<1|2> <string> MMEMory:NAME <file_name> HCOPy:DEVice:PRESet<1|2> ON|OFF HCOPy:DEVice:RESolution<1|2> 150|300 HCOPy:ITEM:FFEed<1|2>:STATe ON|OFF HCOPy:PAGE:ORIentation<1|2> LANDscape | PORTrait
ENABLE DEV1/DEV2	The numeric suffix after HCOPy:IMMediate denotes the first or second device.
COLOR ON/OFF	HCOPy:DEVice:COLor ON | OFF
TRC COLOR AUTO INC	HCOPy:ITEM:WINDow<1|2>:TRACe:CAINcrement ON | OFF

3.9.2.6 MEMORY Key Group

CONFIG

EDIT PATH	MMEMory:MSIS <device> MMEMory:CDIRectory <directory_name>
DELETE	MMEMory:DELete <file_name> MMEMory:RDIRectory <directory_name>
FORMAT DISK	MMEMory:INITialize <msus>
MAKE DIRECTORY	MMEMory:MDIRectory <directory_name>
RENAME	MMEMory:MOVE <file_source>,<file_destination>
SORT MODE	no corresponding IEC/IEEE-bus command
COPY	MMEMory:COPY <file_source>,<file_destination>

SAVE

EDIT NAME	MMEMory:STORe:STATe 1,<file_name>
EDIT PATH	The path is included in the file names
EDIT COMMENT	MMEMory:COMMent <string>
SELECT ITEMS TO SAVE	--
SELECT ITEMS	MMEMory:SELect[:ITEM]:GSETup ON|OFF MMEMory:SELect[:ITEM]:HWSettings ON|OFF MMEMory:SELect[:ITEM]:TRACe<1...4> ON|OFF MMEMory:SELect[:ITEM]:LINes[:ACTive] ON|OFF MMEMory:SELect[:ITEM]:LINes:ALL ON|OFF MMEMory:SELect[:ITEM]:CSETup ON|OFF MMEMory:SELect[:ITEM]:HCOPy ON|OFF MMEMory:SELect[:ITEM]:MACRos ON|OFF MMEMory:SELect[:ITEM]:SCData ON|OFF MMEMory:SELect[:ITEM]:TRANsducer[:ACTive] ON|OFF MMEMory:SELect[:ITEM]:TRANsducer:ALL ON|OFF MMEMory:SELect[:ITEM]:CVL[:ACTive] ON|OFF MMEMory:SELect[:ITEM]:CVL:ALL ON|OFF
ENABLE ALL ITEMS	MMEMory:SELect[:ITEM]:ALL
DISABLE ALL ITEMS	MMEMory:SELect[:ITEM]:NONE
DEFAULT CONFIG	MMEMory:SELect[:ITEM]:DEFault
DATA SET LIST	--

DATA SET CLEAR

```
MMEMory:CLEar:STATe 1,<file_name>
```

DATA SET CLEAR ALL

```
MMEMory:CLEar:ALL
```

RECALL

EDIT NAME

```
MMEMory:LOAD:STATe 1,<file_name>
```

EDIT PATH

The path is included in the file names.

AUTO RECALL

```
MMEMory:LOAD:AUTO 1,<file_name>
```

SELECT ITEMS TO RECALL

```
--
```

SELECT ITEMS

```
MMEMory:SELect[:ITEM]:GSETup ON|OFF
MMEMory:SELect[:ITEM]:HWSettings ON|OFF
MMEMory:SELect[:ITEM]:TRACe<1...4> ON|OFF
MMEMory:SELect[:ITEM]:LINes[:ACTive] ON|OFF
MMEMory:SELect[:ITEM]:LINes:ALL ON|OFF
MMEMory:SELect[:ITEM]:CSETup ON|OFF
MMEMory:SELect[:ITEM]:HCOPy ON|OFF
MMEMory:SELect[:ITEM]:CDATa ON|OFF
MMEMory:SELect[:ITEM]:MACRos ON|OFF
MMEMory:SELect[:ITEM]:SCData ON|OFF
MMEMory:SELect[:ITEM]:TRANsducer[:ACTive] ON|OFF
MMEMory:SELect[:ITEM]:TRANsducer:ALL ON|OFF
MMEMory:SELect[:ITEM]:CVL[:ACTive] ON|OFF
MMEMory:SELect[:ITEM]:CVL:ALL ON|OFF
```

ENABLE ALL ITEMS

```
MMEMory:SELect[:ITEM]:ALL
```

DISABLE ALL ITEMS

```
MMEMory:SELect[:ITEM]:NONE
```

DEFAULT CONFIG

```
MMEMory:SELect[:ITEM]:DEFault
```

DATA SET LIST

```
--
```

DATA SET CLEAR

```
MMEMory:CLEar:STATe 1,<file_name>
```

DATA SET CLEAR ALL

```
MMEMory:CLEar:ALL
```

3.9.2.7 USER Key



3.9.3 Vector Signal Analysis Mode (Option FSE-B7)

3.9.3.1 CONFIGURATION Key Group - Digital Demodulation

MODE –

VECTOR ANALYZER --

DIGITAL STANDARD

```
[SENSe:]DDEMod:PRESet   GSM| FNADc| RNADc| TETRa| DCS1800| PCS1900|
       PHS| PDCup | PDCDown | APCO25CQPSK | APCO25C4FM|
       CDPD| DECT| CT2| ERMes| MODacom| PWT| TFTS| F16| F322| F324|
       F64| FQCDMA| RQCDMA
```

DIGITAL DEMOD

```
INSTrument[:SELect]  DDEMod
[SENSe:]DDEMod:FORMat   QPSK | PSK | MSK |QAM | FSK
[SENSe:]DDEMod:QPSK:FORMat NORMal | DIFFerential | OFFSet | DPI4
[SENSe:]DDEMod:PSK:NSTate   2 | 8
[SENSe:]DDEMod:PSK:FORMat   NORMal | DIFFerential
[SENSe:]DDEMod:MSK:FORMat   TYPE1 | TYPE2 | NORMal | DIFFerential
[SENSe:]DDEMod:QAM:NSTate   16
[SENSe:]DDEMod:FSK:NSTate   2 | 4

CALCulate<1|2>:MARKer<1...2>:FUNCtion:DDEMod:RESult? MERM| MEPK| MEPS|
       PERM| PEPK| PEPS| EVRM| EVPK| EVPS| IQOF| IQIM| ADR| FERR| DEV|
       FSRM| FSPK| FSPS| RHO| FEPK
```

MODULATION PARAMETERS --

SYMBOL RATE

```
[SENSe:]DDEMod:SRATe <num_value>
```

SIDE BAND NORM INV

```
SENSe:DDEMod:SBANd NORMal|INVerse
```

MEAS FILTER

```
[SENSe:]DDEMod:FILTer:MEASurement  OFF| RCOSine| RRCosine| GAUSsian
```

REFERENCE FILTER

```
[SENSe:]DDEMod:FILTer:REFerence  RCOSine | RRCosine | GAUSsian
```

ALPHA/BT

```
[SENSe:]DDEMod:FILTer:ALPHa <num_value>
```

FSK REF DEVIATION

```
CALCulate<1|2>:FSK:DEViation:REFerence <num_value>
```

NORMALIZE ON / OFF

```
[SENSe:]DDEMod:NORMalize ON | OFF
```

MEAS RESULT --

MAGNITUDE CAP BUFFER

```
CALCulate<1|2>:FEED  'TCAP'
```

MEAS SIGNAL

```
CALCulate<1|2>:FEED  'XTIM:DDEM:MEAS'
```

MAGNITUDE

```
CALCulate<1|2>:FORMat MAGNitude
```

PHASE

```
CALCulate<1|2>:FORMat PHASe
```

FREQUENCY

```
CALCulate<1|2>:FORMat FREQuency
```

3.9.3.2 CONFIGURATION Key Group - Analog Demodulation



AVERAGE HOLD ON	SENSe:MSUMmary:AHOLd[:STATe] ON|OFF
SWEEP COUNT	[SENSe:]SWEep:COUNt <num_value>
RELUNIT DB %	CALCulate<1|2>:UNIT:POWer DB|PCT
INDICATION ABS REL	SENSe:MSUMmary:MODE ABSolute | RELative
SET REFERENCE	SENSe:MSUMmary:REFerence <num_value>
MEAS-> REF	SENSe:MSUMmary:REFerence:AUTO ONCe
SINAD 1kHz ON OFF	CALCulate<1|2>:MARKer<1...4>:FUNCtion:ADEMod:SINad[:STATe] CALCulate<1|2>:MARKer<1...4>:FUNCtion:ADEMod:SINad:RESult?
SUMMARY MEAS TIME	SENSe:MSUMmary:MTIMe <num_value>
REAL TIME ON OFF	SENSe:ADEMod:RTIMe[:STATe] ON|OFF
SENSITIV AF OUTPUT	OUTPut:AF:SENSitivity <num_value>
VOLUME	SYSTem:SPEaker:VOLume <num_value>
DEMOD BANDWIDTH	SENSe:BANDwidth|BWIDth:DEMod <num_value>
DEEMPHASIS ON OFF	SENSe:FILTer:DEMPhasis[:STATe] ON|OFF

3.9.3.3 FREQUENCY Key Group

CENTER	[SENSe:]FREQuency:CENTer <num_value>
CENTER FREQUENCY	[SENSe:]FREQuency:CENTer <num_value>
FREQUENCY OFFSET	[SENSe:]FREQuency:OFFSet <num_value>

3.9.3.4 LEVEL Key Group

REF	--
REF LEVEL	DISPlay[:WINDow<1|2>]:TRACe<1...4>:Y[:SCALe]:RLEVel <num_value>
REF LEVEL OFFSET	DISPlay[:WINDow<1|2>]:TRACe<1...4>:Y[:SCALe]:RLEVel:OFFSet <num_value>

RF ATTEN MANUAL	INPut:ATTenuation <num_value>
ATTEN AUTO NORMAL	INPut:ATTenuation:AUTO:MODE NORMal; INPut:ATTenuation:AUTO ON
ATTEN AUTO LOW NOISE	INPut:ATTenuation:AUTO:MODE LNOise; INPut:ATTenuation:AUTO ON
ATTEN AUTO LOW DIST	INPut:ATTenuation:AUTO:MODE LDIStortion; INPut:ATTenuation:AUTO ON
MIXER LEVEL	INPut:MIXer <num_value>
RANGE	-
Y PER DIV	DISPlay[:WINDow<1|2>]:TRACe<1...4>:Y[:SCALe]:PDIVision <num_value>
REF VALUE Y AXIS	DISPlay[:WINDow<1|2>]:TRACe<1...4>:Y[:SCALe]:RVALue <num_value>
REF VALUE X AXIS	DISPlay[:WINDow<1|2>]:TRACe<1...4>:X[:SCALe]:RVALue <num_value>
REF VALUE POSITION	DISPlay[:WINDow<1|2>]:TRACe<1...4>:Y[:SCALe]:RPOSition 0...100PCT
TIME/DIV	[SENSE]:SWEep:TIME <num_value>
SCALE UNIT	--
Y UNIT LOG[dB]	CALCulate<1|2>:UNIT:POWer DB
Y UNIT LINEAR	CALCulate<1|2>:UNIT:POWer UNITLESS
Y UNIT DEG	CALCulate<1|2>:UNIT:ANGLe DEG
Y UNIT RAD	CALCulate<1|2>:UNIT:ANGLe RAD
Y UNIT DBM	CALCulate<1|2>:UNIT:POWer DBM
Y UNIT VOLT	CALCulate<1|2>:UNIT:POWer VOLT
Y UNIT WATT	CALCulate<1|2>:UNIT:POWer WATT
X UNIT TIME	CALCulate:X:UNIT:TIME S
X UNIT SYMBOL	CALCulate:X:UNIT:TIME SYMB
SENSITIV AF OUTPUT	OUTPut:AF:SENSitivity <num_value>
VOLUME	SYSTem:SPEaker:VOLume <num_value>

3.9.3.5 INPUT Key

INPUT	
RF ATTEN MANUAL	INPut:ATTenuation <num_value>
ATTEN AUTO NORMAL	INPut:ATTenuation:AUTO:MODE NORMal; INPut:ATTenuation:AUTO ON
ATTEN AUTO LOW NOISE	INPut:ATTenuation:AUTO:MODE LNOise; INPut:ATTenuation:AUTO ON
ATTEN AUTO LOW DIST	INPut:ATTenuation:AUTO:MODE LDIStortion; INPut:ATTenuation:AUTO ON
MIXER LEVEL	INPut:MIXer <num_value>
INPUT SELECT	--
RF INPUT 50 OHM	INPut:IMPedance 50
RF INPUT 75 OHM/RAM	INPut:IMPedance:CORRection RAM
RF INPUT 75OHM/RAZ	INPut:IMPedance:CORRection RAZ

3.9.3.6 MARKER Key Group

NORMAL	
MARKER 1..2	CALCulate<1|2>:MARKer<1...2>[:STATe] ON | OFF; CALCulate<1|2>:MARKer<1...2>:X <num_value>; CALCulate<1|2>:MARKer<1...2>:Y?
POLAR MARKER R/I / MA/PH	CALCulate<1|2>:MARKer<1...2>:READout MPHase | RIMaginary
POLAR MARKER DEG/ RAD	CALCulate<1|2>:UNIT:ANGLe DEG | RAD
COUPLED MARKER	CALCulate<1|2>:MARKer<1...2>:COUPled[:STATe] ON | OFF
MARKER INFO	DISPlay:WINDow<1|2>:MINFo ON | OFF (indication)
ALL MARKER OFF	CALCulate<1|2>:MARKer<1...2>:AOFF
DELTA	
DELTA 1/2	CALCulate<1|2>:DELTamarker<1...2>:AOFF
DELTA MKR ABS / REL	CALCulate<1|2>:DELTamarker<1...2>:MODE ABSolute | RELative

ALL DELTA OFF	CALCulate<1|2>:DELTamarker<1...2>[:STATe] ON | OFF CALCulate<1|2>:DELTamarker<1...2>:X <num_value> CALCulate<1|2>:DELTamarker<1...2>:Y?
MARKER SEARCH	
PEAK	CALCulate<1|2>:MARKer<1...2>:MAXimum[:PEAK] CALCulate<1|2>:DELTamarker<1...2>:MAXimum[:PEAK]
ACTIVE MKR / DELTA	--
MIN	CALCulate<1|2>:MARKer<1...2>:MINimum[:PEAK] CALCulate<1|2>:DELTamarker<1...2>:MINimum[:PEAK]
MAX |PEAK|	CALCulate<1|2>:MARKer<1...2>:MAXimum:APEak CALCulate<1|2>:DELTamarker<1...2>:MAXimum:APEak
SUMMARY ON OFF	CALCulate<1|2>:MARKer<1..2>:FUNCtion:SUMMary[:STATe] ON | OFF
SUMMARY MARKER	--
MAX |PEAK|	CALCulate<1|2>:MARKer<1..2>:FUNCtion:SUMMary:MAXimum[:STATe] ON | OFF CALCulate<1|2>:MARKer<1...2>:FUNCtion:SUMMary:MAXimum:RESult? CALCulate<1|2>:MARKer<1...2>:FUNCtion:SUMMary:MAXimum:AVERage:RESult? CALCulate<1|2>:MARKer<1...2>:FUNCtion:SUMMary:MAXimum:PHOLd:RESult?
+PEAK	CALCulate<1|2>:MARKer<1...2>:FUNCtion:SUMMary:PPEak[:STATe] ON | OFF CALCulate<1|2>:MARKer<1...2>:FUNCtion:SUMMary:PPEak:RESult? CALCulate<1|2>:MARKer<1...2>:FUNCtion:SUMMary:PPEak:AVERage:RESult? CALCulate<1|2>:MARKer<1...2>:FUNCtion:SUMMary:PPEak:PHOLd:RESult?
-PEAK	CALCulate<1|2>:MARKer<1...2>:FUNCtion:SUMMary:MPEak[:STATe] ON | OFF CALCulate<1|2>:MARKer<1...2>:FUNCtion:SUMMary:MPEak:RESult? CALCulate<1|2>:MARKer<1...2>:FUNCtion:SUMMary:MPEak:AVERage:RESult? CALCulate<1|2>:MARKer<1...2>:FUNCtion:SUMMary:MPEak:PHOLd:RESult?
±PEAK/2	CALCulate<1|2>:MARKer<1...2>:FUNCtion:SUMMary:MIDDle[:STATe] ON | OFF CALCulate<1|2>:MARKer<1...2>:FUNCtion:SUMMary:MIDDle:RESult? CALCulate<1|2>:MARKer<1...2>:FUNCtion:SUMMary:MIDDle:AVERage:RESult? CALCulate<1|2>:MARKer<1...2>:FUNCtion:SUMMary:MIDDle:PHOLd:RESult?
RMS	CALCulate<1|2>:MARKer<1...2>:FUNCtion:SUMMary:RMS[:STATe] ON | OFF CALCulate<1|2>:MARKer<1...2>:FUNCtion:SUMMary:RMS:RESult? CALCulate<1|2>:MARKer<1...2>:FUNCtion:SUMMary:RMS:AVERage:RESult? CALCulate<1|2>:MARKer<1...2>:FUNCtion:SUMMary:RMS:PHOLd:RESult?
MEAN	CALCulate<1|2>:MARKer<1...2>:FUNCtion:SUMMary:MEAN[:STATe] ON | OFF CALCulate<1|2>:MARKer<1...2>:FUNCtion:SUMMary:MEAN:RESult? CALCulate<1|2>:MARKer<1...2>:FUNCtion:SUMMary:MEAN:AVERage:RESult? CALCulate<1|2>:MARKer<1...2>:FUNCtion:SUMMary:MEAN:PHOLd:RESult?
PEAK HOLD ON / OFF	CALCulate<1|2>:MARKer<1...2>:FUNCtion:SUMMary:PHOLd ON | OFF
AVERAGE/HOLD ON / OFF	CALCulate<1|2>:MARKer<1...2>:FUNCtion:SUMMary:AVERage ON | OFF
SWEEP COUNT	[SENSe:]SWEep:COUNt <num_value>
ALL SUM MKR OFF	CALCulate<1|2>:MARKer<1...2>:FUNCtion:SUMMary:AOFF
SEARCH LIMIT ON/OFF	CALCulate<1|2>:MARKer<1...2>:X:SLIMits[:STATe] ON | OFF
SELECT MARKER	--

MKR ->

PEAK
CALCulate<1|2>:MARKer<1...2>:MAXimum[:PEAK]
CALCulate<1|2>:DELTamarker<1...2>:MAXimum[:PEAK]

MKR → TRACE
CALCulate<1|2>:MARKer<1...4>:TRACe <num_value>

SELECT MARKER
--

ACTIVE MKR / DELTA
no corresponding IEC/IEEE-bus command

3.9.3.7 LINES Key Group

D LINES
–

DISPLAY LINE 1/2
CALCulate<1|2>:DLINe<1|2>:STATe ON | OFF;
CALCulate<1|2>:DLINe<1|2> <num_value>

REFERENCE LINE
CALCulate<1|2>:RLINe:STATe ON | OFF;
CALCulate<1|2>:RLINe <num_value>

THRESHOLD LINE
CALCulate<1|2>:THReshold ON | OFF;
CALCulate<1|2>:THReshold <num_value>

TIME/SYMB 1/2
CALCulate<1|2>:TLINe<1|2>:STATe ON | OFF;
CALCulate<1|2>:TLINe<1|2> <num_value>

LIMITS

SELECT LIMIT LINE
CALCulate<1|2>:LIMit<1...8>:NAME <string>;
CALCulate<1|2>:LIMit<1...8>:STATe ON | OFF

NEW LIMIT LINE
see EDIT LIMIT LINE

NAME
CALCulate<1|2>:LIMit<1...8>:NAME <string>

VALUES
no corresponding IEC/IEEE-bus command

INSERT VALUE
no corresponding IEC/IEEE-bus command

DELETE VALUE
no corresponding IEC/IEEE-bus command

SHIFT X LIMIT LINE
CALCulate<1|2>:LIMit<1...8>:CONTrol:SHIFt <num_value>

SHIFT Y LIMIT LINE
CALCulate<1|2>:LIMit<1...8>:UPPer:SHIFt <num_value>
CALCulate<1|2>:LIMit<1...8>:LOWer:SHIFt <num_value>

SAVE LIMIT LINE
automatically executed during IEC/IEEE-bus operation

EDIT LIMIT LINE

```
CALCulate<1|2>:LIMit<1...8>:UNIT  DBM| DBPW| WATT| DBUV | DBMV | VOLT |
                                  DBUA | AMPere| DB|
                                  DBUV_MHZ| DBMV_MHZ | DBUA_MHZ|
                                  DEG| RAD| S| HZ| PCT
CALCulate<1|2>:LIMit<1...8>:TRACe <num_value>
CALCulate<1|2>:LIMit<1...8>:COMMent 'string'
CALCulate<1|2>:LIMit<1...8>:CONTrol[:DATA] <num_value>,<num_value>..
CALCulate<1|2>:LIMit<1...8>:CONTrol:DOMain   FREQuency|TIME
CALCulate<1|2>:LIMit<1...8>:CONTrol:OFFset <num_value>
CALCulate<1|2>:LIMit<1...8>:CONTrol:MODE   RELative | ABSolute
CALCulate<1|2>:LIMit<1...8>:CONTrol:UNIT[:TIME] S | SYM
CALCulate<1|2>:LIMit<1...8>:CONTrol:SPACing LINear | LOGarithmic
CALCulate<1|2>:LIMit<1...8>:UPPer[:DATA] <num_value>,<num_value>..
CALCulate<1|2>:LIMit<1...8>:UPPer:STATe   ON | OFF
CALCulate<1|2>:LIMit<1...8>:UPPer:OFFset <num_value>
CALCulate<1|2>:LIMit<1...8>:UPPer:MARGin <num_value>
CALCulate<1|2>:LIMit<1...8>:UPPer:MODE   RELative | ABSolute
CALCulate<1|2>:LIMit<1...8>:UPPer:SPACing LINear | LOGarithmic
CALCulate<1|2>:LIMit<1...8>:LOWer[:DATA] <num_value>,<num_value>..
CALCulate<1|2>:LIMit<1...8>:LOWer:STATe ON | OFF
CALCulate<1|2>:LIMit<1...8>:LOWer:OFFset <num_value>
CALCulate<1|2>:LIMit<1...8>:LOWer:MARGin <num_value>
CALCulate<1|2>:LIMit<1...8>:LOWer:MODE   RELative | ABSolute
CALCulate<1|2>:LIMit<1...8>:LOWer:SPACing LINear | LOGarithmic
CALCulate<1|2>:LIMit<1...8>:FAIL?
CALCulate<1|2>:LIMit<1...8>:CLEar[:IMMediate]
```

COPY LIMIT LINE

```
CALCulate<1|2>:LIMit<1...8>:COPY 1...8 | <name>
```

DELETE LIMIT LINE

```
CALCulate<1|2>:LIMit<1...8>:DELete
```

X OFFSET

```
CALCulate<1|2>:LIMit<1...8>:CONTrol:OFFset <num_value>
```

Y OFFSET

```
CALCulate<1|2>:LIMit<1...8>:UPPer:OFFset <num_value>
CALCulate<1|2>:LIMit<1...8>:LOWer:OFFset <num_value>
```

3.9.3.8 TRACE Key Group

TRACE

```
--
```

CLEAR/WRITE

```
DISPlay[:WINDow<1|2>]:TRACe<1...4>:MODE WRITe
```

VIEW

```
DISPlay[:WINDow<1|2>]:TRACe<1...4>:MODE VIEW
```

BLANK

```
DISPlay[:WINDow<1|2>]:TRACe<1...4>[:STATe] OFF
```

CONTINUOUS WRITE

```
DISPlay[:WINDow<1|2>]:TRACe<1...4>:MODE:CWRite ON|OFF
```

AVERAGE

```
DISPlay[:WINDow<1|2>]:TRACe<1...4>:MODE  AVERage
```

MAX HOLD

```
DISPlay[:WINDow<1|2>]:TRACe<1...4>:MODE MAXHold
```

MIN HOLD

```
DISPlay[:WINDow<1|2>]:TRACe<1...4>:MODE MINHold
```

SWEEP COUNT

```
[SENSe:]SWEep:COUNt <num_value>
```

3.9.3.9 SWEEP Key Group

COUPLING	--
IF BW AUTO	[SENSe:]BANDwidth|BWIDth[:RESolution]:AUTO ON | OFF
IF BW MANUAL	[SENSe:]BANDwidth|BWIDth[:RESolution] <num_value>
MAIN PLL BANDWIDTH	[SENSe:]BANDwidth|BWIDth:PLL AUTO|HIGH|MEDium|LOW
SWEEP	
CONTINUOUS SWEEP	INITiate:CONTinuous ON; INITiate[:IMMediate]
SINGLE SWEEP	INITiate:CONTinuous OFF; INITiate[:IMMediate]
SWEEP COUNT	[SENSe:]SWEep:COUNt <num_value>
RESULT LENGTH	[SENSe:]DDEMod:TIME <num_value>

3.9.3.10 SWEEP Key Group - Digital Demodulation

TRIGGER	
FREE RUN	TRIGger[:SEQuence]:SOURce IMMediate
VIDEO	TRIGger[:SEQuence]:SOURce VIDeo TRIGger[:SEQuence]:LEVel:VIDeo <num_value>
EXTERN	TRIGger[:SEQuence]:SOURce EXTernal TRIGger[:SEQuence]:LEVel:EXTernal <num_value>
TRIGGER OFFSET	TRIGger[:SEQuence]:HOLDoff <num_value>
SLOPE POS NEG	TRIGger[:SEQuence]:SLOPe POSitive|NEGative
FIND BURST ON OFF	[SENSe:]DDEMod:SEARch:PULSe:STATe ON | OFF
FIND SYNC ON OFF	[SENSe:]DDEMod:SEARch:SYNC:STATe ON | OFF
SYNC OFFSET	[SENSe:]DDEMod:SEARch:SYNC:OFFSET <num_value>
SYNC PATTERN	--
SELECT PATTERN	--

NEW SYNC PATTERN	[SENSe:]DDEMod:SEARch:SYNC:PATTern <string>
NAME	--
COMMENT	--
VALUE	[SENSe:]DDEMod:SEARch:SYNC:PATTern <string>
SAVE PATTERN	automatically executed during IEC/IEEE-bus operation
EDIT SYNC PATTERN	[SENSe:]DDEMod:SEARch:SYNC:PATTern <string>
DELETE PATTERN	--

3.9.3.11 SWEEP Key Group - Analog Demodulation

TRIGGER	
FREE RUN	TRIGger[:SEQuence]:SOURce IMMediate
VIDEO	TRIGger[:SEQuence]:SOURce VIDeo TRIGger[:SEQuence]:LEVel:VIDeo <num_value>
EXTERN	TRIGger[:SEQuence]:SOURce EXTernal TRIGger[:SEQuence]:LEVel[:EXTernal] -5.0...+5.0V
AF SIGNAL	TRIGger[:SEQuence]:SOURce AF
SLOPE POS/NEG	TRIGger[:SEQuence]:SLOPe POSitive|NEGative
TRIGGER OFFSET	TRIGger[:SEQuence]:HOLDoff <num_value>

3.9.4 Tracking Generator Mode (Option FSE-B8 to B11)

3.9.4.1 CONFIGURATION Key Group

MODE	
TRACKING GEN	--
SOURCE ON/OFF	OUTPut:[:STATe] ON | OFF
SOURCE POWER	SOURce:POWer[:LEVel][:IMMediate][:AMPLitude] <num_value>
POWER OFFSET	SOURce:POWer[:LEVel][:IMMediate]:OFFSet <num_value>
SOURCE CAL	--
CAL TRANS	[SENSe:]CORRection:METHod TRANsmission [SENSe:]CORRection:COLLect[:ACQuire] THRough
CAL REFL SHORT	[SENSe:]CORRection:METHod REFLexion [SENSe:]CORRection:COLLect[:ACQuire] THRough
CAL REFL OPEN	[SENSe:]CORRection:METHod REFLexion [SENSe:]CORRection:COLLect[:ACQuire] OPEN
NORMALIZE	[SENSe:]CORRection[:STATe] ON | OFF
REF VALUE POSITION	DISPlay[:WINDow<1|2>]:TRACe<1...4>:Y[:SCALe]:RPOSition 0...100PCT
REF VALUE	DISPlay[:WINDow<1|2>]:TRACe<1...4>:Y[:SCALe]:RVALue <num_value>
RECALL	[SENSe:]CORRection:RECall
FREQUENCY OFFSET	SOURce:FREQuency:OFFSet <num_value>
MODULATION	--
EXT AM	SOURce:AM:STATe ON | OFF
EXT ALC	SOURce:POWer:ALC:SOURce INTernal | EXTernal
EXT FM	SOURce:FM:STATe ON | OFF
EXT I/Q	SOURce:DM:STATe ON | OFF

3.9.5 TV-Demodulation Mode (Option FSE-B3)

3.9.5.1 CONFIGURATION Key Group




```
[SENSe:]TV[:STATe] ON | OFF
TRIGger[:SEQuence]:VIDeo:SSIGnal:POLarity NEGative
TRIGger[:SEQuence]:VIDeo:SSIGnal:POLarity POSitive
TRIGger[:SEQuence]:VIDeo:FORMat:LPFRame   625
TRIGger[:SEQuence]:VIDeo:FORMat:LPFRame   525
[SENSe:]TV:PSOFfset <num_value>
[SENSe:]TV[:STATe] ON | OFF
```

3.9.5.2 SWEEP Key Group




```
TRIGger[:SEQuence]:SOURce TV
--
TRIGger[:SEQuence]:VIDeo:FIELd:SELect   ALL
TRIGger[:SEQuence]:VIDeo:LINE:NUMBer <num_value>
TRIGger[:SEQuence]:VIDeo:FIELd:SELect EVEN
TRIGger[:SEQuence]:VIDeo:FIELd:SELect ODD
```

3.9.6 GSM BTS Analysis Mode (Option FSE-K11)

3.9.6.1 CONFIGURATION Key Group



FRAME COARSE	TRIGger[:SEQuence]:SYNChronize:ADJust:FRAMe <num_value>
FRAME FINE	TRIGger[:SEQuence]:SYNChronize:ADJust:FRAMe <num_value>
AUTO FRAME ADJUST	TRIGger[:SEQuence]:SYNChronize:ADJust:FRAMe:AUTO ONCE
SLOT ADJUST	TRIGger[:SEQuence]:SYNChronize:ADJust:SLOT <num_value>
AUTO SLOT ADJUST	TRIGger[:SEQuence]:SYNChronize:ADJust:SLOT:AUTO ONCE
DEFAULT SETTINGS	CONFigure:BTS:PRESet
P-GSM 900	CONFigure:BTS:NETWork[:TYPE] PGSM
E-GSM 900	CONFigure:BTS:NETWork[:TYPE] EGSM
DCS 1800	CONFigure:BTS:NETWork[:TYPE] DCS
PCS 1900	CONFigure:BTS:NETWork[:TYPE] PCS
PHASE II I	CONFigure:BTS:NETWork:PHASe 1|2
LIMIT MARGIN	CALCulate<1|2>:LIMit<1...8>:MARGin <num_value>
PHASE/FREQ ERROR	CONFigure: BURSt:PFERror[:IMMediate]
SINGLE	INITiate:CONTinuous OFF; INITiate[:IMMediate]
CONTINUOUS	INITiate:CONTinuous ON; INITiate[:IMMediate]
NO. OF BURSTS	--
SET MANUAL	CONFigure:SPECtrum:SWITching:COUNt <num_value>
SET TO STANDARD	--
CARRIER POWER	CONFigure: BURSt:POWer[:IMMediate] CALCulate:LIMit:BURSt:POWer?
MEAS MAX OUTPUT PWR	READ:BURSt:POWer?
INC STATIC PWR CTRL	READ:BURSt:POWer:STATic?
INC DYNAM PWR CTRL	READ:BURSt:POWer:DYNamic?


NO. OF BURSTS
--
SET MANUAL
CONFigure:SPECtrum:SWITching:COUNt <num_value>
SET TO STANDARD
--
CONDITIONS NORM EXTR
CONFigure: BURSt:POWer:CONDition NORMal | EXTReme
SYNC TO MIDAMBLE
TRIGger[:SEQuence]:SYNChronize:SOURce FRAMe | TSC
TRIGGER ADJUST
--
FRAME COARSE
TRIGger[:SEQuence]:SYNChronize:ADJust:FRAMe <num_value>
FRAME FINE
TRIGger[:SEQuence]:SYNChronize:ADJust:FRAMe <num_value>
AUTO FRAME ADJUST
TRIGger[:SEQuence]:SYNChronize:ADJust:FRAMe:AUTO ONCE
SLOT ADJUST
TRIGger[:SEQuence]:SYNChronize:ADJust:SLOT <num_value>
AUTO SLOT ADJUST
TRIGger[:SEQuence]:SYNChronize:ADJust:SLOT:AUTO ONCE
POWER VS TIME
CONFigure: BURSt:PTEMplate[:IMMediate]
CALCulate:LIMit:BURSt:PTEMplate?
SINGLE
INITiate:CONTinuous OFF; INITiate[:IMMediate]
CONTINUOUS
INITiate:CONTinuous ON; INITiate[:IMMediate]
FULL BURST
CONFigure: BURSt:PTEMplate:SELect FULL
BURST HIGH RESOLUTION
CONFigure: BURSt:PTEMplate:SELect TOP
RISING
CONFigure: BURSt:PTEMplate:SELect RISing
FALLING
CONFigure: BURSt:PTEMplate:SELect FALLing
MEAS BANDWIDTH
[SENSe:]BANDwidth|BWIDth[:RESolution] DEF | 300 kHz | 1 MHz
SYNC TO MIDAMBLE
TRIGger[:SEQuence]:SYNChronize:SOURce FRAMe | TSC
NO. OF BURSTS
--
SET MANUAL
CONFigure:SPECtrum:SWITching:COUNt <num_value>
SET TO STANDARD
--
TRIGGER ADJUST
--

FRAME COARSE — TRIGger[:SEQuence]:SYNChronize:ADJust:FRAMe <num_value>

FRAME FINE — TRIGger[:SEQuence]:SYNChronize:ADJust:FRAMe <num_value>

AUTO FRAME ADJUST — TRIGger[:SEQuence]:SYNChronize:ADJust:FRAMe:AUTO ONCE

SLOT ADJUST — TRIGger[:SEQuence]:SYNChronize:ADJust:SLOT <num_value>

AUTO SLOT ADJUST — TRIGger[:SEQuence]:SYNChronize:ADJust:SLOT:AUTO ONCE

MODULATION SPECTRUM — CONFigure:SPECtrum:MODulation[:IMMediate]
CALCulate:LIMit:SPECtrum:MODulation? ARFCn|TXBand|RXBand|COMBined
CALCulate:LIMit:SPECtrum:MODulation:FAILs? ARFCn|TXBand|RXBand|COMBined
CALCulate:LIMit:SPECtrum:MODulation:EXCeptions? ARFCn|TXBand|RXBand|COMBined

SINGLE FREQ SWEEP — INITiate:CONTinuous OFF; INITiate[:IMMediate]

CONTINUOUS FREQ SWEEP — INITiate:CONTinuous ON; INITiate[:IMMediate]

START LIST — READ:SPECtrum:MODulation[:ALL]?

NO. OF BURSTS — --

SET MANUAL — CONFigure:SPECtrum:SWITching:COUNt <num_value>

SET TO STANDARD — --

ARFCN ±1.8 MHZ — CONFigure:SPECtrum:MODulation:RANGe ARFCn

TX BAND — CONFigure:SPECtrum:MODulation:RANGe TXBand

±1.8 MHZ / TX BAND — CONFigure:SPECtrum:MODulation:RANGe COMBined

RX BAND — CONFigure:SPECtrum:MODulation:RANGe RXBand

RX BAND GAIN — [SENSe:]CORRection:RXGain:INPut[:MAGNitude] <num_value>

TRIGGER ADJUST — --

FRAME COARSE — TRIGger[:SEQuence]:SYNChronize:ADJust:FRAMe <num_value>

FRAME FINE — TRIGger[:SEQuence]:SYNChronize:ADJust:FRAMe <num_value>

AUTO FRAME ADJUST — TRIGger[:SEQuence]:SYNChronize:ADJust:FRAMe:AUTO ONCE

SLOT ADJUST — TRIGger[:SEQuence]:SYNChronize:ADJust:SLOT <num_value>

AUTO SLOT ADJUST — TRIGger[:SEQuence]:SYNChronize:ADJust:SLOT:AUTO ONCE


TRANSIENT SPECTRUM
CONFigure:SPECtrum:SWITching[:IMMediate]
CALCulate:LIMit:SPECtrum:SWITching? ARFCn|TXBand|RXBand|COMBined
CALCulate:LIMit:SPECtrum:SWITching:FAILs? ARFCn|TXBand|RXBand|COMBined
SINGLE FREQ SWEEP
INITiate:CONTinuous OFF; INITiate[:IMMediate]
CONTINUOUS FREQ SWEEP
INITiate:CONTinuous ON; INITiate[:IMMediate]
START LIST
READ:SPECtrum:SWITching[:ALL]?
NO. OF BURSTS
--
SET MANUAL
CONFigure:SPECtrum:SWITching:COUNt <num_value>
SET TO STANDARD
--
BTS SFH ON OFF
CONFigure:BTS:CHANnel:SFH ON | OFF
SPURIOUS
CONFigure:SPURious[:IMMediate]
CALCulate:LIMit:SPURious? TXBand | OTXBand | RXBand
CALCulate:LIMit:SPURious:FAILs? TXBand | OTXBand | RXBand
START LIST
READ:SPUR[:ALL]?
START LIST SGL STEP
ABORT;READ:SPUR:STEP?
CONT SGL STEP LIST
READ:SPUR:STEP?
TX SUPPR ON OFF
CONFigure:BTS:TXSupp ON | OFF
RX BAND GAIN
[SENSe:]CORRection:RXGain:INPut[:MAGNitude] <num_value>
SWEEP COUNT
CONFigure:SPURious:COUNt <num_value>
SWP COUNT TX / <> TX
CONFigure:SPURious:RANGe TXBand | OTXBand
SWP COUNT RX BAND
CONFigure:SPURious:RANGe RXBand
SET TO STANDARD
--
TX BAND
CONFigure:SPURious:RANGe TXBand
<> TX BAND
CONFigure:SPURious:RANGe OTXBand
RX BAND
CONFigure:SPURious:RANGe RXBand
BTS SFH ON OFF
CONFigure:BTS:CHANnel:SFH ON | OFF
COSITING
CONFigure:BTS:COSiting ON | OFF

3.9.7 GSM MS Analysis Mode (Option FSE-K10)

3.9.7.1 CONFIGURATION Key Group




P-GSM 900
CONFigure:MS:NETWork[:TYPE] PGSM
E-GSM 900
CONFigure:MS:NETWork[:TYPE] EGSM
DCS 1800
CONFigure:MS:NETWork[:TYPE] DCS
PCS 1900
CONFigure:MS:NETWork[:TYPE] PCS
PHASE II I
CONFigure:MS:NETWork:PHASe 1|2
LIMITS
CONFigure:MS:NETWork[:TYPE] PCS
NEW SET
--
COPY SET
--
DELETE SET
--
RENAME SET
--
EXPORT SET
--
IMPORT SET
--
LIMIT MARGIN
CALCulate<1|2>:LIMit<1...8>:MARGin <num_value>
PHASE/FREQ ERROR
CONFigure: BURSt:PFERror[:IMMediate]
SINGLE
INITiate:CONTinuous OFF; INITiate[:IMMediate]
CONTINUOUS
INITiate:CONTinuous ON; INITiate[:IMMediate]
NO. OF BURSTS
SET MANUAL
CONFigure:SPECtrum:SWITching:COUNt <num_value>
SET TO STANDARD
--
CARRIER POWER
CONFigure: BURSt:POWer[:IMMediate]
CALCulate:LIMit:BURSt:POWer?
MEAS MAX OUTPUT PWR
READ:BURSt:POWer?
INC PWR CTRL LEVEL
READ:BURSt:POWer:LEVel?


NO. OF BURSTS
--
NO. OF BURSTS
CONFigure:SPECtrum:SWITching:COUNt <num_value>
SET TO STANDARD
--
CONDITIONS NORM EXTR
CONFigure: BURSt:POWer:CONDition NORMal | EXTReme
SYNC TO MIDAMBLE
TRIGger[:SEQuence]:SYNChronize:SOURce FRAMe | TSC
TRIGGER ADJUST
see sub menu SETTINGS
POWER VS TIME
CONFigure: BURSt:PTEMplate[:IMMediate]
CALCulate:LIMit:BURSt:PTEMplate?
SINGLE
INITiate:CONTinuous OFF; INITiate[:IMMediate]
CONTINUOUS
INITiate:CONTinuous ON; INITiate[:IMMediate]
FULL BURST
CONFigure: BURSt:PTEMplate:SELect FULL
BURST HIGH RESOLUTION
CONFigure: BURSt:PTEMplate:SELect TOP
RISING
CONFigure: BURSt:PTEMplate:SELect RISing
FALLING
CONFigure: BURSt:PTEMplate:SELect FALLing
MEAS BANDWIDTH
[SENSe:]BANDwidth|BWIDth[:RESolution] DEF | 300 kHz | 1 MHz
SYNC TO MIDAMBLE
TRIGger[:SEQuence]:SYNChronize:SOURce FRAMe | TSC
NO. OF BURSTS
--
NO. OF BURSTS
CONFigure:SPECtrum:SWITching:COUNt <num_value>
SET TO STANDARD
--
TRIGGER ADJUST
--
COURSE ADJUST
TRIGger[:SEQuence]:SYNChronize:ADJust:SLOT <num_value>
FINE ADJUST
TRIGger[:SEQuence]:SYNChronize:ADJust:SLOT <num_value>
AUTO ADJUST
TRIGger[:SEQuence]:SYNChronize:ADJust:SLOT:AUTO ONCE

MODULATION SPECTRUM	CONFigure:SPECtrum:MODulation[:IMMediate] CALCulate:LIMit:SPECtrum:MODulation? ARFCn|TXBand|RXBand|COMBined|DCSRx1800 CALCulate:LIMit:SPECtrum:MODulation:FAILs? ARFCn|TXBand|RXBand|COMBined|DCSRx1800 CALCulate:LIMit:SPECtrum:MODulation:EXCeptions? ARFCn|TXBand|RXBand|COMBined|DCSRx1800
SINGLE FREQ SWEEP	INITiate:CONTinuous OFF; INITiate[:IMMediate]
CONTINUOUS FREQ SWEEP	INITiate:CONTinuous ON; INITiate[:IMMediate]
START LIST	READ:SPECtrum:MODulation[:ALL]?
NO. OF BURSTS	--
NO. OF BURSTS	CONFigure:SPECtrum:SWITching:COUNt <num_value>
SET TO STANDARD	--
ARFCN ± 1.8 MHz	CONFigure:SPECtrum:MODulation:RANGe ARFCn
TX BAND	CONFigure:SPECtrum:MODulation:RANGe TXBand
±1.8 MHZ TX BAND	CONFigure:SPECtrum:MODulation:RANGe COMBined
RX BAND GSM 900	CONFigure:SPECtrum:MODulation:RANGe RXBand
RX BAND DCS 1800	CONFigure:SPECtrum:MODulation:RANGe DCSRx1800
TRIGGER ADJUST	see sub menu SETTINGS
RX BAND GAIN	[SENSe:]CORRection:RXGain:INPut[:MAGNitude] <num_value>
TRANSIENT SPECTRUM	CONFigure:SPECtrum:SWITching[:IMMediate] CALCulate:LIMit:SPECtrum:SWITching? ARFCn|TXBand|RXBand|COMBined CALCulate:LIMit:SPECtrum:SWITching:FAILs? ARFCn|TXBand|RXBand|COMBined
SINGLE FREQ SWEEP	INITiate:CONTinuous OFF; INITiate[:IMMediate]
CONTINUOUS FREQ SWEEP	INITiate:CONTinuous ON; INITiate[:IMMediate]
START LIST	READ:SPECtrum:SWITching[:ALL]?
NO. OF BURSTS	--
SET MANUAL	CONFigure:SPECtrum:SWITching:COUNt <num_value>
SET TO STANDARD	--

TRIGGER ADJUST	--
COURSE ADJUST	TRIGger[:SEQuence]:SYNChronize:ADJust:SLOT <num_value>
FINE ADJUST	TRIGger[:SEQuence]:SYNChronize:ADJust:SLOT <num_value>
AUTO ADJUST	TRIGger[:SEQuence]:SYNChronize:ADJust:SLOT:AUTO ONCE

SPURIOUS	CONFigure:SPURious[:IMMediate] CALCulate:LIMit:SPURious? TXBand | OTXBand | IDLeband CALCulate:LIMit:SPURious:FAILs? TXBand | OTXBand | IDLeband
START LIST	READ:SPUR[:ALL]?
START LIST SGL STEP	ABORT;READ:SPUR:STEP?
CONT SGL STEP LIST	READ:SPUR:STEP?
TX SUPPR ON OFF	CONFigure:MS:TXSupp ON | OFF
SWEEP COUNT	CONFigure:SPURious:COUNt <num_value>
TX BAND	CONFigure:SPURious:RANGe TXBand
<> TX BAND	CONFigure:SPURious:RANGe OTXBand
IDLE MODE	CONFigure:SPURious:RANGe IDLeband

3.9.8 External Mixer (Option FSE-B21)

3.9.8.1 INPUT Key Group




COPY TABLE
--
SAVE TABLE
table is saved with every change of values
PAGE UP
--
PAGE DOWN
--
NEW TABLE
see softkey EDIT TABLE
LOAD TABLE
--
DELETE TABLE
[SENSe:]CORRection:CVL:CLEar
PAGE UP
--
PAGE DOWN
--
DEFAULT SETTINGS
--
HARMONIC#
[SENSe:]MIXer:HARMonic <value>
PORTS 2 3
[SENSe:]MIXer:PORT 2|3
AVG CONV LOSS
[SENSe:]MIXer:LOSS[:LOW] <num_value>
BIAS
--
BIAS
[SENSe:]MIXer:BIAS <num_value>
BIAS OFF
--
SIGNAL ID
--
SIGNAL ID
[SENSe:]MIXer:SIGNal OFF|ON
AUTO ID
[SENSe:]MIXer:SIGNal OFF|AUTO
AUTO ID THRESHOLD
[SENSe:]MIXer:THReshold <num_value>

4 Maintenance and Troubleshooting

4.1 Maintenance

4.1.1 Mechanical Maintenance

The FSE does not require any mechanical maintenance. The front panel can be cleaned from time to time using a damp, soft cloth.

4.1.2 Electrical Maintenance

4.1.2.1 Testing the Level Measuring Accuracy

Due to the total calibration facility by means of the built-in calibration generator, high long-term stability of the level measuring characteristics is guaranteed. It is recommended to check the measuring accuracy every two years according to section 5. Reprogramming of the correction data by a R&S servicing shop is necessary, if tolerances are exceeded.

4.1.2.2 Testing the Frequency Accuracy

The frequency accuracy of the reference oscillator is to be checked once a year according to section 5. It is not necessary to perform this test if the instrument is operated using an external reference.

Test utility: Frequency counter of signal generator

Test setup: Measurement with frequency counter
Connect frequency counter to the REF OUT/IN socket at the rear of the instrument.

Measurement with signal generator
Apply signal with 1GHz, -10dBm to RFin.

Measurement: Settings on FSE:

[CENTER	1000 MHz]
[SPAN	0 MHz]
[REF REF LEVEL	-10 dBm]
[MARKER COUNT	ON
COUNTER RESOL	0.1 Hz]

Activate internal frequency counter (marker function)

This page is intentionally left blank.

4.2 Monitoring the Function of the FSE

4.2.1 Switch-on Test

Following switch-on of the instrument a selftest of the processor functions is executed first. Subsequently, the transputer net is initialized, which adopts control of the analog modules.

4.2.2 Monitoring of the Synthesizers and Signal Levels

The FSE is provided with a large amount of selftest points which can be switched to an A/D converter via multiplexer. Most of these test points are located on the analog modules and, by means of level detectors, allow for monitoring the levels in the signal path, the output levels of the LO drivers and the tuning voltages of the oscillators. The selftest voltages which are required for proper functioning, are additionally monitored by comparators. The output signals of these comparators are stored and checked by the level transputer during each request of a measured value. If one of these comparators responds, one of the following error messages is output:

Message	Meaning	see Section
Reference unlock	Reference osxillator not synchronized	"Error Messages of the Synthesizer"
LO UNL	First LO not synchronized	"Error Messages of the Synthesizer"
2nd/3rd LO unlock	Second and third LO not synchronized	"Error Messages of the Synthesizer"
Level 1st LO	LO level at first mixer too small	"Error Messages of the Synthesizer"
Level 2nd LO	LO level at second mixer too small	"Error Messages of the Synthesizer"
Level 3rd LO	LO level at third mixer too small	"Error Messages of the Synthesizer"
OVLD	Input signal too large	"Overload Messages"
IF OVLD	Signal following IF amplifier too large	"Overload Messages"

4.2.3 Error Messages of the Synthesizer

When the message LO UNL is displayed, the instrument continues operating, however, the signals indicated may have been shifted on the frequency axis. In particular, when the instrument is operated at about the maximum or minimum operating temperature, it may occur, after ageing of the analyzer, that the tuning voltage of the voltage-controlled oscillators drift at the limit of the permitted range. Therefore, correction of the pretuning is provided for the first LO (YIG oscillator) and the third LO (VCO) which is performed during total calibration of the instrument, thus eliminating the error. Correction is not required for the second LO, since it is obtained by multiplication of the third LO. For measuring accuracy reason, it is recommended with very cold or hot environment to call the total calibration of the instrument (after a warm-up period of at least 30 minutes).

When the message "Reference unlock" is output and if the analyzer is set to external reference, check that the latter is applied with the correct frequency and sufficient level at connector EXT REF IN/OUT. If the analyzer is set to internal reference, the message should only occur during a short warm-up phase following switch-on.
The message Level Lo means that the level at the LO gate of one of the mixers is too low, which may lead to dips in the conversion attenuation. In any case, this message indicates a fault inside the instrument.

4.2.4 Overload Messages

The messages OVLD and IF-OVLD indicate an overload in the signal path of the instrument. These messages are a warning that the analyzer indication will seem to be wrong, because one stage in the signal path is operated with the 1-dB compression or above.
The message OVLD indicates that one stage preceding the variable IF amplifier is operated with an exceeded level. The level can only be reduced by an increased attenuation of the input attenuator (RF Attenuation). Overload at the input mixer and in the subsequent stages frequently occurs, if pulsed or highly modulated signals are applied. Such signals have a high peak value compared to the input bandwidth and this may lead to compression of these stages.
If this message is output without an input signal being applied, the input mixer is defective. The LO feedthrough (= the level display with input frequency zero) depends to a large extent on the balance of the input mixer. Since a partially faulty mixer becomes very unbalanced, thus providing very high LO feedthrough, this may lead to overload of the subsequent stages and thus to output of the message OVLD.
The message IF-OVLD indicates compression in one stage following the switchable IF amplifier. This can be remedied even with fixed input attenuation by increasing the reference level. In analyzer mode, the IF amplification depends on the reference level and the RF attenuation.

4.3 Function Description of the Overall Instrument

4.3.1 Introduction

This section informs on the theory of operation of this instrument.

4.3.2 Modules of the Analog Unit

All modules of the analog unit contain an individually programmed EEPROM indicating the model and correction data, such as frequency response, filter parameters, insertion gain. The analog unit consists of the following modules:

- RF modules with RF converter and YIG sampler forming part of the RF module
- v MW converter modules (for instruments with a frequency range > 7 GHz)
- 2nd IF converter
- IF filter
- I/Q-demodulator (vector signal analyzer)
- Fracsyn with static transputer module
- Low phase noise for instrument model 30
- Detector board with dynamic transputer module and DSP module
- Analog motherboard

4.3.3 Modules of the Digital Unit

The boards of the digital unit do not contain any particular correction data. The digital unit is independent of the type of instrument, the only difference is the amount and type of plug-in boards fitted such as VGA board for the DOS option or a network board. The digital unit consists of the following modules:

- Main processor
- Graphic board
- Digital motherboard (containing the interface drivers such as IEC bus, LPT and COM)
- Hard disk
- Floppy disk
- LC display
- Keypad
- Option VGA board
- Option 2nd IEEE-bus
- Option LAN interface

4.3.4 Description of the Analog Unit

The FSE has been conceived as analyzer with triple conversion. Special importance has been attached to reaching high display dynamics, i.e., the individual amplifier stages have not only been trimmed to minimum displayed noise level but adjusted such that they provide good intermodulation characteristics with an acceptable noise factor.

The input signal passes a switchable input divider (attenuation range 0 to 70dB in steps of 10dB), which also switches the internal calibration and test signal.

In the RF converter, the signal is converted to the 1st IF (FSEA: 4.3414 GHz (FSEB: 7.9414 GHz) using the 1st LO (FSEA: 4.3414 to 7.8414 GHz, FSEB: 7.9414 to 14.9414 GHz) after having passed the input lowpass in the 1st mixer. Following the 1st IF filter and the IF gain, the signal is converted to the 2nd IF of 741.4MHz.
By those FSE models having a frequency range greater than 7 GHz, the signal is divided, after the input divider, in a switchable diplexer. The portions of the signal below 7 GHz are further processed in the RF converter. The portions of the signal above 7 GHz are fed via a YIG filter to the MW converter. The conversion of the IF of 741.4 MHz takes place in this module. The LO required for the conversion comes from the RF converter and, depending on the frequency range, is either fed directly or via a doubler to the mixer.
The next module in the signal path is the 2nd IF Converter, which provides for conversion of the second IF to the third IF of 21.4 MHz and generation of the second and third LO. Apart from several amplifiers it contains a filter on 741.4 MHz with a 3-dB bandwidth of 10 MHz. This filter serves as resolution filter if the resolution bandwidth is 10 MHz and it reflects the image frequency which might be generated by the third conversion.

The resolution filters for bandwidths between 1 kHz and 5 MHz are located on the IF filter board . With the 10-MHz bandwidth, the filter stages of the board are bypassed. Crystal filters are used for bandwidths between 1 and 30 kHz, LC filters are provided for bandwidths of 50 kHz or above. The individual filter stages have been decoupled from each other by means of amplifiers which is why they act as Gaussian filter. Subsequent to the first two filter stages, switchable IF amplifiers (Step Gain) and two independent calibration amplifiers are fitted. The step gain can be switched in 0.1-dB steps from 0 to 50 dB and is used to amplify the signal on the reference level. One of the two calibration amplifiers is used to compensate for the deviations of amplification with different bandwidth or step-gain settings. This amplifier is controlled via the serial interface of the level transputer and a D/A converter on the IF filter board. The second calibration amplifier is controlled by an analog voltage, which is modified by the frequency transputer during the sweep according to the frequency response of the input stages.

The IF filters are followed by the log module, which provides for a dynamic of 90 or 110 dB depending on the model. The video signal thus created is passed to the detector board. There, it is through-connected to the rear panel.
If resolution bandwidths are < 1kHz, the signal path via the log module remains unused. The signal is still filtered by the IF filter board to a bandwidth of 3 kHz, but then converted to a 25-kHz IF and filtered digitally on the module. An 18-bit A/D converter is provided on the digital IF for sampling with the 25-kHz IF.

A measuring A/D converter with a sampling rate of 20 MHz is provided on the detector board. Due to the high sampling rate of the A/D converter the analog peak detectors are not required, they are digitally simulated following the converter. Video filtering is carried out digitally, too, in the noise filter gate-array on the detector board. For video bandwidths ≤ 20 kHz, additional filtering is carried out using a DSP, which remains disabled above 20 kHz.

4.3.5 Processor Structure

Apart from a 80486 CPU, the FSE is provided with three T805-32-bit transputers and a 16-bit transputer T225. Two DSPs are provided in the basic instrument for digital signal processing.

The 80486 CPU controls the complete data exchange with the periphery, such as keybaord entry, representation of the softkeys and operation via the IEC bus. The transputers independently control the test procedure, calculate correction factors and display the measuring curve on the screen. The transputers are provided with the current instrument settings by the 80486 CPU via a link adapter, which connects the ISA bus of the CPU board with a transputer link of the T805 on the graphic board (called GTP = graphic transputer in the following). Other transputer links couple the T224 on the graphics board and the two T805 on the detector board (LTP = level transputer) and the Fracsyn (FTP = frequency transputer) to the GTP. T225 is exclusively used as interface between the GTP and the chipset for graphics.

4.3.5.1 Tasks of the Level Transputer

The PTP receives the level-dependent settings from the graphic transputer and causes the corresponding switchovers in the hardware to be made via a serial interface. The PTP has the following functions: making the level-dependent settings such as attenuation of the attenuator, the bandwidths on the IF filter and level correction with the calibration frequency (120 MHz) and, on the other hand, programming of the DSPs, obtaining the measured values and passing the measured values to the graphic transputer via the transputer link. To meet these requirements, the PTP is provided with its individual serial bus to those boards which require level-dependent settings. I.e., the modules IF filter, digital IF, attenuator control board.

4.3.5.2 Tasks of the Frequency Transputer

The FTP receives the current sweep setting from the graphic transputer via the PTP and calculates the required synthesizer settings. For settings which have to be made during a sweep, the FTP is fitted with a fast parallel bus on the fracsyn module, which also addresses the sweep synthesizer. The subsequent settings have to be made: the frequency-dependent level correction, coarse tuning of the YIG oscillator and control of the sweep output. The fracsyn module therefore accommodates D/A converters which are programmed parallely during the sweep and which provide control voltages. The voltage for the sweep output is applied to the rear panel where it provides a sawtooth voltage which starts at 0V at the sweep start and increases to 10 V at the end of sweep. The voltage for frequency-response correction is passed to a voltage-controlled amplifier on the IF filter board which compensates for the frequency-dependent attenuation characteristic of the input stages. The third tuning voltage leads to the RF module where the main coil of the YIG oscillator which is integrated in the YIG sampler is controlled by means of a voltage-controlled current source, thus controlling the coarse tuning of the first LO. D/A converters which are required for options are provided in the basic FSE model. A serial bus is available for the FTP to use when controlling time-critical settings.

This page is intentionally left blank.

4.4 Selftest

The selftest allows for checking the instrument functions without using additional test instruments. When an instrument error occurs, the module which caused the error is indicated on the screen. The following measures are taken to localize an error:

- An additional A/D converter is provided which allows for measuring voltages on the various modules.
- While the selftest is being performed, important dc voltages, on-board supply voltages and amplifier operating points are measured and compared to their rated values.
- Level detectors check the oscillator levels required for operating the mixers
- The calibration generator generates a 120-MHz signal with a level of 0 dBm at the RF input of the instrument. The on-board level detectors in the signal path allow for processing of the input signal in the individual RF and IF stages.

4.4.1 Operation

Operation of the selftest is explained in Chapter 2, Section "Selftest Functions".

4.4.2 Testing the Processor Functions

The test of the processor functions comprises testing of the interface chips and the dynamic RAM, test of the graphic board and the connected transputers.
If the CPU, the dynamic RAM or the hard disk are defective, the instrument may not be able any more to output a detailed error message.

4.4.3 Testing the Synthesizers

Correct functioning of all oscillators is absolutely necessary for checking the signal path. Therefore, all synthesizer modules are checked next. The synthesizer modules are tested in the following order:

1. Test of the reference frequencies with 10 MHz and 120 MHz and the derived signals with 20, 30 and 60 MHz.
2. Measurement of the signals applied to the YIG sampler (output signal of fracsyn and output signal of sampler)
3. Test of the YIG main loop with the cutoff frequencies by measuring the YIG tuning voltage
4. Check of the LO levels and of the operating points of the LO drivers

In case of an error the selftest is aborted since it does not make sense measuring the signal path if e.g., no LO level is provided.

4.4.4 Testing the Signal Path

Subsequently, the modules in the signal path are checked. The fracsyn module accommodates a 120-MHz calibration generator, the output power of which is checked using individual test points. This signal is connected into the signal path via a changeover switch in the input attenuator of the FSE. The test sequence is as follows:

1. Check of the RF attenuator
2. Check of the RF converter by testing the operating points of the amplifiers
3. Check of the 2nd IF converter by testing the operating point of the amplifier for the second IF and reading out of the level detectors in the signal path.
4. Check of the IF filters by testing the supply voltages for the individual filter circuits, the tuning voltages for the filter bandwidths and the level detectors.
5. Check of detector board

Though the selftest provides high measuring depth, it cannot be assumed that the module which has been found out to be faulty is always really faulty. A faulty cable, e.g., has the same effect as an interrupt in the input attenuator. Therefore, have the faulty function checked by an R&S servicing shop when an error message occurs.

5 Checking the Rated Specifications

5.1 Measuring Equipment and Accessories

Item	Type of equipment	Specifications recommended	Equipment recommended	R&S Order No.	Use
1	Frequency counter	error < $1x10^{-9}$, frequency range up to 10 MHz	Advantest R5361B with option 23		5.2.2
2	Signal generator	FSEA: 10 MHz to 3.5 GHz FSEB: 10 MHz to 7 GHz FSEM: 10 MHz to 26.5 GHz FSEK: 10 MHz to 40 GHz	SMHU SMP02 SMP03 SMP04	0835.8011.52 1035.5005.02 1035.5005.03 1035.5005.04	5.2.3 5.2.4 5.2.5.1
3	Signal generator	phase noise at 498 MHz: < -100 dBc/Hz @ 100 Hz < -115 dBc/Hz @ 1 kHz < -127 dBc/Hz @ 10 kHz < -130 dBc/Hz @ 100 kHz < -142 dBc/Hz @ 1MHz	SMHU	0835.8011.52	5.2.1 5.2.5.1 5.2.5.2 5.2.6 5.2.8 to 12
4	Signal generator (FSEB / FSEM / FSEK)	FSEB: 10 MHz to 7 GHz FSEM: 10 MHz to 26.5 GHz FSEK: 10 MHz to 40 GHz	SMP02 SMP03 SMP04	1035.5005.02 1035.5005.03 1035.5005.04	5.2.5.1 5.2.8
5	3-dB coupler (power combiner)	decoupling > 12 dB FSEA: 10 MHz to 3.5 GHz FSEB: 10 MHz to 7 GHz FSEM: 10 MHz to 26.5 GHz FSEK: 10 MHz to 40 GHz			5.2.5.1
6	6-dB divider (power splitter)	level imbalance 1MHz to 1GHz ≤ 0.15 dB 1GHz to 7GHz ≤ 0.2 dB 7GHz to 18GHz ≤ 0.3 dB 18GHz to 26.5GHz ≤ 0.4 dB 26.5GHz to 40GHz ≤ 0.4 dB FSEA: 10 MHz to 3.5 GHz FSEB: 10 MHz to 7 GHz FSEM: 10 MHz to 26,5 GHz FSEK: 10 MHz to 40 GHz			5.2.8
7	50-Ω termination	Return loss > 20 dB FSEA: up to 3.5 GHz FSEB: up to 7 GHz FSEM: up to 26.5 GHz FSEK: up to 40 GHz	 RNA RNA Wiltron 28S50 Wiltron 28K50	 0272.4510.50 0272.4510.50	5.2.7
8	Power meter		NRVD	0857.8008.02	5.2.1 5.2.3 5.2.8
9	Power sensor	1 MHz to 3.5 GHz RSS ≤ 0.8% Meter noise ≤ 20 pW	NRV-Z4	0828.3618.02	5.2.1 5.2.3 5.2.8

Item	Type of equipment	Specifications recommended	Equipment recommended	R&S Order No.	Use
10	Power sensor (FSEB / FSEM / FSEK)	RSS referred to indicated Power: 1 MHz to 1 GHz ≤ 1.5 % 1 GHz to 7 GHz ≤ 2 % 7 GHz to 26.5 GHz ≤ 3.5 % 26.5 GHz to 40 GHz ≤ 4 % FSEB: 10 MHz to 7 GHz FSEM: 50 MHz to 26.5 GHz FSEK: 1 MHz to 40 GHz	 NRV-Z2 NRV-Z6 NRV-Z55	 0828.3218.02 0828.5010.02 1081.2005.02	5.2.3 5.2.8
11	Reflection coefficient VSWR bridge (FSEA / FSEB)	directivity > 30 dB FSEA / FSEB: 10 MHz to 3.5 GHz FSEB: 3.5 GHz to 7 GHz	 ZRC Wiltron 87A50 (also required: adapter 34AN50, open/short 22NF50)	1039.9492.55	5.2.3
12	Network analyzer (FSEM / FSEK)	FSEM: 10 MHz to 26,5 GHz FSEK: 10 MHz to 40 GHz			5.2.3
13	Step attenuator	variable attenuation 0 dB to 100 dB, 1-dB steps attenuation error < 0.05 dB (f = 5 MHz)	RSP	0831.3515.02	5.2.9 5.2.10 5.2.11
14	Attenuator (2 x)	fixed attenuation 10 dB FSEA: 10 MHz to 3.5 GHz FSEB: 10 MHz to 7 GHz FSEM: 10 MHz to 26.5 GHz FSEK: 10 MHz to 40 GHz	 DNF DNF Wiltron 43KB-10 Wiltron 43KC-10	 0272.4210.50 0272.4210.50	5.2.5.1
15	Lowpass[1)]	cut-off frequency: 10 kHz, 40 kHz, 100 kHz, 20 MHz, 29 MHz, 108 MHz, 263 MHz, 454 MHz, 641 MHz, 1.1 GHz, 1.3 GHz, 1.8 GHz			5.2.5.2
16	N-connecting cables Tracking RF input	Attenuation up to 7 GHz < 0.1dB			
17	2 DC sources for I and Q	can be set between ±0.5V	NGT35	0191.2019.02	
18	2 DC voltmeters		URE	0350.5315.02	

1) The lowpass filters improve the harmonics suppression of the test signal. If the harmonics suppression at the signal generator output is already large enough, no filters are required for the frequency ranges concerned (see section 5.2.5.2 for harmonics suppression required)

5.2 Test Instructions

The rated specifications of the analyzer are tested after a warm-up time of at least 30 minutes and overall calibration. Only in this case can the compliance with the guaranteed data be ensured.

Values given in the following sections are not guaranteed. Only the technical specifications of the data sheet are binding.

Conventions for setting the FSE during measurements:

[**<KEY>**]	Press a key on the front panel, eg [SPAN]
[<SOFTKEY>]	Press a softkey, eg [MARKER -> PEAK]
[<nn unit>]	Enter a value and terminate by entering the unit, eg [**12 kHz**]

Successive entries are separated by [:], eg [**SPAN**: **15 kHz**]

5.2.1 Checking the Calibration Source at 120 MHz

Note: *If option FSE-B22 is installed see chapter 5.4.1 for test instructions.*

Test equipment:

- signal generator (section 5.1, item 3):
  frequency 120 MHz
  level -40 dBm
- power meter (section 5.1, item 8)
- power sensor (section 5.1, item 9)
  frequency 120 MHz
  maximum power $P_{max} \geq 1$ µW
  meter noise ≤ 20 pW
  RSS ≤ 0.8% referred to indicated power
  impedance Z = 50 Ω

Power meter settings:

- ➢ connect power sensor to power meter and carry out function ´ZERO´ when no signal is applied to the power sensor.
- ➢ connect power sensor to RF output of signal generator.

Signal generator settings:

- frequency 120 MHz
- level –40 dBm ± 0.1 dB
  Use power meter for exact level adjustment.

Test setup:

- ➢ connect RF output of the signal generator to RF input of the FSE

FSE settings:

- [**SYSTEM PRESET**]
- [**FREQUENCY CENTER** : **120 MHz**]
- [**FREQUENCY SPAN** : **15 kHz**]
- [**SWEEP COUPLING** : RES BW MANUAL : **5 kHz**]
- [**LEVEL REF** : REF LEVEL : **-10 dBm**]
- [**INPUT** : RF ATTEN MANUAL : **20 dB**]

- ➢ set marker to peak of signal
  [**MARKER SEARCH** : PEAK]
- ➢ set reference to peak of signal
  [**MARKER DELTA** : REFERENCE FIXED]
- ➢ switch internal reference generator to RF input
  [**CONFIGURATION SETUP** : SERVICE : INPUT CAL]
- ➢ set marker to peak of signal
  [**MARKER SEARCH** : PEAK]

Evaluation: The reading ´Delta 1 [T1 FXD]´ displays the difference between the output level of the signal generator and the level of the calibration source < 0.3 dB

Note: *The level of the calibration source can be adjusted with R22 on FracSyn module.*

5.2.2 Checking the Frequency Accuracy of the Reference Oscillator

Test equipment: frequency counter (section 5.1, item 1):
error < $1x10^{-9}$
frequency range up to 10 MHz

Test setup: - connect frequency counter to 10-MHz reference output of the FSE (rear panel)

FSE settings: - [**CONFIGURATION SETUP** : REFERENCE INT / EXT]
toggle to internal reference (INT)

Measurement: measure frequency with frequency counter

nominal frequency:
Model 20 without OCXO (option B4) .....10 MHz ± 10 Hz
Model 30 or 20 with OCXO (option B4) .....10 MHz ± 1 Hz

5.2.3 Checking the Return Loss at the RF Input

Test equipment:

FSEA / FSEB:

- signal generator (section 5.1, item 2)
  frequency range FSEA: 10 MHz to 3.5 GHz
  FSEB: 10 MHz to 7 GHz
  maximum level ≥ 0 dBm
- power meter (section 5.1, item 8)
- power sensor (section 5.1; FSEA: item 9; FSEB: item 10)
  frequency range FSEA: 10 MHz to 3.5 GHz
  FSEB: 10 MHz to 7 GHz
- reflection coefficient bridge (section 5.1, item 11)
  frequency range FSEA: 10 MHz to 3.5 GHz
  FSEB: 10 MHz to 7 GHz
  directivity ≥ 30 dB

FSEM / FSEK:

- network analyzer (section 5.1, item 12)
  frequency range FSEM: 10 MHz to 26.5 GHz
  FSEK: 10 MHz to 40 Ghz

Test setup:

FSEA / FSEB:



FSEM / FSEK:
Connect port 1 of network analyzer to RF input of the FSE.

Signal generator settings:
(FSEA / FSEB)

- level 0 dBm
- frequency {f_{in}}

See table 5-1 (item 3) of performance test report for values of f_{in}.

FSE settings:

- [**SYSTEM PRESET**]
- [**INPUT** : RF ATTEN MANUAL : **10 dB**]

Calibration:

FSEA / FSEB:
Use total reflection (OPEN or SHORT) at the test port of the SWR bridge as a reference:
Remove cable from RF input of the FSE and connect precision short or open to the cable. Determine reflected power with the power meter and store measured level L_{Ref} as reference. Repeat this procedure for every measurement over the whole frequency range.

FSEM / FSEK:
See operating manual of the network analyzer for detailed information about calibration for S_{11} measurement.

Measurement

FSEA / FSEB:
Connect the RF input of the FSE to the test port of the SWR bridge. Measure reflected power L_r with the power meter. The return loss a_r of the RF input of the FSE can be calculated as

$$a_r = L_{Ref} - L_r \, .$$

The SWR can be calculated as

$$s = \frac{10^{0.05a_r} + 1}{10^{0.05a_r} - 1} \, .$$

FSEM / FSEK:
Determine S_{11} of the FSE at the frequencies shown in table 5-1 (item 3) of performance test report. See operating manual of the network analyzer for detailed information about S_{11} measurement.

a_r / dB	s
6	3.0
7.4	2.5
8	2.3
9.5	2.0
10	1.9
12	1.7
14	1.5
16	1.4
18	1.3
20	1.2

5.2.4 Checking Imunity to Interference

Test equipment: signal generator (section 5.1, item 2):
frequency range FSEA: 10 MHz to 3.5 GHz
FSEB: 10 MHz to 7 GHz
FSEM / FSEK: 10 MHz to 8 GHz
maximum level ≥ -10 dBm

Test setup: connect RF output of the signal generator to RF input of the FSE.

Signal generator settings: level -10 dBm ± 0.5 dB

FSE settings:
- [**SYSTEM PRESET**]
- [**INPUT** : RF ATTEN MANUAL : **0 dB**]
- [**LEVEL REF** : REF LEVEL : **-30 dBm**]
- [**FREQUENCY SPAN** : **100 kHz**]
- [**SWEEP COUPLING** : RES BW MANUAL : **2 kHz**]

5.2.4.1 1st IF Image Frequency Rejection

Additional signal generator settings:
- frequency f_{in} + 2 x 1st IF

FSEA	f_{in} + 8682.8 MHz
FSEB	f_{in} + 15.8828 GHz
FSEM / FSEK	f_{in} + 15.8828 GHz (f_{in} < 7 GHz)

See table 5-1 (item 4) of performance test report for values of f_{in}

Additional FSE settings:
- [**FREQUENCY CENTER** : {f_{in}}]

See table 5-1 (item 4) of performance test report for values of f_{in}

- set marker to peak of signal
[**MARKER SEARCH** : PEAK]

Evaluation: The image frequency rejection is the difference between the output level of the signal generator and the level reading of marker 1 (L_{dis}):

Image frequency rejection = -10dBm – L_{dis}

Unit	1st IF image frequency rejection
FSEA20	> 75 dB
FSEA30	> 80 dB
FSEB / FSEM / FSEK	> 80 dB

5.2.4.2 2nd IF Image Frequency Rejection

Additional signal generator settings:
- frequency f_{in} + 2 x 2nd IF
  f_{in} + 1482.8 MHz

See table 5-1 (item 5) of performance test report for values of f_{in}.

Additional FSE settings:
- [**FREQUENCY CENTER** : {f_{in}}]

See table 5-1 (item 5) of performance test report for values of f_{in}.

- set marker to peak of signal
  [**MARKER SEARCH** : PEAK]

Evaluation:
The image frequency rejection is the difference between the output level of the signal generator and the level reading of marker 1 (L_{dis}):

Image frequency rejection = –10dBm – L_{dis}

Unit	2nd IF image frequency rejection
FSEA20	> 75 dB
FSEA30	> 80 dB
FSEB / FSEM / FSEK	> 80 dB

5.2.4.3 1st IF Rejection

Additional signal generator settings:
- frequency = 1st IF

FSEA	4341.4 MHz
FSEB	7941.4 GHz
FSEM / FSEK	7941.4 GHz (f_{in} < 7 GHz) 741.4 MHz (f_{in} ≥ 7 GHz)

Additional FSE settings:
- [**FREQUENCY CENTER** : {f_{in}}]

See table 5-1 (item 6) of performance test report for values of f_{in}.

- set marker to peak of signal
  [**MARKER SEARCH** : PEAK]

Evaluation:
The IF rejection is the difference between the output level of the signal generator and the level reading of marker 1 (L_{dis}):

IF rejection = –10dBm – L_{dis}

Unit	1st IF rejection
FSEA20	> 80 dB
FSEA30	> 100 dB
FSEB / FSEM	> 75 dB
FSEK	> 80 dB

5.2.5 Checking Non-linearities

5.2.5.1 Third-Order Intercept

Test equipment:

- 2 signal generators (FSEA: section 5.1, item 2 and 3;
  FSEB / M / K: section 5.1, item 2 and 4)
  frequency range
  FSEA: 10 MHz to 3.5 GHz
  FSEB: 10 MHz to 7 GHz
  FSEM: 10 MHz to 26.5 GHz
  FSEK: 10 MHz to 40 GHz
  maximum level ≥ 0 dBm

- 2 attenuators (section 5.1, item 14)
  attenuation a_{ATT} = 10 dB
  frequency range
  FSEA: 10 MHz to 3.5 GHz
  FSEB: 10 MHz to 7 GHz
  FSEM: 10 MHz to 26.5 GHz
  FSEK: 10 MHz to 40 GHz

- 3-dB coupler (section 5.1, item 5)
  frequency range
  FSEA: 10 MHz to 3.5 GHz
  FSEB: 10 MHz to 7 GHz
  FSEM: 10 MHz to 26.5 GHz
  FSEK: 10 MHz to 40 GHz
  decoupling > 12 dB

Test setup:

- connect RF outputs of the signal generators via 10-dB attenuators to the inputs of the 3-dB coupler
- connect output of the 3-dB coupler to RF input of the FSE.

Signal generator settings:
(both generators)

- frequency: generator 1 $f_{g1} = f_{in}$
  generator 2 $f_{g2} = f_{in}$ + 100 kHz

  See table 5-1 (item 7) of performance test report for values of f_{in}

- level: 0 dBm

FSE settings:

- [**SYSTEM PRESET**]
- [**INPUT** : RF ATTEN MANUAL : **0 dB**]
- [**LEVEL REF** : **-10 dBm**]
- [**FREQUENCY SPAN** : **50 kHz**]
- [**SWEEP COUPLING** : RES BW MANUAL : **2 kHz**]
- [**FREQUENCY CENTER** : {f_{in}}]

  See table 5-1 (item 7) of performance test report for values of f_{in}

- [**MARKER SEARCH** : PEAK]

  Adjust the output level of signal generator 1 until the level reading of marker 1 is -10 dBm ± 0.1 dB.

- [**FREQUENCY CENTER** : {f_{in} + 100 kHz}]

  See table 5-1 (item 7) of performance test report for values of f_{in}

- [**MARKER SEARCH** : PEAK]

  Adjust the output level of signal generator 2 until the level reading of marker 1 is -10 dBm ± 0.1 dB.

- set reference to peak of signal
  [**MARKER DELTA** : REFERENCE FIXED]
- set center frequency to intermodulation product (2 x f_{g2} - f_{g1})
  [**FREQUENCY CENTER** : {f_{in} - 100 kHz}]

- [**MARKER SEARCH** : PEAK]

  The intermodulation ratio IMR_1 is displayed by the reading ´Delta 1 [T1 FXD]´

- set center frequency to intermodulation product (2 x f_{g1} - f_{g2})
  [**FREQUENCY CENTER** : {f_{in} + 200 kHz}]

- [**MARKER SEARCH** : PEAK]

  The intermodulation ratio IMR_2 is displayed by the reading ´Delta 1 [T1 FXD]´

Evaluation:

The third order intercept point (T.O.I) referred to the input signal can be caculated as

$$T.O.I. = \frac{IMR}{2} - 10dBm \ ,$$

where IMR is the lower of IMR_1 and IMR_2

Unit	Frequency range	T.O.I.
FSEA	f ≤ 50 MHz	≥ 7 dBm
	f > 50 MHz	≥ 12 dBm
FSEB / FSEM / FSEK	f ≤ 150 MHz	≥ 7 dBm
	f > 150 MHz	≥ 12 dBm
FSEK	f > 7 GHz	≥ 10 dBm

5.2.5.2 Second-Order Harmonic Distortion

Test equipment:

- signal generator (section 5.1, item 3)
  frequency range
  FSEA: 9 kHz to 1.7 GHz
  FSEB / FSEM / FSEK: 9 kHz to 3.4 GHz
- to improve the harmonic suppression of the generator it is recommended to insert a lowpass filter with a suitable cut-off frequency (section 5.1, item 15) after the generator.

The required suppression of the second harmonics is listed in the table at the end of this section. As a result, the error for the entire frequency range is < 1dB.

Test setup:

- connect RF output of the signal generator to the input of the lowpass
- connect the output of the lowpass to the RF input of the FSE

Note: *If the harmonic suppression of the signal generator is sufficient, the lowpass can be left out.*
The RF output of the generator can be connected directly to the RF input of the FSE in this case.

Signal generator settings:

- frequency: f_{in}

see table 5-1 (item 8) of performance test report for values of f_{in}

- level: -10 dBm

FSE settings:

- [**SYSTEM PRESET**]
- [**INPUT** : RF ATTEN MANUAL : **0 dB**]
- [**LEVEL REF** : **-10 dBm**]
- [**FREQUENCY SPAN** : **3 kHz**]
- [**SWEEP COUPLING** : RES BW MANUAL : **1 kHz**]
- [**FREQUENCY CENTER** : {f_{in}}]

See table 5-1 (item 8) of performance test report for values of f_{in}

- set marker to peak of signal
[**MARKER SEARCH** : PEAK]

- set reference to peak of signal
[**MARKER DELTA** : REFERENCE FIXED]

- set center frequency of the FSE to the frequency of the 2nd harmonic
[**FREQUENCY CENTER** : {2 x f_{in}}]

See table 5-1 (item 8) of performance test report for values of f_{in}

- set marker to peak of the 2nd harmonic
[**MARKER SEARCH** : PEAK]

Evaluation:

The reading ´Delta 1 [T1 FXD]´ displays the second harmonic suppression (a_{k2}). The exact input level L_{in} is displayed by the reading ´FXD {level} dBm´.
The second order harmonic distortion can be calculated as

$$IP_{k2} / dBm = a_{k2} + L_{in}$$

Unit	Frequency range	IP_{k2}	**Required suppression of the second harmonics**
FSEA	f ≤ 50 MHz	> 25 dBm	45 dBc
	f > 50 MHz	> 45 dBm	65 dBc
FSEB / FSEM / FSEK	f ≤ 150 MHz	> 25 dBm	45 dBc
	f > 150 MHz	> 40 dBm	60 dBc

5.2.6 Checking IF Filters

Test equipment: signal generator (section 5.1, item 3):
frequency 120 MHz
level ≥ -10 dBm

Test setup: connect RF output of the signal generator to the RF input of the FSE.

5.2.6.1 Checking the Level Error

Note: *If option FSE-B22 is installed see chapter 5.4.2 for test instructions.*

Reference Measurement (RBW 5 kHz)

Signal generator settings:
- frequency: 120 MHz
- level: -20 dBm

FSE settings:
- [**SYSTEM PRESET**]
- [**INPUT** : RF ATTEN MANUAL : **10 dB**]
- [**LEVEL REF** : **0 dBm**]
- [**FREQUENCY CENTER** : **120 MHz**]
- [**SWEEP COUPLING** : COUPLING RATIO : RBW/VBW SINE [1]]
- [**SWEEP COUPLING** : COUPLING RATIO : SPAN/RBW MANUAL : **5** : **ENTER**]
- resolution bandwidth 5 kHz
  [**FREQUENCY SPAN** : **25 kHz**]
- set marker to peak of signal
  [**MARKER SEARCH** : PEAK]
- set reference to peak of signal
  [**MARKER DELTA** : REFERENCE FIXED]

Checking the Level Error

FSE settings:
- [**FREQUENCY SPAN** : {5 x RBW}]

  See table 5-1 (item 9) of performance test report for values of RBW.
- [**SWEEP COUPLING** : RES BW MANUAL : {RBW}][1]

  [1] ***Note:*** *To check the level error of the 5-MHz and the 10-MHz filter, the resolution bandwidth has to be set manually to 5 MHz or 10 MHz. All other bandwidths will be set automatically by changing the frequency span.*
- set marker to peak of signal
  [**MARKER SEARCH** : PEAK]

  The level error is displayed by the reading
  ´Delta 1 [T1 FXD] {level error} dB´.

Evaluation: See table 5-1 (item 9) of performance test report for upper and lower limits of level error.

5.2.6.2 Checking 3-dB Bandwidths

Signal generator settings:
- frequency: 120 MHz
- level: -20 dBm

FSE settings:
- [**SYSTEM PRESET**]
- [**INPUT** : RF ATTEN MANUAL : **10 dB**]
- [**LEVEL REF** : **0 dBm**]
- [**FREQUENCY CENTER** : **120 MHz**]
- [**SWEEP COUPLING** : COUPLING RATIO : RBW/VBW SINE [1]]
- [**SWEEP COUPLING** : COUPLING RATIO : SPAN/RBW MANUAL : **5** : **ENTER**]
- determine 3-dB bandwidth
  [**MARKER SEARCH** : **MENU** ⇒ : N DB DOWN : **3 dB**]
- [**FREQUENCY SPAN** : {5 x RBW}]
  See table 5-1 (item 10) of performance test report for values of RBW.
- [**SWEEP COUPLING** : RES BW MANUAL : {RBW}][1]

  [1] ***Note:*** *To check the bandwidth of the 5-MHz and the 10-MHz filter, the resolution bandwidth has to be set manually to 5 MHz or 10 MHz. All other bandwidths will be set automatically by changing the frequency span.*
- [**MARKER SEARCH** : PEAK]

  The 3-dB bandwidth is displayed by the reading ´BW {bandwidth}´.

Evaluation:
See table 5-1 (item 10) of performance test report for upper and lower limits of 3dB-bandwidths.

Note: *Due to the phase noise, measurements on models 20 can only be carried with IF filters of a bandwidth ≥5 kHz.*

5.2.6.3 Checking the Shape Factor

Signal generator settings:
- frequency: 120 MHz
- level: –10 dBm

FSE settings:
- [**SYSTEM PRESET**]
- [**INPUT** : RF ATTEN MANUAL : **10 dB**]
- [**LEVEL REF** : **0 dBm**]
- [**FREQUENCY CENTER** : **120 MHz**]
- [**SWEEP COUPLING** : VBW MANUAL : **100 Hz**]
- [**SWEEP COUPLING** : COUPLING RATIO : SPAN/RBW MANUAL : **30** : **ENTER**]
- determine shape factor
  [**MARKER SEARCH** : **MENU** ⇒ : SHAPE FACT 60/3 DB]
- [**FREQUENCY SPAN** : {30 x RBW}]

  See table 5-1 (item 11) of performance test report for values of RBW.
- [**SWEEP COUPLING** : RES BW MANUAL : {RBW}][1]

  [1] ***Note:*** *To check the shape factor of the 5-MHz and the 10-MHz filter the resolution bandwidth has to be set manually to 5 MHz or 10 MHz. All other bandwidths will be set automatically by changing the frequency span.*
- [**MARKER SEARCH** : PEAK]

  The shape factor is displayed by the reading ´SH3 {shape factor}´.

Evaluation:

See table 5-1 (item 11) of performance test report for upper and lower limits of shape factor.

5.2.7 Checking LO Feedthrough, Noise Display

Test equipment: 50-Ω termination (section 5.1, item 7)
frequency range FSEA up to 3.5 GHz
FSEB up to 7 GHz
FSEM up to 26.5 GHz
FSEK up to 40 GHz
return loss > 20 dB

Test setup: terminate the RF input of the FSE with 50 Ω

FSE settings:
- [**SYSTEM PRESET**]
- [**INPUT** : RF ATTEN MANUAL : **0 dB**]
- [**FREQUENCY SPAN** : **0 Hz**]

5.2.7.1 LO Feedthrough

Note: *This measurement is only possible with model 30. The LO feedthrough of model 20 can be checked by measuring the noise display near f = 0 Hz (see 5.3.7.2).*

Additional FSE settings:
- [**LEVEL REF** : **-10 dBm**]
- [**FREQUENCY CENTER** : **0 Hz**]
- start calibration of LO compensation
  [**SYSTEM CAL** : CAL LO SUP]
- set marker to peak
  [**MARKER SEARCH** : PEAK]

Evaluation: The LO feedthrough is displayed by the level reading of marker 1.

5.2.7.2 Noise Display

Additional FSE settings:
- - [**SWEEP COUPLING** : RES BW MANUAL : **10 Hz**]
- [**SWEEP COUPLING** : VIDEO BW MANUAL : **1 Hz**]
- [**SWEEP COUPLING** : SWEEP TIME MANUAL : **0.1 s**]
- [**TRACE 1** : AVERAGE]
- [**TRACE 1** : SWEEP COUNT : **30 ENTER**]
- [**LEVEL REF** : **-60 dBm**]
- [**FREQUENCY CENTER** : {f_n}]

  See table 5-1 (item 13) of the performance test report for values of f_n. On models 20 set the reference level to 30 dBm for receive frequencies less than 100 kHz since the instrument can be overdriven by the LO (message IFOVL).

- set marker to peak
  [**MARKER SEARCH** : PEAK]

f_n	20 Hz	1 kHz	9,9 kHz	≥ 95 kHz
Model 20	-		-30 dBm	-60 dBm
Model 30	-30 dBm	-30 dBm	-60 dBm	-60 dBm

Evaluation: The noise level is displayed by the level reading of marker 1.

5.2.8 Checking the Frequency Response

Test equipment:

- signal generator (FSEA: section 5.1, item 3;
  FSEB / M / K: section 5.1, item 3 and item 4)
  frequency range FSEA: 1 MHz to 3.5 GHz
  FSEB: 1 MHz to 7 GHz
  FSEM: 1 MHz to 26.5 GHz
  FSEK: 1 MHz to 40 GHz
  maximum level ≥ -10 dBm
- power meter (section 5.1, item 8)
- power sensor (FSEA: section 5.1, item 9;
  FSEB / M: section 5.1, item 9 and 10;
  FSEK: section 5.1, item 10)
  frequency range FSEA: 1 MHz to 3.5 GHz
  FSEB: 1 MHz to 7 GHz
  FSEM: 1 MHz to 26.5 GHz
  FSEK: 1 MHz to 40 GHz
  maximum power P_{max} ≥ 100 µW
  RSS referred to indicated power 1 MHz to 1 GHz .....≤ 1.5 %
  1 GHz to 7 GHz.....≤ 2 %
  7 GHz to 26.5 GHz.....≤ 3.5 %
  26.5 GHz to 40 GHz.....≤ 4 %
  impedance Z = 50 Ω
- 6-dB divider (section 5.1, item 6)
  frequency range FSEA: 1 MHz to 3.5 GHz
  FSEB: 1 MHz to 7 GHz
  FSEM: 1 MHz to 26.5 GHz
  FSEK: 1 MHz to 40 GHz
  level imbalance[1] 1 MHz to 1 GHz ≤ 0.15 dB
  1 GHz to 7 GHz ≤ 0.2 dB
  7 GHz to 18 GHz ≤ 0.3 dB
  18 GHz to 26.5 GHz ≤ 0.4 dB
  26.5 GHz to 40 GHz ≤ 0.4 dB

  [1]If a power splitter with higher level imbalance is used correction of the measured frequency response is recommended.

Determining the absolute error at 120 MHz

Test setup:

- connect power sensor (section 5.1, item 9) to the power meter and execute function ´ZERO´ when there is no signal applied to the power sensor
- connect power sensor to RF output of signal generator

Signal generator settings:

- frequency 120 MHz
- level -10 dBm

Measurement:

- determine output power of the signal generator with the power meter
- connect RF output of the signal generator to RF input of the FSE

FSE settings:

- [**SYSTEM PRESET**]
- [**INPUT** : RF ATTEN MANUAL : **10 dB**]
- [**LEVEL REF** : **-7 dBm**]
- [**FREQUENCY SPAN** : **15 kHz**]
- [**SWEEP COUPLING** : RES BW MANUAL : **5 kHz**]
- [**FREQUENCY CENTER** : **120 MHz**]
- set marker to peak of signal
  [**MARKER SEARCH** : PEAK]

Evaluation:

The deviation between the signal levels measured with the power meter and the FSE (level reading of marker 1) reflects the absolute level error of the FSE. It can be calculated as

$$\text{absolute error}_{120\text{MHz}} = L_{FSE} - L_{powermeter}$$

Checking the frequency response

Test setup:

- connect RF output of the signal generator to input of the divider
- connect output 1 of the divider to the power sensor of the power meter
- connect output 2 of the divider to RF input of the FSE

Signal generator settings:

- level -10 dBm
- frequency f_{fresp}

see table 5-1 (item 14) of performance test report for values of f_{fresp}

FSE settings:

- [**SYSTEM PRESET**]
- [**INPUT** : RF ATTEN MANUAL : **10 dB**]
- [**LEVEL REF** : **-7 dBm**]
- [**FREQUENCY SPAN** : **30 kHz**]
- [**SWEEP COUPLING** : RES BW MANUAL : **5 kHz**]
- [**FREQUENCY CENTER** : {f_{fresp}}]

see table 5-1 (item 14) of performance test report for values of f_{fresp}

- activate ´preselector peak´ if center frequency is higher than 7 GHz (only available for FSEM and FSEK)
  [**SYSTEM CAL** : PRESEL PEAK]
- set marker to peak of signal
  [**MARKER SEARCH** : PEAK]

The signal level L_{FSE} is displayed by the level reading of marker 1.

Power meter settings:

Determine signal level $L_{powermeter}$. To achive higher accuracy it is recommended to compensate the frequency response of the power sensor.

Evaluation:

The frequency response can be calculated as

$$\text{Frequency response} = L_{FSE} - L_{powermeter} - \text{absolute error}_{120\text{ MHz}}$$

Note: *If option FSE-B22 is installed see also chapter 5.4.3 for additional test instructions.*

5.2.9 Checking the Display Linearity

Note: *If option FSE-B22 is installed see chapter 5.4.4 for test instructions.*

Test equipment:

- signal generator (section 5.1, item 3)
  frequency 5 MHz
  maximum level ≥ 6 dBm
- step attenuator (section 5.1, item 13)
  frequency 5 MHz
  attenuation 0 to 95 dB
  steps 1 dB
  maximum attenuation error < 0.05 dB

Test setup:

- connect RF output of the signal generator to RF input of the step attenuator
- connect RF output of the step attenuator to RF input of the FSE

Signal generator settings:

- frequency 5 MHz
- level +6 dBm

Step attenuator settings:

attenuation 16 dB

FSE settings:

- [**SYSTEM PRESET**]
- [**INPUT** : RF ATTEN MANUAL : **10 dB**]
- [**LEVEL REF** : **0 dBm**]
- [**FREQUENCY CENTER** : **5 MHz**]
- [**FREQUENCY SPAN** : **500 Hz**]
- [**SWEEP COUPLING** : RES BW MANUAL : **3 kHz**]
- [**SWEEP COUPLING** : VIDEO BW MANUAL : **100 Hz**]
- [**LEVEL RANGE** : LOG 100 dB]
- set marker to peak of signal
  [**MARKER SEARCH** : PEAK]
- set reference to peak of signal
  [**MARKER DELTA** : REFERENCE FIXED]

Measurement

Step attenuator settings:

attenuation $\{a_{ATT}\}$

see table 5-1 (item 15) of performance test report for values of a_{ATT}.

Evaluation:

The difference between the level of the input signal of the FSE and the reference (about 10 dB below the reference level) is displayed by the reading ´Delta 1 [T1 FXD]´. Compare the measured values with the limits given in table 5-1 (item 15) of performance test report.

5.2.10 Checking the Attenuator

Note: *If option FSE-B22 is installed see chapter 5.4.5 for test instructions.*

Test equipment:

- signal generator (section 5.1, item 3)
  frequency 5 MHz
  maximum level ≥ 6 dBm
- step attenuator (section 5.1, item 13)
  frequency 5 MHz
  attenuation 0 to 70 dB
  steps 10 dB
  maximum attenuation error < 0.05 dB

Test setup:

- connect RF output of the signal generator to RF input of the step attenuator
- connect RF output of the step attenuator to RF input of the FSE

Signal generator settings:

- frequency 5 MHz
- level 0 dBm

Step attenuator settings:

attenuation 60 dB

FSE settings:

- [**SYSTEM PRESET**]
- [**FREQUENCY CENTER** : **5 MHz**]
- [**FREQUENCY SPAN** : **500 Hz**]
- [**SWEEP COUPLING** : RES BW MANUAL : **3 kHz**]
- [**SWEEP COUPLING** : VIDEO BW MANUAL : **100 Hz**]
- [**INPUT** : RF ATTEN MANUAL : **10 dB**]
- [**LEVEL REF** : **-30 dBm**]
- [**MARKER SEARCH** : PEAK]

adjust output level of the signal generator until the level reading of marker 1 is exactly -60.0 dBm.

Measurement

Step attenuator settings:

attenuation {a_{ATT}}

see table below for values of a_{ATT}.

FSE settings:

- [**INPUT** : RF ATTEN MANUAL : {a_{FSE}}]
- [**LEVEL REF** : {reference level} **dBm**]
- [**MARKER SEARCH** : PEAK]

see table below for values of a_{FSE} and reference level.

Evaluation:

Compare level reading of marker 1 with the limits given in table 5-1 (item 16) of performance test report.

a_{ATT}	70 dB	60 dB	50 dB	40 dB	30 dB	20 dB	10 dB	0 dB
a_{FSE}	0 dB	10 dB	20 dB	30 dB	40 dB	50 dB	60 dB	70 dB
reference level	-40 dBm	-30 dBm	-20 dBm	-10 dBm	0 dBm	+10 dBm	+20 dBm	+30 dBm

5.2.11 Checking the IF Gain Switching

Test principle:

The IF gain of the FSE can be switched from 0 to 50 dB by changing the reference level at fixed RF attenuation. To prevent the IF gain errors to be mixed up with the log amplifier error it is determined by comparison using an external precision attenuator.

Test equipment:

- signal generator (section 5.1, item 3)
  frequency 5 MHz
  maximum level ≥ -10 dBm

- step attenuator (section 5.1, item 11)
  frequency 5 MHz
  attenuation 0 to 50 dB
  steps 1 dB
  maximum attenuation error < 0.05 dB

Test setup:

- connect RF output of the signal generator to RF input of the step attenuator
- connect RF output of the step attenuator to RF input of the FSE

Signal generator settings:

- frequency 5 MHz
- level -10 dBm

Step attenuator settings:

attenuation 30 dB

FSE settings:

- [**SYSTEM PRESET**]
- [**FREQUENCY CENTER** : **5 MHz**]
- [**FREQUENCY SPAN** : **2 kHz**]
- [**SWEEP COUPLING** : RES BW MANUAL : **1 kHz**]
- [**SWEEP COUPLING** : VIDEO BW MANUAL : **100 Hz**]
- [**INPUT** : RF ATTEN MANUAL : **10 dB**]
- [**LEVEL REF** : **-30 dBm**]
- [**MARKER SEARCH** : PEAK]

adjust output level of the signal generator until the level reading of marker 1 is exactly -40.0 dBm.

Measurement

Step attenuator settings:

attenuation {a_{ATT}}

see table below for values of a_{ATT}.

FSE settings:

- [**LEVEL REF** : {reference level} **dBm**]

  see table below for values of reference level.

- [**MARKER SEARCH** : PEAK]

Evaluation:

Compare level reading of marker 1 with the limits given in table 5-1 (item 17) of performance test report.

10-dB gain steps:

a_{ATT}	reference level	Marker level
0 dB	0 dBm	-10 ± 0.2 dBm
10 dB	-10 dBm	-20 ± 0.2 dBm
20 dB	-20 dBm	-30 ± 0.2 dBm
30 dB	-30 dBm	-40 ± 0.2 dBm
40 dB	-40 dBm	-50 ± 0.2 dBm
50 dB	-50 dBm	-60 ± 0.2 dBm

1-dB gain steps:

a_{ATT}	reference level	Marker level
30 dB	-30 dBm	-40.0 ± 0.2 dBm
31 dB	-31 dBm	-41 ± 0.2 dBm
32 dB	-32 dBm	-42 ± 0.2 dBm
33 dB	-33 dBm	-43 ± 0.2 dBm
34 dB	-34 dBm	-44 ± 0.2 dBm
35 dB	-35 dBm	-45 ± 0.2 dBm
36 dB	-36 dBm	-46 ± 0.2 dBm
37 dB	-37 dBm	-47 ± 0.2 dBm
38 dB	-38 dBm	-48 ± 0.2 dBm
39 dB	-39 dBm	-49 ± 0.2 dBm

5.2.12 Checking the Phase Noise

Test equipment:

signal generator (section 5.1, item 3)

frequency	498 MHz
level	≥ 0 dBm
phase noise at 498 Mhz:	< -100 dBc/Hz @ 100 Hz
	< -115 dBc/Hz @ 1 kHz
	< -127 dBc/Hz @ 10 kHz
	< -130 dBc/Hz @ 100 kHz
	< -142 dBc/Hz @ 1MHz

Test setup:

- connect RF output of the signal generator to RF input of the FSE
- connect signal generator EXT REF input to the EXT REF output of the FSE and set the generator to external reference

Signal generator settings:

- frequency 498 MHz
- level 0 dBm

FSE settings:

- [**SYSTEM PRESET**]
- [**CONFIGURATION SETUP** : REFERENCE INT / EXT]
  toggle to internal reference (INT)
- [**FREQUENCY CENTER** : **498 MHz**]
- [**REF LEVEL** : **0 dBm**]
- [**INPUT** : RF ATTEN MANUAL : **10 dB**]
- [**FREQUENCY SPAN** : {span}]

  depending on offset, see table below for values of span.
- [**SWEEP COUPLING** : COUPLING RATIO : RBW/VBW NOISE]
- [**SWEEP COUPLING** : RBW MANUAL : {RBW}]

  depending on offset, see table below for values of RBW.
- [**TRACE 1** : AVERAGE]
- [**SWEEP** : SWEEP COUNT : **20** : **ENTER**]
- [**MARKER NORMAL**]
- set marker to peak of signal
  [**MARKER SEARCH**: PEAK]
- activate phase noise marker
  [**MARKER DELTA**: PHASE NOISE]
- [**FREQUENCY CENTER** : {498 MHz + offset}]

  see table below for values of offset.
- [**REF LEVEL** : {reference level}]

  depending on offset, see table below for values of reference level.
- [**INPUT** : RF ATTEN MANUAL : {a_{FSE}}]

  depending on offset, see table below for values of a_{FSE} .

- set phase noise marker
[**MARKER DELTA** : {offset}]

see table below for values of offset.

***Note**:Make sure not to measure on a spurious signal. The switching frequency may cause interference especially at an offset of 100 kHz. In this case measure at an offset of 95 kHz.*

Evaluation:

The phase noise is displayed by the reading ´Delta 1 [T1 NOI]´. Compare the measured values with the limits given in table 5-1 (item 18) of performance test report

Phase noise measurement settings				
Offset	**Span**	**RBW**	**Reference Level**	**a_{FSE}**
100 Hz	20 Hz	10 Hz	0 dBm	10 dB
1 kHz	200 Hz	100 Hz	0 dBm	10 dB
10 kHz	2 kHz	500 Hz	-10 dBm	10 dB
100 kHz	10 kHz	3 kHz	-20 dBm	0 dB
1 MHz	100 kHz	30 kHz	-20 dBm	0 dB

Notes: *To obtain a precise measurement of the phase noise at high offsets the level used at the FSE input is 20 dB higher than the reference level. To reduce the measurement time the phase noise is measured with a small span around the frequency offset. This prevents the FSE from being overloaded.*

5.2.13 Checking the Tracking Generator – Option FS-B8/B9/B10/B11

5.2.13.1 Checking the Output Level

Test equipment: N-connecting cable (Section 5.1, item no. 16)

Test setup: ➢ Connect output of tracking generator to RF-input of FSE.

FSE settings:
- [**MODE TRACKING**]
- [**FREQUENCY CENTER** : **120 MHz**]
- [**FREQUENCY SPAN** : **0 MHz**]
- [**SWEEP COUPLING** : RBW MANUAL : **20 kHz**]
- [**SWEEP COUPLING** : VBW MANUAL : **20 kHz**]
- [**LEVEL RANGE** : LOG 50 dB]
- [**MODE TRACKING** : SOURCE ON]
- [**MODE TRACKING** : SOURCE POWER {level}]

Values for {level} : 0 dBm; -3 dBm; -6 dBm; -10 dBm; -20 dBm

Test setup: ➢ Compare measured values with values from Table 5.3-1, item no. 19.

5.2.13.2 Checking the Frequency Response

Test equipment: N-connecting cable (Section 5.1, item no. 16)

Test setup: ➢ Connect output of tracking generator to RF-input of FSE.

FSE settings:
- [**MODE TRACKING**]
- [**FREQUENCY START** : **1 MHz**]
- [**FREQUENCY STOP** : **3.5(7) MHz**]
- [**SWEEP COUPLING** : RBW MANUAL : **20 kHz**]
- [**SWEEP COUPLING** : VBW MANUAL : **20 kHz**]
- [**SWEEP COUPLING** : SWEEP TIME MANUAL : **100 ms**]
- [**LEVEL RANGE** : LOG 50 dB]
- [**MODE TRACKING** : SOURCE ON]
- [**MODE TRACKING** : SOURCE POWER 0 dBm]

Evaluation: ➢ Compare measured values with limits from Table 5.3-1, item no. 20.

5.2.13.3 Checking the I/Q Modulator

Test equipment:
- 2 DC power sources (Section 5.1, item no. 17)
- 2 DC-voltmeters (Section 5.1, item no. 18)

Test setup:
- ➢ Connect DC power sources to the I and Q input of the analyzer.
- ➢ Use DC-voltmeter to measure voltage at the I and Q inputs.

Power source settings
- ➢ Set voltage to 250 mV ± 3 mV.

FSE settings:
- [**MODE TRACKING**]
- [**FREQUENCY CENTER** : **120 MHz**]
- [**FREQUENCY SPAN** : **0 MHz**]
- [**SWEEP COUPLING** : RBW MANUAL : **20 kHz**]
- [**SWEEP COUPLING** : VBW MANUAL : **20 kHz**]
- [**REF** : REF LEVEL : **0 dBm**]
- [**MODE TRACKING** : SOURCE POWER 0 dBm]
- [**MARKER NORMAL**]
- ➢ Rated value: -6 dBm ± 0.5 dB
  This value serves as a reference for the following measurements.

Measurements

Measurement of the residual carrier
- [**LEVEL RANGE** : 100 dB]
- ➢ Short-circuit I and Q voltages (do not remove!)
  The voltmeter must indicate a value < 0.1 mV.
- ➢ Rated value: < -50 dBm

Imbalance measurement (imbalance between the I and Q paths)
- [**LEVEL RANGE** : 10 dBm]
- ➢ Apply ±250 mV at the Q input, short-circuit at the I input.
- ➢ Rated value: (reference value – 3 dB) ±0.5 dB.
- ➢ Apply ±250 mV at the I input, short-circuit at the Q input.
- ➢ Rated value: (reference value - 3dB) ±0.5 dB.

Measurement of the quadrature offset
- ➢ Apply +250 mV at the I input, -250 mV at the Q input.
- ➢ Rated value: (reference value ±0.5 dB.
- ➢ Apply +250 mV at the Q input, -250 mV at the I input.
- ➢ Rated value: (reference value ± 0.5 dB.

This page is intentionally left blank.

5.3 Performance Test Report

Note: *The values given in the datasheet are the guaranteed limits. Due to measurement errors these limits must be extended by the tolerance of the measuring equipment used in this performance test.*

Table 5.3-1 Performance test report

Item No.	Characteristic	Test to section	Min. value	Actual value	Max. value	Unit
1	Calibration source at 120 MHz	5.2.1	-0.3	_____	+0.3	dB
2	Frequency accuracy Reference oscillator	5.2.2				
	Model 20		9.99999	_____	10.00001	MHz
	Model 30 or Model 20 with B4		9.999999	_____	10.000001	MHz
3	Return loss RF input f_{in}	5.2.3				
	FSEA / FSEB / FSEM / FSEK:					
	10 MHz		14	_____	-	dB
	250 MHz		14	_____	-	dB
	500 MHz		14	_____	-	dB
	750 MHz		14	_____	-	dB
	1000 MHz		14	_____	-	dB
	1250 MHz		14	_____	-	dB
	1500 MHz		14	_____	-	dB
	1750 MHz		14	_____	-	dB
	2000 MHz		14	_____	-	dB
	2250 MHz		14	_____	-	dB
	2500 MHz		14	_____	-	dB
	2750 MHz		14	_____	-	dB
	3000 MHz		14	_____	-	dB
	3250 MHz		14	_____	-	dB
	3500 MHz		14	_____	-	dB
	3250 MHz		14	_____	-	dB
	3500 MHz		14	_____	-	dB
	FSEB / FSEM / FSEK:					
	3750 MHz		9.5	_____	-	dB
	4000 MHz		9.5	_____	-	dB
	4250 MHz		9.5	_____	-	dB
	4500 MHz		9.5	_____	-	dB
	4750 MHz		9.5	_____	-	dB
	5000 MHz		9.5	_____	-	dB
	5250 MHz		9.5	_____	-	dB
	5500 MHz		9.5	_____	-	dB
	5750 MHz		9.5	_____	-	dB
	6000 MHz		9.5	_____	-	dB
	6250 MHz		9.5	_____	-	dB
	6500 MHz		9.5	_____	-	dB
	6750 MHz		9.5	_____	-	dB

Item No.	Characteristic	Test to section	Min. value	Actual value	Max. value	Unit
3	Return loss RF input RF ATT: 10 dB	5.2.3				
	FSEM / FSEK:		**FSEM / K:**			
	7000 MHz		6 / 7.4	———	-	dB
	8000 MHz		6 / 7.4	———	-	dB
	9000 MHz		6 / 7.4	———	-	dB
	10 GHz		6 / 7.4	———	-	dB
	11 GHz		6 / 7.4	———	-	dB
	12 GHz		6 / 7.4	———	-	dB
	13 GHz		6 / 7.4	———	-	dB
	14 GHz		6 / 7.4	———	-	dB
	15 GHz		6 / 7.4	———	-	dB
	16 GHz		6 / 7.4	———	-	dB
	17 GHz		6 / 7.4	———	-	dB
	18 GHz		6 / 7.4	———	-	dB
	19 GHz		6 / 7.4	———	-	dB
	20 GHz		6 / 7.4	———	-	dB
	21 GHz		6 / 7.4	———	-	dB
	22 GHz		6 / 7.4	———	-	dB
	23 GHz		6 / 7.4	———	-	dB
	24 GHz		6 / 7.4	———	-	dB
	25 GHz		6 / 7.4	———	-	dB
	26 GHz		6 / 7.4	———	-	dB
	26.5 GHz		6 / 7.4	———	-	dB
	FSEK:					
	27 GHz		7.4	———	-	dB
	28 GHz		7.4	———	-	dB
	29 GHz		7.4	———	-	dB
	30 GHz		7.4	———	-	dB
	31 GHz		7.4	———	-	dB
	32 GHz		7.4	———	-	dB
	33 GHz		7.4	———	-	dB
	34 GHz		7.4	———	-	dB
	35 GHz		7.4	———	-	dB
	36 GHz		7.4	———	-	dB
	37 GHz		7.4	———	-	dB
	38 GHz		7.4	———	-	dB
	39 GHz		7.4	———	-	dB
	39.9 GHz		7.4	———	-	dB

Item No.	Characteristic	Test to section	Min. value	Actual value	Max. value	Unit
4	1st IF image frequency rejection f_{in}	5.2.4.1				
	FSEA:		**Mod. 20 / 30**			
	11 MHz		75 / 80	_____	-	dB
	100 MHz		75 / 80	_____	-	dB
	1701 MHz		75 / 80	_____	-	dB
	3499 MHz		75 / 80	_____	-	dB
	FSEB / FSEM / FSEK:					
	11 MHz		80	_____	-	dB
	100 MHz		80	_____	-	dB
	1701 MHz		80	_____	-	dB
	3499 MHz		80	_____	-	dB
	6999 MHz		80	_____	-	dB
5	2nd IF image frequency rejection f_{in}	5.2.4.2				
	FSEA:		**Mod. 20 / 30**			
	999 MHz		75 / 80	_____	-	dB
	FSEB / FSEM / FSEK:					
	999 MHz		80	_____	-	dB
	7999 MHz		80	_____	-	dB
6	1st IF rejection f_{in}	5.2.4.3				
	FSEA:		**Mod. 20 / 30**			
	100 MHz		80 / 100	_____	-	dB
	1701 MHz		80 / 100	_____	-	dB
	3500 MHz		80 / 100	_____	-	dB
	FSEB / FSEM / FSEK:		**FSEB,M / K**			
	100 MHz		75 / 80	_____	-	dB
	1701 MHz		75 / 80	_____	-	dB
	3500 MHz		75 / 80	_____	-	dB
	FSEM / FSEK:		**FSEM / K**			
	7001 MHz		75 / 80	_____	-	dB

Item No.	Characteristic	Test to section	Min. value	Actual value	Max. value	Unit
7	3rd order intercept, f_{in}	5.2.5.1				
	FSEA / FSEB / FSEM / FSEK:		**FSEA / B,M,K**			
	10 MHz		7 / 7		-	dBm
	28 MHz		7 / 7		-	dBm
	106 MHz		12 / 7		-	dBm
	261 MHz		12 / 12 *)		-	dBm
	640 MHz		12 / 12 *)		-	dBm
	1 GHz		12 / 12 *)		-	dBm
	1.7 GHz		12 / 12 *)		-	dBm
	2.5 GHz		12 / 12 *)		-	dBm
	3.48 GHz		12 / 12 *)		-	dBm
	FSEB / FSEM / FSEK:					
	6.98 GHz		12		-	dBm
	FSEM / FSEK:		**FSEM / K**			
	7.5 GHz		12 / 10		-	dBm
	15 GHz		12 / 10		-	dBm
	25 GHz		12 / 10		-	dBm
	FSEK:					
	30 GHz		10		-	dBm
	35 GHz		10		-	dBm
	39 GHz		10		-	dBm
*) 15 dBm for FSEB models 25 / 35 . 17 dBm for FSEM / FSEK models 25 / 35						
	2nd order harmonic distortion f_{in}	5.2.5.2				
	FSEA / FSEB / FSEM / FSEK:		**FSEA / B,M,K**			
	9 kHz		25 / 25		-	dBm
	35 kHz		25 / 25		-	dBm
	99 kHz		25 / 25		-	dBm
	19 MHz		25 /25		-	dBm
	28 MHz		25 / 25		-	dBm
	107 MHz		45 / 25		-	dBm
	262 MHz		45 / 40		-	dBm
	453 MHz		45 / 40		-	dBm
	640 MHz		45 / 40		-	dBm
	1 GHz		45 / 40		-	dBm
	1,25 GHz		45 / 40		-	dBm
	1,7 GHz		45 / 40		-	dBm
	FSEB / FSEM / FSEK:					
	3,4 GHz		40		-	dBm

Item No.	Characteristic	Test to section	Min. value	Actual value	Max. value	Unit
9	IF bandwidths Level error	5.2.6.1				
	reference (Ref): 5 kHz		-	_____	-	dBm
	100 Hz		-0.2	_____	+0.2	dB
	1 kHz		-0.2	_____	+0.2	dB
	2 kHz		-0.2	_____	+0.2	dB
	3 kHz		-0.2	_____	+0.2	dB
	10 kHz		-0.2	_____	+0.2	dB
	20 kHz		-0.2	_____	+0.2	dB
	30 kHz		-0.2	_____	+0.2	dB
	50 kHz		-1.0	_____	+1.0	dB
	100 kHz		-0.2	_____	+0.2	dB
	200 kHz		-0.2	_____	+0.2	dB
	300 kHz		-0.2	_____	+0.2	dB
	500 kHz		-0.2	_____	+0.2	dB
	1 MHz		-0.3	_____	+0.3	dB
	2 MHz		-0.3	_____	+0.3	dB
	3 MHz		-0.3	_____	+0.3	dB
	5 MHz		-0.3	_____	+0.3	dB
	10 MHz		-0.3	_____	+0.3	dB
10	IF bandwidths 3-dB bandwidth	5.2.6.2				
	100 Hz		-10 %-	_____	+10 %	-
	1 kHz		-10 %-	_____	+10 %	-
	2 kHz		-10 %-	_____	+10 %	-
	3 kHz		-10 %-	_____	+10 %	-
	5 kHz		-10 %-	_____	+10 %	-
	10 kHz		-10 %-	_____	+10 %	-
	20 kHz		-10 %-	_____	+10 %	-
	30 kHz		-10 %-	_____	+10 %	-
	50 kHz		-10 %-	_____	+10 %	-
	100 kHz		-10 %-	_____	+10 %	-
	200 kHz		-10 %-	_____	+10 %	-
	300 kHz		-10 %-	_____	+10 %	-
	500 kHz		-10 %-	_____	+10 %	-
	1 MHz		-10 %-	_____	+10 %	-
	2 MHz		-10 %-	_____	+10 %	-
	3 MHz		-10 %-	_____	+10 %	-
	5 MHz		-15 %-	_____	+15 %	-
	10 MHz		-10 %-	_____	+25 %	-

Item No.	Characteristic	Test to section	Min. value	Actual value	Max. value	Unit
11	IF bandwidths Shape factor	5.2.6.2			**Mod. 20 / 30**	
	100 Hz		-	_____	- / 6	-
	1 kHz		-	_____	- / 12	-
	2 kHz		-	_____	- / 12	-
	3 kHz		-	_____	- / 12	-
	5 kHz		-	_____	15 / 12	-
	10 kHz		-	_____	15 / 12	-
	20 kHz		-	_____	15 / 12	-
	30 kHz		-	_____	15 / 12	-
	50 kHz		-	_____	15 / 12	-
	100 kHz		-	_____	15 / 12	-
	200 kHz		-	_____	15 / 12	-
	300 kHz		-	_____	15 / 12	-
	500 kHz		-	_____	15 / 12	-
	1 MHz		-	_____	15 / 12	-
	2 MHz		-	_____	15 / 12	-
	3 MHz		-	_____	7 / 7	-
	5 MHz		-	_____	7 / 7	-
	10 MHz		-	_____	7 / 7	-
12	LO feedthrough **(only model 30)**	5.2.7.1	-	_____	-20	dBm

Item No.	Characteristic	Test to section	Min. value	Actual value	Max. value	Unit
13	Noise display f_n	5.2.7.2				
	FSEA:				Mod. 20 / 30	
	20 Hz		-	_____	- / -80	dBm
	1 kHz		-	_____	- / -110	dBm
	9.9 kHz		-	_____	-90 / -125	dBm
	95 kHz		-	_____	-110 / -135	dBm
	999 kHz		-	_____	-130 / -145	dBm
	9.99 MHz		-	_____	-145 / -145	dBm
	19.99 MHz		-	_____	-145 / -145	dBm
	49.99 MHz		-	_____	-145 / -145	dBm
	99.99 MHz		-	_____	-145 / -145	dBm
	199.99 MHz		-	_____	-145 / -145	dBm
	499.99 MHz		-	_____	-145 / -145	dBm
	999.9 MHz		-	_____	-145 / -145	dBm
	1999.9 MHz		-	_____	-145 / -145	dBm
	3499.9 MHz		-	_____	-145 / -145	dBm
	FSEB:				Mod. 20 / 30	
	20 Hz		-	_____	- / -74	dBm
	1 kHz		-	_____	- /-104	dBm
	9.9 kHz		-	_____	-84 / -119	dBm
	95 kHz		-	_____	-104 / -129	dBm
	999 kHz		-	_____	-125 / -142	dBm
	9.99 MHz		-	_____	-142 / -142	dBm
	19.99 MHz		-	_____	-142 / -142	dBm
	49.99 MHz		-	_____	-142 / -142	dBm
	99.99 MHz		-	_____	-142 / -142	dBm
	199.99 MHz		-	_____	-142 / -142	dBm
	499.99 MHz		-	_____	-142 / -142	dBm
	999.9 MHz		-	_____	-142 / -142	dBm
	1999.9 MHz		-	_____	-142 / -142	dBm
	3499.9 MHz		-	_____	-142 / -142	dBm
	5999.9 MHz		-	_____	-142 / -142	dBm
	6999.9 MHz		-	_____	-139 / -139	dBm

Item No.	Characteristic	Test to section	Min. value	Actual value	Max. value	Unit
13	**FSEM:**	5.2.7.2			Mod. 20 / 30	
	20 Hz		-	_____	- / -74	dBm
	1 kHz		-	_____	- /-104	dBm
	9.9 kHz		-	_____	-84 / -119	dBm
	95 kHz		-	_____	-104 / -129	dBm
	999 kHz		-	_____	-124 / -142	dBm
	9.99 MHz		-	_____	-138 / -138	dBm
	19.99 MHz		-	_____	-138 / -138	dBm
	49.99 MHz		-	_____	-138 / -138	dBm
	99.99 MHz		-	_____	-138 / -138	dBm
	199.99 MHz		-	_____	-138 / -138	dBm
	499.99 MHz		-	_____	-138 / -138	dBm
	999.9 MHz		-	_____	-138 / -138	dBm
	1999.9 MHz		-	_____	-138 / -138	dBm
	3499.9 MHz		-	_____	-138 / -138	dBm
	5999.9 MHz		-	_____	-138 / -138	dBm
	6999.9 MHz		-	_____	-135 / -135	dBm
	7199.9 MHz		-	_____	-138 / -138	dBm
	11999.9 MHz		-	_____	-138 / -138	dBm
	17999.9 MHz		-	_____	-138 / -138	dBm
	21999.9 MHz		-	_____	-135 / -135	dBm
	26399.9 MHz		-	_____	-135 / -135	dBm
	FSEK:				Mod. 20 / 30	
	20 Hz		-	_____	- / -74	dBm
	1 kHz		-	_____	- /-104	dBm
	9.9 kHz		-	_____	-84 / -119	dBm
	95 kHz		-	_____	-104 / -129	dBm
	999 kHz		-	_____	-124 / -142	dBm
	9.99 MHz		-	_____	-138 / -138	dBm
	19.99 MHz		-	_____	-138 / -138	dBm
	49.99 MHz		-	_____	-138 / -138	dBm
	99.99 MHz		-	_____	-138 / -138	dBm
	199.99 MHz		-	_____	-138 / -138	dBm
	499.99 MHz		-	_____	-138 / -138	dBm
	999.9 MHz		-	_____	-138 / -138	dBm
	1999.9 MHz		-	_____	-138 / -138	dBm
	3499.9 MHz		-	_____	-138 / -138	dBm
	5999.9 MHz		-	_____	-138 / -138	dBm
	6999.9 MHz		-	_____	-135 / -135	dBm
	7199.9 MHz		-	_____	-134 / -134	dBm
	11999.9 MHz		-	_____	-134 / -134	dBm
	17999.9 MHz		-	_____	-134 / -134	dBm
	21999.9 MHz		-	_____	-131 / -131	dBm
	26499.9 MHz		-	_____	-131 / -131	dBm
	27000 MHz		-	_____	-120 / -120	dBm
	29999 MHz		-	_____	-120 / -120	dBm
	30000 MHz		-	_____	-116 / -116	dBm
	35000 MHz		-	_____	-116 / -116	dBm
	40000 MHz		-	_____	-116 / -116	dBm

Item No.	Characteristic	Test to section	Min. value	Actual value	Max. value	Unit
14	Frequency response	5.2.8				
	FSEA / FSEB / FSEM / FSEK:					
	120 MHz (absolute error)		-0.3	_____	+0.3	dB
	f_{fresp}					
	1 MHz		-0.5	_____	+0.5	dB
	10 MHz		-0.5	_____	+0.5	dB
	50 MHz		-0.5	_____	+0.5	dB
	100 MHz		-0.5	_____	+0.5	dB
	200 MHz		-0.5	_____	+0.5	dB
	300 MHz		-0.5	_____	+0.5	dB
	400 MHz		-0.5	_____	+0.5	dB
	500 MHz		-0.5	_____	+0.5	dB
	600 MHz		-0.5	_____	+0.5	dB
	700 MHz		-0.5	_____	+0.5	dB
	800 MHz		-0.5	_____	+0.5	dB
	900 MHz		-0.5	_____	+0.5	dB
	1000 MHz		-0.5	_____	+0.5	dB
	1500 MHz		-1	_____	+1	dB
	2000 MHz		-1	_____	+1	dB
	2500 MHz		-1	_____	+1	dB
	3000 MHz		-1	_____	+1	dB
	3499 MHz		-1	_____	+1	dB
	FSEB / FSEM / FSEK:					
	4000 MHz		-1	_____	+1	dB
	4500 MHz		-1	_____	+1	dB
	5000 MHz		-1	_____	+1	dB
	5500 MHz		-1	_____	+1	dB
	6000 MHz		-1	_____	+1	dB
	6500 MHz		-1	_____	+1	dB
	6999 MHz		-1	_____	+1	dB

Item No.	Characteristic	Test to section	Min. value	Actual value	Max. value	Unit
14	**FSEM / FSEK:**	5.2.8				
	8000 MHz		-2	_____	+2	dB
	9000 MHz		-2	_____	+2	dB
	10000 MHz		-2	_____	+2	dB
	11000 MHz		-2	_____	+2	dB
	12000 MHz		-2	_____	+2	dB
	13000 MHz		-2	_____	+2	dB
	14000 MHz		-2	_____	+2	dB
	15000 MHz		-2	_____	+2	dB
	16000 MHz		-2	_____	+2	dB
	17000 MHz		-2	_____	+2	dB
	18000 MHz		-2	_____	+2	dB
	19000 MHz		-2.5	_____	+2.5	dB
	20000 MHz		-2.5	_____	+2.5	dB
	21000 MHz		-2.5	_____	+2.5	dB
	22000 MHz		-2.5	_____	+2.5	dB
	23000 MHz		-2.5	_____	+2.5	dB
	24000 MHz		-2.5	_____	+2.5	dB
	25000 MHz		-2.5	_____	+2.5	dB
	26000 MHz		-2.5	_____	+2.5	dB
	26499 MHz		-2.5	_____	+2.5	dB
	FSEK:					
	27000 MHz		-3	_____	+3	dB
	28000 MHz		-3	_____	+3	dB
	29000 MHz		-3	_____	+3	dB
	30000 MHz		-3	_____	+3	dB
	31000 MHz		-3	_____	+3	dB
	32000 MHz		-3	_____	+3	dB
	33000 MHz		-3	_____	+3	dB
	34000 MHz		-3	_____	+3	dB
	35000 MHz		-3	_____	+3	dB
	36000 MHz		-3	_____	+3	dB
	37000 MHz		-3	_____	+3	dB
	38000 MHz		-3	_____	+3	dB
	39000 MHz		-3	_____	+3	dB
	40000 MHz		-3	_____	+3	dB

Item No.	Characteristic	Test to section	Min. value	Actual value	Max. value	Unit
15	Display linearity	5.2.9				
	a_{ATT}					
	6 dB		9.7	_____	10.3	dB
	8 dB		7.7	_____	8.3	dB
	10 dB		5.7	_____	6.3	dB
	12 dB		3.7	_____	4.3	dB
	14 dB		1.7	_____	2.3	dB
	16 dB		-	Reference	-	-
	18 dB		-2.3	_____	-1.7	dB
	20 dB		-4.3	_____	-3.7	dB
	22 dB		-6.3	_____	-5.7	dB
	24 dB		-8.3	_____	-7.7	dB
	26 dB		-10.3	_____	-9.7	dB
	28 dB		-12.3	_____	-11.7	dB
	30 dB		-14.3	_____	-13.7	dB
	32 dB		-16.3	_____	-15.7	dB
	34 dB		-18.3	_____	-17.7	dB
	36 dB		-20.3	_____	-19.7	dB
	38 dB		-22.3	_____	-21.7	dB
	40 dB		-24.3	_____	-23.7	dB
	42 dB		-26.3	_____	-25.7	dB
	44 dB		-28.3	_____	-27.7	dB
	46 dB		-30.3	_____	-29.7	dB
	48 dB		-32.3	_____	-31.7	dB
	50 dB		-34.3	_____	-33.7	dB
	52 dB		-36.3	_____	-35.7	dB
	54 dB		-38.3	_____	-37.7	dB
	56 dB		-40.3	_____	-39.7	dB
	61 dB		-45.5	_____	-44.5	dB
	66 dB		-50.5	_____	-49.5	dB
	71 dB		-55.5	_____	-54.5	dB
	76 dB		-60.5	_____	-59.5	dB
	81 dB		-66.0	_____	-64.0	dB
	86 dB		-71.0	_____	-69.0	dB
	only models 30					
	91 dB		-76.0	_____	-74.0	dB
	96 dB		-81.0	_____	-79.0	dB
	101 dB		-86.0	_____	-84.0	dB
16	Attenuator	5.2.10				
	a_{ATT}					
	70		-70.3	_____	-69.7	dBm
	60		-60.3	_____	-59.7	dBm
	50		-50.3	_____	-49.7	dBm
	40		-40.3	_____	-39.7	dBm
	30		-30.3	_____	-29.7	dBm
	20		-20.3	_____	-19.7	dBm
	10		-10.3	_____	-9.7	dBm
	0		-0.3	_____	+0.3	dBm

Item No.	Characteristic	Test to section	Min. value	Actual value	Max. value	Unit
17	IF gain switching	5.2.11				
	Reference level					
	0 dBm		-10.2	_____	-9.8	dBm
	-10 dBm		-20.2	_____	-19.8	dBm
	-20 dBm		-30.2	_____	-29.8	dBm
	-30 dBm		-40.2	_____	-39.8	dBm
	-40 dBm		-50.2	_____	-49.8	dBm
	-50 dBm		-60.2	_____	-59.8	dBm
	-31 dBm		-41.2	_____	-40.8	dBm
	-32 dBm		-42.2	_____	-41.8	dBm
	-33 dBm		-43.2	_____	-42.8	dBm
	-34 dBm		-44.2	_____	-43.8	dBm
	-35 dBm		-45.2	_____	-44.8	dBm
	-36 dBm		-46.2	_____	-45.8	dBm
	-37 dBm		-47.2	_____	-46.8	dBm
	-38 dBm		-48.2	_____	-47.8	dBm
	-39 dBm		-49.2	_____	-48.8	dBm
18	Phase noise offset:	5.2.12				
	FSEA20 without B4 :					
	1 kHz		-	_____	–85	dBc/Hz
	10 kHz		-	_____	–95	dBc/Hz
	100 kHz		-	_____	–119	dBc/Hz
	1 MHz		-	_____	–135	dBc/Hz
	FSEA30 or FSEA20 with B4 :					
	100 Hz		-	_____	–87	dBc/Hz
	1 kHz		-	_____	–107	dBc/Hz
	10 kHz		-	_____	–120	dBc/Hz
	100 kHz		-	_____	–117 / 119 *)	dBc/Hz
	1 MHz		-	_____	–135 / 138 *)	dBc/Hz
	FSEB/M/K 20 without B4:					
	1 kHz		-	_____	–79	dBc/Hz
	10 kHz		-	_____	–90	dBc/Hz
	100 kHz		-	_____	–113	dBc/Hz
	1 MHz		-	_____	–129	dBc/Hz
	FSEB/M/K 30 or FSEB/M/K20 withB4:					
	100 Hz		-	_____	–81	dBc/Hz
	1 kHz		-	_____	–100	dBc/Hz
	10 kHz		-	_____	–114	dBc/Hz
	100 kHz		-	_____	–111 / 113 *)	dBc/Hz
	1 MHz		-	_____	–129 / 132 *)	dBc/Hz

*) The better values apply to models 25 / 35

Item No.	Characteristic	Test to section	Min. value	Actual value	Max. value	Unit
19	option tracking generator output level	5.2.13				
	0 dBm		- 1	———	+ 1	dBm
	–3 dBm		-4	———	-2	dBm
	–6 dBm		-8	———	-4	dBm
	–10 dBm		-12	———	-8	dBm
	–20 dBm		- 21	———	- 19	dBm
20	option tracking generator frequency response	5.2.13				
	1 MHz to 1 GHz		-2	———	2	dBm
	1 GHz to 3.5 GHz		-3	———	3	dBm
	3.5 GHz to 7 GHz		-3	———	3 (typ)	dBm
21	option tracking generator I/Q-modulator	5.2.13				
	residual carrier		-	———	-46	dBm
	imbalance		-10	———	-8	dBm
	quadrature offset		- 7	———	-5	dBm

This page is intentionally left blank.

5.4 Test Instructions (option FSE-B22 included)

The rated specifications of the analyzer are tested after a warm-up time of at least 30 minutes and overall calibration. Only in this case can the compliance with the guaranteed data be ensured.

Values given in the following sections are not guaranteed. Only the technical specifications of the data sheet are binding.

Additional equipment required for performance test (option FSE-B22 included)

Item	Type of equipment	Specifications recommended	Recommended equipment	R&S Order No.	Use
1	Power sensor	frequency 1 MHz to 2 GHz RSS referred to indicated power ≤ 0.8 %	NRV-Z51	0857.9004.02	5.3.3
2	6-dB divider (power splitter)	frequency 1 MHz to 2 GHz level imbalance ≤ 0.1 dB	RVZ	0800.6612.52	5.3.3

5.4.1 Checking the Calibration Source at 120 MHz

Test equipment:

- signal generator (section 5.1, item 3):
  frequency 120 MHz
  level -40 dBm
- power meter (section 5.1, item 8)
- power sensor (section 5.1, item 9)
  frequency 120 MHz
  maximum power $P_{max} \geq 1$ µW
  meter noise ≤ 20 pW
  RSS ≤ 0.8% referred to indicated power
  impedance Z = 50 Ω

Power meter settings:

- connect power sensor to power meter and carry out function ´ZERO´ when no signal is applied to the power sensor.
- connect power sensor to RF output of signal generator.

Signal generator settings:

- frequency 120 MHz
- level -40 dBm ± 0.1 dB
  Use power meter for exact level adjustment.

Test setup: connect RF output of the signal generator to RF input of the FSE

FSE settings:

- [**SYSTEM PRESET**]
- [**FREQUENCY CENTER** : **120 MHz**]
- [**FREQUENCY SPAN** : **15 kHz**]
- [**SWEEP COUPLING** : RES BW MANUAL : **5 kHz**]
- [**LEVEL REF** : REF LEVEL : **-10 dBm**]
- [**INPUT** : RF ATTEN MANUAL : **20 dB**]

- set marker to peak of signal
  [**MARKER SEARCH** : PEAK]
- set reference to peak of signal
  [**MARKER DELTA** : REFERENCE FIXED]
- switch internal reference generator to RF input
  [**CONFIGURATION SETUP** : SERVICE : INPUT CAL]
- set marker to peak of signal
  [**MARKER SEARCH** : PEAK]

Evaluation: The reading ´Delta 1 [T1 FXD]´ displays the difference between the output level of the signal generator and the level of the calibration source ..... < 0.2 dB

Note: *The level of the calibration source can be adjusted with R22 on FracSyn module.*

5.4.2 Checking IF Filters

Test equipment: signal generator (section 5.1, item 3):
frequency 120 MHz
level ≥ -10 dBm

Test setup: connect RF output of the signal generator to the RF input of the FSE.

5.4.2.1 Checking the Level Error

Reference Measurement (RBW 5 kHz)

Signal generator settings:
- frequency: 120 MHz
- level: -20 dBm

FSE settings:
- [**SYSTEM PRESET**]
- [**INPUT** : RF ATTEN MANUAL : **10 dB**]
- [**LEVEL REF** : **0 dBm**]
- [**FREQUENCY CENTER** : **120 MHz**]
- [**SWEEP COUPLING** : COUPLING RATIO : RBW/VBW SINE [1]]
- [**SWEEP COUPLING** : COUPLING RATIO : SPAN/RBW MANUAL : **5** : **ENTER**]
- resolution bandwidth 5 kHz
  [**FREQUENCY SPAN** : **25 kHz**]
- set marker to peak of signal
  [**MARKER SEARCH** : PEAK]
- set reference to peak of signal
  [**MARKER DELTA** : REFERENCE FIXED]

Checking the Level Error

FSE settings:

- [**FREQUENCY SPAN** : {5 x RBW}]

  See table 5-2 (item 2) of performance test report for values of RBW.

- set marker to peak of signal
  [**MARKER SEARCH** : PEAK]

  The level error is displayed by the reading
  ´Delta 1 [T1 FXD] {level error} dB´.

Evaluation:

See table 5-2 (item 2) of performance test report for upper and lower limits of level error.

5.4.3 Checking the Frequency Response

Test equipment:

- signal generator (section 5.1, item 3)
  frequency range 1 MHz to 2 GHz
  maximum level ≥ -10 dBm
- power meter (section 5.1, item 8)
- power sensor (section 5.3, item 1)
  frequency range 1 MHz to 2 GHz
  maximum power $P_{max} \geq 100\ \mu W$
  RSS referred to indicated power ≤ 0.8 %
  impedance Z = 50 Ω
- 6-dB divider (section 5.3, item 2)
  frequency range 1 MHz to 2 GHz
  level imbalance[1] ≤ 0.1 dB

  [1]If a power splitter with higher level imbalance is used correction of the measured frequency response is recommended.

Determining the absolute error at 120 MHz

Test setup:

- connect power sensor (section 5.3, item 1) to the power meter and execute function ´ZERO´ when there is no signal applied to the power sensor
- connect power sensor to RF output of signal generator

Signal generator settings:

- frequency 120 MHz
- level -10 dBm

Measurement:

- determine output power of the signal generator with the power meter
- connect RF output of the signal generator to RF input of the FSE

FSE settings:

- [**SYSTEM PRESET**]
- [**INPUT** : RF ATTEN MANUAL : {a_{FSE}} **dB**]
  See
- [**LEVEL REF** : **-7 dBm**]
- [**FREQUENCY SPAN** : **15 kHz**]
- [**SWEEP COUPLING** : RES BW MANUAL : **5 kHz**]
- [**FREQUENCY CENTER** : **120 MHz**]

- set marker to peak of signal
  [**MARKER SEARCH** : PEAK]

Evaluation:

The deviation between the signal levels measured with the power meter and the FSE (level reading of marker 1) reflects the absolute level error of the FSE. It can be calculated as

$$\text{absolute error}_{120MHz} = L_{FSE} - L_{powermeter}$$

Checking the frequency response

Test setup:

- connect RF output of the signal generator to input of the divider
- connect output 1 of the divider to the power sensor of the power meter
- connect output 2 of the divider to RF input of the FSE

Signal generator settings:

- level -10 dBm
- frequency f_{fresp}

see table 5-2 (item 3) of performance test report for values of f_{fresp}

FSE settings:

- [**SYSTEM PRESET**]
- [**INPUT** : RF ATTEN MANUAL : **10 dB**]
- [**LEVEL REF** : **-7 dBm**]
- [**FREQUENCY SPAN** : **30 kHz**]
- [**SWEEP COUPLING** : RES BW MANUAL : **5 kHz**]
- [**FREQUENCY CENTER** : {f_{fresp}}]

see table 5-2 (item 3) of performance test report for values of f_{fresp}

- activate ´preselector peak´ if center frequency is higher than 7 GHz (only available for FSEM and FSEK)
  [**SYSTEM CAL** : PRESEL PEAK]

- set marker to peak of signal
  [**MARKER SEARCH** : PEAK]

the signal level L_{FSE} is displayed by the level reading of marker 1.

Power meter settings:

Determine signal level $L_{powermeter}$. To achive higher accuracy it is recommended to compensate the frequency response of the power sensor.

Evaluation:

The frequency response can be calculated as

$$\text{Frequency response} = L_{FSE} - L_{powermeter} - \text{absolute error}_{120\ MHz}$$

5.4.4 Checking the Display Linearity

Test equipment:

- signal generator (section 5.1, item 3)
  frequency 5 MHz
  maximum level ≥ 6 dBm
- step attenuator (section 5.1, item 13)
  frequency 5 MHz
  attenuation 0 to 95 dB
  steps 1 dB
  maximum attenuation error < 0.01 dB

Test setup:

- connect RF output of the signal generator to RF input of the step attenuator
- connect RF output of the step attenuator to RF input of the FSE

Signal generator settings:

- frequency 5 MHz
- level +6 dBm

Step attenuator settings:

attenuation 16 dB

FSE settings:

- [**SYSTEM PRESET**]
- [**INPUT** : RF ATTEN MANUAL : **10 dB**]
- [**LEVEL REF** : **0 dBm**]
- [**FREQUENCY CENTER** : **5 MHz**]
- [**FREQUENCY SPAN** : **500 Hz**]
- [**SWEEP COUPLING** : RES BW MANUAL : **3 kHz**]
- [**SWEEP COUPLING** : VIDEO BW MANUAL : **100 Hz**]
- [**LEVEL RANGE** : LOG 100 dB]
- set marker to peak of signal
  [**MARKER SEARCH** : PEAK]
- set reference to peak of signal
  [**MARKER DELTA** : REFERENCE FIXED]

Measurement

Step attenuator settings:

attenuation {a_{ATT}}

See table 5-2 (item 4) of performance test report for values of a_{ATT}.

Evaluation:

The difference between the level of the input signal of the FSE and the reference (about 10 dB below the reference level) is displayed by the reading ´Delta 1 [T1 FXD]´. Compare the measured values with the limits given in table 5-2 (item 4) of performance test report.

5.4.5 Checking the Attenuator

Test equipment:

- signal generator (section 5.1, item 3)
  frequency 5 MHz
  maximum level ≥ 6 dBm
- step attenuator (section 5.1, item 13)
  frequency 5 MHz
  attenuation 0 to 70 dB
  steps 10 dB
  maximum attenuation error < 0.05 dB

Test setup:

- connect RF output of the signal generator to RF input the step attenuator
- connect RF output of the step attenuator to RF input of the FSE

Signal generator settings:

- frequency 5 MHz
- level 0 dBm

Step attenuator settings:

attenuation 60 dB

FSE settings:

- [**SYSTEM PRESET**]
- [**FREQUENCY CENTER** : **5 MHz**]
- [**FREQUENCY SPAN** : **500 Hz**]
- [**SWEEP COUPLING** : RES BW MANUAL : **3 kHz**]
- [**SWEEP COUPLING** : VIDEO BW MANUAL : **100 Hz**]
- [**INPUT** : RF ATTEN MANUAL : **10 dB**]
- [**LEVEL REF** : **-30 dBm**]
- [**MARKER SEARCH** : PEAK]

adjust output level of the signal generator until the level reading of marker 1 is exactly -60.0 dBm.

Measurement

Step attenuator settings:

attenuation {a_{ATT}}

See table below for values of a_{ATT}.

FSE settings:

- [**INPUT** : RF ATTEN MANUAL : {a_{FSE}}]
- [**LEVEL REF** : {reference level} **dBm**]
- [**MARKER SEARCH** : PEAK]

see table below for values of a_{FSE} and reference level.

Evaluation:

Compare level reading of marker 1 with the limits given in table 5-2 (item 5) of performance test report.

a_{ATT}	40 dB	30 dB	20 dB	10 dB
a_{FSE}	30 dB	40 dB	50 dB	60 dB
reference level	-10 dBm	0 dBm	+10 dBm	+20 dBm

5.5 Performance Test Report (option FSE-B22 included)

Note: *The values given in the datasheet are the guaranteed limits. Due to measurement errors these limits must be extended by the tolerance of the measuring equipment used in this performance test.*

Table 5.5-1 Performance test report

Item No.	Characteristic	Test to section	Min. value	Actual value	Max. value	Unit
1	Calibration source at 120 MHz	5.3.1	-0.2	_____	+0.2	dB
2	IF bandwidths Level error	5.3.2.1				
	reference (Ref): 5 kHz		-	_____	-	dBm
	100 Hz		-0.15	_____	+0.15	dB
	1 kHz		-0.15	_____	+0.15	dB
	2 kHz		-0.15	_____	+0.15	dB
	3 kHz		-0.15	_____	+0.15	dB
	5 kHz		-0.15	_____	+0.15	dB
	10 kHz		-0.15	_____	+0.15	dB
	20 kHz		-0.15	_____	+0.15	dB
	30 kHz		-0.15	_____	+0.15	dB
	300 kHz		-0.15	_____	+0.15	dB
3	Frequency response	5.3.3				
	RF-Attenuation a_{FSE} = 10 dB 120 MHz (absolute error)		-0.2	_____	+0.2	dB
	f_{fresp}		-0.3	_____	+0.3	dB
	1 MHz		-0.3	_____	+0.3	dB
	10 MHz		-0.3	_____	+0.3	dB
	50 MHz		-0.3	_____	+0.3	dB
	100 MHz		-0.3	_____	+0.3	dB
	200 MHz		-0.3	_____	+0.3	dB
	300 MHz		-0.3	_____	+0.3	dB
	400 MHz		-0.3	_____	+0.3	dB
	500 MHz		-0.3	_____	+0.3	dB
	600 MHz		-0.3	_____	+0.3	dB
	700 MHz		-0.3	_____	+0.3	dB
	800 MHz		-0.3	_____	+0.3	dB
	900 MHz		-0.3	_____	+0.3	dB
	1000 MHz		-0.3	_____	+0.3	dB
	1100 MHz		-0.3	_____	+0.3	dB
	1200 MHz		-0.3	_____	+0.3	dB
	1300 MHz		-0.3	_____	+0.3	dB
	1400 MHz		-0.3	_____	+0.3	dB
	1500 MHz		-0.3	_____	+0.3	dB
	1600 MHz		-0.3	_____	+0.3	dB
	1700 MHz		-0.3	_____	+0.3	dB
	1800 MHz		-0.3	_____	+0.3	dB
	1900 MHz		-0.3	_____	+0.3	dB
	2000 MHz		-0.3	_____	+0.3	dB

Item No.	Characteristic	Test to section	Min. value	Actual value	Max. value	Unit
3	Frequency response	5.3.3				
	RF-Attenuation					
	a_{FSE} = 20 dB					
	120 MHz		-0.2	_____	+0.2	dB
	(absolute error)					
	f_{fresp}					
	1 MHz		-0.45	_____	+0.45	dB
	10 MHz		-0.45	_____	+0.45	dB
	50 MHz		-0.45	_____	+0.45	dB
	100 MHz		-0.45	_____	+0.45	dB
	200 MHz		-0.45	_____	+0.45	dB
	300 MHz		-0.45	_____	+0.45	dB
	400 MHz		-0.45	_____	+0.45	dB
	500 MHz		-0.45	_____	+0.45	dB
	600 MHz		-0.45	_____	+0.45	dB
	700 MHz		-0.45	_____	+0.45	dB
	800 MHz		-0.45	_____	+0.45	dB
	900 MHz		-0.45	_____	+0.45	dB
	1000 MHz		-0.45	_____	+0.45	dB
	1100 MHz		-0.45	_____	+0.45	dB
	1200 MHz		-0.45	_____	+0.45	dB
	1300 MHz		-0.45	_____	+0.45	dB
	1400 MHz		-0.45	_____	+0.45	dB
	1500 MHz		-0.45	_____	+0.45	dB
	1600 MHz		-0.45	_____	+0.45	dB
	1700 MHz		-0.45	_____	+0.45	dB
	1800 MHz		-0.45	_____	+0.45	dB
	1900 MHz		-0.45	_____	+0.45	dB
	2000 MHz		-0.45	_____	+0.45	dB

Item No.	Characteristic	Test to section	Min. value	Actual value	Max. value	Unit
3	Frequency response	5.3.3				
	RF-Attenuation					
	a_{FSE} = 30 dB					
	120 MHz		-0.2	_____	+0.2	dB
	(absolute error)					
	f_{fresp}					
	1 MHz		-0.45	_____	+0.45	dB
	10 MHz		-0.45	_____	+0.45	dB
	50 MHz		-0.45	_____	+0.45	dB
	100 MHz		-0.45	_____	+0.45	dB
	200 MHz		-0.45	_____	+0.45	dB
	300 MHz		-0.45	_____	+0.45	dB
	400 MHz		-0.45	_____	+0.45	dB
	500 MHz		-0.45	_____	+0.45	dB
	600 MHz		-0.45	_____	+0.45	dB
	700 MHz		-0.45	_____	+0.45	dB
	800 MHz		-0.45	_____	+0.45	dB
	900 MHz		-0.45	_____	+0.45	dB
	1000 MHz		-0.45	_____	+0.45	dB
	1100 MHz		-0.45	_____	+0.45	dB
	1200 MHz		-0.45	_____	+0.45	dB
	1300 MHz		-0.45	_____	+0.45	dB
	1400 MHz		-0.45	_____	+0.45	dB
	1500 MHz		-0.45	_____	+0.45	dB
	1600 MHz		-0.45	_____	+0.45	dB
	1700 MHz		-0.45	_____	+0.45	dB
	1800 MHz		-0.45	_____	+0.45	dB
	1900 MHz		-0.45	_____	+0.45	dB
	2000 MHz		-0.45	_____	+0.45	dB

Item No.	Characteristic	Test to section	Min. value	Actual value	Max. value	Unit
3	Frequency response	5.3.3				
	RF-Attenuation					
	a_{FSE} = 40 dB					
	120 MHz		-0.2	_____	+0.2	dB
	(absolute error)					
	f_{fresp}					
	1 MHz		-0.45	_____	+0.45	dB
	10 MHz		-0.45	_____	+0.45	dB
	50 MHz		-0.45	_____	+0.45	dB
	100 MHz		-0.45	_____	+0.45	dB
	200 MHz		-0.45	_____	+0.45	dB
	300 MHz		-0.45	_____	+0.45	dB
	400 MHz		-0.45	_____	+0.45	dB
	500 MHz		-0.45	_____	+0.45	dB
	600 MHz		-0.45	_____	+0.45	dB
	700 MHz		-0.45	_____	+0.45	dB
	800 MHz		-0.45	_____	+0.45	dB
	900 MHz		-0.45	_____	+0.45	dB
	1000 MHz		-0.45	_____	+0.45	dB
	1100 MHz		-0.45	_____	+0.45	dB
	1200 MHz		-0.45	_____	+0.45	dB
	1300 MHz		-0.45	_____	+0.45	dB
	1400 MHz		-0.45	_____	+0.45	dB
	1500 MHz		-0.45	_____	+0.45	dB
	1600 MHz		-0.45	_____	+0.45	dB
	1700 MHz		-0.45	_____	+0.45	dB
	1800 MHz		-0.45	_____	+0.45	dB
	1900 MHz		-0.45	_____	+0.45	dB
	2000 MHz		-0.45	_____	+0.45	dB
4	Display linearity	5.3.4				
	a_{ATT}					
	16 dB		-	Reference	-	-
	18 dB		-2.15	_____	-1.85	dB
	20 dB		-4.15	_____	-3.85	dB
	22 dB		-6.15	_____	-5.85	dB
	24 dB		-8.15	_____	-7.85	dB
	26 dB		-10.15	_____	-9.85	dB
	28 dB		-12.15	_____	-11.85	dB
	30 dB		-14.15	_____	-13.85	dB
	32 dB		-16.15	_____	-15.85	dB
	34 dB		-18.15	_____	-17.85	dB
	36 dB		-20.15	_____	-19.85	dB
	38 dB		-22.15	_____	-21.85	dB
	40 dB		-24.15	_____	-23.85	dB
	42 dB		-26.15	_____	-25.85	dB
	44 dB		-28.15	_____	-27.85	dB
	46 dB		-30.15	_____	-29.85	dB
	48 dB		-32.15	_____	-31.85	dB
	50 dB		-34.15	_____	-33.85	dB
	52 dB		-36.15	_____	-35.85	dB
	54 dB		-38.15	_____	-37.85	dB
	56 dB		-40.15	_____	-39.85	dB

Item No.	Characteristic	Test to section	Min. value	Actual value	Max. value	Unit
5	Attenuator	5.3.5				
	a_{ATT}					
	40		-40.1	_____	-39.9	dBm
	30		-30.1	_____	-29.9	dBm
	20		-20.1	_____	-19.9	dBm
	10		-10.1	_____	-9.9	dBm

A - Interfaces

A.1 IEC Bus Interface

The standard instrument is equipped with an IEC/IEEE Bus connector. An IEEE 488 interface connector is located on the rear panel of the FSE. An external controller for remote control of the instrument can be connected via the IEEE 488 interface connector using a shielded cable.

A further optional IEC/IEEE-bus interface can be installed in the FSE and is, with an installed computer option, assigned to the MS-DOS computer. This interface can be controlled by standard software (R&S-Basic, QUICK-Basic, etc.) under MS-DOS as well as under WINDOWS (VISUAL BASIC, etc.) with the delivered driver software. It enables the remote control of the instrument via an external link to the two IEC/IEEE-bus interfaces and in addition the control of other equipment via the IEC/IEEE-bus connector at the rear of the unit (eg control of a complete test setup).

The following section describes the first IEC Bus interface over which the instrument can be remotely controlled. The characteristics of the PC2A/PC-AT controller interface depend upon the user-installed software running on the MS-DOS processor and is, therefore, not described here.

A.1.1 Interface Characteristics

- 8-bit parallel data transfer
- bidirectional data transfer
- three-line handshake
- high data transfer rate of max. 350 kbyte/s
- up to 15 instruments can be connected
- maximal length of the interconnecting cables 15 m (single connection, 2m)
- wired-OR connection if several instruments are connected in parallel.



Fig. A-1 Pin assignment of IEC-Bus interface

A.1.2 Bus Lines

1. **Data bus with 8 lines DIO 1 to DIO 8.**
   The transmission is bit-parallel and byte-serial in the ASCII/ISO code. DIO1 is the least significant, DIO8 the most significant bit.

2. **Control bus with 5 lines.**
   IFC (Interface Clear),
   active low resets the interfaces of the devices connected to the default setting.

   ATN (Attention),
   active low signals the transmission of interface messages
   inactive high signals the transmission of device messages.

   SRQ (Service Request),
   active low enables a device connected to send a service request to the controller.

   REN (Remote Enable),
   active low permits the switch over to remote control.

   EOI (End or Identify),
   has two functions in connection with ATN:
   active low marks the end of data transmission when ATN=high
   active low triggers a parallel poll when ATN=low.

3. **Handshake bus with three lines.**
   DAV (Data Valid),
   active low signals a valid data byte on the data bus.

   NRFD (Not Ready For Data),
   active low signals that one of the devices connected is not ready for data transfer .

   NDAC (Not Data Accepted),
   active low as long as the device connected is accepting the data present on the data bus.

A.1.3 Interface Functions

Instruments which can be remote controlled via the IEC bus can be equipped with different interface functions. Table A-1lists the interface functions appropriate for the instrument.

Table A-1 Interface functions

Control character	Interface function
SH1	Handshake source function (source handshake), full capability
AH1	Handshake sink function (acceptor handshake), full capability
L4	Listener function, full capability, deaddressed by MTA.
T6	Talker function, full capability, ability to respond to serial poll, deaddressed by MLA
SR1	Service request function (Service Request), full capability
PP1	Parallel poll function, full capability
RL1	Remote/Local switch over function, full capability
DC1	Reset function (Device Clear), full capability
DT1	Trigger function (Device Trigger), full capability
C12	Controller function, capability to send interface messages, to accept or relinquish the controller function

A.1.4 IEC Bus Messages

The messages transferred via the data lines of the IEC bus can be divided into two groups:

– **interface messages**
and
– **instrument messages.**

A.1.5 Interface Messages

Interface messages are transferred on the data lines of the IEC Bus when the "ATN" control line is active (LOW). They are used for communication between controller and instruments and can only be sent by the controller which currently has control of the IEC Bus.

Universal Commands

The universal commands are encoded 10 - 1F hex. They affect all instruments connected to the bus without addressing.

Table A-2 Universal Commands

Command	QuickBASIC command	Effect on the instrument
DCL (Device Clear)	IBCMD (controller%, CHR$(20))	Aborts the processing of the commands just received and sets the command processing software to a defined initial state. Does not change the instrument settings.
IFC (Interface Clear)	IBSIC (controller%)	Resets the interfaces to the default setting.
LLO (Local Lockout)	IBCMD (controller%, CHR$(17))	The LOC/IEC ADDR key is disabled.
SPE (Serial Poll Enable)	IBCMD (controller%, CHR$(24))	Ready for serial poll.
SPD (Serial Poll Disable)	IBCMD (controller%, CHR$(25))	End of serial poll.
PPU (Parallel Poll Unconfigure)	IBCMD (controller%, CHR$(21))	End of the parallel-poll state.

Addressed Commands

The addressed commands are encoded 00 - 0F hex. They are only effective for instruments addressed as listeners.

Table A-3 Addressed Commands

Command	QuickBASIC command	Effect on the instrument
SDC (Selected Device Clear)	IBCLR (device%)	Aborts the processing of the commands just received and sets the command processing software to a defined initial state. Does not change the instrument setting.
GTL (Go to Local)	IBLOC (device%)	Transition to the "Local" state (manual control).
PPC (Parallel Poll Configure)	IBPPC (device%, data%)	Configure instrument for parallel poll. Additionally, the QuickBASIC command executes PPE/PPD.

A.1.6 Instrument Messages

Instrument messages are transferred on the data lines of the IEC bus when the "ATN" control line is not active. ASCII code is used.
Structure and syntax of the instrument messages are described in Chapter 3, Section 3.5. The commands are listed and explained in detail in Chapter 3, Section 3.6.

A.2 RS-232-C Interface

The standard FSE is equipped with two serial interfaces (RS-232-C). The RS-232-C interfaces are two independent, remote-control channels, both of which may be active at the same time. The programming and interrogation commands affect the same instrument hardware. The interfaces can be set up manually in the *SETUP-GENERAL SETUP* menu in the *COM PORT1/2* table or, via remote control, switched on/off with the command `SYSTem:COMMunication:SERial1|2:STATe`.

Each of the active RS-232-C interfaces is assigned to one of the 9-pin connectors located on the rear panel. Interface 1 is assigned to the connector COM1 and Interface 2 is assigned to the connector COM2.

A.2.1 Interface Characteristics

- Serial data transmission in asynchronous mode
- Bidirectional data transfer via two separate lines
- Transmission rate selectable from 110 to 19200 baud
- Logic '0' signal from+3 V to +15 V
- Logic '1' signal from -15 V to -3 V
- An external instrument (controller) can be connected.
- Software handshake (XON, XOFF)
- Hardware handshake



Fig. A-2 Pin assignment of the RS-232-C interface

A.2.2 Signal Lines

1. Data lines

The data transmission is bit-serial in ASCII code starting with the LSB. Two lines, **RxD** and **TxD** are necessary as the minimum requirement for transmission; however, no hardware handshake is possible. For handshaking, only the XON/XOFF software handshake protocol can be used .

RxD (Receive Data)
Input, LOW = logic '1', HIGH = logic '0'.
Data line, local terminal receives data from remote station.

TxD (Transmit Data)
Output, LOW = logic '1', HIGH = logic '0'.
Data line, local terminal transmits data to remote station.

2. Control lines

DCD (Data Carrier Detect),
Not used in FSE.
Input; active LOW.
Using this signal, the local terminal recognises that the modem of the remote station receives valid signals with sufficient level. DCD is used to disable the receiver in the local terminal and prevent reading of false data if the modem cannot interpret the signals of the remote station.

DTR (Data Terminal Ready),
Output, active LOW,
Indicates that the local terminal is ready to receive data.

DSR (Data Set Ready),
Input, active LOW,
Indicates that the remote station is ready to receive data.

RTS (Request To Send),
Output, active LOW.
Indicates that the local terminal wants to transmit data.

CTS (Clear To Send),
Input, active LOW.
Used to tell the local terminal that the remote station is ready to receive data.

RI (Ring Indicator),
Not used in FSE.
Input, active LOW.
Used by a modem to indicate that a remote station wants to establish a connection.

A.2.3 Transmission Parameters

To ensure error-free data transmission, the parameters of the instrument and the controller must have the same settings. The parameters are defined in the *SETUP-GENERAL SETUP* menu.

Transmission rate (baud rate) — the following transmission rates can be set in the analyzer: 110, 300, 600, 1200, 2400, 4800, 9600, 19200.

Data bits — Data transmission is in 7- or 8-bit ASCII code. The first bit transmitted is the LSB (least significant bit).

Start bit — Each data byte starts with a start bit. The falling edge of the start bit indicates the beginning of the data byte.

Parity bit — In order to detect errors, a parity bit may be transmitted. No parity, even parity or odd parity may be selected. In addition, the parity bit can be set to logic '0' or to logic '1'.

Stop bits — The transmission of a data byte is terminated by 1, 1,5 or 2 stop bits.

Example:
Transmission of character 'A' (41 hex) in 7-bit ASCII code, with even parity and 2 stop bits:



A.2.4 Interface Functions

For interface control, several strings are defined and control characters are reserved which are based upon IEC Bus control.

Table A-4 Control strings or control characters of the RS-232 interface

Control string or character	Function
'@REM'	Switch over to remote
'@LOC'	Switch over to local
'@SRQ'	Service Request SRQ (SRQ is sent by the instrument)
'@GET'	Group Execute Trigger (GET)
'@DCL'	Reset instrument (Device Clear DCL)
<Ctrl Q> 11 Hex	Enables character output / XON
<Ctrl S> 13 Hex	Inhibits character output / XOFF
0D Hex, 0A Hex	Terminator <CR>, <LF>

A.2.5 Handshake

Software handshake

In the software handshake mode of operation, the data transfer is controlled using the two control characters XON / XOFF.

The instrument uses the control character XON to indicate that it is ready to receive data. If the receive buffer is full, it sends the XOFF character via the interface to the controller. The controller then interrupts the data output until it receives another XON from the instrument. The controller indicates to the instrument that it is ready to receive data in the same way.

Cable required for software handshake

The connection of the instrument with a controller for software handshake is made by crossing the data lines. The following wiring diagram applies to a controller with a 9-pin or 25-pin configuration.



Fig. A-3 Wiring of the data lines for software handshake

Hardware handshake

For hardware handshake, the instrument indicates that it is ready to receive data via the lines DTR and RTS. A logic '0' on both lines means 'ready' and a logic '1' means 'not ready'. The RTS line is always active (logic '0') as long as the serial interface is switched on. The DTR line thus controls the readiness of the instrument to receive data.

The readiness of the remote station to receive data is reported to the instrument via the CTS and DSR line. A logic '0' on both lines activates the data output and a logic '1' on both lines stops the data output of the instrument. The data output takes place via the TxD line.

Cable for hardware handshake

The connection of the instrument to a controller is made with a so-called zero modem cable. Here, the data, control and acknowledge lines must be crossed. The following wiring diagram applies to a controller with a 9-pin or 25-pin configuration.



Fig. A-4 Wiring of the data, control and acknowledge lines for hardware handshake

A.3 RSIB Interface Functions

The RSIB interface allows the control of FSE by Windows applications WinWord and Excel or by Visual C++ and VisualBasic programs. The functions for the programming of control applications are provided by DLL `RSIB.DLL`.

Control applications may run locally on the measuring instrument, the name `'@local'` is specified for link setup by means of function `RSDLLibfind()`.



To access the measuring instruments via the RSIB interface the DLL should be installed in the control application directory.

The DLL is already installed in the corresponding directory on the measuring instruments.

For the different programming languages, files exist containing the declarations for the DLL functions and the error code definitions.

Visual Basic: `'RSIB.BAS'  (D:/runtime/RSIB)`
C: `'RSIBC.H'  (D:/runtime/RSIB)`
Winword: `'RSIBWB.BAS'(D:/runtime/RSIB)`

A.3.1 Variables ibsta, iberr, ibcntl

Same as with the National Instrument interface, successful execution of a command can be checked by means of the variables `ibsta`, `iberr` and `ibcntl`. To this end, references to the three variables are transferred to all RSIB functions. In addition, the status word `ibsta` is returned as a function value by all functions.

Status word ibsta
All functions send back a status word that provides information on the status of the RSIB interface. The following bits are defined:

Bit name	Bit	Hex code	Description
ERR	15	8000	This bit is set if an error occurs during a function call. If this bit is set, `iberr` contains an error code which specifies the error.
TIMO	14	4000	This bit is set if a timeout occurs during a function call. A timeout may occur in the following situations: • while waiting for an SRQ with the function `RSDLLWaitSrq()`. • if no acknowledgment is received for data sent to an instrument with `RSDLLibwrt()` or `RSDLLilwrt()`. • if no response from server to a data request with function `RSDLLibrd()` or `RSDLLilrd()`.
CMPL	8	0100	This bit is set if the reply of the IEC/IEEE-bus parser is completely read. If a reply of the parser is read with the function `RSDLLilrd()` and the buffer length is not sufficient, the bit is cleared.

Error variable iberr
If the ERR bit (8000h) is set in the status word, `iberr` contains an error code that specifies the error. The RSIB has error codes of its own independent of the National Instrument interface.

Error	Error code	Description
IBERR_DEVICE_REGISTER	1	RSIB.DLL cannot register any new device.
IBERR_CONNECT	2	Link to the device has failed.
IBERR_NO_DEVICE	3	An interface function was called with an invalid device handle.
IBERR_MEM	4	No free memory available.
IBERR_TIMEOUT	5	Timeout has occurred.
IBERR_BUSY	6	The RSIB interface is blocked by a function not yet completed. Windows is not blocked, for example, by function RSDLLibrd() if data are still to be transmitted in response to this function. In this case a new call is possible. Further calls are however rejected by RSIB.DLL with error code IBERR_BUSY.
IBERR_FILE	7	Error in reading from or writing to a file.

Count variable - ibcntl
The variable ibcntl is updated with the number of bytes transmitted on every read and write function call.

A.3.2 List of Interface Functions

The DLL functions are matched to the interface functions for IEC/IEEE-bus programming from National Instruments. Functions supported by the DLLs are listed in the following table.

Function	Description
RSDLLibfind()	Provides a handle for accessing a device.
RSDLLibwrt()	Sends a string terminated with a null to a device.
RSDLLibrd()	Reads data from a device into a string.
RSDLLilwrt()	Sends a specific number of bytes to a device.
RSDLLilrd()	Reads a specific number of bytes from a device.
RSDLLilwrtf()	Sends the contents of a file to a device.
RSDLLilrdf()	Reads data from a device into a file.
RSDLLTestSrq()	Checks if a device has generated an SRQ.
RSDLLWaitSrq()	Waits until a device generates an SRQ.
RSDLLibtmo()	Sets timeout period for RSIB functions.
RSDLLibsre()	Switches a device to local or remote.
RSDLLibloc()	Switches a device temporarily to local.
RSDLLibeot()	Enables/disables END message in write operations.

A.3.3 Description of Interface Functions

RSDLLibeot

The function enables the END message after write operations or disables it.

VB format:
```
Function RSDLLibeot (ByVal ud%, ByVal v%, ibsta%, iberr%,
ibcntl&) As Integer
```

C format:
```
void FAR PASCAL RSDLLibsre( short ud, short v, short far
*ibsta, short far *iberr, unsigned long far *ibcntl)
```

Parameter:

ud	Device handle.
v	0 - no END message
	1 - send END message

Example:
```
RSDLLibeot (ud, 1, ibsta, iberr, ibcntl)
```

If the END message is disabled, the data of a command can be sent by means of several successive write function calls. The END message must be enabled prior to the last data block.

RSDLLibfind()

The function provides a handle for accessing the instrument with the name `udName`.

VB format:
```
Function RSDLLibfind (ByVal udName$, ibsta%, iberr%, ibcntl&)
As Integer
```

C format:
```
short FAR PASCAL RSDLLibfind( char far *udName, short far
*ibsta, short far *iberr, unsigned long far *ibcntl)
```

Parameter: `udName` Instrument name

Example:
```
ud = RSDLLibfind ("@local", ibsta, iberr, ibcntl)
```

The function must be called before all other interface functions.
The function supplies a handle as a return value. The handle must be specified in all functions for accessing the instrument. If no instrument with the name `udName` is found, the handle will take on a negative value.

The local link on the instrument is established with the name `'@local'`.

RSDLLibloc

The function switches the instrument temporarily to LOCAL mode.

VB format:
```
Function RSDLLibloc (ByVal ud%, ibsta%, iberr%, ibcntl&) As
Integer
```

C format:
```
void FAR PASCAL RSDLLibloc( short ud, short far *ibsta, short
far *iberr, unsigned long far *ibcntl)
```

Parameter: `ud` Device handle

Example:
```
RSDLLibloc (ud, ibsta, iberr, ibcntl)
```

After switchover the instrument can be manually operated from the front panel. On the next access to the instrument by means of one of the functions of the RSIB.DLL, the instrument is switched again to the REMOTE state.

RSDLLibrd()

The function reads data from the instrument into the string `Rd` with the handle `ud`.

VB format:
```
Function RSDLLibrd (ByVal ud%, ByVal Rd$, ibsta%, iberr%,
ibcntl&) As Integer
```

C format:
```
short FAR PASCAL RSDLLibrd( short ud, char far *Rd, short far
*ibsta, short far *iberr, unsigned long far *ibcntl )
```

Parameter: `ud` Device handle

`Rd` String into which the read data are copied.

Example:
```
RSDLLibrd (ud, Rd, ibsta, iberr, ibcntl)
```

This function fetches replies of the IEC/IEEE-bus parser in response to a query command.
For this, a string of sufficient length must be generated when programming in Visual Basic. This can be accomplished in the definition of the string or with the command `Space$()`.

Generation of a string of the length 100:

- `Dim Rd as String * 100`
- ```
  Dim Rd as String
  Rd = Space$(100)
  ```
  ```

RSDLLibrdf()

Reads data from the instrument into the file `file` with the handle `ud`.

VB format: `Function RSDLLibrdf (ByVal ud%, ByVal file$, ibsta%, iberr%, ibcntl&) As Integer`

C format: `short FAR PASCAL RSDLLibrd( short ud, char far *file, short far *ibsta, short far *iberr, unsigned long far *ibcntl )`

Parameter:

`ud`	Device handle
`file`	File into which the read data are written.

Example: `RSDLLibrdf (ud, c:\db.sav, ibsta, iberr, ibcntl)`

This function serves to read replies of the IEC/IEEE-bus parser that are larger than 64 KB. The file name may include the drive and path.

RSDLLibwrt

The function sends data to the instrument with the handle `ud`.

VB format: `Function RSDLLibwrt (ByVal ud%, ByVal Wrt$, ibsta%, iberr%, ibcntl&) As Integer`

C format: `short FAR PASCAL RSDLLibwrt( short ud, char far *Wrt, short far *ibsta, short far *iberr, unsigned long far *ibcntl )`

Parameter:

`ud`	Device handle
`Wrt`	String sent to the instrument.

Example: `RSDLLibwrt(ud, "SENS:FREQ:STAR?", ibsta, iberr, ibcntl)`

The function allows setting and query commands to be sent to the measuring instruments. The function `RSDLLibeot()` is used for defining whether the data are interpreted as a complete command.

RSDLLibwrtf

The function sends the contents of a `file` to the instrument with the handle `ud`.

VB format: `Function RSDLLibwrtf (ByVal ud%, ByVal file$, ibsta%, iberr%, ibcntl&) As Integer`

C format: `short FAR PASCAL RSDLLibwrt( short ud, char far *Wrt, short far *ibsta, short far *iberr, unsigned long far *ibcntl )`

Parameter:

`ud`	Device handle
`file`	File whose contents are sent to the instrument.

Example: `RSDLLibrdf(ud, "C:\db.sav", ibsta, iberr, ibcntl)`

The function allows setting and query commands to be sent to the measuring instruments. The function `RSDLLibeot()` is used for defining whether the data are interpreted as a complete command.

RSDLLibsre

The function switches the instrument to LOCAL or REMOTE mode.

VB format: `Function RSDLLibsre (ByVal ud%, ByVal v%, ibsta%, iberr%, ibcntl&) As Integer`

C format: `void FAR PASCAL RSDLLibsre( short ud, short v, short far *ibsta, short far *iberr, unsigned long far *ibcntl)`

Parameter:

`ud`	Device handle
`v`	Instrument status
	0 - local
	1 - remote

Example: `RSDLLibsre (ud, 0, ibsta, iberr, ibcntl)`

RSDLLibtmo

The function defines the timeout for an instrument. The default value for the timeout is 5 seconds.

VB format: `Function RSDLLibtmo (ByVal ud%, ByVal tmo%, ibsta%, iberr%, ibcntl&) As Integer`

C format: `void FAR PASCAL RSDLLibtmo( short ud, short tmo, short far *ibsta, short far *iberr, unsigned long far *ibcntl )`

Parameter:

`ud`	Device handle
`tmo`	Time in seconds

Example: `RSDLLibtmo (ud, 10, ibsta, iberr, ibcntl)`

Timeout can occur in the following cases:

- Waiting for an SRQ with the function `RSDLLWaitSrq()`.
- Waiting for an acknowledgment for data sent to an instrument with `RSDLLibwrt()` or `RSDLLilwrt()`.
- Waiting for a reply to a data request made with function `RSDLLibrd()` or `RSDLLilrd()`.

RSDLLilrd

The function reads `Cnt` bytes from the instrument with the handle `ud`.

VB format: `Function RSDLLilrd (ByVal ud%, ByVal Rd$, ByVal Cnt&, ibsta%, iberr%, ibcntl&) As Integer`

C format: `short FAR PASCAL RSDLLilrd( short ud, char far *Rd, unsigned long Cnt, short far *ibsta, short far *iberr, unsigned long far *ibcntl )`

Parameter:

`ud`	Device handle
`cnt`	Maximum number of bytes copied to target string `Rd` by the DLL.

Example: `RSDLLilrd (ud, RD, 100, ibsta, iberr, ibcntl)`

The function reads data from an instrument same as function `RSDLLibrd()` but with the difference that here the maximum number of bytes is allowed to be copied to target string `Rd` to be defined with `Cnt`. Writing beyond a string can thus be prevented with this function. The number of bytes cut off is lost.

RSDLLilwrt

The function sends `Cnt` bytes to the instrument with the handle `ud`.

VB format:
```
Function RSDLLilwrt (ByVal ud%, ByVal Wrt$, ByVal Cnt&,
ibsta%, iberr%, ibcntl&) As Integer
```

C format:
```
short FAR PASCAL RSDLLilwrt( short ud, char far *Wrt,
unsigned long Cnt, short far *ibsta, short far *iberr,
unsigned long far *ibcntl)
```

Parameter:

`ud`	Device handle
`Wrt`	String sent to the IEC/IEEE-bus parser.
`Cnt`	Number of bytes sent to the instrument.

Example:
```
RSDLLilwrt (ud, '......', 100, ibsta, iberr, ibcntl)
```

This function sends data to an instrument same as function `RSDLLibwrt()` but with the difference that binary data, too, can be sent. The length of the data is determined not by a zero-terminated string but by the definition of `Cnt` bytes. If the data are to be terminated with EOS (0Ah), the EOS byte must be appended to the string.

RSDLLTestSRQ

The function checks the status of the SRQ bit.

VB format:
```
Function RSDLLTestSrq (ByVal ud%, Result%, ibsta%, iberr%,
ibcntl&) As Integer
```

C format:
```
void FAR PASCAL RSDLLTestSrq( short ud, short far *result,
short far *ibsta, short far *iberr, unsigned long far *ibcntl)
```

Parameter:

`ud`	Device handle
`result`	Reference to an integer value in which the library returns the status of the SRQ bit. 0 - no SRQ 1 - SRQ active, instrument has output a service request

Example:
```
RSDLLTestSrq (ud, result%, ibsta, iberr, ibcntl)
```

The function corresponds to the function `RSDLLWaitSrq` but with the difference that `RSDLLTestSRQ` returns immediately the current status of the SRQ bit whereas `RSDLLWaitSrq` waits for an SRQ to occur.

RSDLLWaitSrq

The function waits until the instrument triggers an SRQ with the handle `ud`.

VB format:
```
Function RSDLLWaitSrq (ByVal ud%, Result%, ibsta%, iberr%,
ibcntl&) As Integer
```

C format:
```
void FAR PASCAL RSDLLWaitSrq( short ud, short far *result,
short far *ibsta, short far *iberr, unsigned long far *ibcntl)
```

Parameter:

`ud`	Device handle
`result`	Reference to an integer value in which the library returns the status of the SRQ bit. 0 - no SRQ occurred within the timeout 1 - SRQ occurred within the timeout

Parameter:
```
RSDLLWaitSrq( ud, result, ibsta, iberr, ibcntl );
```

The function waits until one of the two following events occurs:

- The instrument triggers an SRQ.
- No SRQ occurs during the timeout defined with `RSDLLibtmo()`.

A.4 User Interface (USER)

The user interface, located on the rear panel of the FSE, is a 25 pin Cannon connector which provides access to the two user ports (Port A and Port B). Each port is 8 bits wide (A0 - A7 and B0 -B7) and can be configured either as output or as input. The voltage levels are TTL levels (Low < 0,4 V, High > 2 V).

In addition, an internal +5 V power supply voltage is provided. The maximum load current is 100 mA.

The pin assignments for the USER connector can be seen in the following diagram:



Fig. A-5 Pin assignments for the USER connector.

The configuration of the user ports takes place in the *SETUP* menu (SETUP key) in the *GENERAL SETUP* sub-menu.

A.5 Printer Interface (LPT)

The 25-pin LPT connector on the rear panel of the FSE is provided for the connection of a printer.. The LPT interface is compatible with the CENTRONICS printer interface.



Pin	Signal	Input (I) Output (O)	Description
1	STROBE	O	Pulse for transmitting a data byte, min. 1µs pulse width (active LOW)
2	D0	O	Data Line 0
3	D1	O	Data Line 1
4	D2	O	Data Line 2
5	D3	O	Data Line 3
6	D4	O	Data Line 4
7	D5	O	Data Line 5
8	D6	O	Data Line 6
9	D7	O	Data Line 7
10	ACK	I	Indicates that the printer is ready to receive the next byte. (active LOW)
11	BUSY	I	Signal is active when the printer cannot accept data. (active HIGH)
12	PE	I	Signal is active when the paper tray is empty. (active HIGH)
13	SELECT	I	Signal is active when the printer is selected. (active HIGH)
14	AUTOFEED	O	When signal is active, the printer automatically performs a linefeed after each line. (active LOW)
15	ERROR	I	This signal is high when the printer has no paper, is not selected or has an error status. (active LOW)
16	INIT	O	Initialise the printer. (active LOW)
17	SELECT IN	O	If signal is active, the codes DC1/DC3 are ignored by the printer. (active LOW).
18 - 25	GND		Ground connection.

Fig. A-6Pin assignments for the LPT connector.

A.6 Measurement Converters (PROBE CODE)

The PROBE CODE connector is used for supplying power to measurement converters and the providing the correct conversion factor coding to the FSE. Using it, the conversion factors for high-impedance probes, current converters and antennas can be encoded in 10dB steps. In addition, the quantity to be measured (field strength, current and voltage) is also passed to the FSE. Active converters can be supplied with ±10 V via the PROBE CODE connector. The following R&S accessories are deliverable with the applicable coding:

· Wide band dipole	20...80 MHz	HUF-Z2
· HF current converter	100 kHz..30 MHz	ESH2-Z1
· VHF current converter	20...300 MHz	ESV-Z1
· Current converter	20 Hz...100 MHz	EZ-17
· Preamplifier	20...1000 MHz	ESV-Z2.

The pins of the PROBE CODE connector are assigned as follows:



A ground
B +10 V, max. 50 mA
C µV/m (elec. field strength)
D µA
E 10 dB
F 20 dB
G 40 dB
H 80 dB
K -10 V, max. 50 mA
M factor sign inversion

Fig A-7 Pin assignment for the 12-pin Tuchel connector.

A 12-pin connector is used for coding (manufacturer: Tuchel, R&S part number 0018.5362.00, Tuchel type number: T3635/2). The input pins for implementing the code are connected to ground.

Example: An antenna for measurement of the electromagnetic field strength has an antenna factor of 10 dB, i.e., a field strength of 10 dBµV/m produces a voltage at the RF input of 0 dBµV.

-> Pins C and E are connected to ground.

A.7 Probe Connector (PROBE POWER)

To allow the connection of probes, the FSE provides the PROBE POWER power connector. It delivers the power supply voltages +15 V and -12,6 V and ground.

The connector is also suited for powering the high-impedance probes from Hewlett Packard.

A.8 AF-Output (AF OUTPUT)

A miniature telephone jack can be used at the AF OUTPUT connector to connect an external loudspeaker, a headphone set or, e.g., a LF voltmeter. The internal resistance is 10 ohms and the output voltage can be controlled in the *MARKER DEMOD* menu. When a jack is plugged in, the internal loudspeaker is automatically turned off.

A.9 IF Output 21.4 MHz (21.4 MHz OUT)

The 21,4 MHz IF signal of the FSE is available at the IF 21.4 MHz OUT BNC connector. The bandwidth corresponds to the selected bandwidth for a resolution bandwidth between 2 kHz and 10 MHz. For a resolution bandwidth below 2 kHz, the bandwidth of the output is 5 kHz.
The signal level at the IF output is 0 dBm for signals which correspond to the selected reference level.

A.10 Video Output (VIDEO OUT)

he video output delivers the logarithmic envelope curve of the IF signal independent of the level scaling on the display screen (linear or logarithmic). The bandwidth of the video signal always corresponds to one-half of the IF bandwidth and is not limited by the video filter in the measurement path.

A.11 Reference Output/Input (EXT REF IN/OUT)

When the FSE is operated with the internal reference, the internal 10 MHz reference signal is also available at the REF IN/OUT connector and thus provides the capability of, e.g., synchronisation of external instruments to the FSE. The level is 1 V RMS at 50 ohms source impedance.

For operation with an external reference, this connector becomes an input connector. The internal reference oscillator is then synchronised to the reference applied to the connector. The reference frequency can be between 1 and 16 MHz in 1 MHz steps. The necessary level is > 0 dBm.

The selection of internal or external references takes place in the *SETUP* menu.

A.12 Sweep Output (SWEEP)

The SWEEP BNC connector delivers a saw-tooth voltage between - 5V and + 5 V which, for the frequency spectrum display, is proportional to the instantaneous frequency. The selected start frequency corresponds to a voltage of -5 V and the stop frequency corresponds to a voltage of +5 V.

A.13 External Trigger Input (EXT TRIGGER/GATE)

The EXT TRIG/GATE connector is used for controlling the measurement via an external signal.

Trigger voltage range:: -5 V ... +5 V

A.14 Noise Source Control (NOISE SOURCE)

Using the NOISE SOURCE connector, an external noise source can be switched on/off, in order, e.g., to measure the noise figure of Units Under Test (UUTs). Usual noise sources require a +28 V signal to be turned on. At 0 V, they are turned off. These switching voltages are delivered by the connector.

A.15 External Keyboard (KEYBOARD)

A 5-pin DIN connector is provided to allow connecting an external keyboard. Because of its low interference radiation, the PSA-Z1 keyboard is recommended (Order No. 1009.5001.31). However, any other multi-function keyboard may also be used.



Pin	Signal
1	Keyboard Clock
2	Data
3	Free
4	Ground
5	+5-V-Power Supply

Fig. A-8 Pin assignments of the KEYBOARD connector.

A.16 Mouse Connector (MOUSE)



Pin	Signal
1	MOUSEDATA
2	NC
3	MOUSEGND
4	MOUSEVD5
5	MOUSECLK
6	NC

Fig A-9 Pin assignments for the MOUSE connector.

A.17 Monitor Connector (MONITOR)



Pin	Signal
1	R
2	G
3	B
4	MID2
5	NC
6	R-GND
7	G-GND
8	B-GND
9	NC
10	GND
11	MID0
12	MID1
13	HSYNC
14	VSYNC
15	NC

Fig. A-10 Pin assignments of the MONITOR connector.

Annex B – List of Error Messages

The following list contains all error messages for errors occurring in the instrument. The meaning of negative error codes is defined in SCPI, positive error codes mark errors specific of the instrument.

The table contains the error code in the left-hand column. In the right-hand column the error text being entered into the error/event queue or being displayed is printed in bold face. Below the error text, there is an explanation as to the respective error.

B.1 SCPI-Specific Error Messages

No Error

Error code	Error text in the case of queue poll Error explanation
0	**No error** This message is output if the error queue does not contain any entries.

Command Error - Faulty command; sets bit 5 in the ESR register.

Error code	Error text in the case of queue poll Error explanation
-100	**Command Error** The command is faulty or invalid.
-101	**Invalid Character** The command contains an invalid sign. Example: A header contains an ampersand, "**SENSe&**".
-102	**Syntax error** The command is invalid. Example: The command contains block data the instrument does not accept.
-103	**Invalid separator** The command contains an impermissible sign instead of a separator. Example: A semicolon is missing after the command.
-104	**Data type error** The command contains an invalid value indication. Example: ON is indicated instead of a numeric value for frequency setting.
-105	**GET not allowed** A Group Execute Trigger (GET) is within a command line.
-108	**Parameter not allowed** The command contains too many parameters. Example: Command **SENSe:FREQuency:CENTer** permits only one frequency indication.

Continuation: Command Error

Error code	Error text in the case of queue poll Error explanation
-109	**Missing parameter** The command contains too few parameters. Example: The command `SENSe:FREQuency:CENTer` requires a frequency indication.
-110	**Command header error** The header of the command is faulty.
-111	**Header separator error** The header contains an impermissible separator. Example: the header is not followed by a "White Space", "`*ESE255`"
-112	**Program mnemonic too long** The header contains more than 12 characters.
-113	**Undefined header** The header is not defined for the instrument. Example: `*XYZ` is undefined for every instrument.
-114	**Header suffix out of range** The header contains an impermissible numeric suffix. Example: `SENSe3` does not exist in the instrument.
-120	**Numeric data error** The command contains a faulty numeric parameter.
-121	**Invalid character in number** A number contains an invalid character. Example: An "A" in a decimal number or a "9" in an octal number.
-123	**Exponent too large** The absolute value of the exponent is greater than 32000.
-124	**Too many digits** The number includes too many digits.
-128	**Numeric data not allowed** The command includes a number which is not allowed at this position. Example: The command `INPut:COUPling` requires indication of a text parameter.
-130	**Suffix error** The command contains a faulty suffix.
-131	**Invalid suffix** The suffix is invalid for this instrument. Example: nHz is not defined.
-134	**Suffix too long** The suffix contains more than 12 characters.
-138	**Suffix not allowed** A suffix is not allowed for this command or at this position of the command. Example: The command `*RCL` does not permit a suffix to be indicated.
-140	**Character data error** The command contains a faulty text parameter
-141	**Invalid character data** The text parameter either contains an invalid character or it is invalid for this command. Example: Write error with parameter indication;`INPut:COUPling XC`.

Continuation: Command Error

Error code	Error text in the case of queue poll Error explanation
-144	**Character data too long** The text parameter contains more than 12 characters.
-148	**Character data not allowed** The text parameter is not allowed for this command or at this position of the command. Example: The command `*RCL` requires a number to be indicated.
-150	**String data error** The command contains a faulty string.
-151	**Invalid string data** The command contains a faulty string. Example: An END message has been received prior to the terminating apostrophe.
-158	**String data not allowed** The command contains a valid string at a position which is not allowed. Example: A text parameter is set in quotation marks, `INPut:COUPling "DC"`
-160	**Block data error** The command contains faulty block data.
-161	**Invalid block data** The command contains faulty block data. Example: An END message was received prior to reception of the expected number of data.
-168	**Block data not allowed** The command contains valid block data at an impermissible position. Example: The command `*RCL` requires a number to be indicated.
-170	**Expression error** The command contains an invalid mathematical expression.
-171	**Invalid expression** The command contains an invalid mathematical expression. Example: The expression contains mismatching parentheses.
-178	**Expression data not allowed** The command contains a mathematical expression at an impermissible position.
-180	**Macro error** A faulty macro has been defined, or an error has occurred during execution of a macro.
-181	**Invalid outside macro definition** A macro parameter placeholder was encountered outside of a macro definition.
-183	**Invalid inside macro definition** A macro definition is syntactically wrong.
-184	**Macro parameter error** A command inside the macro definition has the wrong number or type of parameters.

Execution Error - Error on execution of a command; sets bit 4 in the ESR register

Error code	**Error text in the case of queue poll** Error explanation
-200	**Execution error** Error on execution of the command.
-201	**Invalid while in local** The command is not executable while the device is in local due to a hard local control. Example: The device receives a command which would change the rotary knob state, but the device is in local so the command can not be executed.
-202	**Settings lost due to rtl** A setting associated with hard local control was lost when the device changed to LOCS from REMS or to LWLS from RWLS.
-210	**Trigger error** Error on triggering the device.
-211	**Trigger ignored** The trigger (GET, *TRG or trigger signal) was ignored because of device timing considerations. Example: The device was not ready to respond.
-212	**Arm ignored** An arming signal was ignored by the device.
-213	**Init ignored** Measurement initialisation was ignored as another measurement was already in progress.
-214	**Trigger deadlock** The trigger source for the initiation of measurement is set to GET and subsequent measurement is received. The measurement cannot be started until a GET is received, but the GET would cause an interrupted-error)
-215	**Arm deadlock** The trigger source for the initiation of measurement is set to GET and subsequent measurement is received. The measurement cannot be started until a GET is received, but the GET would cause an interrupted-error.
-220	**Parameter error** The command contains a faulty or invalid parameter.
-221	**Settings conflict** There is a conflict between setting of parameter value and instrument state.
-222	**Data out of range** The parameter value lies out of the permissible range of the instrument.
-223	**Too much data** The command contains too many data. Example: The instrument does not have sufficient storage space.
-224	**Illegal parameter value** The parameter value is invalid. Example: The text parameter is invalid , **`TRIGger:SWEep:SOURce TASTe`**

Continuation: Execution Error

Error code	Error text in the case of queue poll Error explanation
-230	**Data corrupt or stale** The data are incomplete or invalid. Example: The instrument has aborted a measurement.
-231	**Data questionable** The measurement accuracy is suspect.
-240	**Hardware error** The command cannot be executed due to problems with the instrument hardware.
-241	**Hardware missing** Hardware is missing. Example: An option is not fitted.
-250	**Mass storage error** A mass storage error occured.
-251	**Missing mass storage** The mass storage is missing. Example: An option is not installed.
-252	**Missing media** The media is missing. Example: There is no floppy in the floppy disk drive.
-253	**Corrupt media** The media is corrupt. Example: The floppy is bad or has the wrong format.
-254	**Media full** The media is full. Example: There is no room on the floppy.
-255	**Directory full** The media directory is full.
-256	**File name not found** The file name cannot be found on the media.
-257	**File name error** The file name is wrong. Example: An attempt is made to copy to a duplicate file name.
-258	**Media protected** The media is protected. Example: The write-protect tab on the floppy is present.
-260	**Expression error** The expression contains an error.
-261	**Math error in expression** The expression contains a math error. Example: Divide-by-zero.

Continuation: Execution Error

Error code	Error text in the case of queue poll Error explanation
-270	**Macro error** Error on the execution of a macro.
-271	**Macro syntax error** The macro definition contains a syntax error.
-272	**Macro execution error** The macro definition contains an error.
-273	**illegal macro label** An illegal macro label is defined in the *DMC command. Example: The label is too long. The label is identical with the common command header or contains an invalid header syntax.
-274	**Macro parameter error** The macro definition improperly uses a macro parameter placeholder.
-275	**Macro definition too long** The macro definition is too long.
-276	**Macro recursion error** The command sequence defined by the macro is trapped in a program loop. Example: The event that would allow the loop to be exited does not occur.
-277	**Macro redefinition not allowed** The macro label defined in the *DMC command is already defined elsewhere.
-278	**Macro header not found** The macro label in the *GMC? query is not yet defined.
-280	**Program error** Error on the execution of a down-loaded program.
-281	**Cannot create program** The program cannot be created.
-282	**illegal program name** The name of the programm is illegal. Example: The name relates to a non-existing program.
-283	**illegal variable name** The inputted variable does not exist in the program.
-284	**Program currently running** The desired operation is not possible while the program is running. Example: A running program cannot be deleted.
-285	**Program syntax error** The down-loaded program contains a syntax error.
-286	**Program runtime error**

Device Specific Error; sets bit 3 in the ESR register

Error code	Error test in the case of queue poll Error explanation
-300	**Device-specific error** FSE-specific error not defined in greater detail.
-310	**System error** This error message suggests an error within the instrument. Please inform the R&S Service.
-311	**Memory error** Error in the instrument memory.
-312	**PUD memory lost** Loss of the protected user data stored using the *PUD command.
-313	**Calibration memory lost** Loss of the non-volatile calibration data stored using the *CAL? command.
-314	**Save/recall memory lost** Loss of the non-volatile data stored using the *SAV command.
-315	**Configuration memory lost** Loss of the non-volatile configuration data stored by the instrument.
-330	**Self-test failed** The selftest could not be executed.
-350	**Queue overflow** This error code is entered in the queue instead of the actual error code if the queue is full. It indicates that an error has occurred but not been accepted. The queue can accept 5 entries.

Query Error - Error in data request; sets bit 2 in the ESR register

Error code	Error text in the case of queue poll Error explanation
-400	**Query error** General error occurring when data are requested by a query.
-410	**Query INTERRUPTED** The query has been interrupted. Example: After a query, the instrument receives new data before the response has been sent completely.
-420	**Query UNTERMINATED** The query is incomplete. Example: The instrument is addressed as a talker and receives incomplete data.
-430	**Query DEADLOCKED** The query cannot be processed. Example: The input and output buffers are full, the instrument cannot continue operation.
-440	**Query UNTERMINATED after indefinite response** A query is in the same command line after a query which requests an indefinite response.

Annex C – Alphabetical List of Commands

Command	Parameter	Page
ABORt		3.6-7
CALCulate<1|2>:DELTamarker<1 to 4>:AOFF		3.6-9
CALCulate<1|2>:DELTamarker<1 to 4>:FUNCtion:FIXed:RPOint:X	<numeric_value>	3.6-12
CALCulate<1|2>:DELTamarker<1 to 4>:FUNCtion:FIXed:RPOint:Y		3.6-12
CALCulate<1|2>:DELTamarker<1 to 4>:FUNCtion:FIXed:RPOint:Y:OFFSet	<numeric_value>	3.6-12
CALCulate<1|2>:DELTamarker<1 to 4>:FUNCtion:FIXed[:STATe]	ON | OFF	3.6-12
CALCulate<1|2>:DELTamarker<1 to 4>:FUNCtion:PNOise:RESult?		3.6-13
CALCulate<1|2>:DELTamarker<1 to 4>:FUNCtion:PNOise[:STATe]	ON | OFF	3.6-13
CALCulate<1|2>:DELTamarker<1 to 4>:MAXimum:APEak		3.6-10
CALCulate<1|2>:DELTamarker<1 to 4>:MAXimum:LEFT		3.6-11
CALCulate<1|2>:DELTamarker<1 to 4>:MAXimum:NEXT		3.6-10
CALCulate<1|2>:DELTamarker<1 to 4>:MAXimum[:PEAK]		3.6-10
CALCulate<1|2>:DELTamarker<1 to 4>:MAXimum:RIGHt		3.6-10
CALCulate<1|2>:DELTamarker<1 to 4>:MINimum:LEFT		3.6-11
CALCulate<1|2>:DELTamarker<1 to 4>:MINimum:NEXT		3.6-11
CALCulate<1|2>:DELTamarker<1 to 4>:MINimum[:PEAK]		3.6-11
CALCulate<1|2>:DELTamarker<1 to 4>:MINimum:RIGHt		3.6-11
CALCulate<1|2>:DELTamarker<1 to 4>:MODE	ABSolute | RELative	3.6-9
CALCulate<1|2>:DELTamarker<1 to 4>:STEP:AUTO	ON | OFF	3.6-13
CALCulate<1|2>:DELTamarker<1 to 4>:STEP[:INCRement)]	<numeric value>	3.6-13
CALCulate<1|2>:DELTamarker<1 to 4>:TRACe	1 to 4	3.6-9
CALCulate<1|2>:DELTamarker<1 to 4>:X:RELative?		3.6-9
CALCulate<1|2>:DELTamarker<1 to 4>:Y?		3.6-10
CALCulate<1|2>:DELTamarker<1 to 4>[:STATe]	ON | OFF	3.6-8
CALCulate<1|2>:DELTamarker<1...4>:X	0 to MAX (freq | sweep time | symbols)	3.6-9
CALCulate<1|2>:DLINe<1|2>	MINimum to MAXimum (depending on current unit)	3.6-14
CALCulate<1|2>:DLINe<1|2>:STATe	ON | OFF	3.6-14
CALCulate<1|2>:FEED	'XTIM:DDEM:MEAS' | 'XTIM:DDEM:REF' | 'XTIM:DDEM:ERR:MPH' | 'XTIM:DDEM:ERR:VECT' | 'XTIM:DDEM:SYMB' | 'XTIM:AM' | 'XTIM:FM' | 'XTIM:PM' | 'XTIM:AMSummary' | 'XTIM:FMSummary' | 'XTIM:PMSummary' '	3.6-17
CALCulate<1|2>:FLINe<1|2>	0 GHz to f_{max}	3.6-15
CALCulate<1|2>:FLINe<1|2>:STATe	ON | OFF	3.6-15
CALCulate<1|2>:FORMat	MAGNitude | PHASe | UPHase | RIMag | FREQuency | IEYE | QEYE | TEYE | FEYE | COMP | CONS	3.6-18
CALCulate<1|2>:FSK:DEViation:REFerence	<numeric_value>	3.6-18
CALCulate<1|2>:LIMit<1 to 8>:ACPower:ACHannel	0 to 100 dB, 0 to 100 dB	3.6-30
CALCulate<1|2>:LIMit<1 to 8>:ACPower:ACHannel:RESult?		3.6-31

Command	Parameter	Page
CALCulate<1|2>:LIMit<1 to 8>:ACPower:ACHannel:STATe	ON | OFF	3.6-30
CALCulate<1|2>:LIMit<1 to 8>:ACPower:ALTernate<1|2>	0 to 100 DB, 0 to 100 DB	3.6-31
CALCulate<1|2>:LIMit<1 to 8>:ACPower:ALTernate<1|2>:STATe	ON | OFF	3.6-31
CALCulate<1|2>:LIMit<1 to 8>:ACPower[:STATe]	ON | OFF	3.6-30
CALCulate<1|2>:LIMit<1 to 8>:BURSt:POWer?		3.6-27
CALCulate<1|2>:LIMit<1 to 8>:BURSt:PTEMplate?		3.6-27
CALCulate<1|2>:LIMit<1 to 8>:CLEar[:IMMediate]		3.6-25
CALCulate<1|2>:LIMit<1 to 8>:COMMent	<string>	3.6-26
CALCulate<1|2>:LIMit<1 to 8>:CONTrol[:DATA]	<numeric_value>,<numeric_value>..	3.6-21
CALCulate<1|2>:LIMit<1 to 8>:CONTrol:DOMain	FREQuency | TIME	3.6-21
CALCulate<1|2>:LIMit<1 to 8>:CONTrol:MODE	RELative | ABSolute	3.6-22
CALCulate<1|2>:LIMit<1 to 8>:CONTrol:OFFset	<numeric_value>	3.6-21
CALCulate<1|2>:LIMit<1 to 8>:CONTrol:SHIFt	<numeric_value>	3.6-22
CALCulate<1|2>:LIMit<1 to 8>:CONTrol:SPACing	LINear < LOGarithmic	3.6-22
CALCulate<1|2>:LIMit<1 to 8>:CONTrol:UNIT[:TIME]	S | SYM	3.6-22
CALCulate<1|2>:LIMit<1 to 8>:COPY	1 to 8 | <name>	3.6-26
CALCulate<1|2>:LIMit<1 to 8>:DELete		3.6-26
CALCulate<1|2>:LIMit<1 to 8>:FAIL?		3.6-25
CALCulate<1|2>:LIMit<1 to 8>:LOWer[:DATA]	<numeric_value>	3.6-24
CALCulate<1|2>:LIMit<1 to 8>:LOWer:MARGin	<numeric_value>	3.6-24
CALCulate<1|2>:LIMit<1 to 8>:LOWer:MODE	RELative | ABSolute	3.6-25
CALCulate<1|2>:LIMit<1 to 8>:LOWer:OFFset	<numeric_value>	3.6-24
CALCulate<1|2>:LIMit<1 to 8>:LOWer:SHIFt	<numeric_value>	3.6-25
CALCulate<1|2>:LIMit<1 to 8>:LOWer:SPACing	LINear | LOGarithmic	3.6-25
CALCulate<1|2>:LIMit<1 to 8>:LOWer:STATe	ON | OFF	3.6-24
CALCulate<1|2>:LIMit<1 to 8>:MARGin	0 to 100DB	3.6-30
CALCulate<1|2>:LIMit<1 to 8>:NAME	1 to 8 | <string>	3.6-26
CALCulate<1|2>:LIMit<1 to 8>:SPECtrum:MODulation?	ARFCn | TXBand | RXBand | COMBined | DCSRx1800	3.6-27
CALCulate<1|2>:LIMit<1 to 8>:SPECtrum:MODulation:EXCeptions?	ARFCn | TXBand | RXBand | COMBined | DCSRx1800	3.6-28
CALCulate<1|2>:LIMit<1 to 8>:SPECtrum:MODulation:FAILs?	ARFCn | TXBand | RXBand | COMBined | DCSRx1800	3.6-28
CALCulate<1|2>:LIMit<1 to 8>:SPECtrum:SWITching?		3.6-28
CALCulate<1|2>:LIMit<1 to 8>:SPECtrum:SWITching:FAILs?		3.6-29
CALCulate<1|2>:LIMit<1 to 8>:SPURious:FAILs?	TXBand | OTXBand | RXBand | IDLeband	3.6-29
CALCulate<1|2>:LIMit<1 to 8>:SPURious?	ARFCn | TXBand | RXBand | IDLeband	3.6-29
CALCulate<1|2>:LIMit<1 to 8>:STATe	ON | OFF	3.6-20
CALCulate<1|2>:LIMit<1 to 8>:TRACe	<numeric_value>	3.6-20
CALCulate<1|2>:LIMit<1 to 8>:UPPer:MARGin	<numeric_value>	3.6-23
CALCulate<1|2>:LIMit<1 to 8>:UPPer:MODE	RELative | ABSolute	3.6-23
CALCulate<1|2>:LIMit<1 to 8>:UPPer:OFFset	<numeric_value>	3.6-23
CALCulate<1|2>:LIMit<1 to 8>:UPPer:SHIFt	<numeric_value>	3.6-23
CALCulate<1|2>:LIMit<1 to 8>:UPPer:SPACing	LINear | LOGarithmic	3.6-24
CALCulate<1|2>:LIMit<1 to 8>:UPPer:STATe	ON | OFF	3.6-23
CALCulate<1|2>:LIMit<1 to 8>:UPPer[:DATA]	<numeric_value>,<numeric_value>..	3.6-22

Command	Parameter	Page
CALCulate<1|2>:LIMit<1 to 8>:UNIT	DBM | DBPW | WATT | DBUV | DBMV | VOLT | DBUA | AMPere | DB | DBUV_MHZ | DBMV_MHZ | DBUA_MHZ |DBUV_M | DBUA_M | DBUV_MHZ | DBUA_MHZ | DEG | RAD | S | HZ | PCT | UNITLESS	3.6-21
CALCulate<1|2>:MARKer<1 to 4>:AOFF		3.6-34
CALCulate<1|2>:MARKer<1 to 4>:COUNt	ON | OFF	3.6-35
CALCulate<1|2>:MARKer<1 to 4>:COUNt:FREQuency?		3.6-35
CALCulate<1|2>:MARKer<1 to 4>:COUNt:RESolution	0.1 | 1 | 10 | 100 | 1000 | 10000 Hz	3.6-35
CALCulate<1|2>:MARKer<1 to 4>:COUPled[:STATe]	ON | OFF	3.6-36
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:ADEMod:AFRequency[:RESult]?		3.6-43
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:ADEMod:AM[:RESult]?	PPEak | MPEak | MIDDle | RMS	3.6-42
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:ADEMod:CARRier[:RESult]?		3.6-43
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:ADEMod:FERRor[:RESult]?		3.6-43
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:ADEMod:FM[:RESult]?	PPEak | MPEak | MIDDle | RMS | RDEV	3.6-42
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:ADEMod:PM[:RESult]?	PPEak | MPEak | MIDDle | RMS	3.6-42
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:ADEMod:SINad:RESult?		3.6-43
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:ADEMod:SINad[:STATe]	ON | OFF	3.6-43
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:CENTer	ON | OFF	3.6-53
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:CSTep	ON | OFF	3.6-53
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:DDEMod:RESult?	MERM | MEPK | MEPS | PERM PEPK | PEPS | EVRM | EVPK | EVPS IQOF | IQIM |ADR | FERR | RHO	3.6-44
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:DEModulation:HOLDoff	10ms to 1000s	3.6-41
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:DEModulation:SELect	AM | FM	3.6-40
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:DEModulation[:STATe]	ON | OFF	3.6-40
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:MSTep		3.6-54
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:NDBDown	<numeric_value>	3.6-39
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:NDBDown:FREQuency?		3.6-39
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:NDBDown:RESult?		3.6-39
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:NDBDown:STATe	ON | OFF	3.6-39
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:NOISe:RESult?		3.6-40
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:NOISe[:STATe}	ON | OFF	3.6-40
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:POWer:CFILter	ON | OFF	3.6-46
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:POWer:PRESet	NADC | TETRA | PDC | PHS | CDPD | F8CDma | R8CDma | F19Cdma | R19Cdma | NONE	3.6-46
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:POWer:RESult?	ACPower | CPOWer | OBANdwidth | OBWidth | CN | CN0	3.6-45
CALCulate<1|2>:MARKer<1to 4>:FUNCtion:POWer:SELect?	ACPower | CPOWer | OBANdwidth | OBWidth | CN | CN0	3.6-44
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:POWer[:STATe]	OFF	3.6-45
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:REFerence	ON | OFF	3.6-54
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SFACtor	(60dB/3dB) | (60dB/6dB)	3.6-41
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SFACtor:FREQuency?		3.6-41
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SFACtor:RESult?		3.6-41
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SFACtor:STATe	ON | OFF	3.6-41

Command	Parameter	Page
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:STARt		3.6-53
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:STOP		3.6-53
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:STRack[:STATe]	ON | OFF	3.6-42
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:AOFF		3.6-53
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:AVERage	ON | OFF	3.6-52
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MAX:AVER:RESult?		3.6-47
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MAX:PHOLd:RESult?		3.6-47
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MAX:RESult?		3.6-47
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MAX[:STATe]	ON | OFF	3.6-46
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MEAN:AVER:RESult?		3.6-52
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MEAN:PHOLd:RESult?		3.6-52
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MEAN:RESult?		3.6-52
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MEAN[:STATe]	ON | OFF	3.6-51
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MIDDle:AVER:RESult?		3.6-50
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MIDDle:PHOL:RESult?		3.6-50
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MIDDle:RESult?		3.6-50
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MIDDle[:STATe]	ON | OFF	3.6-49
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MPEak:AVER:RESult?		3.6-49
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MPEak:PHOL:RESult?		3.6-49
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MPEak:RESult?		3.6-49
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MPEak[:STATe]	ON | OFF	3.6-48
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:PHOLd	ON | OFF	3.6-52
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:PPEak:AVER:RESult?		3.6-48
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:PPEak:PHOLd:RESult?		3.6-48
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:PPEak:RESult?		3.6-48
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:PPEak[:STATe]	ON | OFF	3.6-47
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:RMS:AVER:RESult?		3.6-51
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:RMS:PHOLd:RESult?		3.6-51
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:RMS:RESult?		3.6-51
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:RMS[:STATe]		3.6-5
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:STATe	ON | OFF	3.6-46
CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:ZOOM	<numeric_value>	3.6-40
CALCulate<1|2>:MARKer<1 to 4>:LOEXclude	ON | OFF	3.6-36
CALCulate<1|2>:MARKer<1 to 4>:MAXimum:APEak		3.6-36
CALCulate<1|2>:MARKer<1 to 4>:MAXimum:LEFT		3.6-37
CALCulate<1|2>:MARKer<1 to 4>:MAXimum:NEXT		3.6-37
CALCulate<1|2>:MARKer<1 to 4>:MAXimum[:PEAK]		3.6-36
CALCulate<1|2>:MARKer<1 to 4>:MAXimum:RIGHt		3.6-37
CALCulate<1|2>:MARKer<1 to 4>:MINimum:LEFT		3.6-38
CALCulate<1|2>:MARKer<1 to 4>:MINimum:NEXT		3.6-37
CALCulate<1|2>:MARKer<1 to 4>:MINimum[:PEAK]		3.6-37
CALCulate<1|2>:MARKer<1 to 4>:MINimum:RIGHt		3.6-38
CALCulate<1|2>:MARKer<1 to 4>:PEXCursion	<numeric_value>	3.6-38
CALCulate<1|2>:MARKer<1 to 4>:READout	MPHase | RIMaginary	3.6-39
CALCulate<1|2>:MARKer<1 to 4>[:STATe]	ON | OFF	3.6-34
CALCulate<1|2>:MARKer<1 to 4>:STEP:AUTO	ON | OFF	3.6-38

Command	Parameter	Page
CALCulate<1|2>:MARKer<1 to 4>:STEP[:INCRement]	<numeric_value>	3.6-38
CALCulate<1|2>:MARKer<1 to 4>:TRACe	1 to 4	3.6-35
CALCulate<1|2>:MARKer<1 to 4>:X	0 to MAX (freq | sweep time | symb)	3.6-35
CALCulate<1|2>:MARKer<1 to 4>:X:SLIMits[:STATe]	ON | OFF	3.6-35
CALCulate<1|2>:MARKer<1 to 4>:Y?		3.6-36
CALCulate<1|2>:MATH[:EXPRession][:DEFine]	<expr>	3.6-55
CALCulate<1|2>:MATH:STATe	ON | OFF	3.6-55
CALCulate<1|2>:RLINe	MIN to MAX (dep. on current unit)	3.6-15
CALCulate<1|2>:RLINe:STATe	ON | OFF	3.6-15
CALCulate<1|2>:THReshold	MIN to MAX (dep. on current unit)	3.6-14
CALCulate<1|2>:THReshold:STATe	ON | OFF	3.6-15
CALCulate<1|2>:TLINe<1|2>	0 to 1000s	3.6-16
CALCulate<1|2>:TLINe<1|2>:STATe	ON | OFF	3.6-16
CALCulate<1|2>:UNIT:ANGLe	DEG | RAD	3.6-56
CALCulate<1|2>:UNIT:POWer	DBM | V | W | DB | PCT | UNITLESS | DBPW | WATT | DBUV | DBMV | VOLT | DBUA | AMPere | DBUV_MHZ | DBMV_MHZ | DBUA_MHZ | DBUV_M | DBUA_M | DBUV_MMHZ | DBUA_MMHZ	3.6-56
CALCulate<1|2>:X:UNIT:TIME	S | SYM	3.6-56
CALibration[:ALL]		3.6-57
CALibration:BANDwidth| BWIDth[:RESolution]?		3.6-57
CALibration:IQ?		3.6-57
CALibration:LDETector?		3.6-58
CALibration:LOSuppression?		3.6-58
CALibration:PPEak?		3.6-58
CALibration:SHORt?		3.6-58
CALibration:STATe	ON | OFF	3.6-58
CONFigure:BTS:ARFCn	<numeric_value>	3.6-59
CONFigure:BTS:ARFCn:AUTO	ONCE	3.6-60
CONFigure:BTS:CHANnel:SFH	ON | OFF	3.6-61
CONFigure:BTS:CHANnel:SLOT	0 to 7	3.6-61
CONFigure:BTS:CHANnel:SLOT:AUTO	ONCE	3.6-61
CONFigure:BTS:CHANnel:TSC	0 to 7	3.6-61
CONFigure:BTS:CHANnel:TSC:AUTO	ON | OFF	3.6-61
CONFigure:BTS:COSiting	ON | OFF	3.6-62
CONFigure:BTS:NETWork:PHASe	1 | 2	3.6-62
CONFigure:BTS:NETWork[:TYPE]	PGSM | EGSM | DCS | PCS	3.6-62
CONFigure:BTS:POWer:CLASs	1 to 8 | 1 to 4 | M1 | M2 | M3	3.6-60
CONFigure:BTS:POWer:DYNamic	0 to 15	3.6-60
CONFigure:BTS:POWer:EXPected	<numeric_value>	3.6-60
CONFigure:BTS:POWer:STATic	0 to 6	3.6-60
CONFigure:BTS:PRESet		3.6-62
CONFigure:BTS:TXSupp	ON | OFF	3.6-62
CONFigure:BURSt:PFERror:COUNt	1 to 1000	3.6-63
CONFigure:BURSt:PFERror[:IMMediate]		3.6-63

Command	Parameter	Page
CONFigure:BURSt:POWer:CONDition	NORMal | EXTReme	3.6-64
CONFigure:BURSt:POWer:COUNt	1 to 1000	3.6-64
CONFigure:BURSt:POWer[:IMMediate]		3.6-63
CONFigure:BURSt:PTEMplate:COUNt	1 to 1000	3.6-64
CONFigure:BURSt:PTEMplate:SELect	FULL | TOP | RISing | FALLing	3.6-64
CONFigure:BURSt:PTEMplate[:IMMediate]		3.6-64
CONFigure:MS:ARFCn	<numeric_value>	3.6-65
CONFigure:MS:ARFCn:AUTO	ONCE	3.6-65
CONFigure:MS:CHANnel:TSC	0 to 7	3.6-66
CONFigure:MS:NETWork:PHASe	1 | 2	3.6-67
CONFigure:MS:NETWork[:TYPE]	PGSM | EGSM | DCS | PCS	3.6-67
CONFigure:MS:POWer:CLASs	1 to 8 | 1 to 4 | M1 | M2 | M3	3.6-66
CONFigure:MS:POWer:EXPected	<numeric_value>	3.6-66
CONFigure:MS:POWer:LEVel	0 to 6	3.6-66
CONFigure:MS:PRESet		3.6-67
CONFigure:MS:TXSupp	ON | OFF	3.6-67
CONFigure:SPECtrum:MODulation:COUNt	1 to 1000	3.6-68
CONFigure:SPECtrum:MODulation[:IMMediate]		3.6-68
CONFigure:SPECtrum:MODulation:RANGe	ARFCn | TXBand | RXBand | COMBined | DCSRx1800	3.6-69
CONFigure:SPECtrum:SWITching:COUNt	1 to 1000	3.6-69
CONFigure:SPECtrum:SWITching[:IMMediate]		3.6-69
CONFigure:SPURious:COUNt	1 to 1000	3.6-70
CONFigure:SPURious:COUNt:RXBand	1 to 1000	3.6-70
CONFigure:SPURious[:IMMediate]		3.6-70
CONFigure:SPURious:RANGe	TXBand | OTXBand | RXBand	3.6-71
DIAGnostic:SERVice:FUNCtion	numeric_value>,<numeric_value>...	3.6-72
DIAGnostic:SERVice:INPut[:SELect]	CALibration | RF	3.6-72
DIAGnostic:SERVice:NSOurce	ON | OFF	3.6-72
DISPlay:ANNotation:FREQuency	ON | OFF	3.6-74
DISPlay:CMAP<1 to 13>:DEFault		3.6-74
DISPlay:CMAP<1 to 13>:HSL	0 to 1 (tint), 0 to 1 (saturation), 0 to 1 (brightness)	3.6-75
DISPlay:CMAP<1 to 13>:PDEFined	<color>	3.6-75
DISPlay:FORmat	SINGle | SPLit	3.6-74
DISPlay:LOGO	ON | OFF	3.6-74
DISPlay:PROGram[:MODE]	ON | OFF	3.6-74
DISPlay[:WINDow<1|2>]:MINFo	ON | OFF	3.6-75
DISPlay[:WINDow<1|2>]:TEXT[:DATA]	<string>	3.6-76
DISPlay[:WINDow<1|2>]:TEXT:STATe	ON | OFF	3.6-76
DISPlay[:WINDow<1|2>]:TIME	ON | OFF	3.6-76
DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:EYE:COUNt	1 to Result Length	3.6-81
DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:MODE	WRITe | VIEW | AVERage | MAXHold | MINHold	3.6-80
DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:MODE:ANALog	ON | OFF	3.6-80
DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:MODE:CWRite	ON | OFF	3.6-80
DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:MODE:HCONtinuous	ON | OFF	3.6-81

Command	Parameter	Page
DISPlay[:WINDow<1|2>]:TRACe<1 to 4>[:STATe]	ON | OFF	3.6-81
DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:SYMBol	DOTS | BARS | OFF	3.6-81
DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:X[:SCALe]:RVALue	<numeric_value>	3.6-76
DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:X[:SCALe]:ZOOM	ON | OFF	3.6-76
DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:X[:SCALe]:ZOOM[:FREQ]:CENTer	<numeric_value>	3.6-77
DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:X[:SCALe]:ZOOM[:FREQ]:STARt	<numeric_value>	3.6-77
DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:X[:SCALe]:ZOOM[:FREQ]:STOP	<numeric_value>	3.6-77
DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:X:SPACing	LINear | LOGarithmic	3.6-77
DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:Y[:SCALe]	10dB to 200dB	3.6-78
DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:Y[:SCALe]:MODE	ABSolute | RELative	3.6-78
DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:Y[:SCALe]:PDIVision	<numeric_value>	3.6-80
DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:Y[:SCALe]:RLEVel	-200dBm to 200dBm	3.6-78
DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:Y[:SCALe]:RLEVel:OFFSet	-200dB to 200dB	3.6-78
DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:Y[:SCALe]:RPOSition	0 to 100 PCT	3.6-79
DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:Y[:SCALe]:RVALue	<numeric_value>	3.6-79
DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:Y[:SCALe]:RVALue:AUTO	ON | OFF	3.6-79
DISPlay[:WINDow<1|2>]:TRACe<1 to 4>:Y:SPACing	LINear | LOGarithmic | PERCent	3.6-80
FETCh:BURSt:FERRor:AVERage?		3.6-83
FETCh:BURSt:FERRor:MAXimum?		3.6-84
FETCh:BURSt:PERRor:PEAK:AVERage?		3.6-83
FETCh:BURSt:PERRor:PEAK:MAXimum?		3.6-83
FETCh:BURSt:PERRor:RMS:AVERage?		3.6-82
FETCh:BURSt:PERRor:RMS:MAXimum?		3.6-83
FETCh:BURSt:POWer:ALL?		3.6-85
FETCh:BURSt:POWer[:IMMediate]?		3.6-84
FETCh:MODulation[:ALL]?	ARFCn | TXBand | RXBand | COMBined | DCSRx1800	3.6-86
FETCh:SPECtrum:SWITching[:ALL]?		3.6-87
FETCh:SPURious[:ALL]?	TXBand | OTXBand | RXBand | IDLeband	3.6-88
FETCh:SPURious:STEP?		3.6-89
FORMat[:DATA]	ASCii | REAL | UINT [,32]	3.6-90
HCOPy:ABORt		3.6-91
HCOPy:DESTination<1|2>	"SYST:COMM:GPIB' | 'SYST:COMM:SER1' | 'SYST:COMM:SER2' | 'SYST:COMM:CENT' | 'MMEM'	3.6-92
HCOPy:DEVice:COLor	ON | OFF	3.6-92
HCOPy:DEVice:ITEM:ALL		3.6-93
HCOPy:DEVice:ITEM:FFEed<1|2>:STATe	ON | OFF	3.6-94
HCOPy:DEVice:ITEM:LABel:TEXT	<string>	3.6-94
HCOPy:DEVice:ITEM:PFEed<1|2>:STATe	ON | OFF	3.6-94
HCOPy:DEVice:ITEM:WINDow<1|2>:TABle:STATe	ON | OFF	3.6-94
HCOPy:DEVice:ITEM:WINDow<1|2>:TEXT	<string>	3.6-94
HCOPy:DEVice:ITEM:WINDow<1|2>:TRACe:CAINcrement	ON | OFF	3.6-95
HCOPy:DEVice:ITEM:WINDow<1|2>:TRACe:STATe	ON | OFF	3.6-95
HCOPy:DEVice:LANGuage<1|2>	HPGL | PCL4 | PCL5 | POSTscript | ESCP | WMF | PCX | HP7470...	3.6-92

Command	Parameter	Page
HCOPy:DEVice:PRESet<1|2>	ON | OFF	3.6-93
HCOPy:DEVice:RESolution<1|2>	150 | 300	3.6-93
HCOPy[:IMMediate]		3.6-93
HCOPy:PAGE:DIMensions:FULL		3.6-95
HCOPy:PAGE:DIMensions:QUADrant<1 to 4>		3.6-95
HCOPy:PAGE:ORIentation<1|2>	LANDscape | PORTrait	3.6-95
INITiate<1|2>:CONMeas		3.6-96
INITiate<1|2>:CONTinuous	ON | OFF	3.6-96
INITiate<1|2>:DISPlay	ON | OFF	3.6-96
INITiate<1|2>[:IMMediate]		3.6-96
INPut<1|2>:ATTenuation	0 to 70dB	3.6-97
INPut<1|2>:ATTenuation:AUTO	ON | OFF	3.6-97
INPut<1|2>:ATTenuation:AUTO:MODE	NORMal | LNOise | LDIStorsion	3.6-97
INPut<1|2>:IMPedance	50 | 75	3.6-98
INPut<1|2>:IMPedance:CORRection	RAM | RAZ	3.6-98
INPut<1|2>:MIXer	-10 to -100 dBm	3.6-98
INPut<1|2>:UPORt<1|2>:STATe	ON | OFF	3.6-98
INPut<1|2>:UPORt<1|2>[:VALue]		3.6-98
INSTrument<1|2>:NSELect	1to 5	3.6-99
INSTrument<1|2>[:SELect]	SANalyzer | DDEMod | ADEMod | BGSM | MGSM	3.6-99
MMEMory:CATalog?	<string>	3.6-102
MMEMory:CDIRectory	directory name	3.6-102
MMEMory:CLear:ALL		3.6-106
MMEMory:CLear:STATe	1,path	3.6-106
MMEMory:COMMent	<string>	3.6-110
MMEMory:COPY	path, file name	3.6-103
MMEMory:DATA	<file name>,<block data>	3.6-103
MMEMory:DELete	path, file name	3.6-103
MMEMory:INITialize	'A:'	3.6-103
MMEMory:LOAD:AUTO	1,Path	3.6-104
MMEMory:LOAD:STATe	path, file name	3.6-104
MMEMory:MDIRectory	path	3.6-104
MMEMory:MOVE	path, file name	3.6-105
MMEMory:MSIS	'A:' | 'C:'	3.6-105
MMEMory:NAME	path, file name	3.6-105
MMEMory:RDIRectory	directory name	3.6-105
MMEMory:SELect[:ITEM]:ALL		3.6-109
MMEMory:SELect[:ITEM]:CSETup	ON|OFF	3.6-108
MMEMory:SELect[:ITEM]:CVL:ALL	ON | OFF	3.6-109
MMEMory:SELect[:ITEM]:CVL[:ACTive]	ON | OFF	3.6-109
MMEMory:SELect[:ITEM]:DEFault		3.6-110
MMEMory:SELect[:ITEM]:GSETup	ON | OFF	3.6-106
MMEMory:SELect[:ITEM]:HCOPy	ON | OFF	3.6-108
MMEMory:SELect[:ITEM]:HWSettings	ON | OFF	3.6-107
MMEMory:SELect[:ITEM]:LINes:ALL	ON | OFF	3.6-107

Command	Parameter	Page
MMEMory:SELect[:ITEM]:LINes[:ACTive]	ON | OFF	3.6-107
MMEMory:SELect[:ITEM]:MACRos	ON | OFF	3.6-108
MMEMory:SELect[:ITEM]:NONE		3.6-110
MMEMory:SELect[:ITEM]:TRACe<1 to 4>	ON | OFF	3.6-107
MMEMory:SELect[:ITEM]:TRANsducer:ALL	ON | OFF	3.6-109
MMEMory:SELect[:ITEM]:TRANsducer[:ACTive]	ON | OFF	3.6-108
MMEMory:STORe:STATe	path, file name	3.6-106
OUTPut:AF:SENSitivity	<numeric_value>	3.6-112
OUTPut:UPORt<1|2>:STATe	ON | OFF	3.6-111
OUTPut:UPORt<1|2>[:VALue]	#B00000000 to #B11111111	3.6-111
OUTPut[:STATe]	ON | OFF	3.6-111
READ:BURSt:FERRor:AVERage?		3.6-115
READ:BURSt:FERRor:MAXimum?		3.6-115
READ:BURSt:PERRor:PEAK:AVERage?		3.6-114
READ:BURSt:PERRor:PEAK:MAXimum?		3.6-114
READ:BURSt:PERRor:RMS:AVERage?		3.6-113
READ:BURSt:PERRor:RMS:MAXimum?		3.6-114
READ:BURSt:POWer:DYNamic?		3.6-118
READ:BURSt:POWer:POWer:LEVel?		3.6-119
READ:BURSt:POWer:STATic?		3.6-117
READ:BURSt:POWer?		3.6-116
READ:SPECtrum:MODulation[:ALL]?		3.6-120
READ:SPECtrum:SWITching[:ALL]?		3.6-121
READ:SPURious[:ALL]?		3.6-122
READ:SPURious:STEP?		3.6-123
[SENSe:]ADEMod:AF:COUPling	AC | DC	3.6-124
[SENSe:]ADEMod:RTIMe	ON | OFF	3.6-125
[SENSe:]ADEMod:SBAND	NORMal | INVerse	3.6-125
[SENSe:]ADEMod:SQUelch:LEVel	30 to -150 dBm	3.6-125
[SENSe:]ADEMod:SQUelch[:STATe]	ON | OFF	3.6-124
[SENSe:]AVERage:AUTO	ON | OFF	3.6-126
[SENSe:]AVERage:COUNt	0 to 256	3.6-126
[SENSe:]AVERage:TYPE	MAXimum | SCALar	3.6-126
[SENSe:]AVERage[:STATe]	ON | OFF	3.6-126
[SENSe:]BANDwidth|BWIDth:DEMod	5 kHz to 200 kHz (Real Time on) 5 kHz to 5 MHz (Real Time off)	3.6-129
[SENSe:]BANDwidth|BWIDth:PLL	AUTO | HIGH | MEDium | LOW	3.6-129
[SENSe:]BANDwidth|BWIDth[:RESolution]	10Hz to 10MHz (model 20) 1Hz...10MHz (model 30)	3.6-127
[SENSe:]BANDwidth|BWIDth[:RESolution]:AUTO	ON | OFF	3.6-128
[SENSe:]BANDwidth|BWIDth[:RESolution]:MODE	ANALog | DIGital	3.6-128
[SENSe:]BANDwidth|BWIDth[:RESolution]:MODE:FFT	ON | OFF	3.6-128
[SENSe:]BANDwidth|BWIDth[:RESolution]:RATio	0.0001 to 1	3.6-128
[SENSe:]BANDwidth|BWIDth:VIDeo	1Hz to 10MHz	3.6-129
[SENSe:]BANDwidth|BWIDth:VIDeo:AUTO	ON | OFF	3.6-129
[SENSe:]BANDwidth|BWIDth:VIDeo:RATio	0.001 to 1000 |SINe |PULSe |NOISe	3.6-129

Command	Parameter	Page
[SENSe:]CORRection:COLLect[:ACQuire]	THRough | OPEN	3.6-131
[SENSe:]CORRection:CVL:BAND	A|Q|U|V|E|W|F|D|G|Y|J	3.6-136
[SENSe:]CORRection:CVL:BIAS	<numeric_value>	3.6-136
[SENSe:]CORRection:CVL:CLEar		3.6-137
[SENSe:]CORRection:CVL:COMMent	<string>	3.6-136
[SENSe:]CORRection:CVL:DATA	<freq>,<level>..	3.6-137
[SENSe:]CORRection:CVL:MIXer	<string>	3.6-135
[SENSe:]CORRection:CVL:PORTs	2 | 3	3.6-136
[SENSe:]CORRection:CVL:SELect	<file_name>	3.6-135
[SENSe:]CORRection:CVL:SNUMber	<string>	3.6-135
[SENSe:]CORRection:CVL:TYPE	ODD | EVEN | EODD	3.6-136
[SENSe:]CORRection:LOSS:INPut[:MAGNitude]	<numeric_value>	3.6-134
[SENSe:]CORRection:METHod	TRANsmission | REFLexion	3.6-131
[SENSe:]CORRection:RECall		3.6-131
[SENSe:]CORRection:RXGain:INPut[:MAGNitude]	<numeric_value>	3.6-135
[SENSe:]CORRection[:STATe]	ON | OFF	3.6-130
[SENSe:]CORRection:TRANsducer:DATA	<freq>,<level>..	3.6-132
[SENSe:]CORRection:TRANsducer:DELete		3.6-133
[SENSe:]CORRection:TRANsducer:SCALing	LINear|LOGarithmic	3.6-132
[SENSe:]CORRection:TRANsducer:SELect	<name>	3.6-131
[SENSe:]CORRection:TRANsducer[:STATe]	ON | OFF	3.6-132
[SENSe:]CORRection:TRANsducer:UNIT	<string>	3.6-132
[SENSe:]CORRection:TSET:BREak	ON | OFF	3.6-133
[SENSe:]CORRection:TSET:DELete		3.6-134
[SENSe:]CORRection:TSET:RANGe	<1 to 10> <freq>,<freq>,<name>..	3.6-134
[SENSe:]CORRection:TSET:SELect	<name>	3.6-133
[SENSe:]CORRection:TSET[:STATe]	ON | OFF	3.6-134
[SENSe:]CORRection:TSET:UNIT	<string>	3.6-133
[SENSe:]DDEMod:FILTer:ALPHa	0.2 to 1	3.6-142
[SENSe:]DDEMod:FILTer:MEASurement	OFF | RCOSine | RRCosine | GAUS	3.6-142
[SENSe:]DDEMod:FILTer:REFerence	RCOSine | RRCosine | GAUSsian	3.6-142
[SENSe:]DDEMod:FORMat	QPSK | PSK | MSK | QAM | FSK	3.6-140
[SENSe:]DDEMod:FSK:NSTate	2 | 4	3.6-141
[SENSe:]DDEMod:MSK:FORMat	TYPE1 | TYPE2 | NORMal | DIFF	3.6-141
[SENSe:]DDEMod:NORMalize	ON | OFF	3.6-142
[SENSe:]DDEMod:PRATe	1 | 2 | 4 | 8 | 16	3.6-142
[SENSe:]DDEMod:PRESet	GSM | NADC | TETRa | DCS1800 | PCS1900 | PHS | PDCup | PDCDown | APCO25CQPSK | APCO25C4FM | CDPD | DECT | CT2 | ERMes | MODacom | PWT | TFTS | F16 | F322 | F324 | F64 | FQCDma | RQCDma	3.6-144
[SENSe:]DDEMod:PSK:FORMat	2 | 8	3.6-140
[SENSe:]DDEMod:PSK:NSTate	2 | 8	3.6-140
[SENSe:]DDEMod:QAM:NSTate	16	3.6-141
[SENSe:]DDEMod:QPSK:FORMat	NORMal | DIFFerential | OFFSet | DPI4	3.6-140

Command	Parameter	Page
[SENSe:]DDEMod:SBANd	NORMal | INVerse	3.6-140
[SENSe:]DDEMod:SEARch:PULSe:STATe	ON | OFF	3.6-143
[SENSe:]DDEMod:SEARch:SYNC:OFFSet	<numeric_value>	3.6-143
[SENSe:]DDEMod:SEARch:SYNC:PATTern	<string>	3.6-143
[SENSe:]DDEMod:SEARch:SYNC:STATe	ON | OFF	3.6-143
[SENSe:]DDEMod:SEARch:TIME	<numeric value>	3.6-143
[SENSe:]DDEMod:SRATe	160 Hz to 1.6 MHz	3.6-141
[SENSe:]DDEMod:TIME	1 to Frame Length	3.6-141
[SENSe:]DETector<1 to 4>[:FUNCtion]	APEak |NEGative | POSitive | SAMPle | RMS | AVERage	3.6-138
[SENSe:]DETector<1 to 4>[:FUNCtion]:AUTO	ON | OFF	3.6-138
[SENSe:]FILTer:CCITt[:STATe]	ON | OFF	3.6-146
[SENSe:]FILTer:CMESsage[:STATe]	ON | OFF	3.6-146
[SENSe:]FILTer:DEMPhasis:LINK	DISPlay | AUDio	3.6-147
[SENSe:]FILTer:DEMPhasis[:STATe]	ON | OFF	3.6-146
[SENSe:]FILTer:DEMPhasis:TCONstant	<numeric_value>	3.6-146
[SENSe:]FILTer:HPASs:FREQuency	30 Hz | 300 HZ	3.6-145
[SENSe:]FILTer:HPASS[:STATe]	ON | OFF	3.6-145
[SENSe:]FILTer:LPASs:FREQuency	3 kHz | 15 kHz (real time on) 5 PCT | 10 PCT | 25 PCT (real time off)	3.6-146
[SENSe:]FILTer:LPASs[:STATe]	ON | OFF	3.6-145
[SENSe:]FREQuency:CENTer	0 GHz to f_{max}	3.6-148
[SENSe:]FREQuency:CENTer:LINK	STARt | STOP | SPAN	3.6-148
[SENSe:]FREQuency:CENTer:STEP	0 to f_{max}	3.6-148
[SENSe:]FREQuency:CENTer:STEP:LINK	SPAN | RBW | OFF	3.6-149
[SENSe:]FREQuency:CENTer:STEP:LINK:FACTor	1 to 100 PCT	3.6-149
[SENSe:]FREQuency:MODE	CW|FIXed | SWEep	3.6-150
[SENSe:]FREQuency:OFFSet	<numeric_value>	3.6-151
[SENSe:]FREQuency:SPAN	0 GHz to f_{max}	3.6-149
[SENSe:]FREQuency:SPAN:FULL		3.6-149
[SENSe:]FREQuency:SPAN:LINK	CENTer | STOP | SPAN	3.6-149
[SENSe:]FREQuency:STARt	0 GHz to f_{max}	3.6-150
[SENSe:]FREQuency:STARt:LINK	CENTer | STOP | SPAN	3.6-150
[SENSe:]FREQuency:STOP	0 GHz to f_{max}	3.6-150
[SENSe:]FREQuency:STOP:LINK	CENTer | STARt | SPAN	3.6-150
[SENSe:]MIXer:BIAS	<numeric_value>	3.6-154
[SENSe:]MIXer:BIAS:LIMit[:MAX]	<numeric_value>	3.6-155
[SENSe:]MIXer:BIAS:LIMit:MIN	<numeric_value>	3.6-155
[SENSe:]MIXer:BLOCk	ON | OFF	3.6-152
[SENSe:]MIXer:HARMonic	<numeric_value>	3.6-153
[SENSe:]MIXer:HARMonic:BAND	A | Q | U | V | E | W | F | D | G | Y | J	3.6-154
[SENSe:]MIXer:HARMonic:TYPE	ODD | EVEN | EODD	3.6-153
[SENSe:]MIXer:LOSS:HIGH	<numeric_value>	3.6-154
[SENSe:]MIXer:LOSS[:LOW]	<numeric_value>	3.6-154
[SENSe:]MIXer:LOSS:TABLE	<file_name>	3.6-154
[SENSe:]MIXer:PORTs	2 | 3	3.6-153

Command	Parameter	Page
[SENSe:]MIXer:SIGNal	ON | OFF | AUTO	3.6-153
[SENSe:]MIXer[:STATe]	ON | OFF	3.6-152
[SENSe:]MIXer:THReshold	0.1 to 100 dB	3.6-153
[SENSe:]MSUMmary:AHOLd[:STATe]	ON | OFF	3.6-156
[SENSe:]MSUMmary:MODE	ABSolute | RELative	3.6-156
[SENSe:]MSUMmary:MTIMe	0.1 s | 1 s	3.6-157
[SENSe:]MSUMmary:REFerence	<numeric_value>	3.6-156
[SENSe:]POWer:ACHannel:ACPairs	1 to 3	3.6-159
[SENSe:]POWer:ACHannel:BANDwidth|BWIDth:ACHannel	0 to 1000 MHz	3.6-159
[SENSe:]POWer:ACHannel:BANDwidth|BWIDth:ALTernate<1|2>	0 to 1000 MHz	3.6-160
[SENSe:]POWer:ACHannel:BANDwidth|BWIDth[:CHANnel]	0 to 1000 MHz	3.6-159
[SENSe:]POWer:ACHannel:MODE	ABSolute | RELative	3.6-160
[SENSe:]POWer:ACHannel:PRESet	ACPower | CPOWer | OBANdwidth | OBWidth | CN | CN0	3.6-160
[SENSe:]POWer:ACHannel:REFerence:AUTO	ONCE	3.6-160
[SENSe:]POWer:ACHannel:SPACing:ACHannel	0 to 1000 MHz	3.6-158
[SENSe:]POWer:ACHannel:SPACing:ALTernate<1|2>	0 to 1000 MHz	3.6-159
[SENSe:]POWer:ACHannel:SPACing[:UPPer]	0 to 1000 MHz	3.6-158
[SENSe:]POWer:BANDwidth|BWIDth	0 to 100PCT	3.6-160
[SENSe:]ROSCillator:EXTernal:FREQuency	1MHz to 16MHz	3.6-161
[SENSe:]ROSCillator:SOURce	INTernal | EXTernal	3.6-161
[SENSe:]ROSCillator[:INTernal]:TUNe	0 to 4095l8	3.6-161
[SENSe:]ROSCillator[:INTernal]:TUNe:SAVe		3.6-161
[SENSe:]SWEep:COUNt	0 to 32767	3.6-162
[SENSe:]SWEep:EGATe	ON | OFF	3.6-163
[SENSe:]SWEep:EGATe:HOLDoff	0 to 100s	3.6-163
[SENSe:]SWEep:EGATe:LENGth	0 to 100s	3.6-164
[SENSe:]SWEep:EGATe:LEVel	-5V to +5V	3.6-163
[SENSe:]SWEep:EGATe:POLarity	POSitive | NEGative	3.6-163
[SENSe:]SWEep:EGATe:SOURce	EXTernal | RFPower	3.6-164
[SENSe:]SWEep:EGATe:TYPE	LEVel | EDGE	3.6-163
[SENSe:]SWEep:GAP	ON | OFF	3.6-164
[SENSe:]SWEep:GAP:LENGth	0 to 100s	3.6-165
[SENSe:]SWEep:GAP:PRETrigger	0 to 100s	3.6-164
[SENSe:]SWEep:GAP:TRGTogap	0 to 100s	3.6-164
[SENSe:]SWEep:SPACing	LINear | LOGarithmic	3.6-165
[SENSe:]SWEep:TIME	<numeric_value>	3.6-162
[SENSe:]SWEep:TIME:AUTO	ON | OFF	3.6-162
[SENSe:]TCAPture:LENGth	1024 | 2048 | 4096 | 8192 | 16384	3.6-144
[SENSe:]TV:PSOFfset	0 to 6.5 MHz	3.6-166
[SENSe:]TV[:STATe]	ON | OFF	3.6-166
SOURce:AM:STATe	ON | OFF	3.6-167
SOURce:DM:STATe	ON | OFF	3.6-167
SOURce:FREQuency:OFFSet	-200 MHz to 200 MHz	3.6-168
SOURce:POWer:ALC:SOURce	INTernal | EXTernal	3.6-168

Command	Parameter	Page
SOURce:POWer[:LEVel][:IMMediate][:AMPLitude]	20dBm to 0dBm / Option FSE-B12: -90dBm to 0dBm	3.6-168
SOURce:POWer[:LEVel][:IMMediate]:OFFSet	-200 dB to +200 dB	3.6-169
STATus:OPERation:CONDition?		3.6-171
STATus:OPERation:ENABle	0 to 65535	3.6-171
STATus:OPERation[:EVENt]?		3.6-171
STATus:OPERation:NTRansition	0 to 65535	3.6-172
STATus:OPERation:PTRansition	0 to 65535	3.6-172
STATus:PRESet		3.6-172
STATus:QUEStionable:CONDition?		3.6-172
STATus:QUEStionable:ENABle	0 to 65535	3.6-173
STATus:QUEStionable[:EVENt]?		3.6-172
STATus:QUEStionable:NTRansition	0 to 65535	3.6-173
STATus:QUEStionable:PTRansition	0 to 65535	3.6-173
STATus:QUEStionable:ACPLimit:CONDition?		3.6-177
STATus:QUEStionable:ACPLimit:ENABle	0 to 65535	3.6-178
STATus:QUEStionable:ACPLimit[:EVENt]?		3.6-177
STATus:QUEStionable:ACPLimit:NTRansition	0 to 65535	3.6-178
STATus:QUEStionable:ACPLimit:PTRansition	0 to 65535	3.6-178
STATus:QUEStionable:FREQuency:CONDition?		3.6-178
STATus:QUEStionable:FREQuency:ENABle	0 to 65535	3.6-179
STATus:QUEStionable:FREQuency[:EVENt]?		3.6-178
STATus:QUEStionable:FREQuency:NTRansition	0 to 65535	3.6-179
STATus:QUEStionable:FREQuency:PTRansition	0 to 65535	3.6-179
STATus:QUEStionable:LIMit:CONDition?		3.6-174
STATus:QUEStionable:LIMit:ENABle	0 to 65535	3.6-175
STATus:QUEStionable:LIMit[:EVENt]?		3.6-174
STATus:QUEStionable:LIMit:NTRansition	0 to 65535	3.6-175
STATus:QUEStionable:LIMit:PTRansition	0 to 65535	3.6-175
STATus:QUEStionable:LMARgin:CONDition?		3.6-175
STATus:QUEStionable:LMARgin:ENABle	0 to 65535	3.6-176
STATus:QUEStionable:LMARgin[:EVENt]?		3.6-175
STATus:QUEStionable:LMARgin:NTRansition	0 to 65535	3.6-176
STATus:QUEStionable:LMARgin:PTRansition	0 to 65535	3.6-176
STATus:QUEStionable:POWer:CONDition?		3.6-173
STATus:QUEStionable:POWer:ENABle	0 to 65535	3.6-174
STATus:QUEStionable:POWer:NTRansition	0 to 65535	3.6-174
STATus:QUEStionable:POWer:PTRansition	0 to 65535	3.6-174
STATus:QUEStionable:POWer[:EVENt]?		3.6-173
STATus:QUEStionable:SYNC:CONDition?		3.6-176
STATus:QUEStionable:SYNC:ENABle	0 to 65535	3.6-177
STATus:QUEStionable:SYNC[:EVENt]?		3.6-176
STATus:QUEStionable:SYNC:NTRansition	0 to 65535	3.6-177
STATus:QUEStionable:SYNC:PTRansition	0 to 65535	3.6-177
STATus:QUEStionable:TRANsducer:CONDition?		3.6-179
STATus:QUEStionable:TRANsducer:ENABle	0 to 65535	3.6-180

Command	Parameter	Page
STATus:QUEStionable:TRANsducer[:EVENt]?		3.6-179
STATus:QUEStionable:TRANsducer:NTRansition	0 to 65535	3.6-180
STATus:QUEStionable:TRANsducer:PTRansition	0 to 65535	3.6-180
STATus:QUEue[:NEXT]?		3.6-180
SYSTem:COMMunicate:GPIB:RDEVice<1|2>:ADDRess	0 to 30	3.6-182
SYSTem:COMMunicate:GPIB[:SELF]:ADDRess	0 to 30	3.6-181
SYSTem:COMMunicate:GPIB[:SELF]:RTERminator	LFEOI | EOI	3.6-182
SYSTem:COMMunicate:SERial<1|2>:CONTrol:DTR	IBFull | OFF	3.6-182
SYSTem:COMMunicate:SERial<1|2>:CONTrol:RTS	IBFull | OFF	3.6-182
SYSTem:COMMunicate:SERial<1|2>[:RECeive]:BAUD	<numeric_value>	3.6-182
SYSTem:COMMunicate:SERial<1|2>[:RECeive]:BITS	7 | 8	3.6-183
SYSTem:COMMunicate:SERial<1|2>[:RECeive]:PACE X	ON | NONE	3.6-183
SYSTem:COMMunicate:SERial<1|2>[:RECeive]:PARity[:TYPE]	EVEN | ODD | NONE	3.6-183
SYSTem:COMMunicate:SERial<1|2>[:RECeive]:SBITs	1 | 2	3.6-183
SYSTem:DATE	1980 to 2099, 1 to 12, 1 to 31	3.6-183
SYSTem:ERRor?		3.6-184
SYSTem:PASSword[:CENable]	'password'	3.6-184
SYSTem:PRESet		3.6-185
SYSTem:SET	<block>	3.6-184
SYSTem:SPEaker:VOLume	0 to 1	3.6-185
SYSTem:TIME	0 to 23, 0 to 59, 0 to 59	3.6-185
SYSTem:UPDate	ON | OFF	3.6-184
SYSTem:VERSion?		3.6-185
TRACe:COPY	TRACE1 | TRACE2 | TRACE3 | TRACE4 ,TRACE1 | TRACE2 | TRACE3 | TRACE4	3.6-187
TRACe[:DATA]	TRACE1 | TRACE2 | TRACE3 | TRACE4, <block> | <numeric_value>	3.6-186
TRIGger<1|2>[:SEQuence]:HOLDoff	-100 to 100 s	3.6-189
TRIGger<1|2>[:SEQuence]:LEVel:VIDeo	0 to 100 PCT	3.6-189
TRIGger<1|2>[:SEQuence]:LEVel[:EXTernal]	–5.0 V to +5.0 V	3.6-189
TRIGger<1|2>[:SEQuence]:SLOPe	POSitive | NEGative	3.6-189
TRIGger<1|2>[:SEQuence]:SOURce	IMMediate | LINE | EXTernal | VIDeo | RFPower | TV | AF	3.6-188
TRIGger[:SEQuence]:SYNChronize:ADJust:FRAMe:AUTO	ONCE	3.6-191
TRIGger[:SEQuence]:SYNChronize:ADJust:SLOT	0 to 100 s	3.6-191
TRIGger[:SEQuence]:SYNChronize:ADJust:SLOT:AUTO	ONCE	3.6-191
TRIGger[:SEQuence]:SYNChronize:SOURce	FRAMe | TSC	3.6-192
TRIGger<1|2>[:SEQuence]:VIDeo:FIELd:SELect	ALL | ODD | EVEN	3.6-190
TRIGger<1|2>[:SEQuence]:VIDeo:FORMat:LPFRame	525 | 625	3.6-189
TRIGger<1|2>[:SEQuence]:VIDeo:LINE:NUMBer	<numeric value>	3.6-190
TRIGger<1|2>[:SEQuence]:VIDeo:SSIGnal:POLarity	NEGative | POSitive	3.6-190
UNIT<1|2>:POWer	DBM | DBPW | WATT | DBUV | DBMV | VOLT | DBUA | AMP | DB | PCT | UNITLESS | DBUV_MHZ | DBMV_MHZ | DBUA_MHZ | DBUV_M | DBIA_M | DBUV_MMHZ | DBUA_MMHZ	3.6-193
UNIT<1|2>:PROBe	ON | OFF	3.6-193

Annex D – Programming Examples

The examples explain the programming of the instrument and can serve as a basis to solve more complex programming tasks.

QuickBASIC has been used as programming language. However, the programs can be translated into other languages.

D.1 Including IEC-Bus Library for QuickBasic

```
REM ----------- Include IEC-bus library for quickbasic ----------------
'$INCLUDE: 'c:\qbasic\qbdecl4.bas'
```

D.2 Initialization and Default Status

The IEC bus as well as the settings of the instrument are brought into a defined default status at the beginning of every program. Subroutines `"InitController"` and `"InitDevice"` are used to this effect.

D.2.1 Initiate Controller

```
REM ------------ Initiate controller -----------
REM InitController
iecaddress% = 20                          'IEC-bus address of the
                                          'instrument
CALL IBFIND("DEV1", analyzer%)            'Open port to the instrument
CALL IBPAD(analyzer%, iecaddress%)        'Inform controller on instrument
                                          'address
CALL IBTMO(analyzer%, 11)                 'Response time to 1 sec
REM ********************************************************************
```

D.2.2 Initiate Instrument

The IEC-bus status registers and instrument settings of the instrument are brought into the default status.

```
REM ------------ Initiate instrument --------------
REM InitDevice
CALL IBWRT(analyzer%, "*CLS")           'Reset status register
CALL IBWRT(analyzer%, "*RST")           'Reset instrument
REM*********************************************************************
```

D.3 Transmission of Instrument Setting Commands

Center frequency, span, and reference level of the instrument are set in this example.

```
REM -------- Instrument setting commands -------------
CALL IBWRT(analyzer%, "FREQUENCY:CENTER 120MHz")    'Center frequency 120 MHz
CALL IBWRT(analyzer%, "FREQUENCY:SPAN 10MHZ")       'Span 10 MHz
CALL IBWRT(analyzer%, "DISPLAY:TRACE:Y:RLEVEL -10dBm")
                                                    'Reference level -10dBm
REM ************************************************************************
```

D.4 Switchover to Manual Control

```
REM -------- Switch instrument over to manual control -----------
CALL IBLOC(analyzer%)                          'Set instrument to Local state
REM ************************************************************************
```

D.5 Reading out Instrument Settings

The settings made in example 3 are read out here. The abbreviated commands are used.

```
REM --------- Reading out instrument settings ---------
CFfrequency$ = SPACE$(20)             'Provide text variables (20 characters)
CALL IBWRT(analyzer%, "FREQ:CENT?")   'Request center frequency
CALL IBRD(analyzer%, CFfrequency$)    'Read value

CFspan$ = SPACE$(20)                  'Provide text variables (20 characters)
CALL IBWRT(analyzer%, "FREQ:SPAN?")   'Request span
CALL IBRD(analyzer%, CFspan$)         'Read value

RLevel$ = SPACE$(20)                  'Provide text variables (20 characters)
CALL IBWRT(analyzer%, "DISP:TRAC:Y:RLEV?")
                                      'Request reference level
CALL IBRD(analyzer%, RLevel$)         'Read value

REM -------- Display values on the screen -----------
PRINT "Center frequency: "; CFfrequency$,
PRINT "Span:             "; CFspan$,
PRINT "Reference level:  "; RLevel$,
REM************************************************************************
```

D.6 Positioning a Marker and Displaying Values

```
REM -------- Examples of marker functions -----------
CALL IBWRT(analyzer%, "CALC:MARKER ON;MARKER:MAX")
                                'Activate marker1 and start peak search
MKmark$ = SPACE$(30)            'Provide text variables (30 characters)
CALL IBWRT(analyzer%, "CALC:MARK:X?;Y?")    'Request frequency and level
CALL IBRD(analyzer%, MKmark$)               'Read value

REM -------- Display values on the screen -----------
PRINT "Center frequency / level "; MKmark$,
REM ************************************************************************
```

D.7 Command synchronization

The possibilities for synchronization implemented in the following example are described in Section 3.7.6, Command Order and Command Synchronization.

```
REM -------- Examples of command synchronization ---------
REM The command INITiate[:IMMediate] starts a single sweep if the command
REM INIT:CONT OFF was previously sent. It should be ensured that the next
REM command is only then executed when the entire sweep is complete.

CALL IBWRT(analyzer%, "INIT:CONT OFF")

REM -------- First possibility: Use of *WAI ---------
CALL IBWRT(analyzer%, "ABOR;INIT:IMM; *WAI")

REM -------- Second possibility: Use of *OPC? ---------
OpcOk$ = SPACE$(2)                  'Space for *OPC? - Provide response
CALL IBWRT(analyzer%, "ABOR;INIT:IMM; *OPC?")
REM -------- here the controller can service other instruments ---------
CALL IBRD(analyzer%, OpcOk$)        'Wait for "1" from *OPC?

REM -------- Third possibility: Use of *OPC ---------
REM In order to be able touse the service request function in conjugation
REM with a National Instruments GPIB driver, the setting "Disable
REM Auto Serial Poll" must be changed to "yes" by means of IBCONF!

CALL IBWRT(analyzer%, "*SRE 32")     'Permit service request for ESR
CALL IBWRT(analyzer%, "*ESE 1")      'Set event-enable bit for
                                     'operation-complete bit
ON PEN GOSUB OpcReady                'Initialization of the
                                     'service request routine
PEN ON
CALL IBWRT(analyzer%, "ABOR;INIT:IMM; *OPC")

REM Continue main program here
STOP                                 'End of program

OpcReady:
REM As soon as the sweep has ended, this subroutine is activated
REM Program suitable reaction to the OPC service request.
ON PEN GOSUB OpcReady                'Enable service request routine again
RETURN
REM ************************************************************************
```

D.8 Service Request

The service request routine requires an extended initialization of the instrument in which the respective bits of the transition and enable registers are set.
In order to use the service request function in conjugation with National Instruments GPIB driver, the setting "Disable Auto Serial Poll" must be changed to "yes" by means of IBCONF!

```
REM ---- Example of initialization of the SRQ in the case of errors  ------
CALL IBWRT(analyzer%, "*CLS")                    'Reset Status Reporting System
CALL IBWRT(analyzer%,"*SRE 168")                 'Permit service request for
                                                 'STAT:OPER,STAT:QUES and ESR
                                                 'register
CALL IBWRT(analyzer%,"*ESE 60")                  'Set event-enable bit for
                                                 'command, execution, device-
                                                 'dependent and query error
CALL IBWRT(analyzer%,"STAT:OPER:ENAB 32767")     'Set OPERation enable bit for
                                                 'all events
CALL IBWRT(analyzer%,"STAT:OPER:PTR 32767")      'Set appropriate OPERation
                                                 'Ptransition bits
CALL IBWRT(analyzer%,"STAT:QUES:ENAB 32767")     'Set questionable enable bits
                                                 'for all events
CALL IBWRT(analyzer%,"STAT:QUES:PTR 32767")      'Set appropriate questionable
                                                 'Ptransition bits
ON PEN GOSUB Srq                                 'Initialization of the service
                                                 'request routine

PEN ON
REM Continue main program here
STOP
```

A service request is then processed in the service request routine.
Note: the variables userN% and userM% must be pre-assigned usefully!

```
Srq:
REM ------------ Service request routine -----------
DO
   SRQFOUND% = 0
   FOR I% = userN% TO userM%                     'Poll all bus users
        ON ERROR GOTO nouser                     'No user existing
        CALL IBRSP(I%, STB%)                     'Serial poll, read status byte
        IF STB% > 0 THEN                         'This instrument has bits set
                                                 'in the STB
           SRQFOUND% = 1
           IF (STB% AND 16)  > 0 THEN GOSUB Outputqueue
           IF (STB% AND 4)   > 0 THEN GOSUB Failure
           IF (STB% AND 8)   > 0 THEN GOSUB Questionablestatus
           IF (STB% AND 128) > 0 THEN GOSUB Operationstatus
           IF (STB% AND 32)  > 0 THEN GOSUB Esrread
        END IF
nouser:
   NEXT I%
LOOP UNTIL SRQFOUND% = 0
ON ERROR GOTO error handling
ON PEN GOSUB Srq: RETURN                         'Enable SRQ routine again
                                                 'End of SRQ routine
```

Reading out the status event registers, the output buffer and the error/event queue is effected in subroutines.

```
REM -------- Subroutines for the individual STB bits ------
Outputqueue:                                    'Reading the output buffer
Message$ = SPACE$(100)                          'Make space for response
CALL IBRD(analyzer%, Message$)
PRINT "Message in output buffer :"; Message$
RETURN

Failure:                                        'Read error queue
ERROR$ = SPACE$(100)                            'Make space for error variable
CALL IBWRT(analyzer%, "SYSTEM:ERROR?")
CALL IBRD(analyzer%, ERROR$)
PRINT " Error text :"; ERROR$
RETURN


Questionablestatus:                         'Read questionable status register
Ques$ = SPACE$(20)                          'Preallocate blanks to text variable
CALL IBWRT(analyzer%, "STATus:QUEStionable:EVENt?")
CALL IBRD(analyzer%, Ques$)
PRINT "Questionable Status:"; Ques$
RETURN

Operationstatus:                            'Read operation status register
Oper$ = SPACE$(20)                          'Preallocate blanks to text variable
CALL IBWRT(analyzer%, "STATus:OPERation:EVENt?")
CALL IBRD(analyzer%, Oper$)
PRINT "Operation Status:"; Oper$
RETURN


Esrread:                                    'Read event status register
Esr$ = SPACE$(20)                           'Preallocate blanks to text variable
CALL IBWRT(analyzer%, "*ESR?")              'Read ESR
CALL IBRD(analyzer%, Esr$)
IF (VAL(Esr$) AND 1) > 0 THEN PRINT "Operation complete"
IF (VAL(Esr$) AND 4) > 0 THEN GOTO Failure
IF (VAL(Esr$) AND 8) > 0 THEN PRINT "Device dependent error"
IF (VAL(Esr$) AND 16) > 0 THEN GOTO Failure
IF (VAL(Esr$) AND 32) > 0 THEN GOTO Failure
IF (VAL(Esr$) AND 64) > 0 THEN PRINT "User request"
IF (VAL(Esr$) AND 128) > 0 THEN PRINT "Power on"
RETURN
REM ************************************************************************

REM ------------- Error routine ----------------
Error handling:
PRINT "ERROR                                'Output error message
STOP                                        'Stop software
```

D.9 Programming via the RSIB Interface

The RSIB interface supports links to max. 16 measuring instruments at the same time.

D.9.1 Visual Basic

Programming Hints:

- Access to RSIB.DLL functions

  To generate Visual Basic control applications, the file RSIB.BAS (D:/runtime/rsib) is added to a project to enable call-up of the RSIB.DLL functions.

- Declaration of DLL functions as procedures

  All DLL functions return an integer value. All functions in the file RSIB.BAS are therefore declared as follows:

  ```
  Declare Function RSDLLxxx Lib "rsib.dll" ( ... ) As Integer
  ```

  The function value with the status variable `ibsta` must be assigned a variable for every call. Since this value is also returned via a reference parameter of the functions, it is possible to declare the functions as procedures in the following way:

  ```
  Declare Sub RSDLLxxx Lib "rsib.dll" ( ... )
  ```

- Generation of reply buffer

  Since the DLL returns zero-terminated strings as replies, a string of sufficient length must be generated before functions `RSDLLibrd()` and `RSDLLilrd()` are called because Visual Basic assigns the strings a length value which is not updated by the DLL. The string length data can be generated with one of the following:

  ```
  -Dim Rd as String * 100
  ```

  ```
  -Dim Rd as String
   Rd = Space$(100)
  ```

- Reading trace data in real format

  When the function declarations of the file RSIB.BAS are used, replies from the instrument can be assigned to only one string. Trace data can be read faster and processing is simpler, however, if data are read in real format into float arrays. Data can be assigned to an array with float values as follows:

  Function declaration of `RSDLLibrd()` in RSIB.BAS:

  ```
  Declare Function RSDLLibrd Lib "rsib.dll" (ByVal ud%, ByVal Rd$,
  ibsta%, iberr%, ibcntl&) As Integer
  ```

  To read data directly into an array with real numbers, the string variable must be replaced by a suitable structure which can be defined as follows:

```
Type TRACEREAL
  len As String * 6          ' Header of real data "#42000"
  Points(500)  As Single     ' Float-Array
    End Type
```

Note: *the structure must be defined in a code module.*

To be able to transfer the structure as a reference parameter to the DLL, a special function declaration must be created.

eg
```
Declare Function RSDLLibrdTraceReal Lib "rsib.dll" Alias "RSDLLibrd"
(ByVal ud%, rd as Any, ibsta%, iberr%, ibcntl&) As Integer
```

Using this function, trace data can be read into a reply buffer of the type TRACEREAL.

Programming examples:

- In the following example, the start frequency of the local instrument is queried.

```
    Dim ibsta As Integer     ' Status variable
    Dim iberr As Integer     ' Error variable
    Dim ibcntl As Long       ' Count variable
    Dim ud As Integer        ' Unit descriptor (handle) for measuring
                           instrument
Dim Cmd As String          ' Command string

    ' Setting up link to measuring instrument
    ud = RSDLLibfind("@local", ibsta, iberr, ibcntl)
    If (ud < 0) Then
      ' error handling
    End If

    ' Sending query command to instrument
    Cmd = "SENS:FREQ:STAR?"
    If (RSDLLibwrt(ud, Cmd, ibsta, iberr, ibcntl) And IBSTA_ERR) Then
      ' error handling
    End If

    ' Making space for response
    Response = Space$(100)

    ' Querying response of instrument
    If (RSDLLibrd(ud, Response, ibsta, iberr, ibcntl) And IBSTA_ERR) Then
      ' error handling
    End If
```

- In the following example, save and recall of the instrument settings is made.

```
Dim ibsta As Integer     ' Status variable
Dim iberr As Integer     ' Error variable
Dim ibcntl As Long       ' Count variable
Dim ud As Integer        ' Handle for measuring instrument
Dim Cmd As String        ' Command string

' Setting up link to measuring instrument
   ud = RSDLLibfind("@local", ibsta, iberr, ibcntl)
   If (ud < 0) Then
   ' error handling
End If

' Querying instrument settings
  Cmd = "SYST:SET?"
  RSDLLibwrt(ud, Cmd, ibsta, iberr, ibcntl) And IBSTA_ERR
' Saving response of instrument in file
  RSDLLibrdf(ud, "C:\db.sav", ibsta, iberr, ibcntl)

' Resetting the instrument
  RSDLLibwrt(ud, "*RST", ibsta, iberr, ibcntl)

' and recalling the previous settings
' Disabling END message for this purpose
  RSDLLibeot(ud, 0, ibsta, iberr, ibcntl) And IBSTA_ERR
' Sending command first
  RSDLLibwrt(ud, "SYST:SET ", ibsta, iberr, ibcntl) And IBSTA_ERR
' Enabling the END message
  RSDLLibeot(ud, 1, ibsta, iberr, ibcntl) And IBSTA_ERR
' and sending the data
  RSDLLibwrtf(ud, "C:\db.sav", ibsta, iberr, ibcntl)
```

D.9.2 C / C++

Programming Hint:

Access to RSIB.DLL functions

The functions of `RSIB.DLL` are declared in the header file `RSIBC.H`. The DLL functions can be incorporated in a C/C++ program in three different ways:

1. By generating the import library `RSIB.LIB` by means of `IMPLIB.EXE` from `RSIB.DLL` and adding the library to the project.
2. By specifying the functions of `RSIB.DLL` in the module definition file (*.def) under `IMPORTS`.
3. By loading the library with the `LoadLibrary()` function while the program is running and determining the pointers of the DLL functions with `GetProcAddress()`. Prior to program end, `RSIB.DLL` must be freed with function `FreeLibrary()`.

For the first two ways of incorporating a DLL, the latter will be automatically loaded immediately before the start of the application. At the end of the program, the DLL will be freed provided it is not used by other applications.

Programming example:

In the following C program, a single sweep is started and a marker is set to the maximum level. Before the maximum level can be determined, the sweep must be terminated. Synchronization to the end of the sweep is made by triggering a service request at the end of the sweep with command `"*OPC"` (operation complete). The control program waits for the SRQ with the function `RSDLLWaitSrq()`. Then the maximum level is determined (`"CALC:MARK:MAX"`) and the level is read out (`"Y?"`).

```
#define MAX_RESP_LEN  100

short           ibsta, iberr;
unsigned long   ibcntl;
short           ud;
short           srq;
char                  Maxlevel[MAX_RESP_LEN];

// Determining the handle for the instrument
ud = RSDLLibfind( "@local", &ibsta, &iberr, &ibcntl );

// If instrument exists
if ( ud >= 0 ) {

  // Setting timeout for RSDLLWaitSrq() to 10 seconds
  RSDLLibtmo( ud, 10, &ibsta, &iberr, &ibcntl );

  // Activate SRQ generation through event status register (ESR)
  // and enable ESB bit of SRE register
  RSDLLibwrt( ud, "*ESE 1;*SRE 32", &ibsta, &iberr, &ibcntl );

  // Set single sweep, trigger sweep
  // and generate SRQ at the end of the sweep with "*OPC"
  RSDLLibwrt( ud, "INIT:CONT off;INIT;*OPC", &ibsta, &iberr, &ibcntl );

  // Wait for SRQ (end of sweep)
  RSDLLWaitSrq( ud, &srq, &ibsta, &iberr, &ibcntl );

  // If sweep is terminated
  if (srq) {

    // Set marker to first maximum and query level
    RSDLLibwrt( ud, "CALC:MARK:MAX;Y?", &ibsta, &iberr, &ibcntl );
    RSDLLilrd( ud, MaxPegel, MAX_RESP_LEN, &ibsta, &iberr, &ibcntl );
  }
}

else {
  ; // Error - instrument not found
}
```

D.9.3 WinWord (Word Basic)

Programming Hints:

- Access to RSIB.DLL functions

  The functions of DLL `RSIB.DLL` can be utilized from a WinWord macro (WinWord 2.0/6.0) with certain restrictions. The function declarations for WinWord are defined in the module `rsibwb.bas` and must be copied into the macro when a WinWord macro is created.

- Examples of macros in the file RSIB.DOT

  The following programming examples show examples of the macros `SetStartFreq` and `GetStartFreq`, by which setting commands are sent to the instrument or instrument settings can be queried. The two macros are contained in the document pattern `rsib.dot`.

- Restrictions for WinWord macros

  Parameters of the integer type can be defined only as value parameters in the declaration of the DLL functions with the statement Declare. However, the functions of DLL `RSIB.DLL` expect, for the variables `ibsta`, `iberr` and `ibcntl`, references via which the DLL can return values to the caller. To be able to specify variable references for these parameters, the functions are to be declared with the string parameter type.
  By declaring the variables `ibsta`, `iberr` and `ibcntl` as strings, attempts to access undefined memory ranges are avoided. This method, however, makes the querying of parameters more difficult. For example, the error code is returned in the event of an error in the variable `iberr`. In this process, the two bytes of the integer value are copied into the string. WinWord however does not use the length information to handle strings but expects a zero at the end of the string. Therefore, for an integer value whose low-byte is equal to zero, the high-byte will not be queried since the low-byte with the zero is regarded as the end of the string.



Problem of variable declaration in WinWord

Querying error variables with values other than zero is nevertheless possible since error codes with the first character being less than 100h can be queried (`iberr=ASC(iberr$)`).
Querying the status variable, on the other hand, is not possible in the manner described since the low-byte of the status variable is always zero. The status byte is however returned also by the DLL function value so that an error check can be made.
For the use of the DLL `RSIB.DLL` from WinWord, it would be expedient to generate a DLL whose interface functions are adapted to the capabilities of WinWord.

Programming examples:

- Sending a setting command

  The macro `SetStartFreq` is used as an example for setting the start frequency. The macro first reads the desired value from an input box. The value is then set with the DLL function `RSDLLibwrt()` via an SCPI command.

```
' Declaration from file "rsibwb.bas":
  Declare Function RSDLLibfind Lib "rsib.dll"(udName$, ibsta$, iberr$,
  ibcntl$) As Integer
  Declare Function RSDLLibwrt Lib "rsib.dll"(ud As Integer,  Wrt$, ibsta$,
  iberr$, ibcntl$) As Integer

Sub MAIN

  Dim ud, status
  Dim cmd$, value$
  Dim ibsta$, iberr$, ibcntl$

  ' Query the frequency to be set:
    value$ = InputBox$("Enter the start frequency:", "R&S-IECBUS-
    Interface")

  ' Generate SCPI command
    cmd$ = "SENS:FREQ:STAR" + value$

  // Determine the handle for the instrument
    ud = RSDLLibfind("@local", ibsta$, iberr$, ibcntl$)
    If(ud < 0) Then
      MsgBox "Error in function RSDLLibfind" + Chr$(10) + "Errorcode:
      " + Str$(Asc(iberr$)), 'error', 48
      Goto End
    End If

  ' Send command to instrument parser
    status = RSDLLibwrt(ud, cmd$, ibsta$, iberr$, ibcntl$)
    If(status <> 0) Then
      MsgBox "Error in function RSDLLibwrt" + Chr$(10) + "Errorcode:
      " + Str$(Asc(iberr$)), 'error', 48
      Goto End
    End If

End:

End Sub
```

- Querying instrument setups

  The macro `GetStartFreq` is used as an example for querying the start frequency of the local instrument and reading it into the current document. First, the SCPI query command is sent to the instrument with the function `RSDLLibwrt()`, then the value is fetched with the function `RSDLLibrd()`. A string of sufficient length is not required for reading the output buffer since WinWord, like language C, processes the string length by using the terminating zero rather and not a prefixed length information as in Visual Basic.

```
' Declaration from file "rsibwb.bas"
  Declare Function RSDLLibfind Lib "rsib.dll"(udName$, ibsta$, iberr$,
  ibcntl$) As Integer
  Declare Function RSDLLibwrt Lib "rsib.dll"(ud As Integer,  Wrt$, ibsta$,
  iberr$, ibcntl$) As Integer
  Declare Function RSDLLilrd Lib "rsib.dll"(ud As Integer,  Rd$, cnt As
  Long, ibsta$, iberr$, ibcntl$) As Integer

Sub MAIN

  Dim ud, status
  Dim buffer$, cmd$
  Dim ibsta$, iberr$, ibcntl$

// Determine the handle for the instrument
  ud = RSDLLibfind("@local", ibsta$, iberr$, ibcntl$)
  If(ud < 0) Then
    MsgBox "Error in function ibfind" + Chr$(10) + "Errorcode: " +
Str$(Asc(iberr$)), 'error', 48
    Goto End
  End If

  ' Generate SCPI command for querying the start frequency
    cmd$ = "SENS:FREQ:STAR?"

  ' Send command to instrument parser
    status = RSDLLibwrt(ud, cmd$, ibsta$, iberr$, ibcntl$)
    If(status <> 0) Then
      MsgBox "Error in function ibwrt" + Chr$(10) + "Errorcode: " +
Str$(Asc(iberr$)), 'error', 48
      Goto End
    End If

  ' Read reply from parser
    status = RSDLLilrd(ud, buffer$, 10, ibsta$, iberr$, ibcntl$)
    If(status <> 0) Then
      MsgBox "Error in function ibrd" + Chr$(10) + "Errorcode: " +
Str$(Asc(iberr$)), 'error', 48
     Goto End
    End If

  ' Insert reply into document
    Insert buffer$ + "Hz"

End:
End Sub
```

D.9.4 Excel

The use of DLL functions in the macro language of Excel 4.0 has not been examined.
Excel 5.0 uses VBA (Visual Basic for Applications) as macro language, which can create Excel macros same as Visual Basic programs.

[illegible]

[illegible]

[illegible]

E - Emulations

E.1 Mouse Control of Display Elements

The FSE can be optionally equipped with a mouse (see Chapter 1 "Connecting a Mouse").

All display and control elements (enhancement labels, soft keys, function fields, display and limit lines) which can be displayed on the display screen can also be controlled by the mouse. Each soft key or key is assigned to a display element.

The following table lists the controllable display elements and the assigned keys

Display element for mouse control.		**Assigned soft key or key**
Display field for Soft Key 1 to Soft Key 10		Soft Key 1 to Soft Key 10
Display field for menu arrow: right/center/left		Key right/center/left supplementary menu
Enhancement labels	*	--
	PA	SETUP key
	PS	SETUP key
	UNS	COUPLING key
	LVL	REF key
	FRQ	CENTER key
	1-x	TRACE 1 key
	2-x	TRACE 2 key
	3-x	TRACE 3 key
	4-x	TRACE 4 key
	TRG	TRIGGER key
	DC	INPUT key
	75Ω	INPUT key
	MAC	USER key
Status display	UNCAL	CAL key
	OVLD	REF key
	ERR	INFO key
Display fields above the diagram		
	Ref. Level / Max	REF key
	Level	NORMAL key
	Marker	COUPLING key
	RBW	COUPLING key
	VBW	COUPLING key
	SWT	INPUT key
	RF Att	INPUT key
	Mixer	REF key
	Unit	
Display fields below the diagram		
	Start	START key
	Stop	STOP key
	Center	CENTER key
	Span	SPAN key
	Trigger	TRIGGER key
	/Div	--

E.2 Front Panel Keyboard Emulation

The FSE can be equipped with an optionalexternal keyboard.(see Chapter 1 "Connecting an External Keyboard"). The following table shows the external keyboard key combinations through which the functions of the front panel keys can be emulated.

Note: – *The key combination <ALT><S-Abf> (German keyboard) or <ALT> <SYSREQ> (English keyboard)switches between the instrument display screen and the controller display screen (for an installed processor option FSE-B15).*
– *In instrument mode, the key combination <ALT> <F1> switches the keyboard between the US-American language and the language selected in the GENERAL SETUP* menu.

FSE front panel keys		Key assignments for the external keyboard
Soft keys:	SK1	F1
	SK2	F2
	SK3	F3
	SK4	F4
	SK5	F5
	SK6	F6
	SK7	F7
	SK8	F8
	SK9	F9
	SK10	F10
Menu select:	Menu left	CTRL ←
	Menu right	CTRL →
	Menu up	CTRL ↑
Cursor control:	Cursor left	←
	Cursor right	→
	Cursor up	↑
	Cursor down	↓
Roll-key:	Turn left	SHIFT ↑
	Turn right	SHIFT ↓
Numeric keys:	0	0
	1	1
	2	2
	3	3
	4	4
	5	5
	6	6
	7	7
	8	8
	9	9
Units keys:	GHz...	ALT-G
	MHz...	ALT-M
	kHz...	ALT-K
	Hz...	<ENTER>
Edit keys:	Clear	<ESC>
	Backspace	BACK
Misc. data entry keys:		
	Exponent "Exp"	ALT-E
	Sign "+/-"	-
	Decimal point"."	.
Hold key:	Hold	SHIFT-F1
User menu:	User	SHIFT-F2
System keys:	Preset	SHIFT-F4
	Cal	ALT-F12
	Display	ALT-F10
	Info	SHIFT-F5

FSE front panel keys		Key assignments for the external keyboard
Configuration key group:	Mode	ALT-F2
	Setup	SHIFT-F8
Hardcopy key group:	Start	SHIFT-F6
	Settings	SHIFT-F9
Status key group :	Local	SHIFT-F3
Frequency key group:	Start	CTRL-F7
	Stop	CTRL-F8
	Center	CTRL-F9
	Span	CTRL-F10
Level key group:	Ref	CTRL-F11
	Range	CTRL-F12
	Input	ALT-F11
	Cal	ALT-F12
Marker key group :	Normal	CTRL-F1
	Search	CTRL-F2
	Delta	CTRL-F3
	→ Mkr	CTRL-F4
Lines key group :	Display	CTRL-F5
	Limit	CTRL-F6
Traces key group :	1	ALT-1
	2	ALT-2
	3	ALT-3
	4	ALT-4
Sweep key group :	--	ALT-F3
	--	ALT-F4
	--	ALT-F5
	Coupl.	ALT-F6
	Sweep	ALT-F7
	Trigger	ALT-F8
Memory key group:	Save	SHIFT-F10
	Recall	SHIFT-F11
	Config	SHIFT-F12
Data entry key group :	Step	SHIFT-F7
Letters and special characters		A to Z (ext.) a to z (ext.) Special characters (ext.)
Edit key		Delete
Cursor control		Home End Page up Page down

E.2 Front Panel Keyboard Emulation

The EPC can be equipped with a [illegible] keyboard. The Operator Keyboard". The following table shows the [illegible] functions of the front panel keys [illegible] emulated.

Note [illegible]

Front panel keys		Key assignment for the "Enter" keyboard
Soft keys	SK1	F1
	SK2	F2
	SK3	F3
	SK4	F4
	SK5	F5
	SK6	F6
	SK7	F7
	SK8	F8
	SK9	F9
	SK10	F10
Menu selection	Menu up	CTRL ↑
	Menu down	CTRL ↓
	Menu left	CTRL ←
	Menu right	CTRL →
Operation keys	Clear key	Esc
	Confirm key	Enter
	Cursor up	↑
	Cursor down	↓
Numeric keys	0	0
	1	1
	2	2
	3	3
	4	4
	5	5
	6	6
	7	7
	8	8
	9	9
Alpha keys	[illegible]	ALT 1
	[illegible]	ALT 2
	[illegible]	ALT 3
	[illegible]	ALT 4
Edit keys	Delete	Del
	Backspace	Backspace
Menu selection keys	Home	Home
	Page up	Page up
	Page down	Page down
	End	End
Help key	Help	F1
User menu	Menu	Shift F1
Shift key	Shift	Shift
Control key	Control	Ctrl
Alternate key	Alternate	Alt
Tab key	Tab	Tab
Escape key	Escape	Esc
Enter key	Enter	Enter

Front panel keys		Key assignment for the "Enter" keyboard
Soft keys	SK1	F1
	SK2	F2
	SK3	F3
	SK4	F4
	SK5	F5
	SK6	F6
	SK7	F7
	SK8	F8
	SK9	F9
	SK10	F10
Menu selection	Menu up	CTRL ↑
	Menu down	CTRL ↓
	Menu left	CTRL ←
	Menu right	CTRL →
Operation keys	Clear key	Esc
	Confirm key	Enter
	Cursor up	↑
	Cursor down	↓
Numeric keys	0	0
	1	1
	2	2
	3	3
	4	4
	5	5
	6	6
	7	7
	8	8
	9	9
Alpha keys	[illegible]	ALT 1
	[illegible]	ALT 2
	[illegible]	ALT 3
	[illegible]	ALT 4
Edit keys	Delete	Del
	Backspace	Backspace
Menu selection keys	Home	Home
	Page up	Page up
	Page down	Page down
	End	End
Help key	Help	F1
User menu	Menu	Shift F1
Shift key	Shift	Shift
Control key	Control	Ctrl
Alternate key	Alternate	Alt
Tab key	Tab	Tab
Escape key	Escape	Esc
Enter key	Enter	Enter

www.manualsplus.com
1000496